

WSM

WORKSHOP MANUAL

TRACTOR, MOWER

**BX1880, BX2380, BX2680,
RCK60B-23BX, RCK54-23BX,
RCK48-18BX, RCK60D-26BX,
RCK54D-26BX**

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of *BX1880*, *BX2380*, *BX2680*, *RCK60B-23BX*, *RCK54-23BX*, *RCK48-18BX*, *RCK60D-26BX* and *RCK54D-26BX*. It contains 4 parts: "Information", "General", "Mechanism", and "Servicing".

Information

This section primarily contains information below.

- Safety first
- Safety decal
- Specifications
- Dimensions

General

This section primarily contains information below.

- Engine identification
- Model identification
- General precautions
- Maintenance check list
- Check and maintenance
- Special tools

Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Servicing

This section primarily contains information below.

- Troubleshooting
- Servicing specifications (Service specifications)
- Tightening torques
- Checking, disassembling and servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

Kubota reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

February 2017

© KUBOTA Corporation

RECORD OF REVISIONS

For pdf, use search function [Search word] to find all the revised locations.

Last digit of the code No.	Month of revision	Main revised point and corrective measure [Search word]	Reference page
1	2017 April	Addition of contents for the model BX1880.	—
2	2019 February	Added quick coupler disassembly and assembly.	2-67 7-50
		Revised service intervals: <ul style="list-style-type: none">• Transmission fluid• Transmission strainer	2-15

CONTENTS

1. INFORMATION

SAFETY FIRST	1-1
1. Safety first.....	1-1
2. Before you start service	1-2
3. Start safely.....	1-2
4. Operate safely	1-2
5. Avoiding high pressure fluid.....	1-3
6. Avoiding hot exhaust	1-3
7. Cleaning exhaust filter	1-3
8. Prevent a fire	1-4
9. Keep a good airflow in the work area	1-4
10. Discard fluids correctly	1-4
11. Prevent acid burns.....	1-4
12. Preparing for emergencies	1-5
SAFETY LABEL	1-7
1. Safety labels for BX tractor.....	1-7
2. Safety labels for mower	1-12
2.1 Care of danger, warning and caution labels.....	1-14
SPECIFICATIONS	1-15
1. BX tractor specifications	1-15
2. Mower specifications (RCK60B-23BX, RCK54-23BX and RCK48-18BX).....	1-17
3. Mower specifications (RCK60D-26BX and RCK54D-26BX)	1-18
TRAVELING SPEEDS	1-19
DIMENSIONS	1-21

2. GENERAL

IDENTIFICATION.....	2-1
1. Tractor identification	2-1
1.1 Checking serial number and hour meter.....	2-1
1.2 Cylinder number.....	2-2
2. Checking mower identification.....	2-2
GENERAL PRECAUTIONS.....	2-3
HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING	2-5
LUBRICANTS, FUEL AND COOLANT	2-7
1. BX tractor.....	2-7
1.1 Lubricants, fuel, and coolant	2-7
1.1.1 Fuel.....	2-8
1.1.2 Engine oil.....	2-8
1.1.3 Transmission oil	2-8
1.2 Overview of biodiesel fuel (BDF).....	2-9
2. Mower	2-11
2.1 Lubricants.....	2-11
TIGHTENING TORQUES	2-13
1. General use screws, bolts and nuts	2-13
2. Stud bolts.....	2-13
3. Metric screws, bolts and nuts	2-14
4. American standard screws, bolts and nuts with UNC or UNF threads	2-14
5. Plugs.....	2-14
MAINTENANCE CHECK LIST	2-15
1. BX tractor service intervals.....	2-15
2. Mower service intervals	2-17
CHECK AND MAINTENANCE.....	2-19
1. Periodic service	2-19
1.1 Opening bonnet.....	2-19

1.2 Daily check.....	2-19
1.2.1 Walk around inspection.....	2-19
1.2.2 Checking fuel gauge and refueling	2-19
1.2.3 Checking engine oil level	2-20
1.2.4 Checking transmission fluid level.....	2-20
1.2.5 Checking coolant level.....	2-21
1.2.6 Cleaning panel and radiator screen.....	2-21
1.2.7 Checking brake pedal	2-22
1.2.8 Checking gauges, meters, and Easy Checker™	2-22
1.2.9 Checking head light, hazard light, and tail light	2-22
1.2.10 Checking seat belt and ROPS	2-22
1.2.11 Checking and cleaning electrical wiring and battery cables.....	2-22
1.2.12 Checking movable parts	2-23
1.3 Check points of initial 50 hours	2-23
1.3.1 Changing engine oil	2-23
1.3.2 Replacing engine oil filter.....	2-23
1.3.3 Replacing transmission oil filter	2-24
1.4 Check points of every 50 hours.....	2-24
1.4.1 Greasing	2-24
1.4.2 Checking engine start system.....	2-26
1.4.3 Checking operator presence control (OPC) system	2-26
1.4.4 Checking wheel bolt torque	2-26
1.4.5 Cleaning lock lever shaft.....	2-27
1.5 Check points of every 100 hours.....	2-27
1.5.1 Checking battery condition	2-27
1.5.2 Cleaning air cleaner element	2-28
1.5.3 Checking fuel filter	2-29
1.5.4 Adjusting fan belt tension.....	2-30
1.5.5 Adjusting HST neutral spring	2-30
1.5.6 Adjusting brake pedal	2-31
1.6 Check point of every 200 hours	2-31
1.6.1 Replacing engine oil filter.....	2-31
1.6.2 Changing engine oil	2-32
1.6.3 Replacing transmission oil filter	2-33
1.6.4 Adjusting toe-in	2-33
1.7 Check points of every 400 hours.....	2-33
1.7.1 Adjusting front axle pivot.....	2-33
1.7.2 Changing transmission fluid.....	2-34
1.7.3 Cleaning transmission strainer	2-35
1.7.4 Changing front axle case oil	2-35
1.7.5 Replacing fuel filter element	2-35
1.8 Check points of every 800 hours.....	2-36
1.8.1 Adjusting engine valve clearance	2-36
1.9 Check points of every 1000 hours or 1 year	2-36
1.9.1 Replacing air cleaner element	2-36
1.10 Check points of every 1500 hours.....	2-36
1.10.1 Checking injection pressure of fuel injection nozzle	2-36
1.11 Check points of every 2000 hours or 2 years	2-36
1.11.1 Flushing cooling system and changing coolant.....	2-36
1.11.2 Antifreeze	2-37
1.12 Check points of every 3000 hours.....	2-38
1.12.1 Checking injection pump.....	2-38
1.13 Check points of every 1 year.....	2-38
1.13.1 Checking intake air line.....	2-38
1.13.2 Checking radiator hoses and hose clamps	2-38
1.13.3 Checking power steering line.....	2-39
1.13.4 Checking fuel lines.....	2-39
1.13.5 Checking engine breather hose	2-40

1.14 Check points of every 4 years	2-40
1.14.1 Replacing radiator hose	2-40
1.14.2 Replacing fuel hose	2-40
1.14.3 Replacing power steering hose	2-40
1.14.4 Replacing intake air line	2-40
1.14.5 Replacing engine breather hose	2-40
1.15 Service as required	2-41
1.15.1 Bleeding fuel system	2-41
1.15.2 Replacing fuse	2-41
1.15.3 Replacing light bulb	2-42
2. Mower	2-42
2.1 Check points of daily or each use	2-42
2.1.1 Retightening mower blade screw	2-42
2.1.2 Checking mower blade	2-42
2.1.3 Checking mower belt	2-43
2.1.4 Checking gear box oil level	2-43
2.1.5 Greasing spindle shafts, belt tension pivot and tension pulley	2-43
2.1.6 Greasing balance shaft	2-44
2.1.7 Greasing front and rear anti-scalp rollers	2-45
2.1.8 Greasing universal joint	2-45
2.2 Check points of initial 50 hours	2-45
2.2.1 Changing gear box oil	2-45
2.3 Check point of every 150 hours	2-46
2.3.1 Changing gear box oil	2-46
2.4 Check points of every 1 year	2-46
2.4.1 Checking gear box oil seal	2-46
2.5 Check point of every 4 years	2-46
2.5.1 Replacing gear box oil seal	2-46
TIRES, WHEELS, AND BALLAST	2-47
1. Tires	2-47
1.1 Inflation pressure of tires	2-47
1.2 Dual tires	2-47
2. Wheel tread	2-47
2.1 Front wheels	2-48
2.2 Rear wheels	2-48
3. Ballast	2-49
3.1 Front ballast	2-49
3.2 Rear ballast	2-49
IMPLEMENT LIMITATIONS	2-51
1. Weight of implements as rear ballast	2-51
2. Implement limitation tables	2-52
SPECIAL TOOLS	2-55
1. Special tools for engine	2-55
1.1 Special use puller set	2-55
1.2 Diesel engine compression tester (for injection nozzle)	2-55
1.3 Nozzle tester	2-55
1.4 Injection pump pressure tester	2-55
1.5 Valve guide replacing tool	2-56
1.6 Bushing replacing tool	2-57
1.7 Bushing replacing tool	2-58
1.8 Flywheel stopper	2-58
1.9 Crankshaft bearing 1 replacing tool	2-59
1.10 Governor gear holder busing replacing tool	2-59
2. Special tools for tractor	2-60
2.1 Tie-rod end lifter	2-60
2.2 Independent PTO clutch spring compression tool	2-60
2.3 Disassembling and assembling stand (1/2)	2-61
2.4 Disassembling and assembling stand (2/2)	2-63

2.5 Check and high pressure relief valve assembly tool	2-65
2.6 Quick coupler cartridge socket	2-67

3. ENGINE

MECHANISM	3-1
1. Engine body	3-1
1.1 Function of cylinder block	3-1
1.2 Function of closed breather	3-1
1.3 Function of half-floating head cover	3-1
1.4 Function of piston	3-2
1.5 Function of piston ring	3-2
1.6 Function of connecting rod	3-2
1.7 Function of crankshaft	3-2
1.8 Function of camshaft	3-3
1.9 Function of rocker arm	3-3
1.10 Function of flywheel	3-3
1.11 Function of timing gears	3-4
2. Lubricating system	3-5
2.1 Overview of lubricating system	3-5
2.2 Function of oil strainer	3-7
2.3 Function of oil pump	3-7
2.4 Function of oil filter	3-7
2.5 Function of relief valve	3-8
2.6 Function of oil pressure switch	3-8
3. Cooling system	3-9
3.1 Overview of cooling system	3-9
3.2 Function of water pump	3-11
3.3 Function of radiator	3-11
3.4 Function of radiator cap	3-11
4. Fuel system	3-12
4.1 Overview of fuel system	3-12
4.2 Function of fuel filter	3-12
4.3 Function of fuel feed pump	3-12
4.4 Function of injection nozzle	3-12
SERVICING	3-15
1. Troubleshooting for engine	3-15
2. Servicing specifications for engine	3-19
3. Tightening torques for engine	3-28
4. Checking and adjusting	3-30
4.1 Engine body	3-30
4.1.1 Checking compression pressure	3-30
4.1.2 Checking valve clearance	3-30
4.2 Lubricating system	3-31
4.2.1 Checking engine oil pressure	3-31
4.3 Cooling system	3-32
4.3.1 Checking fan belt tension	3-32
4.3.2 Checking fan belt damage and wear	3-32
4.3.3 Checking radiator cap air leakage	3-32
4.3.4 Checking radiator water leakage	3-33
4.3.5 Checking thermostat valve opening temperature	3-33
4.4 Fuel system	3-34
4.4.1 Checking injection timing	3-34
4.4.2 Checking fuel tightness of pump element	3-35
4.4.3 Checking fuel tightness of delivery valve	3-35
4.4.4 Checking nozzle spraying condition	3-36
4.4.5 Checking fuel injection pressure	3-36
4.4.6 Checking valve seat tightness	3-37
4.4.7 Checking nozzle holder	3-37

5. Disassembling and assembling	3-38
5.1 Separating engine	3-38
5.1.1 Draining engine oil	3-38
5.1.2 Removing battery.....	3-38
5.1.3 Removing bonnet.....	3-39
5.1.4 Disconnecting wiring harness and ground cables	3-40
5.1.5 Disconnecting fuel hoses	3-40
5.1.6 Disconnecting accelerator wire	3-41
5.1.7 Disconnecting propeller shaft assembly	3-41
5.1.8 Separating engine.....	3-41
5.1.9 Draining coolant and removing outer engine parts	3-42
5.2 Disassembling engine	3-43
5.2.1 Cylinder head and valve	3-43
5.2.2 Gear case and timing gears.....	3-47
5.2.3 Piston and connecting rod	3-51
5.2.4 Flywheel and crankshaft	3-53
6. Servicing	3-55
6.1 Cylinder head and valve.....	3-55
6.1.1 Checking top clearance	3-55
6.1.2 Checking cylinder head surface flatness	3-55
6.1.3 Checking cylinder head flaw	3-56
6.1.4 Checking valve recessing	3-57
6.1.5 Checking clearance between valve stem and valve guide	3-57
6.1.6 Replacing valve guide.....	3-58
6.1.7 Checking valve seating	3-58
6.1.8 Correcting valve	3-59
6.1.9 Correcting valve seat	3-59
6.1.10 Lapping valve.....	3-60
6.1.11 Checking free length and tilt of valve spring	3-60
6.1.12 Checking valve spring setting load	3-60
6.1.13 Checking oil clearance between rocker arm and rocker arm shaft.....	3-61
6.1.14 Checking push rod alignment	3-61
6.1.15 Checking oil clearance between tappet and tappet guide bore	3-62
6.2 Timing gears, camshaft and governor gear.....	3-62
6.2.1 Checking timing gear backlash.....	3-62
6.2.2 Checking idle gear 1 side clearance	3-63
6.2.3 Checking camshaft side clearance	3-63
6.2.4 Checking camshaft alignment.....	3-64
6.2.5 Checking cam height	3-64
6.2.6 Checking oil clearance of camshaft journal	3-64
6.2.7 Checking oil clearance between idle gear 1 shaft and idle gear bushing	3-65
6.2.8 Replacing idle gear bushing	3-66
6.3 Piston and connecting rod.....	3-66
6.3.1 Checking piston pin bore I.D.....	3-66
6.3.2 Checking oil clearance between piston pin and small end bushing.....	3-66
6.3.3 Replacing small end bushing.....	3-67
6.3.4 Checking connecting rod alignment.....	3-67
6.3.5 Checking piston ring gap	3-68
6.3.6 Checking clearance between piston ring and piston ring groove	3-68
6.4 Crankshaft.....	3-69
6.4.1 Checking crankshaft side clearance	3-69
6.4.2 Checking crankshaft alignment.....	3-70
6.4.3 Checking oil clearance between crankpin and crankpin bearing	3-70
6.4.4 Checking oil clearance between crankshaft journal and crankshaft bearing 1	3-72
6.4.5 Replacing crankshaft bearing 1	3-73
6.4.6 Checking oil clearance between crankshaft journal and crankshaft bearing 2 and crankshaft bearing 3	3-74
6.5 Cylinder	3-76

6.5.1 Checking cylinder wear.....	3-76
6.5.2 Correcting cylinder (Oversize)	3-76
6.6 Oil pump	3-77
6.6.1 Checking rotor lobe clearance	3-77
6.6.2 Checking clearance between outer rotor and pump body	3-77
6.6.3 Checking clearance between rotor and cover	3-78
6.7 Relief valve spring	3-78
6.7.1 Checking relief valve.....	3-78

4. TRANSAXLE

MECHANISM	4-1
1. Structure of transaxle	4-1
2. Traveling system.....	4-2
2.1 Hydrostatic transmission	4-2
2.1.1 Structure of hydrostatic transmission.....	4-2
2.1.2 Oil flow of hydrostatic transmission	4-3
2.1.3 Structure of HST control linkage.....	4-8
2.1.4 Speed set linkage	4-9
2.2 Range gear shift section	4-12
2.2.1 Structure of range gear shift	4-12
2.3 Front wheel drive section	4-13
2.3.1 Structure of front wheel drive	4-13
2.4 Differential gear section.....	4-14
2.4.1 Structure of differential gears.....	4-14
2.4.2 Structure of differential lock	4-16
2.5 Brake section	4-17
2.5.1 Structure of brake system.....	4-17
3. PTO system	4-19
3.1 Structure of PTO system	4-19
3.1.1 Function of PTO clutch relief valve	4-20
3.1.2 Engaged function of PTO clutch	4-20
3.1.3 Disengaged function of PTO clutch	4-20
3.2 Structure of mid and rear PTO	4-21
4. Others.....	4-22
4.1 Hydraulic pump drive gear section.....	4-22
4.1.1 Structure of hydraulic pump drive gear	4-22
SERVICING	4-23
1. Troubleshooting for transaxle	4-23
2. Servicing specifications for transaxle	4-27
3. Tightening torques for transaxle	4-28
4. Checking and adjusting	4-29
4.1 Adjusting maximum speed	4-29
4.2 Adjusting HST neutral position	4-29
4.3 Checking and adjusting HST neutral spring (dynamic braking)	4-30
4.4 Checking charge relief pressure	4-31
4.5 Checking high relief pressure (Forward)	4-32
4.6 Checking high relief pressure (Reverse).....	4-33
4.7 Readjusting relief valve (When HST does not work due to its loose hexagon socket head screw)	4-33
4.8 Checking PTO clutch operating pressure.....	4-35
4.9 Adjusting brake pedal free travel.....	4-35
5. Disassembling and assembling	4-36
5.1 Separating transaxle	4-36
5.1.1 Draining transmission fluid.....	4-36
5.1.2 Removing battery.....	4-36
5.1.3 Removing lift rod and lower link.....	4-37
5.1.4 Removing ROPS	4-37
5.1.5 Removing seat.....	4-37
5.1.6 Removing step.....	4-38

5.1.7 Removing fender	4-38
5.1.8 Removing fuel tank	4-38
5.1.9 Removing rear wheel	4-39
5.1.10 Removing fender center stay	4-39
5.1.11 Removing fender bracket and hitch plate	4-39
5.1.12 Removing transaxle assembly	4-40
5.1.13 Removing brake pedal	4-41
5.1.14 Removing propeller shaft	4-42
5.1.15 Removing differential lock pedal	4-42
5.1.16 Removing speed control pedal, HST damper, and cruise rod	4-42
5.2 Hydrostatic transmission	4-43
5.2.1 Removing levers and mower lift arm	4-43
5.2.2 Removing PTO clutch valve	4-43
5.2.3 Removing oil cooler cover	4-44
5.2.4 Removing center section and valve plates	4-44
5.2.5 Removing check and high pressure relief valve plug	4-45
5.2.6 Checking check and high pressure relief valve	4-45
5.2.7 Removing cylinder block	4-45
5.2.8 Removing cylinder block and piston	4-46
5.2.9 Removing swashplate and trust roller bearing	4-46
5.2.10 Removing 4WD detent ball	4-47
5.2.11 Removing neutral arm and trunnion arm	4-47
5.3 Hydraulic cylinder	4-48
5.3.1 Removing hydraulic cylinder	4-48
5.4 Transaxle shafts	4-48
5.4.1 Removing transaxle case front cover	4-48
5.4.2 Removing hydraulic pump assembly	4-50
5.4.3 Removing rear PTO cover assembly	4-51
5.4.4 Disassembling rear axle (L.H.)	4-51
5.4.5 Removing rear axle case (R.H.)	4-52
5.4.6 Removing 66T final gear	4-53
5.4.7 Removing rear axle case, R.H. and brake	4-54
5.4.8 Removing PTO clutch assembly	4-55
5.5 Assembling shafts	4-55
5.5.1 Assembling select arms and HST pump shaft (PTO clutch shaft)	4-55
5.5.2 Assembling front wheel drive shaft, shifter, spiral bevel pinion shaft and mid-PTO shaft	4-56
6. Servicing	4-57
6.1 Hydrostatic transmission	4-57
6.1.1 Checking center section	4-57
6.1.2 Checking charge relief valve	4-57
6.1.3 Checking check and high pressure relief valve	4-57
6.1.4 Checking cylinder block assembly	4-58
6.1.5 Checking thrust washer, thrust roller bearing, thrust plate and cradle bearing	4-58
6.1.6 Checking pump shaft (PTO clutch shaft)	4-58
6.1.7 Checking needle bearing	4-59
6.2 Transaxle case	4-59
6.2.1 Checking bearing	4-59
6.2.2 Checking PTO clutch disc wear	4-59
6.2.3 Checking separate plate and back plate wear	4-59
6.2.4 Checking flatness of clutch piston, pressure plate and steel plate	4-60
6.2.5 Checking clutch spring free length	4-60
6.2.6 Checking PTO brake disc wear	4-60
6.2.7 Checking PTO brake plate	4-60
6.2.8 Checking clearance between differential case and differential side gear	4-61
6.2.9 Checking clearance between differential pinion shaft and differential pinion	4-61
6.2.10 Checking backlash between differential pinion and differential side gear	4-61
6.2.11 Checking backlash between spiral bevel pinion gear and bevel gear	4-62
6.2.12 Checking brake cam lever movement	4-62

6.2.13 Checking flatness of actuator and bearing holder	4-62
6.2.14 Checking height of cam plate and ball	4-63
6.2.15 Checking brake disc and friction plate wear	4-63

5. FRONT AXLE

MECHANISM	5-1
1. Structure of front axle	5-1
2. Front wheel alignment	5-2
2.1 Camber of front axle	5-2
2.2 Kingpin angle of front axle	5-2
2.3 Caster of front axle	5-2
2.4 Toe-in of front axle	5-2
SERVICING	5-5
1. Troubleshooting for front axle	5-5
2. Servicing specifications for front axle	5-6
3. Tightening torques for front axle	5-7
4. Checking and adjusting	5-8
4.1 Adjusting toe-in	5-8
4.2 Adjusting front axle rocking force	5-8
4.3 Adjusting front wheel steering angle	5-9
5. Disassembling and assembling	5-9
5.1 Separating front axle assembly	5-9
5.1.1 Draining front axle case oil	5-9
5.1.2 Removing battery	5-9
5.1.3 Removing bonnet	5-10
5.1.4 Removing front wheel and propeller shaft cover	5-10
5.1.5 Disconnecting propeller shaft	5-11
5.1.6 Removing front axle assembly	5-11
5.2 Front axle assembly	5-12
5.2.1 Removing power steering cylinder	5-12
5.2.2 Removing bevel gear case and front gear case	5-12
5.2.3 Removing front gear case cover	5-12
5.2.4 Removing 36T bevel gear and front axle shaft	5-13
5.2.5 Removing front gear case and bevel gear case	5-13
5.2.6 Removing bevel pinion shaft and differential gear assembly	5-14
5.2.7 Removing differential gear	5-15
6. Servicing	5-15
6.1 Checking clearance between differential case and differential side gear	5-15
6.2 Checking clearance between differential pinion shaft and differential pinion	5-15
6.3 Checking backlash between differential pinion and differential side gear	5-16
6.4 Checking turning torque of bevel pinion shaft	5-16
6.5 Checking backlash between bevel pinion shaft and bevel gear	5-17
6.6 Checking backlash between 12T bevel gear and 15T bevel gear	5-17
6.7 Checking clearance between center pin and pin support bushing	5-18

6. STEERING

MECHANISM	6-1
1. Structure of steering system	6-1
2. Hydraulic circuit of steering	6-2
3. Steering controller	6-3
3.1 Structure of steering controller	6-3
3.1.1 Control valve	6-3
3.1.2 Metering device	6-3
3.1.3 Relief valve	6-4
4. Steering cylinder	6-5
4.1 Structure of steering cylinder	6-5
SERVICING	6-7
1. Troubleshooting for steering	6-7

2. Servicing specifications for steering	6-9
3. Tightening torques for steering	6-10
4. Checking and adjusting	6-11
4.1 Checking relief valve operating pressure	6-11
5. Disassembling and assembling	6-11
5.1 Power steering cylinder	6-11
5.1.1 Removing adapter and tie-rod	6-11
5.1.2 Disassembling steering cylinder	6-12
5.2 Separating power steering controller	6-12
5.2.1 Removing battery	6-12
5.2.2 Removing steering wheel	6-13
5.2.3 Removing upper panel	6-13
5.2.4 Removing steering controller	6-13
5.3 Separating power steering cylinder	6-14
5.3.1 Removing bonnet	6-14
5.3.2 Removing front axle assembly	6-15
5.3.3 Removing power steering cylinder	6-15
6. Servicing	6-16
6.1 Checking steering cylinder I.D.	6-16
6.2 Checking clearance between rod and guide	6-16

7. HYDRAULIC SYSTEM

MECHANISM	7-1
1. Structure of hydraulic system	7-1
2. Hydraulic circuit	7-2
3. Hydraulic pump	7-4
3.1 Outline of hydraulic pump	7-4
3.2 Structure of hydraulic pump	7-4
3.3 Specification of hydraulic pump	7-4
4. Control valve	7-4
4.1 Outline of control valve	7-4
4.2 Function of control valve	7-5
4.2.1 Control valve in neutral position	7-5
4.2.2 Control valve in lift position	7-6
4.2.3 Control valve in down position	7-7
5. Flow priority valve	7-8
5.1 Outline of flow priority valve	7-8
5.2 Structure of flow priority valve	7-9
5.3 Specification of flow priority valve	7-10
6. Relief valve	7-10
6.1 Outline of relief valve	7-10
6.2 Structure of relief valve	7-11
6.3 Function of relief valve	7-12
6.4 Specification of relief valve	7-13
7. Hydraulic cylinder	7-14
7.1 Structure of hydraulic cylinder	7-14
8. Hydraulic block type outlet	7-15
8.1 Structure of hydraulic block type outlet	7-15
9. Mower linkage	7-16
9.1 Structure of mower linkage	7-16
10. Front loader valve	7-17
10.1 Structure	7-17
10.1.1 Structure of front loader valve and pipe	7-17
10.1.2 Structure of front loader control valve	7-18
10.2 Front loader hydraulic circuit	7-19
10.3 Function of loader control valve	7-20
10.3.1 Loader control lever in neutral position	7-20
10.3.2 Loader control lever in up position	7-21

10.3.3 Loader control lever in down position	7-23
10.3.4 Loader control lever in floating position	7-25
10.3.5 Loader control lever in roll-back position	7-27
10.3.6 Loader control lever in dump position	7-29
SERVICING	7-31
1. Troubleshooting for hydraulic system	7-31
2. Servicing specifications for hydraulic system	7-32
3. Tightening torques for hydraulic system	7-33
4. Checking and adjusting	7-34
4.1 Relief valve.....	7-34
4.1.1 Checking relief valve setting pressure	7-34
4.2 Pump and priority valve.....	7-34
4.2.1 Checking hydraulic pump oil flow	7-34
4.2.2 Checking power steering oil flow	7-35
4.3 Mower lift linkage	7-36
4.3.1 Adjusting mower lift linkage	7-36
5. Disassembling and assembling	7-37
5.1 Hydraulic pump	7-37
5.1.1 Removing battery.....	7-37
5.1.2 Removing lift rod and lower link.....	7-37
5.1.3 Removing ROPS	7-38
5.1.4 Removing seat.....	7-38
5.1.5 Removing step.....	7-38
5.1.6 Removing fender	7-38
5.1.7 Removing fuel tank	7-39
5.1.8 Removing fender center stay	7-39
5.1.9 Removing hydraulic pump	7-39
5.2 Hydraulic cylinder block	7-40
5.2.1 Removing battery.....	7-40
5.2.2 Removing lift rod and lower link.....	7-41
5.2.3 Removing ROPS	7-41
5.2.4 Removing seat.....	7-41
5.2.5 Removing step.....	7-41
5.2.6 Removing fender	7-42
5.2.7 Removing fuel tank	7-42
5.2.8 Removing fender center stay	7-43
5.2.9 Removing mower linkage and wire harness	7-43
5.2.10 Removing hydraulic cylinder block	7-43
5.3 Hydraulic cylinder and control valve.....	7-44
5.3.1 Removing control valve	7-44
5.3.2 Removing control valve lever.....	7-44
5.3.3 Removing lift arm, hydraulic arm shaft and hydraulic arm.....	7-45
5.3.4 Removing hydraulic piston.....	7-45
5.3.5 Removing lowering speed adjusting valve.....	7-45
5.4 Mower lift linkage	7-46
5.4.1 Disassembling mower linkage	7-46
5.5 Control valve (Front loader)	7-47
5.5.1 Removing battery.....	7-47
5.5.2 Removing ROPS	7-47
5.5.3 Removing seat.....	7-47
5.5.4 Removing step.....	7-47
5.5.5 Removing fender	7-48
5.5.6 Removing control valve	7-48
5.5.7 Disassembling control valve	7-49
5.6 Quick coupler	7-50
5.6.1 Removing quick coupler (tractor side)	7-50
6. Servicing.....	7-50
6.1 Hydraulic pump	7-50

6.1.1 Checking clearance between tip of gear tooth and casing	7-50
6.1.2 Checking clearance between bushing and shaft	7-51
6.1.3 Checking side plate thickness	7-51
6.2 Hydraulic cylinder	7-51
6.2.1 Checking hydraulic cylinder bore	7-51
6.2.2 Checking hydraulic arm shaft bushing	7-52

8. ELECTRICAL SYSTEM

MECHANISM	8-1
1. Wiring diagram of BX tractor	8-1
2. Electrical connector chart	8-2
3. Reading electrical circuit diagrams	8-3
3.1 Electrical wiring chart symbols	8-3
3.2 Layout of connector diagrams	8-6
3.3 Precautions on handling electrical connectors	8-7
4. Starting system	8-8
4.1 Electrical circuit of starting system	8-8
4.2 Function of relay	8-9
4.3 Function of starter	8-9
4.4 Function of glow plug	8-10
4.5 Function of safety switch	8-10
4.6 Function of fuel pump	8-10
5. Operator presence control (OPC) system	8-11
5.1 Electrical circuit of OPC timer	8-11
6. Charging system	8-12
6.1 Electrical circuit for charging system	8-12
6.2 Function of IC regulator (3P connector type)	8-13
7. Lighting system	8-14
7.1 Electrical circuit for lighting system	8-14
8. Gauges	8-15
8.1 Electrical circuit of gauge system	8-15
8.2 Meter panel	8-16
8.2.1 Function of hour meter	8-16
8.2.2 Function of tachometer	8-16
8.2.3 Function of fuel gauge	8-16
8.2.4 Function of coolant temperature gauge	8-16
8.3 Function of fuel level sensor	8-17
8.4 Function of coolant temperature sensor	8-17
8.5 Function of oil pressure switch	8-18
9. Others	8-19
9.1 Electrical circuit for accessory	8-19
9.2 Function of DC outlet	8-20
SERVICING	8-21
1. Troubleshooting for electrical system	8-21
2. Service specifications for electrical system	8-27
3. Tightening torques for electrical system	8-28
4. Checking and adjusting	8-29
4.1 Battery	8-29
4.1.1 Checking battery voltage	8-29
4.1.2 Checking battery terminal connection	8-29
4.1.3 Checking battery specific gravity	8-29
4.2 Main switch	8-30
4.2.1 Checking main switch connector voltage	8-30
4.2.2 Checking main switch continuity at off position	8-30
4.2.3 Checking main switch continuity at on position	8-31
4.2.4 Checking main switch continuity at preheat position	8-31
4.2.5 Checking main switch continuity at start position	8-31
4.3 Starter	8-32

4.3.1	Checking motor.....	8-32
4.3.2	Testing starter magnet switch (pull-in, holding coils)	8-32
4.4	Glow plug	8-32
4.4.1	Checking glow plug lead terminal voltage	8-32
4.4.2	Checking glow plug continuity	8-33
4.5	Safety switch	8-33
4.5.1	Checking PTO shift lever switch continuity	8-33
4.5.2	Checking HST neutral switch continuity	8-34
4.6	Operator presence control (OPC) system	8-34
4.6.1	Checking seat switch and seat turnover switch continuity	8-34
4.6.2	Checking OPC timer	8-36
4.7	Fuel pump	8-36
4.7.1	Checking fuel pump connector voltage	8-36
4.7.2	Checking fuel pump continuity	8-37
4.8	Engine stop solenoid	8-37
4.8.1	Testing engine stop solenoid	8-37
4.9	Timer relay	8-37
4.9.1	Checking timer relay connector voltage	8-37
4.9.2	Testing timer relay	8-37
4.10	Charging system	8-38
4.10.1	Checking battery charging current	8-38
4.11	Combination switch	8-38
4.11.1	Removing combination switch	8-38
4.11.2	Checking combination switch connector voltage	8-38
4.11.3	Checking head light switch continuity when setting switch at OFF position	8-39
4.11.4	Checking head light switch continuity when setting switch at ON position	8-39
4.11.5	Checking turn signal light switch continuity when setting switch knob at OFF position	8-40
4.11.6	Checking turn signal light switch continuity when setting switch knob at RIGHT position	8-40
4.11.7	Checking turn signal light switch continuity when setting switch knob at LEFT position	8-41
4.11.8	Checking hazard switch continuity when setting switch knob at OFF position	8-41
4.11.9	Checking hazard switch continuity when setting switch knob at ON position	8-42
4.11.10	Checking flasher unit connector voltage	8-42
4.11.11	Testing flasher unit actuation	8-43
4.12	Gauge	8-43
4.12.1	Checking charge lamp (charging circuit)	8-43
4.12.2	Checking engine oil pressure lamp	8-44
4.12.3	Checking engine oil pressure switch continuity	8-44
4.12.4	Checking fuel level sensor continuity	8-44
4.12.5	Checking coolant temperature sensor connector voltage	8-45
4.12.6	Checking coolant temperature sensor continuity	8-45
4.12.7	Checking hour meter and tachometer	8-46
4.13	Accessory	8-46
4.13.1	Checking DC outlet connector voltage	8-46
4.13.2	Checking DC outlet continuity	8-46
4.14	Meter panel	8-47
4.14.1	Checking connector voltage, sensor resistance and switch	8-47
5.	Disassembling and assembling	8-47
5.1	Starter	8-47
5.1.1	Disassembling starter motor	8-47
5.1.2	Removing magnet switch	8-48
5.1.3	Removing plunger	8-48
5.2	Alternator	8-48
5.2.1	Removing pulley	8-48
5.2.2	Removing rear end cover	8-49
5.2.3	Removing brush holder	8-49
5.2.4	Removing IC regulator	8-49
5.2.5	Removing rectifier	8-49
5.2.6	Removing rear end frame	8-49

5.2.7 Removing rotor	8-50
5.2.8 Removing retainer plate	8-50
5.2.9 Removing bearing on drive end side	8-50
5.2.10 Removing bearing at slip ring side	8-50
6. Servicing	8-50
6.1 Starter	8-50
6.1.1 Checking overrunning clutch	8-50
6.1.2 Checking commutator and mica	8-51
6.1.3 Checking brush wear	8-51
6.1.4 Checking brush holder	8-52
6.1.5 Checking armature coil	8-52
6.1.6 Checking field coil	8-52
6.2 Alternator	8-53
6.2.1 Checking bearing	8-53
6.2.2 Checking stator	8-53
6.2.3 Checking rotor	8-53
6.2.4 Checking slip ring	8-53
6.2.5 Checking brush wear	8-54
6.2.6 Checking rectifier	8-54

9. MOWER

MECHANISM	9-1
1. Structure of power transmission of mower	9-1
2. Structure of lifting mechanism of mower	9-2
3. Structure of self-balancer system of mower	9-3
SERVICING	9-5
1. Troubleshooting for mower	9-5
2. Servicing specifications for mower	9-6
3. Tightening torques for mower	9-7
4. Setting up mower [RCK48-18BX, RCK54-23BX, and RCK60B-23BX]	9-8
4.1 Assembling mower	9-8
4.2 Setting mower	9-8
4.3 Installing universal joint	9-9
4.4 Mounting rear link	9-9
4.5 Mounting front link	9-9
4.6 Mounting front link	9-10
5. Setting up mower [RCK54D-26BX and RCK60D-26BX]	9-10
5.1 Assembling mower	9-10
5.2 Setting mower	9-11
5.3 Mounting front link	9-11
5.4 Mounting frame link	9-12
5.5 Setting tractor	9-13
5.6 Mounting mower	9-13
6. Checking and adjusting	9-14
6.1 Mower adjustment	9-14
6.1.1 Adjusting mower link	9-14
6.1.2 Adjusting front and rear cutting height	9-15
6.1.3 Adjusting front and rear cutting height	9-16
6.1.4 Adjusting left and right cutting height	9-16
6.1.5 Adjusting self-balance suspended linkage	9-17
6.1.6 Adjusting cutting height	9-18
6.2 Checking mower blade and belt	9-19
6.2.1 Checking mower blade	9-19
6.2.2 Checking mower belt	9-19
7. Disassembling and assembling	9-20
7.1 Removing universal joint and belt cover	9-20
7.2 Removing ramps and belt covers	9-20
7.3 Removing mower blades	9-20

7.4 Removing blade boss.....	9-21
7.5 Removing gear box and mower belt	9-21
7.6 Disassembling gear box.....	9-22
7.7 Removing center pulley holder.....	9-22
7.8 Removing outer pulley and blade shaft.....	9-23
7.9 Removing balancer	9-24
8. Servicing.....	9-25
8.1 Adjusting turning torque of pinion shaft.....	9-25
8.2 Adjusting backlash between bevel gears	9-25

1. INFORMATION

SAFETY FIRST

1. Safety first

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you try to repair or use this unit.



DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



IMPORTANT


- Indicates that equipment or property damage could result if instructions are not followed.



NOTE

- Gives helpful information.

2. Before you start service





- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a stable and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, then remove the key.
- Disconnect the battery negative cable.
- Hang a **[DO NOT OPERATE]** tag in the operator station.

3. Start safely



- Do not do the procedures below when you start the engine.
 1. Short across starter terminals.
 2. Bypass the safety start switch.
- Do not alter or remove any part of machine safety system.
- Before you start the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Do not start the engine when you stay on the ground. Start the engine only from operator's seat.

4. Operate safely



- Do not use the machine after you consume alcohol or medication or when you are tired.
- Put on applicable clothing and safety equipment.
- Use applicable tools only. Do not use alternative tools or parts.
- When 2 or more persons do servicing, make sure that you do it safely.
- Do not touch the hot parts or parts that turn when the engine operates.
- Do not remove the radiator cap when the engine operates, or immediately after it stops. If not, hot water can spout out from the radiator. Only remove the radiator cap when it is at a sufficiently low temperature to touch with bare hands. Slowly

loosen the cap to release the pressure before you remove it fully.


- Released fluid (fuel or hydraulic oil) under pressure can cause damage to the skin and cause serious injury. Release the pressure before you disconnect hydraulic or fuel lines. Tighten all connections before you apply the pressure.
- Do not open a fuel system under high pressure. The fluid under high pressure that stays in fuel lines can cause serious injury. Do not disconnect or repair the fuel lines, sensors, or any other components between the fuel pump and injectors on engines with a common rail fuel system under high pressure.
- Put on an applicable ear protective device (earmuffs or earplugs) to prevent injury against loud noises.
- Be careful about electric shock. The engine generates a high voltage of more than DC100 V in the ECU and is applied to the injector.

5. Avoiding high pressure fluid




- Keep away from high pressure fluids bursting from a hose or pipe. The fluid can penetrate your skin and cause serious injuries.
- Get a medical aid immediately if the accident occurs.

6. Avoiding hot exhaust




- Avoid skin exposure and contact with hot exhaust gas or components.
- Exhaust gas and components are extremely hot during operation.




- Do not work immediately after stopping the engine. The engine, muffler, radiator, and hydraulic components are extremely hot.
- Do not remove caps and plugs soon after stopping the engine. The temperature and pressure of the coolant, hydraulic oil, and fuel are still high.

7. Cleaning exhaust filter



- Avoid skin exposure and contact with hot exhaust gas or components. Exhaust gas and components are extremely hot during regeneration of diesel particulate filter (DPF).

8. Prevent a fire



- Fuel is very flammable and explosive under some conditions. Do not smoke or let flames or sparks in your work area.
- To prevent sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- The battery gas can cause an explosion. Keep the sparks and open flame away from the top of battery, especially when you charge the battery.
- Make sure that you do not spill fuel on the engine.

9. Keep a good airflow in the work area




- If the engine is in operation, make sure that the area has good airflow. Do not operate the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.

10. Discard fluids correctly




- Do not discard fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you discard oil, fuel, coolant, electrolyte and other dangerous waste.

11. Prevent acid burns



- Keep electrolyte away from your eyes, hands and clothing. Sulfuric acid in battery electrolyte is poisonous and it can burn your skin and clothing and cause blindness. If you spill electrolyte on yourself, clean yourself with water, and get medical aid immediately.

12. Preparing for emergencies



- Keep a first aid kit and fire extinguisher ready at all times.
- Keep emergency numbers near your telephone at all times.

SAFETY LABEL

1. Safety labels for BX tractor

The safety labels are installed on the machine. If a label becomes damaged, illegible or is not on the machine, replace it. The label part number is listed in the parts list.

1. INFORMATION

(1) Part No. K2871-6548-1

⚠ WARNING

TO AVOID PERSONAL INJURY OR DEATH:

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Slow down for turns, or rough roads.

1AGAJBMAP0460

(2) Part No. K1272-6585-2
Diesel fuel No fire
only

**ULTRA LOW SULFUR
DIESEL FUEL ONLY**

1BDAHAP002A

(3) Part No. K2591-6557-2

⚠ WARNING

TO AVOID PERSONAL INJURY OR DEATH FROM ROLL-OVER:




1. Keep Roll-Over Protective Structures (ROPS) in the upright and locked position.
2. Fasten SEAT BELT before operating.


THERE IS NO OPERATOR PROTECTION WHEN THE ROPS IS IN THE FOLDED POSITION.

1. Check the operating area and fold the ROPS only when absolutely necessary.
2. Do not wear SEAT BELT if ROPS is folded.
3. Raise and lock ROPS as soon as vertical clearance allows.
4. Read ROPS related instructions and warnings.

1HNAAACAP0690



(1) Part No. K2581-6554-1



1AGAJBMAP0470

(2) Part No. K2581-6555-1




1AGAJBMAP0480

(3) Part No. K2871-6556-1



1AGAJBMAP0490

(4) Part No. K2871-6552-2



1AGAJBMAP0500

(5) Part No. K2651-6568-1





1AYAACAAP1000

(6) Part No. K2871-6558-1




1AGAJBMAP0530



1. INFORMATION

(1) Part No. K2871-6541-1



1AGAJAXAP048E

(2) [BX1880, BX2380]

Part No. K2581-6547-1
Stay clear of engine fan and fanbelt.

1AGAJAXAP049E


(3) Part No. K2581-6543-1

Stay clear of engine fan and fanbelt.




1AGAJAXAP052E

[BX1880, BX2380]




1BXMC00018A01




1BXMC00019A01

[BX1800, BX2380]



1BXMC00094A02

[BX2680]



1BXMC00020A01

(1) Part No. K7591-6114-3

			DANGER EXPLOSIVE GASES CIGARETTES, FLAMES OR SPARKS COULD CAUSE BATTERY TO EXPLODE. ALWAYS SHIELD EYES AND FACE FROM BATTERY. DO NOT CHARGE OR USE BOOSTER CABLES OR ADJUST POST CONNECTIONS WITHOUT PROPER INSTRUCTION AND TRAINING. POISON CAUSES SEVERE BURNS CONTAINS SULFURIC ACID. AVOID CONTACT WITH SKIN, EYES OR CLOTHING. IN EVENT OF ACCIDENT FLUSH WITH WATER AND CALL A PHYSICIAN IMMEDIATELY. KEEP OUT OF REACH OF CHILDREN California Proposition 65 WARNING : This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov .
			
CAUTION OF SULFURIC ACID	READ INSTRUCTION MANUAL CAREFULLY	EXPLOSIVE	

1AGAJBMAP096A

(2) Part No. K2871-6564-1

⚠ WARNING
 Never modify or repair a ROPS because welding, grinding, drilling or cutting any portion may weaken the structure.

⚠ WARNING
 TO AVOID PERSONAL INJURY OR DEATH WHEN RAISING OR FOLDING ROPS:

1. Set parking brake and stop engine.
2. Remove any obstruction that may prevent raising or folding of the ROPS.
3. Do not allow any bystanders.
4. Always perform function from a stable position at the rear of the tractor.
5. Hold the top of the ROPS securely when raising or folding.
6. Make sure all pins are installed and locked.

1AGAJBMAP0560

(3) Part No. K2883-6527-1

Do not touch hot surface like muffler, etc.



1PPEP00062000

(4) Part No. K2601-9616-2

PROPOSITION 65 WARNING: Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Batteries also contain other chemicals known to the State of California to cause cancer. **WASH HANDS AFTER HANDLING.**


ADVERTENCIA DE LA PROPOSICIÓN 65: Los postes de batería, terminales y accesorios relacionados pueden contener plomo y compuestos de plomo, productos químicos conocidos en el estado de California por causar cáncer y daños a la reproducción. Las baterías también contienen otros productos químicos conocidos en el estado de California por causar cáncer. **LÁVESE LAS MANOS DESPUÉS DE LA MANIPULACIÓN.**

AVERTISSEMENT PROPOSITION 65 : Les bornes de batterie, les prises et les accessoires associés contiennent du plomb et des composés de plomb, des produits chimiques connus dans l'État de la Californie pour causer le cancer et des effets nocifs sur la reproduction. Les batteries contiennent aussi d'autres produits chimiques connus dans l'État de la Californie pour causer le cancer. **SE LAVER LES MAINS APRÈS MANIPULATION.**




4-3121

1AYAACPAP080A




1BXM000102A06



1BXM000021A01

1BXM00013A01enUS




1BXM000105A01

2. Safety labels for mower

The safety labels are installed on the mower. If a label becomes damaged, illegible or is not on the mower, replace it. The label part number is listed in the parts list.

[RCK60B-23BX, RCK54-23BX, RCK48-18BX]



(A) Forward

(1) Part No. K5112-7311-1



1BDACADAP003E

(2) Part No. K5112-7312-1



1BDACADAP004E


(3) Part No. K5763-4715-1




1BDACADAP002E

9Y1210855ICI005US


[RCK60D-26BX]



[RCK54D-26BX]



(1) Part No. K5112-7311-2



(3) Part No. K5384-4715-1



(2) Part No. K5112-7312-2



(4) Part No. K5384-4171-1



2LEQP00023A01enUS

2.1 Care of danger, warning and caution labels

- Keep danger, warning and caution labels clean and free from obstructing material.
- Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
- Replace damaged or missing danger, warning and caution labels with new labels.
- If a component with danger, warning and caution label(s) affixed is replaced with new part, make sure new label(s) is (are) attached in the same location(s) as the replaced component.
- Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

SPECIFICATIONS

1. BX tractor specifications

Model		BX1880	BX2380	BX2680
PTO power*1		10.2 kW (13.7 HP)	13.2 kW (17.7 HP)	14.5 kW (19.5 HP)
Engine	Maker	Kubota		
	Model	D722	D902	D1005
	Type	Liquid-cooled, 4-cycle diesel		
	Number of cylinders	3		
	Bore and stroke	67 × 68 mm (2.64 × 2.68 in.)	72 × 73.6 mm (2.83 × 2.90 in.)	76 × 73.6 mm (2.99 × 2.90 in.)
	Total displacement	719 cm ³ (43.9 cu. in.)	898 cm ³ (54.8 cu. in.)	1001 cm ³ (61.1 cu. in.)
	Engine gross power*2	12.4 kW (16.6 HP)	16.1 kW (21.6 HP)	18.5 kW (24.8 HP)
	Rated revolution	3200 rpm		
	Low idling revolution	1350 to 1550 rpm		
	Maximum torque	44.9 N · m (33.1 lbf · ft)	56.1 N · m (41.4 lbf · ft)	60.2 N · m (44.4 lbf · ft)
	Battery	12 V, CCA: 560 A, RC: 86 min.		
	Fuel	Diesel fuel No.1 [below -10 °C (14 °F)] Diesel fuel No.2 [above -10 °C (14 °F)]		
Capacities	Fuel tank	25 L 6.6 U.S.gals 5.5 Imp.gals		
	Engine crankcase (with filter)	3.0 L 3.2 U.S.qts 2.6 Imp.qts	3.3 L 3.5 U.S.qts 2.9 Imp.qts	4.0 L 4.2 U.S.qts 3.5 Imp.qts
	Engine coolant	2.9 L 3.1 U.S.qts 2.6 Imp.qts	3.1 L 3.3 U.S.qts 2.7 Imp.qts	3.3 L 3.5 U.S.qts 2.9 Imp.qts
	Recovery tank	0.4 L 0.1 U.S.gals 0.09 Imp.gals		
	Transmission case	11.3 L 2.99 U.S.gals 2.49 Imp.gals		
Dimensions	Overall length (without 3p)		2120 mm (83.5 in.)	
	Overall length (with 3p)		2425 mm (95.5 in.)	
	Overall width (Min. tread)		1120 mm (44.1 in.)	1145 mm (45.1 in.)
	Overall height	(with ROPS)	2080 mm (81.9 in.)	
		(Top of seat)	1230 mm (48.4 in.)	1255 mm (49.4 in.)
	Wheel base		1400 mm (55.1 in.)	
	Min. ground clearance		148 mm (5.8 in.)	166 mm (6.5 in.)
	Tread	Front	930 mm (36.6 in.)	
		Rear	820 mm (32.3 in.)	

(Continued)

1. INFORMATION

Model			BX1880	BX2380	BX2680
Weight (with ROPS)			606 kg (1336 lbs)	660 kg (1455 lbs)	690 kg (1521 lbs)
Clutch			N/A		
Traveling system	Tire	Front: Turf / Bar / industrial	16 × 7.50-8	18 × 8.50-10	
		Rear: Turf / Bar / industrial	24 × 12.00-12	26 × 12.00-12	
	Steering		Hydrostatic type power steering		
	Transmission		Main: Hydrostatic transmission, High-Low gear shift (2 forward, 2 reverse)		
	Brake		Wet disk type		
	Min. turning radius		2.3 m (7.5 ft)		
Hydraulic unit	Hydraulic control system		Directional control, auto-return lever system		
	Pump capacity		23.5 L/min. (6.2 gals/min)		
	System pressure		12.3 to 12.8 MPa (126 to 130 kgf/cm ²) [1790 to 1850 psi]		
	3-point hitch		SAE Category 1		
	Max. lift force ^{*3}	At lift points	5120 to 5390 N (1151 to 1213 lbf)		
		24 in. behind lift points	3040 N (680 lbf)		
	Remote control valve coupler (Rear: Option)	System	2 valves		
		Coupler	ISO 7241-1 series A		
	Remote control valve coupler (Front: Option)	System	2 valves		
		Coupler (Fitting)	ISO 7241-1 series B		
PTO	Rear PTO	Type	SAE 1-3/8, 6 splines		
		Revolution	STD 540 min ⁻¹ (rpm)		
	Mid PTO	Type	USA No.5 (Kubota 10-tooth) involute spline		
		Revolution	STD 2500 mm ¹ (rpm)		

*1 Manufacturer's estimate

*2 SAE J1995

The engine output value indicated on the EPA exhaust gas label is the ISO 8178 net value without a cooling fan.
 BX1880: 12.2 kW / BX2380: 15.9 kW / BX2680: 18.2 kW.

*3 See and check Implement limitation tables.

2. Mower specifications (RCK60B-23BX, RCK54-23BX and RCK48-18BX)

Model		RCK60B-23BX	RCK54-23BX	RCK48-18BX
Suitable tractor		BX2380, BX2680	BX1880, BX2380	BX1880
Mounting method		Quick-Joint, parallel linkage		
		Self-balance suspended linkage	Suspended linkage	
Adjustment of cutting height		Dial gauge		
Cutting width		1524 mm (60 in.)	1372 mm (54 in.)	1219 mm (48 in.)
Cutting height		25 to 102 mm (1.0 to 4.0 in.)		
Weight (Approx.)		115 kg (250 lbs)	95 kg (210 lbs)	75 kg (165 lbs)
Blade spindle speed		44.1 r/s (2647 rpm)	49.5 r/s (2969 rpm)	54.7 r/s (3281 rpm)
Blade tip velocity		72.5 m/s (14271 fpm)	73.8 m/s (14527 fpm)	72.8 m/s (14331 fpm)
Blade length		523 mm (20.6 in.)	475 mm (18.7 in.)	424 mm (16.7 in.)
Number of blades		3		
Dimensions	Overall length	1000 mm (39.4 in.)	928 mm (36.5 in.)	895 mm (35.2 in.)
	Overall width	1930 mm (76.0 in.)	1780 mm (66.5 in.)	1544 mm (60.8 in.)
	Overall height (Min.)	281 mm (11.0 in.)	268 mm (10.5 in.)	

3. Mower specifications (RCK60D-26BX and RCK54D-26BX)

Model		RCK60D-26BX	RCK54D-26BX
Suitable tractor		BX2380, BX2680	BX2380
Mounting method		Drive-over-quick-joint, parallel linkage	
		Drive-over-suspended-linkage	
Adjustment of cutting height		Dial gauge	
Cutting width		1524 mm (60 in.)	1372 mm (54 in.)
Cutting height		25 to 102 mm (1.0 to 4.0 in.)	
Weight	Mower	115 kg (250 lbs)	103 kg (227 lbs)
	Mower with frame link ^{*1}	134 kg (295 lbs)	122 kg (269 lbs)
Blade spindle speed		44.1 r/s (2647 rpm)	49.5 r/s (2969 rpm)
Blade tip velocity		72.5 m/s (14271 fpm)	73.8 m/s (14527 fpm)
Blade length		523 mm (20.6 in.)	475 mm (18.7 in.)
Number of blades		3	
Dimensions	Overall length	1000 mm (39.4 in.)	928 mm (36.5 in.)
	Overall width	1930 mm (76.0 in.)	1780 mm (66.5 in.)
	Overall height (Min.)	281 mm (11.0 in.)	
Tire		Industrial, turf ^{*2}	


*1 Remove the frame link when rear attachment is on. Remove the frame link when snow attachment is on.

*2 Bar tires are prohibited from driving over mower deck.

TRAVELING SPEEDS

Model		BX1880	BX2380 and BX2680
Tire size (Rear)		24 × 12.00-12	26 × 12.00-12
Speed control pedal	Range gear shift lever	(At max engine rpm)	
Forward	Low	0 to 5.5 km/h 0 to 3.4 mph	0 to 6.0 km/h 0 to 3.7 mph
	High	0 to 12.0 km/h 0 to 7.5 mph	0 to 13.0 km/h 0 to 8.1 mph
Reverse	Low	0 to 4.0 km/h 0 to 2.5 mph	0 to 4.5 km/h 0 to 2.8 mph
	High	0 to 9.0 km/h 0 to 5.6 mph	0 to 10.0 km/h 0 to 6.2 mph

DIMENSIONS



2LEQP00059A01enUS


2. GENERAL

IDENTIFICATION


1. Tractor identification

1.1 Checking serial number and hour meter




- When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.




(1) Tractor identification plate (2) Tractor serial number




(3) ROPS identification plate



(4) Engine serial number [C] BX2680
[A] BX1880
[B] BX2380



(5) Hour meter




(1) Mower serial number

[A] RCK48-18BX, RCK54-23BX,
and RCK60B-23BX[B] RCK54D-26BX and
RCK60D-26BX

1.2 Cylinder number


The cylinder numbers of KUBOTA diesel engine are designated as shown in the figure.




The sequence of cylinder numbers is given as No.1, No.2 and No.3 starting from the gear case side.

2. Checking mower identification

- When contacting your local KUBOTA distributor, always specify mower serial number.



GENERAL PRECAUTIONS



- | | |
|-----------------|-----------------------|
| (1) Grease | (5) Rotating movement |
| (2) Force | (A) External circlip |
| (3) Sharp edge | (B) Internal circlip |
| (4) Axial force | |


- Before you disassemble or repair machine, make sure that you always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before you measure.
- Use KUBOTA genuine parts for replacement to keep the machine performance and to make sure of safety.
- You must replace the gaskets and O-rings when you assemble again. Apply grease (1) to new O-rings or oil seals before you assemble.
- When you assemble the external or internal snap rings, make sure that the sharp edge (3) faces against the direction from which force (2) is applied.
- When inserting spring pins, their splits must face the direction from which a force is applied.
- To prevent damage to the hydraulic system, use specified fluid or equivalent.
- Clean the parts before you measure them.
- Tighten the fittings to the specified torque. Too much torque can cause damage to the hydraulic units or the fittings. Not sufficient torque can cause oil leakage.
- When you use a new hose or pipe, tighten the nuts to the specified torque. Then loosen (approx. by 45°) and let them be stable before you tighten to the specified torque (This is not applied to the parts with seal tape.).
- When you remove the two ends of a pipe, remove the lower end first.
- Use two pliers in removal and installation. One to hold the stable side, and the other to turn the side you remove to prevent twists.
- Make sure that the sleeves of flared connectors and tapers of hoses are free of dust and scratches.
- After you tighten the fittings, clean the joint and apply the maximum operation pressure 2 to 3 times to check oil leakage.

- When you disassemble, carefully put the parts in a clean area to make it easy to find the parts. You must install the screws, bolts and nuts in their initial position to prevent the reassembly errors.
- When it is necessary to use special tools, use KUBOTA special tools. Refer to the drawings when you make special tools that you do not use frequently.

HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING

■ IMPORTANT

- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not try to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.



3TMABAB0P006A

(1) Negative terminal

(2) Positive terminal

To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.

LUBRICANTS, FUEL AND COOLANT

1. BX tractor

1.1 Lubricants, fuel, and coolant

■ IMPORTANT

- To prevent serious damage to hydraulic systems, use only KUBOTA genuine fluid or its equivalent.

No.	Locations	Capacities			Grade	
		BX1880	BX2380	BX2680		
1	Fuel	25 L 6.6 U.S.gals 5.5 Imp.gals			<ul style="list-style-type: none">No. 2-D diesel fuelNo. 1-D diesel fuel if temperature is below -10 °C (14 °F)	
2	Coolant with recovery tank	2.9 L 3.1 U.S.qts 2.6 Imp.qts	3.1 L 3.3 U.S.qts 2.7 Imp.qts	3.3 L 3.5 U.S.qts 2.9 Imp.qts	Fresh clean soft water with anti-freeze	
3	Engine crankcase	3.0 L 3.2 U.S.qts 2.6 Imp.qts *1	3.3 L 3.5 U.S.qts 2.9 Imp.qts *1	4.0 L 4.2 U.S.qts 3.5 Imp.qts *1	• Engine oil API Service Classification CF or higher	
					Above 25 °C (77 °F)	SAE30, SAE10W-30 or 15W-40
					-10 °C to 25 °C (14 °F to 77 °F)	SAE20, SAE10W-30, or 15W-40
					Below -10 °C (14 °F)	SAE10W-30
4	Transmission case	11.3 L 2.99 U.S.gals 2.49 Imp.gals			<ul style="list-style-type: none">KUBOTA SUPER UDT-2 fluid*2	
5	Front axle case	3.6 L 3.8 U.S.qts 3.2 Imp qts			<ul style="list-style-type: none">KUBOTA SUPER UDT-2 fluid*2 or SAE 80-SAE90 gear oil	
6	Greasing	No. of greasing points			Capacity	Type of grease
	Battery terminal	2			Moderate amount	Multipurpose EP2 Grease (NLGI Grade No. 2)
	Speed control pedal	1			Until grease overflow	
	Rear link	4			Moderate amount	
	Bonnet lock	1			Moderate amount	
	Bonnet guide	1			Moderate amount	

*1 Oil amount when the oil level is at the upper level of the oil level gauge.

*2 The product name of KUBOTA genuine UDT fluid may be different from that in the operator's manual depending on countries or territories.

2. GENERAL

1.1.1 Fuel

- Use the ultra low sulfur diesel fuel only [below 0.0015% (15 ppm)] for these engines.
- Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20 °C (-4 °F) or elevations above 1500 m (5000 ft).
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engines in industrial and heavy mobile service. (SAE J313 JUN87)

1.1.2 Engine oil

- Oil used in the engine should have an American Petroleum Institute (API) service classification and Proper SAE Engine Oil according to the ambient temperatures.
- Refer to the following table for the suitable API classification engine oil according to the engine type (with internal EGR, external EGR or non-EGR) and the fuel.

Fuel used	Engine oil classification (API classification)	
	Oil class of engines except external EGR	Oil class of engines with external EGR
Ultra Low Sulfur Fuel [< 0.0015% (< 15 ppm)]	CF, CF-4, CG-4, CH-4 or CI-4	CF or CI-4 (Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR type engines)

EGR:

Exhaust gas re-circulation

- The CJ-4 engine oil is intended for diesel particulate filter (DPF) type engines, and cannot be used on this tractor.

1.1.3 Transmission oil

*KUBOTA Super UDT-2: For an enhanced ownership experience, we highly recommend Super UDT-2 to be used instead of standard hydraulic/transmission fluid.

Super UDT-2 is a proprietary KUBOTA formulation that delivers superior performance and protection in all operating conditions.

Regular UDT is also permitted for use in this machine.

- Indicated capacities of water and oil are manufacturer's estimate.

1.2 Overview of biodiesel fuel (BDF)

B0-B20 biodiesel fuels (BDF)

You can use mixed diesel fuels containing 20% or less biodiesel under the following conditions.

■ IMPORTANT

- **Concentrations greater than B5 (5%) are not approved for common rail engines and engines with aftertreatment device. Using concentrations greater than B5 (5%) can cause damage and reduce engine life.**
- **Refuel and use the fuel with caution in order to avoid contact with the fuel and spillage that could create a potential environmental or fire hazard. Wear appropriate protective equipment when refueling.**

Applicable BDF

- You can use blended diesel fuels containing 6% through 20% BDF (B6-B20) which comply with American society for testing and materials (ASTM) D7467 standard, as revised, without adversely affecting the performance and durability of the engine and the components of the fuel system.
- Any mineral-oil-diesel-fuel, if used, must conform to ASTM D975 (or the European EN590) Standard, as revised. B100 fuel used to generate biodiesel-blended-fuels must meet ASTM D6751 (or EN14214) Standard, as revised. The final blended fuel B20 must conform to ASTM D7467 standard, as revised. Straight-vegetable-oil is not allowed in any blended fuel.
- Allowable blended fuel is mineral-oil-diesel-fuel blended with B100 (for example 100% BDF). The blended fuel ratio shall be less than 20% B100 and 80% or more diesel fuel. Purchase the B100 source used for biodiesel blends from an accredited BQ-9000 marketer or producer. You can find more information about qualified marketer(s) and producer(s) at <http://www.bq-9000.org>.

Product warranty, emission, and other precautions

- The engine-emission-control-system was certified according to current regulations based on the use of non-BDF. When using BDF, the owner is advised to check applicable local and federal emission regulations, and comply with all of them.
- BDF may cause restricted or clogged fuel filters during cold weather conditions, resulting in the engine not operating properly.
- BDF encourages the growth of microorganisms which may cause degradation of the fuel. Degradation of the fuel may cause corrosion of the fuel line or reduce the fuel filter flow earlier than expected.
- BDF inherently absorbs moisture which may cause degradation of the fuel earlier than expected. To avoid absorbing moisture of BDF, drain the water separator and the fuel-filter-port often.
- Do not use biodiesel whose concentrations higher than 20% (for example, greater than B20). Higher concentrated biodiesel will affect engine performance and fuel consumption, and degradation of the fuel system components may occur.
- Do not readjust the engine-fuel-control-system because readjusting it will violate the emission-control-levels for which the equipment was approved.
- Compared with soybean-based and rapeseed-based feedstock, palm-oil-based feedstock has a thicker consistency (for example, higher viscosity) at lower temperatures. Consequently, palm-oil-based feedstock may reduce performance of the fuel filter, particularly during cold weather conditions.
- The Kubota warranty, as specified in the Owner's Warranty Information Guide, only covers flaws in product materials and workmanship. Accordingly, the Kubota warranty does not cover any problems that may arise due to the use of poor quality fuels that fail to meet the preceding requirements, whether biodiesel or mineral-oil-based.

Routine using

- Avoid spilling BDF onto painted surfaces because this may damage the finish. If the fuel is spilled, immediately wipe clean and flush with soapy water to avoid permanent damage.
- When using BDF, you are advised to keep a full tank of the fuel, especially overnight and during short term storage, to reduce condensation within the tank. Be sure to tighten the fuel cap after refueling to prevent moisture build up within the tank. Water in the biodiesel mixture will damage the fuel filters and may damage the engine components.

Maintenance requirements when using BDF B0 through B5

Extended oil-change-intervals may result in premature wear or engine damage.

Maintenance requirements when using BDF B6 through B20

The maintenance interval for fuel related parts changes.

2. GENERAL

See the following table for the new maintenance interval.

Items		Interval	Remarks
Fuel filter	Check	Every 50 hr	—
	Replace	Every 200 hr	—
Fuel hose	Check	Every 6 months	Replace if any deterioration (crack, hardening, scar, or deformation) or damage occurred.
	Replace	Every 2 years	—

Long term storage for B5

- BDF easily deteriorates due to oxygen, water, heat, and foreign substances. Do not store B5 longer than three months.
- When using B5 fuel and storing the machine longer than three months, drain the fuel from the tanks and replace with light-mineral-oil-diesel-fuel. Subsequently, operate the engine at least the following minutes to remove all of the biodiesel from the fuel lines.

Operating the engine	30 minutes
----------------------	------------

Long term storage for B6 through B20

- BDF easily deteriorates due to oxygen, water, heat, and foreign substances. Do not store B6 through B20 longer than one month.
- When using B6 through B20 fuel and storing the machine longer than one months, drain the fuel from the tanks and replace with light-mineral-oil-diesel-fuel. Subsequently, operate the engine at least the following minutes to remove all of the biodiesel from the fuel lines.

Operating the engine	30 minutes
----------------------	------------

2. Mower

2.1 Lubricants









RCK60B-23BX, RCK54-23BX, RCK48-18BX, RCK60D-26BX, and RCK54D-26BX

No.	Place	Capacity	Lubricant
1	Gear box	0.36 L 0.38 U.S.qts 0.32 Imp.qts	<ul style="list-style-type: none"> SAE 90 gear oil (API Service GL-5 gear oil)

Greasing			
No.	Place	Capacity	Type of grease
2	Universal joint	Until grease overflows	SAE multi-purpose type grease NLGI-2 or NLGI-1 (GC-LB)
3	Three spindle shafts		
4	Belt tension pulley		
5	Belt tension pivot		
6	Balance shaft (RCK60B-23BX only)		
7	Front and rear anti-scalp roller		

TIGHTENING TORQUES



1. General use screws, bolts and nuts

Indica- tion on top of bolt	 4 No-grade or 4T						 7 7T						 9 9T			
Indica- tion on top of nut	  No-grade or 4T												   6T			
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness			
	Unit	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
	M6	7.9 to 9.3	0.80 to 0.95	5.8 to 6.8	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5	12.3 to 14.2	1.25 to 1.45	9.05 to 10.4
	M8	18 to 20	1.8 to 2.1	13 to 15	17 to 19	1.7 to 2.0	13 to 14	24 to 27	2.4 to 2.8	18 to 20	18 to 20	1.8 to 2.1	13 to 15	30 to 34	3.0 to 3.5	22 to 25
	M10	40 to 45	4.0 to 4.6	29 to 33	32 to 34	3.2 to 3.5	24 to 25	48 to 55	4.9 to 5.7	36 to 41	40 to 44	4.0 to 4.5	29 to 32	61 to 70	6.2 to 7.2	45 to 52
	M12	63 to 72	6.4 to 7.4	47 to 53	—	—	—	78 to 90	7.9 to 9.2	58 to 66	63 to 72	6.4 to 7.4	47 to 53	103 to 117	10.5 to 12.0	76.0 to 86.7
	M14	108 to 125	11.0 to 12.8	79.6 to 92.5	—	—	—	124 to 147	12.6 to 15.0	91.2 to 108	—	—	—	167 to 196	17.0 to 20.0	123 to 144
	M16	167 to 191	17.0 to 19.5	123 to 141	—	—	—	197 to 225	20.0 to 23.0	145 to 166	—	—	—	260 to 304	26.5 to 31.0	192 to 224
	M18	246 to 284	25.0 to 29.0	181 to 209	—	—	—	275 to 318	28.0 to 32.5	203 to 235	—	—	—	344 to 402	35.0 to 41.0	254 to 296
M20	334 to 392	34.0 to 40.0	246 to 289	—	—	—	368 to 431	37.5 to 44.0	272 to 318	—	—	—	491 to 568	50.0 to 58.0	362 to 419	



2. Stud bolts

Material of oppo- nent part	Ordinariness			Aluminum		
Unit	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
M8	12 to 15	1.2 to 1.6	8.7 to 11	8.9 to 11	0.90 to 1.2	6.5 to 8.6
M10	25 to 31	2.5 to 3.2	18 to 23	20 to 25	2.0 to 2.6	15 to 18
M12	30 to 49	3.0 to 5.0	22 to 36	31	3.2	23
M14	62 to 73	6.3 to 7.5	46 to 54	—	—	—
M16	98.1 to 112	10.0 to 11.5	72.4 to 83.1	—	—	—
M18	172 to 201	17.5 to 20.5	127 to 148	—	—	—



3. Metric screws, bolts and nuts

Grade	 Property class 8.8			 Property class 10.9		
Unit	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
M8	24 to 27	2.4 to 2.8	18 to 20	30 to 34	3.0 to 3.5	22 to 25
M10	48 to 55	4.9 to 5.7	36 to 41	61 to 70	6.2 to 7.2	45 to 52
M12	78 to 90	7.9 to 9.2	58 to 66	103 to 117	10.5 to 12.0	76.0 to 86.7
M14	124 to 147	12.6 to 15.0	91.2 to 108	167 to 196	17.0 to 20.0	123 to 144
M16	197 to 225	20.0 to 23.0	145 to 166	260 to 304	26.5 to 31.0	192 to 224

4. American standard screws, bolts and nuts with UNC or UNF threads

Grade	 SAE GR.5			 SAE GR.8		
Unit	N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
1/4	11.7 to 15.7	1.20 to 1.60	8.63 to 11.5	16.3 to 19.7	1.67 to 2.00	12.0 to 14.6
5/16	23.1 to 27.7	2.36 to 2.82	17.0 to 20.5	33 to 39	3.4 to 3.9	25 to 28
3/8	48 to 56	4.9 to 5.7	36 to 41	61 to 73	6.3 to 7.4	45 to 53
1/2	110 to 130	11.3 to 13.2	81.2 to 95.8	150 to 178	15.3 to 18.1	111 to 131
9/16	150 to 178	15.3 to 18.1	111 to 131	217 to 260	22.2 to 26.5	160 to 191
5/8	204 to 244	20.8 to 24.8	151 to 179	299 to 357	30.5 to 36.4	221 to 263

5. Plugs

Shape	Size	Material of opponent part					
		Ordinariness			Aluminum		
		N · m	kgf · m	lbf · ft	N · m	kgf · m	lbf · ft
Tapered screw 	R1/8	13 to 21	1.3 to 2.2	9.4 to 15	13 to 19	1.3 to 2.0	9.4 to 14
	R1/4	25 to 44	2.5 to 4.5	18 to 32	25 to 34	2.5 to 3.5	18 to 25
	R3/8	49 to 88	5.0 to 9.0	37 to 65	49 to 58	5.0 to 6.0	37 to 43
	R1/2	58.9 to 107	6.00 to 11.0	43.4 to 79.5	59 to 78	6.0 to 8.0	44 to 57
Straight screw 	G1/4	25 to 34	2.5 to 3.5	18 to 25	—	—	—
	G3/8	62 to 82	6.3 to 8.4	46 to 60	—	—	—
	G1/2	49 to 88	5.0 to 9.0	37 to 65	—	—	—

MAINTENANCE CHECK LIST

1. BX tractor service intervals

No.	Items		Indication on hour meter														Since then	Refer- ence page		
			50	100	150	200	250	300	350	400	450	500	550	600	650	700				
1	Engine oil	Change	⊙			○				○				○			Every 200 Hr	2-23	*1	
2	Engine oil filter	Replace	⊙			○				○				○			Every 200 Hr	2-23	*1	
3	Transmission oil filter	Replace	⊙			○				○				○			Every 200 Hr	2-24	*1	
4	Engine start system	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	2-26		
5	OPC system	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	2-26		
6	Greasing	—	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	2-24		
7	Wheel bolt torque	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	2-26		
8	Lock lever	Clean	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	2-27		
9	Battery condition	Check		○		○		○		○		○		○		○	Every 100 Hr	2-27	*B	
10	Air cleaner element	Clean		○		○		○		○		○		○		○	Every 100 Hr	2-23	*2	@
		Replace															Every 1000 Hr or 1 year	2-36	*3	
11	Fuel filter element	Check		○		○		○		○		○		○		○	Every 100 Hr	2-29		@
		Replace								○							Every 400 Hr	2-35		
12	Fan belt	Adjust		○		○		○		○		○		○		○	Every 100 Hr	2-30		
13	HST neutral spring	Adjust		○		○		○		○		○		○		○	Every 100 Hr	2-30		
14	Brake pedal	Adjust		○		○		○		○		○		○		○	Every 100 Hr	2-31		
15	Toe-in	Adjust				○				○				○			Every 200 Hr	2-33		
16	Transmission fluid	Change								○							Every 400 Hr	2-34	*1	
17	Transmission strainer	Clean								○							Every 400 Hr	2-35	*1	
18	Front axle case oil	Change								○							Every 400 Hr	2-35		
19	Front axle pivot	Adjust								○							Every 400 Hr	2-33		
20	Engine valve clearance	Adjust															Every 800 Hr	2-36		
21	Injection pressure of the fuel injection nozzle	Check															Every 1500 Hr	2-36		@
22	Cooling system	Flush															Every 2000 Hr or 2 years	2-36	*4	
23	Coolant	Change															Every 2000 Hr or 2 years	2-36 2-37	*4	
24	Injection pump	Check															Every 3000 Hr	2-38		@
25	Radiator hose and clamp	Check															Every 1 year	2-38	*R	
		Replace															Every 4 years	2-40		
26	Power steering oil line	Check															Every 1 year	2-39	*R	
		Replace															Every 4 years	2-40		
27	Fuel line	Check															Every 1 year	2-39	*R	@

(Continued)

2. GENERAL

No.	Items		Indication on hour meter													Since then	Ref- eren ce page		
			50	100	150	200	250	300	350	400	450	500	550	600	650	700			
27	Fuel line	Replace															Every 4 years	2-40	@
28	Intake air line	Check															Every 1 year	2-38	*R
		Replace															Every 4 years	2-40	@
29	Engine breather hose	Check															Every 1 year	2-40	*R
		Replace															Every 4 years	2-40	
30	Fuel system	Bleed															Service as required	2-41	
31	Fuse	Replace																2-41	
32	Light bulb	Replace																2-42	

IMPORTANT

- You must do the jobs indicated by © after the first 50 hours of operation.
- The items which is @ marked are registered as the emission-related-critical-parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the preceding instruction.
Please see Warranty Statement in detail.

*1 The initial 50 hours should not be a replacement (changing) cycle.

*B When the battery is used for less than 100 hours per year, check the battery condition by reading the indicator annually.

*2 You should clean the air cleaner more often in dusty conditions than in normal conditions.

*3 Every 1,000 hours or every 1 year whichever comes faster.

*4 Every 2,000 hours or every 2 years whichever comes faster.

*R Replace if any deterioration (crack, hardening, scar, or deformation) or damage occurred.

2. Mower service intervals

To keep the mower working in good condition as well as to avoid any accident and trouble, do periodic inspection and maintenance. Check the following points before use.

No.	Item	Service interval					Reference page
		Daily check	Every 50 hrs	Every 150 hrs	Every 1 year	Every 4 years	
1	Oil leakage check	○					2-43
2	Make sure blade bolts are tight.	○					2-42
3	Blade wear check	○					2-42
4	Belt wear check	○					2-43
5	All hardware check	○					—
6	Make sure that all pins are in place.	○					—
7	Mower deck cleaning	○					—
8	Greasing • Universal joint • Three spindle shafts • Belt tension pulley • Belt tension pivot • Balance shaft* ¹ • Front and rear anti-scalp rollers • Frame link* ²	○					2-43 2-45
9	Gear box oil check	○					2-43
10	Gear box oil change		◎	○			2-45
11	Gear box oil seal check				○ * ³		2-46
12	Gear box oil seal replace					○	2-46

■ IMPORTANT

- The jobs indicated by ◎ must be done after the first 50 hours of operation.

*1 RCK60B-23BX only

*2 RCK60D-26BX and RCK54D-26BX only

*3 Replace the gear-box-oil-seal if any deterioration (crack, hardening, scar, or deformation) or damage occurred.

2. GENERAL

CHECK AND MAINTENANCE

1. Periodic service

WARNING

To avoid serious injury or death:


- Do not work under any hydraulically supported devices. Hydraulically supported devices can settle, suddenly leak down, or be accidentally lowered.
- If necessary to work under the tractor or any machine elements for servicing or adjustment, securely support the tractor or any machine elements with stands or suitable blocking beforehand.

1.1 Opening bonnet

WARNING

- Never open the bonnet while the engine is running.
- Do not touch the muffler or the exhaust pipes while they are hot.
Touching the hot muffler or exhaust pipes could cause severe burns.

1. Pull the bonnet-open-lever to release the latch to open the bonnet, and open the bonnet.



- (1) Bonnet
(2) Bonnet-open-lever

(A) Pull

1.2 Daily check

WARNING

- To avoid serious injury or death:
Take the following precautions when checking the tractor.

- Park the machine on firm and level ground.
- Set the parking brake.
- Lower the implement to the ground.
- Release all residual pressure of the hydraulic system.
- Stop the engine and remove the key.

For your own safety and maximum service life of the machine, make a thorough daily inspection before operating the machine or starting the engine.

1.2.1 Walk around inspection

Look around and under the tractor for such items as loose bolts, trash build-up, oil or coolant leaks, or broken or worn parts.

1.2.2 Checking fuel gauge and refueling

WARNING

To avoid serious injury or death:

- Do not smoke while refueling.
- Be sure to stop the engine and remove the key before refueling.

To avoid allergic skin reaction:

- Wash hands immediately after contact with diesel fuel.

■ IMPORTANT

- Do not permit dirt, trash, or water to get into the fuel system.
- Be careful not to empty the fuel tank, otherwise air will enter the fuel system, necessitating bleeding before next starting the engine.
- Be careful not to spill the fuel during refueling. If you should spill, wipe it off at once, or it may cause a fire.
- To prevent water condensation and water accumulation in the fuel tank, fill the tank before parking overnight.

Using fuel


Temperature	fuel
Above -10 °C (14 °F)	Grade No. 2-Diesel fuel
Below -10 °C (14 °F)	Grade No. 1-Diesel fuel

1. Turn the key switch to the **ON** position and check the amount of fuel by the fuel gauge.

2. GENERAL

- Fill the fuel tank with fuel when the fuel gauge shows as follows.

Amount of fuel for refueling		1/4 or less in the fuel tank
Fuel tank	Capacity	25 L 6.6 U.S.gals



(1) Fuel tank cap

1.2.3 Checking engine oil level

WARNING


To avoid serious injury or death:

- Be sure to stop the engine before checking the engine oil level.


IMPORTANT

- When using an engine oil of different maker or viscosity from the previous one, remove all of the old oil and oil filter. Never mix two different types of oil.
 - If the engine oil level is low, do not run the engine.
- Park the machine on a firm, flat, and level surface.
 - Check the engine oil before starting the engine, or, after five minutes or more when the engine has been stopped.
 - To check the engine oil level, draw out the dipstick, wipe it clean, replace it, and draw it out again.
 - Check to see that the engine oil level lies between the two notches.
 - If the engine oil level is too low, add new oil to the prescribed level at the oil inlet.

BX1880 and BX2380



BX2680



(1) Oil inlet
(2) Dipstick

(A) Engine oil level is acceptable within this range.

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.2.4 Checking transmission fluid level

WARNING


To avoid serious injury or death:

- Park the tractor on a firm, flat, and level surface, lower the implement to the ground, and stop the engine.

IMPORTANT

- If the transmission fluid level is low, do not operate the engine.
- To check the transmission fluid level, check the dipstick as the following procedure.
 - Draw out the dipstick.
 - Wipe the dipstick clean.
 - Replace the dipstick.
 - Draw the dipstick out again.

2. Check to see that the transmission fluid level lies between the two notches.
3. If the transmission fluid level is too low, add new fluid to the prescribed level at the oil inlet.



- (1) Oil inlet
(2) Dipstick
(A) Transmission fluid level is acceptable within this range.

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.2.5 Checking coolant level


! WARNING

To avoid serious injury or death:

- Be sure to stop the engine and remove the key before checking coolant level.
- Do not remove the radiator cap while the coolant is hot. When coolant is cool, slowly rotate the radiator cap to the first stop and allow sufficient time for excess pressure to escape before removing the radiator cap completely.

■ IMPORTANT

- If the radiator cap has to be removed, follow the preceding warning and securely retighten the radiator cap.
 - Use clean, fresh, soft water and anti-freeze to fill the recovery tank.
1. Check to see that the coolant level is between the [H] and [L] marks of the recovery tank.
 2. When the coolant level drops due to evaporation, add soft water only. In case of leakage, add antifreeze and soft water in the specified mixing ratio up to the [H] level.



- (1) Recovery tank
(A) [H]
(B) [L]

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.2.6 Cleaning panel and radiator screen

! WARNING

To avoid serious injury or death:

- Be sure to stop the engine and remove the key before removing the screen.
- Before checking or cleaning the panel, wait long enough until it cools down.

■ IMPORTANT



- The panel and the radiator screen must be clean from debris to prevent the engine from overheating and to allow good air intake for the air cleaner.
- Be sure to reinstall the panel on the pillar completely to prevent the invasion of dust.
- Be sure to stop the engine to avoid personal injury and to allow good air intake for air cleaner.

1. Check the panel and the radiator screen to be sure that they are clean from debris.

- Detach the radiator screen, and then remove all the foreign material.

■ NOTE

- If the dust or chaff is accumulated in the battery compartment, open the panel and clean completely.



- | | |
|-------------------|---------------------|
| (1) Panel | (4) Radiator screen |
| (2) Knob | (A) Detach |
| (3) Center pillar | |

1.2.7 Checking brake pedal

- Inspect the brake pedal for free travel, and smooth operation.
- Adjust the brake pedal if incorrect measurement is found.

1.2.8 Checking gauges, meters, and Easy Checker™

- Inspect the instrument panel for broken gauge(s), meter(s) and Easy Checker™ lamps.
- Replace the gauge(s), the meter(s), or the Easy Checker™ if they are broken.

1.2.9 Checking head light, hazard light, and tail light

- Inspect the lights for broken bulbs and lenses.
- Replace the lights if they are broken.

1.2.10 Checking seat belt and ROPS

- Always check condition of the seat belt and the ROPS attaching hardware before operating the tractor.
- Replace the seat belt or the ROPS if it is damaged.

1.2.11 Checking and cleaning electrical wiring and battery cables



WARNING

To avoid serious injury or death:

- A loosened terminal or connector, or damaged wire may affect the performance of the electrical components or cause short circuits. Leakage of electricity could result in a fire hazard, a dead battery, or damage to the electrical components.
 - Replace the damaged wires or connections promptly.
 - If a fuse blows soon after replacement, do not use the capacity larger than recommended or bypass the fuse system.
 - Many wiring connections are protected by waterproof plugs. Plug and unplug these connections carefully and make sure that they are sealed correctly after assembly.
 - Accumulation of dust, chaff, and deposits of spilled fuel around the battery, electrical wiring, engine, or exhaust system may cause fire hazards.
- Clean around the battery, electrical wiring, engine or exhaust system before starting to work.
- To avoid premature electrical malfunctions, do not apply high pressure water directly to the battery, the wiring, the connectors, the electrical components, or the instrument panel.

- Inspect the following check items regularly.
 - Check the wiring for chafed or cracked insulation.
 - Check the wiring harness clamps. Replace them if necessary.
 - Check the connectors and the terminals for looseness, contamination, or overheated or discolored connections.
 - Check the instrument panel for correct operation of the switches and the gauges.

1.2.12 Checking movable parts

1. If any of the movable parts, such as levers and pedals, is not smoothly moved because of rust or sticky material, remove the rust or the sticky material, and apply oil or grease on the relevant spot.
Do not force the movable parts into motion.
Otherwise, the machine may get damaged.

1.3 Check points of initial 50 hours

1.3.1 Changing engine oil

WARNING

To avoid serious injury or death:

- Be sure to stop the engine and remove the key before changing the oil.
- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

BX1880

Engine oil with filter	Capacity	3.0 L 3.2 U.S.qts
------------------------	----------	----------------------

BX2380


Engine oil with filter	Capacity	3.3 L 3.5 U.S.qts
------------------------	----------	----------------------

BX2680


Engine oil with filter	Capacity	4.0 L 4.2 U.S.qts
------------------------	----------	----------------------

1. To drain the used engine oil, remove the drain plug at the bottom of the engine, and drain the engine oil completely into the oil pan.
2. After draining of the used engine oil, reinstall the drain plug.
3. Fill the engine with the new engine oil up to the upper notch on the dipstick.
4. Properly dispose of the used engine oil.


BX1880 and BX2380



BX2680



BX1880, BX2380, and BX2680



- (1) Oil inlet
(2) Dipstick
(3) Drain plug
- (A) Oil level is acceptable within this range.

— RELATED PAGE —
[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.3.2 Replacing engine oil filter

WARNING

To avoid serious injury or death:


- Be sure to stop the engine before replacing the oil filter cartridge.
- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

■ IMPORTANT

- To prevent serious damage to the engine, use only a KUBOTA genuine filter.


1. Remove the oil filter.
2. Put a film of the clean engine oil on the rubber seal of the new filter.
3. Tighten the filter quickly until it contacts the mounting surface.

4. Tighten filter by hand an additional 1/2 turn only.
5. After the new filter has been replaced, the engine oil normally decreases a little. Make sure that the engine oil does not leak through the seal and be sure to check the oil level on the dipstick.
6. Fill the engine with the engine oil up to the prescribed level.
7. Properly dispose of the used engine oil.



(1) Engine oil filter

— RELATED PAGE —
[1.1 Lubricants, fuel, and coolant on page 2-7](#)



(1) Filter

— RELATED PAGE —
[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.4 Check points of every 50 hours

1.4.1 Greasing

NOTE

- If the machine is operated in extremely wet and muddy conditions, lubricate grease fittings more often.

1.3.3 Replacing transmission oil filter

WARNING

To avoid serious injury or death:









- Be sure to stop the engine before changing the transmission oil filter cartridge.
- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

IMPORTANT

- To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.

1. Remove the transmission oil filter.
2. Put a film of clean transmission oil on rubber seal of new transmission oil filter.
3. Tighten the transmission oil filter quickly until it contacts the mounting surface.
4. Tighten the transmission oil filter by hand an additional 1/2 turn only.
5. After the new transmission oil filter has been replaced, the transmission fluid level will decrease a little. Make sure that the transmission fluid does not leak through the seal, and check the fluid level.
6. Check the dipstick and refill with oil to prescribed level.
7. Properly dispose of used oil.

1. Apply a small amount of multipurpose grease to the following points.



- (1) Speed control pedal
(2) Battery terminals
(3) Rear link
(4) Bonnet guide rod
[A] Figure (A)

- [B] Figure (B)
[C] Figure (C)
[D] Figure (D)

— RELATED PAGE —
1.1 Lubricants, fuel, and coolant on page 2-7

1.4.2 Checking engine start system

WARNING

To avoid serious injury or death:

- Do not allow anyone near the tractor while testing.
- If the tractor does not pass the test, do not operate the tractor.

Preparation before testing


1. Sit on the operator's seat.
2. Set the parking brake and stop the engine.
3. Shift the range gear shift lever to the neutral position.
4. Check whether the speed control pedal is in the neutral position.
5. **Shift the PTO clutch lever to the off position.**

[Test 1] Switch for the speed control pedal

1. Make sure that the range gear shift lever is set in the neutral position.
2. Depress the speed control pedal.
3. Turn the key to the start position.
The engine must not crank.

[Test 2] Switch for the PTO clutch lever

1. Make sure that the range gear shift lever is set in the neutral position.
2. Make sure that the speed control pedal is set in the neutral position.
3. **Shift the PTO clutch lever to the on position.**
4. Turn the key to the start position.
The engine must not crank.



- (1) Range gear shift lever (Hi-Lo) (2) PTO clutch lever
(3) Speed control pedal

1.4.3 Checking operator presence control (OPC) system

WARNING

To avoid serious injury or death:

- Do not allow anyone near the tractor while testing.
- If the tractor does not pass the test, do not operate the tractor.

Preparation before testing


1. Sit on the operator's seat.
2. Set the parking brake and stop the engine.
3. Shift the range gear shift lever to the neutral position.
4. Check whether the speed control pedal is in the neutral position.
5. Shift the PTO clutch lever to the off position.

[Test 1] Switches for the operator's seat and the speed control pedal

1. Start the engine.
2. Depress the speed control pedal.
3. Stand up.
Do not get off the machine.
The engine must stop after approximately one second.

[Test 2] Switches for the operator's seat and the PTO clutch lever

1. Start the engine.
2. Engage the PTO clutch lever.
3. Stand up.
Do not get off the machine.
The engine must stop after approximately one second.



- (1) Range gear shift lever (Hi-Lo) (2) PTO clutch lever
(3) Speed control pedal



1.4.4 Checking wheel bolt torque

WARNING

To avoid serious injury or death:

- Never operate the tractor with a loose rim, wheel, or axle.
- Any time bolts are loosened, retighten to the specified torque.
- Check all bolts frequently and keep them tight.

1. Check the wheel bolts regularly especially when new.
2. If they are loose, tighten them as follows.




(1) Front wheel bolt

(2) Rear wheel bolt

Tightening torque	Front wheel bolt	149.2 to 179.0 N·m 15.2 to 18.3 kgf·m 110 to 132 lbf·ft
	Rear wheel bolt	108.5 to 130.2 N·m 11.1 to 13.3 kgf·m 80 to 96 lbf·ft

1.4.5 Cleaning lock lever shaft

1. Before you use the lock lever, clean the lever movable area (1).



(1) Lever movable area

1.5 Check points of every 100 hours

1.5.1 Checking battery condition

! DANGER

To avoid the possibility of battery explosion:
For the refillable type battery, follow the instructions below.

- Do not use or charge the refillable type battery if the fluid level is below the [LOWER] (lower limit level) mark. Otherwise, the battery component parts may prematurely deteriorate, which may shorten the battery's service life or cause an explosion.
- Check the fluid level regularly and add distilled water as required so that the fluid level is between the [UPPER] and [LOWER] levels.

! DANGER

To avoid serious injury or death:

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.

! WARNING

To avoid serious injury or death:

- Batteries, battery posts, terminals and related accessories contain lead and lead compounds, and other chemicals known to the State of California to cause cancer and birth problems or other reproductive harm. Wash hands after handling.
- Never remove the battery cap while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are splattered with it, wash it away completely with water immediately and get medical attention.

2. GENERAL

- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.
- Wear eye protection and rubber gloves when working around battery.

IMPORTANT

- The factory-installed battery is of non-refillable type. If the battery is weak, charge the battery or replace it with new one.
- Mishandling the battery shortens the service life and adds to maintenance costs.
The original battery is maintenance free, but needs some servicing.
If the battery is weak, the engine will be difficult to start and the lights will be dim. It is important to check the battery periodically.
- When exchanging an old battery for new one, use battery of equal specification in table below.

Battery type	Volts	Reserve capacity	Cold cranking amps	Normal charging rate
526RMF	12 V	86 min.	560	8.6 A

Maintenance-free, non-accessible batteries are designed to eliminate the need to add water. Yet the volume of electrolyte above plates may eventually become depleted due to abnormal conditions such as high heat or improper regulator setting. Use a voltmeter to check the state of charge. See reference chart below to determine if charging is necessary.

Battery voltage	Reference state of charge
12.6	100% (Full charge)
12.4	75%
12.2	50%
12.0	25%
11.8	0%

Battery charging**DANGER**

To avoid serious injury or death:

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.


**WARNING**

To avoid serious injury or death:

- When disconnecting the cable from the battery, start with the negative terminal first. When

connecting the cable to the battery, start with the positive terminal first.

- Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.



(1) Battery

(2) Clamp

1. To slow charge the battery, connect the battery positive terminal to the charger positive terminal and the negative to the negative, then charge for at least 1 hour at 6.5 amperes.
2. A boost charge is only for emergencies. It will partially charge the battery at a high rate and in a short time. When using a boost-charged battery, it is necessary to recharge the battery as early as possible. Failure to do this will shorten the battery's service life.
3. When the specific gravity of electrolyte is between 1.27 and 1.29 the charging is completed.

Battery for storage

1. When storing the machine for a long period, remove the battery from machine, adjust the electrolyte to the proper level and store in a dry place out of direct sunlight.
2. The battery self-discharges while it is stored. Recharge it once every 3 months in hot seasons and once every 6 months in cold seasons.

1.5.2 Cleaning air cleaner element**WARNING**

To avoid serious injury or death:

- Be sure to stop the engine and remove the key before cleaning the air cleaner element.

IMPORTANT

- The air cleaner uses a dry element. Never apply oil to the air cleaner.
- Do not run the engine with filter element removed.
- Align the arrow marks when reinstalling the cover. If the cover is improperly fitted, dust

passes by the baffle and directly adheres to the air cleaner element.

NOTE

- Check to see if the evacuator valve is blocked with dust.

Open the evacuator valve once a week under ordinary conditions or daily when used in a dusty place to get rid of large particles of dust and dirt.

Cleaning dust from the air cleaner element


- Remove the air cleaner cover and the element.
- When dry dust adheres to the element, blow compressed air from the inside, turning the element. Pressure of compressed air must be below 205 kPa (2.1 kgf/cm², 30 psi).

Cleaning carbon or oil from the air cleaner element


- Remove the air cleaner cover and the element.
- Soak the air cleaner element in detergent for 15 minutes.
- Then wash it several times in water.
- Rinse the air cleaner element with clean water.
- Dry the air cleaner element naturally.
- After the air cleaner element is fully dried, inspect inside of it with a light and check if it is damaged or not.

Refer to the instructions on the label attached to the case.

BX1880 and BX2380



BX2680



- (1) Element
(2) Cover

- (3) Evacuator valve

1.5.3 Checking fuel filter



WARNING

To avoid serious injury or death:

- Stop the engine and remove the key before checking the fuel lines and the fuel filter.
- Check the fuel lines periodically. The fuel lines are subject to wear and aging. Fuel may leak out onto the running engine, causing a fire.

IMPORTANT



- When the fuel line is disconnected for maintenance or repair, plug both ends of the fuel line with a clean plug of suitable size to prevent dust and dirt from entering. You must take particular care of the fuel filter in order to avoid dust and dirt getting into the fuel system. Entrance of dust and dirt causes malfunction of the fuel pump.

The fuel line is made of rubber and ages regardless of service period.

- Inspect the fuel filter.
- After inspection of the fuel filter, if the fuel line and clamps are found damaged or deteriorated, replace them.

2. GENERAL

3. Check the fuel filter. If the fuel filter is clogged by debris or contaminated by water, replace it.



- (1) Pipe clamps
(2) Fuel line
(3) Fuel filter
(4) Fuel pump

NOTE

- If the fuel line is removed, be sure to properly bleed the fuel system.

1.5.4 Adjusting fan belt tension

WARNING

To avoid serious injury or death:


- Be sure to stop the engine and remove the key before checking the fan belt tension.

1. Stop the engine and remove the key.
2. Apply moderate thumb pressure to belt between pulleys.

Fan belt tension	Factory specification	A deflection of between 7 to 9 mm (0.28 to 0.35 in.) when the belt is pressed in the middle of the span.
------------------	-----------------------	--

3. If tension is incorrect, loosen the alternator mounting bolts and, using a lever placed between the alternator and the engine block, pull the

alternator out until the deflection of the belt falls within acceptable limits.



- (1) Bolt
(A) Check the belt tension.

4. Replace fan belt if it is damaged.

1.5.5 Adjusting HST neutral spring


WARNING

- Do not operate if tractor moves on level ground with foot off speed control pedal.
- If tractor moves on level ground with foot off the pedal, or, if the pedal is too slow in returning to neutral position when removing the foot from the pedal, adjust the HST neutral spring.

The HST neutral spring located under the front right side of the fender can adjust returning speed of speed control pedal. Since the HST neutral spring tension is weakened, the HST tension should be checked and adjusted every 100 hours.

Checking the HST neutral spring tension: Dynamic braking

1. Start the engine and hold the maximum engine speeds.
2. Operate the machine on the concrete level ground.
3. Shift the range gear shift lever to hi position.
4. Depress the speed control pedal to forward.
5. Release the foot from the speed control pedal.
6. Check the distance between the foot releasing point (A) and the machine stopping point (B). If distance (L) is more than approximately 3 m (10 ft.), strengthen the HST neutral spring tension so that the machine will stop in approximately 3 m (10 ft.) after releasing the foot from the speed control pedal.




(A) Foot releasing point
(B) Machine stopping point

(L) Distance between foot releasing point and the machine stopping point

Adjusting the HST neutral spring tension: Dynamic braking

1. Remove the step from the machine.
2. Loosen the lock nut (2).



(1) HST neutral spring
(2) Lock nut
(3) Adjusting nut
(4) Adjusting rod

(M) Length of adjusting rod from stay

3. Adjust the adjusting nut (3) on the adjusting rod (4).
4. Tighten the lock nut (2).
5. Start the engine and check dynamic brake as mentioned former.
6. If the machine will not stop with dynamic brake in approximately 3 m (10 ft.), adjust the neutral spring again.

Length (M)	Factory specification	10 mm 0.39 in.
------------	-----------------------	-------------------

1.5.6 Adjusting brake pedal



WARNING



To avoid serious injury or death:

- Stop the engine, remove the key, lower the implement to the ground, and chock the wheels before checking the brake pedal.

- Even if free travel of the brake pedal is within the limitation, adjust the brake pedal.

1. Release the parking brake.
2. Loosen the lock nut and turn the turnbuckle to adjust the rod length so that the brake free travel is 10 mm (0.4 in.).
3. Extend the turnbuckle one additional turn.
4. Retighten the lock nut.
5. Depress the brake pedal several times and make sure that free travel is inside factory specification.

Brake pedal free travel	Factory specification	25 to 35 mm 1.0 to 1.4 in.
-------------------------	-----------------------	-------------------------------



(1) Lock nut
(2) Turnbuckle
(A) Free travel

(B) Right rear tire

1.6 Check point of every 200 hours

1.6.1 Replacing engine oil filter



WARNING


To avoid serious injury or death:

- Be sure to stop the engine before replacing the oil filter cartridge.
- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

IMPORTANT

- To prevent serious damage to the engine, use only a KUBOTA genuine filter.

1. Remove the oil filter.
2. Put a film of the clean engine oil on the rubber seal of the new filter.
3. Tighten the filter quickly until it contacts the mounting surface.
4. Tighten filter by hand an additional 1/2 turn only.
5. After the new filter has been replaced, the engine oil normally decreases a little. Make sure that the engine oil does not leak through the seal and be sure to check the oil level on the dipstick.
6. Fill the engine with the engine oil up to the prescribed level.
7. Properly dispose of the used engine oil.



(1) Engine oil filter

1.6.2 Changing engine oil**WARNING**

To avoid serious injury or death:

- Be sure to stop the engine and remove the key before changing the oil.
- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

BX1880

Engine oil with filter	Capacity	3.0 L 3.2 U.S.qts
------------------------	----------	----------------------




BX2380

Engine oil with filter	Capacity	3.3 L 3.5 U.S.qts
------------------------	----------	----------------------

BX2680

Engine oil with filter	Capacity	4.0 L 4.2 U.S.qts
------------------------	----------	----------------------

1. To drain the used engine oil, remove the drain plug at the bottom of the engine, and drain the engine oil completely into the oil pan.
2. After draining of the used engine oil, reinstall the drain plug.
3. Fill the engine with the new engine oil up to the upper notch on the dipstick.
4. Properly dispose of the used engine oil.

BX1880 and BX2380**BX2680****BX1880, BX2380, and BX2680**

- (1) Oil inlet
- (2) Dipstick
- (3) Drain plug

(A) Oil level is acceptable within this range.

1.6.3 Replacing transmission oil filter



WARNING


To avoid serious injury or death:

- Be sure to stop the engine before changing the transmission oil filter cartridge.
- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

IMPORTANT

- To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.

1. Remove the transmission oil filter.
2. Put a film of clean transmission oil on rubber seal of new transmission oil filter.
3. Tighten the transmission oil filter quickly until it contacts the mounting surface.
4. Tighten the transmission oil filter by hand an additional 1/2 turn only.
5. After the new transmission oil filter has been replaced, the transmission fluid level will decrease a little. Make sure that the transmission fluid does not leak through the seal, and check the fluid level.
6. Check the dipstick and refill with oil to prescribed level.
7. Properly dispose of used oil.



1BXM00048A02

(1) Filter

1.6.4 Adjusting toe-in



WARNING

To avoid serious injury or death:


- Park the tractor on a firm, flat, and level place.
- Lower the implement to the ground, and apply the parking brake.
- Stop the engine and remove the key.

Checking toe-in

1. Turn the steering wheel so that the front wheels are in the straight ahead position.

2. Measure the distance between the tire beads at front of the tires, and at the hub heights.
3. Measure the distance between the tire beads at rear of the tires, and at the hub heights.
4. Front distance should be 0 to 5.0 mm (0 to 0.2 in.) less than rear distance. If front distance is not proper length, adjust the length of the tie rod.


Toe-in ((B) - (A))	Factory specification	0 to 5.0 mm 0 to 0.2 in.
--------------------	-----------------------	-----------------------------



- (A) Wheel-to-wheel distance at rear
(B) Wheel-to-wheel distance at front
(C) Front

Adjusting toe-in

1. Loosen the lock nuts and turn the tie-rod to adjust the rod length until the proper toe-in measurement is obtained.
2. Retighten the lock nuts.



- (1) Lock nut
(2) Tie-rod

1.7 Check points of every 400 hours

1.7.1 Adjusting front axle pivot



WARNING

To avoid serious injury or death:


- Be sure to stop the engine and remove the key before adjusting the front axle pivot.

If the front axle pivot pin adjustment is not correct, front wheel vibration can occur causing vibration in the steering wheel.

1. Remove the split pin and tighten the adjusting nut.

Tightening torque	Adjusting nut	20 N · m 2.0 kgf · m 15 lbf · ft
-------------------	---------------	--

2. Make sure that one of the nut slots aligns with the split pin hole.
3. Tighten the nut slightly if necessary when aligning the nut slots with the split pin hole.
4. Replace the split pin.



(1) Adjusting nut

(2) Split pin


1.7.2 Changing transmission fluid

WARNING

To avoid serious injury or death:


- Oil can be hot and can burn. Allow the engine to cool down sufficiently.

1. To drain the used transmission fluid, remove the drain plug at the bottom of the transmission case and drain the transmission fluid completely into the oil pan.



(1) Drain plug

2. After draining the transmission fluid, reinstall the drain plug.
3. Clean the transmission strainer.
4. Fill with new transmission fluid up to the upper notch on the dipstick.

(2) Oil inlet
(3) Dipstick

(A) Transmission fluid level is acceptable within this range.

Transmission fluid	Capacity	11.3 L 2.99 U.S.gals 2.49 Imp.gals
--------------------	----------	--

5. After operating the engine for a few minutes, stop it and check the transmission fluid level again.
6. If the transmission fluid level is lower than the prescribed level shown on the dipstick (3), add fluid to the prescribed level.
7. Properly dispose of used transmission fluid.

IMPORTANT



- Do not operate the tractor immediately after changing the transmission fluid. Operate the engine at medium speed for a few minutes to prevent damage to the transmission.

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.7.3 Cleaning transmission strainer

1. When changing the transmission fluid, disassemble and rinse the transmission strainer with nonflammable solvent to completely clean off filings. When reassembling the transmission strainer, be careful not to damage the parts.



(1) Transmission strainer (2) Filter plate

NOTE

- Since the fine filings in the oil can damage the precision component parts of the hydraulic system, the end of the suction line is provided with an oil strainer.


1.7.4 Changing front axle case oil

WARNING

To avoid serious injury or death:

- Be sure to stop the engine and remove the key before changing the front axle case oil.

1. Park the tractor on a firm, flat, and level place.
2. To drain the used front-axle-case-oil, remove the right and left drain plugs and oil gauge at the front axle case.



(1) Breather plug (2) Oil gauge with dipstick (3) Drain plug (A) Front axle case oil level is acceptable within this range.

3. Drain the front-axle-case-oil completely into the oil pan.
4. After draining the front-axle-case-oil, reinstall the drain plugs.
5. Remove the right and left breather plugs.
6. Fill with new front-axle-case-oil up to the upper notch on the dipstick.

Front axle case oil	Capacity	4.7 L 5.0 U.S.qts 4.1 Imp.qts
---------------------	----------	-------------------------------------

IMPORTANT

- After 10 minutes, check the front-axle-case-oil level again. If the front-axle-case-oil level is lower than the prescribed level, add the front-axle-case-oil to prescribed level.

7. After filling with front-axle-case-oil, reinstall the oil gauge and breather plugs.

RELATED PAGE

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.7.5 Replacing fuel filter element



NOTE

- If the fuel line is removed, be sure to properly bleed the fuel system.

1. Disconnect the fuel hoses and replace the fuel filter (2).

2. GENERAL

2. Disconnect the fuel hoses and loosen the pipe clamp to replace the fuel filter (5).



- (1) Fuel pump
(2) Fuel filter
(3) Fuel line
(4) Hose clamp
(5) Fuel filter

1.8 Check points of every 800 hours**1.8.1 Adjusting engine valve clearance**

- See “Checking engine valve clearance”.

— RELATED PAGE —
[4.1.2 Checking valve clearance on page 3-30](#)

1.9 Check points of every 1000 hours or 1 year

Be sure to do the following servicing once every 1000 hours or yearly, whichever comes first.

1.9.1 Replacing air cleaner element

See “Cleaning air cleaner element”.

— RELATED PAGE —
[1.5.2 Cleaning air cleaner element on page 2-28](#)

1.10 Check points of every 1500 hours**1.10.1 Checking injection pressure of fuel injection nozzle**

- See “Checking fuel injection pressure”.

— RELATED PAGE —
[4.4.5 Checking fuel injection pressure on page 3-36](#)

1.11 Check points of every 2000 hours or 2 years**1.11.1 Flushing cooling system and changing coolant****! WARNING**

To avoid serious injury or death:

- Do not remove the radiator cap while the coolant is hot. When the coolant is cool, slowly rotate the radiator cap to the first stop and allow sufficient time for excess pressure to escape before removing the radiator cap completely.

■ IMPORTANT

- Do not start the engine without coolant.
- Use clean, fresh soft water and the anti-freeze to fill the radiator and the recovery tank.
- When mixing the anti-freeze with water, the anti-freeze mixing ratio is 50%.
- Securely tighten the radiator cap. If the radiator cap is loose or improperly fitted, water may leak out and the engine could overheat.

BX1880

Coolant (with recovery tank)	Capacity	2.9 L 3.1 U.S.qts 2.6 Imp.qts
------------------------------	----------	-------------------------------------

BX2380



Coolant (with recovery tank)	Capacity	3.1 L 3.3 U.S.qts 2.7 Imp.qts
------------------------------	----------	-------------------------------------

BX2680


Coolant (with recovery tank)	Capacity	3.3 L 3.5 U.S.qts 2.9 Imp.qts
------------------------------	----------	-------------------------------------

1. Stop the engine and let it cool down.
2. To drain the coolant, open the radiator drain plug or the engine drain plug and remove the radiator cap. The radiator cap must be removed to completely drain the coolant.
3. After all coolant is drained, close the drain plug.


4. Fill the radiator with clean soft water and the cooling system cleaner.
5. Follow directions of the instruction of cooling system cleaner.
6. After flushing the radiator, fill it with clean soft water and the anti-freeze until the coolant level is just below the radiator cap.
7. Install the radiator cap securely.
8. Fill the recovery tank with coolant up to the **[H]** mark on the recovery tank.
9. Start and operate the engine for a few minutes.
10. Stop the engine and let it cool.
11. Check the coolant level of the recovery tank and add the coolant if necessary.



BX1880 and BX2380



BX2680



- (1) Radiator cap
(2) Radiator drain plug
(3) Engine drain plug

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

1.11.2 Antifreeze

! WARNING

To avoid serious injury or death:

- When using the antifreeze, put on some protection such as rubber gloves. The antifreeze contains poison.
- If someone drank antifreeze, seek immediate medical help. Do not make a person throw up unless told to throw up by poison-control-center or a health care professional. Use standard first aid and CPR for signs of shock or cardiac arrest. Call your local poison control center or your local emergency number for further assistance.
- When the antifreeze comes in contact with the skin or clothing, wash it off immediately.
- Do not mix different types of the antifreeze. The mixture can produce chemical reaction causing harmful substances.
- The antifreeze is extremely flammable and explosive under certain conditions. Keep fire and children away from the antifreeze.
- When draining fluids from the engine, place some container underneath the engine body.
- Do not pour waste onto the ground, down a drain, or into any water source.
- Also, follow the relevant environmental protection regulations when disposing of the antifreeze.

Always use a 50/50 mix of long-life coolant and clean soft water in KUBOTA engines.

■ NOTE

- The following data represent industry standards that necessitate a minimum glycol content in the concentrated antifreeze.
- Long-life coolant (hereafter LLC) comes in several types. Use ethylene glycol (EG) type for this engine.
- Before using LLC-mixed cooling water, fill the radiator with fresh water and empty it again. Repeat this procedure two times or three times to clean up the inside.
- Mixing the LLC

Premix	50% LLC with 50% clean soft water.
--------	------------------------------------

When mixing, stir it up well, and then fill into the radiator.

- Adding the LLC.
 - Add only water if the mixture reduces in amount by evaporation.
 - If there is a mixture leak, add the LLC of the same manufacturer and type in the same mixture percentage.

■ IMPORTANT

- **Never add any long-life coolant of different manufacturer. Different brands may have different additive components, and the engine may fail to perform as specified.**
- When the LLC is mixed, do not use any radiator cleaning agent. The LLC contains anticorrosive agent. If mixed with the cleaning agent, sludge may build up, adversely affecting the engine parts.
- KUBOTA's genuine long-life coolant has a service life of two years.
Be sure to change the coolant every two years.
- The procedure for the mixing of water and the antifreeze differs according to the make of the antifreeze and the ambient temperature. Refer to SAE J1034 standard, more specifically also to SAE J814c.

Antifreeze	Freezing point		Boiling point* ¹	
50 Vol %	-37 °C	-34 °F	108 °C	226 °F

*1 At 1.013×10^5 Pa (760 mmHg) atmospheric pressure. A higher boiling point is obtained by using a radiator pressure cap which permits the development of pressure within the cooling system.

1.12 Check points of every 3000 hours

1.12.1 Checking injection pump

- See “*Fuel system*” for checking injection pump.

— RELATED PAGE —

[4. Fuel system on page 3-12](#)

1.13 Check points of every 1 year

1.13.1 Checking intake air line




WARNING

To avoid serious injury or death:


- Stop the engine and remove the key before checking the intake air line.

1. Check to see that the hose and the hose clamps are tight and not damaged.
2. If the hose and the clamps are found worn or damaged, replace or repair them at once.

BX2380



BX2680



(1) Hose

(2) Hose clamps

1.13.2 Checking radiator hoses and hose clamps




WARNING

To avoid serious injury or death:

- **Be sure to stop the engine and remove the key before checking the radiator hose and the hose clamps.**

1. If the hose clamps are loose or water leaks, tighten them securely.
2. Replace the radiator hoses and tighten the hose clamps securely if you checked and found that the radiator hoses are swollen, hardened, or cracked.
3. Properly dispose of used coolant.



(1) Radiator hoses (2 pcs) (2) Hose clamps (4 pcs)

1.13.3 Checking power steering line




WARNING

To avoid serious injury or death:

- **Be sure to stop the engine and remove the key before checking the power steering line.**

1. Check to see that all power steering lines are tight and not damaged.
2. If the power steering pressure hoses are found to be worn or damaged, replace or repair them at once.



(1) Power steering pressure hose

1.13.4 Checking fuel lines



WARNING

To avoid serious injury or death:

- **Stop the engine and remove the key before checking the fuel lines and fuel filter.**
- **Check the fuel lines periodically. The fuel lines are subject to wear and aging. Fuel may leak out onto the running engine, causing a fire.**



■ IMPORTANT

- **When the fuel line is disconnected for maintenance or repair, plug both ends of the fuel line with a clean plug of suitable size to prevent dust and dirt from entering. You must take particular care of the fuel lines in order to avoid dust and dirt getting into the fuel system. Entrance of dust and dirt causes malfunction of the fuel pump.**

The fuel line is made of rubber and ages regardless of service period.

1. Inspect the fuel lines.
2. After inspection, if the fuel lines and clamps are found damaged or deteriorated, replace them.

3. Check the fuel filter. If the fuel filter is clogged by debris or contaminated by water, replace it.




- (1) Pipe clamps
(2) Fuel line
(3) Fuel filter
(4) Fuel pump

NOTE

- If the fuel line is removed, be sure to properly bleed the fuel system.

1.13.5 Checking engine breather hose


1. Check the engine breather hose (1) for damage.
2. If the engine breather hose (1) is damaged, replace it with new one.



- (1) Engine breather hose

1.14 Check points of every 4 years**1.14.1 Replacing radiator hose**

1. Replace the radiator hoses and tighten the hose clamps securely.



- (1) Radiator hoses (2 pcs) (2) Hose clamps (4 pcs)

1.14.2 Replacing fuel hose

- See "Checking fuel lines".

— RELATED PAGE —

[1.13.4 Checking fuel lines on page 2-39](#)**1.14.3 Replacing power steering hose**

- See "Checking power steering line".

— RELATED PAGE —

[1.13.3 Checking power steering line on page 2-39](#)**1.14.4 Replacing intake air line**

- See "Checking intake air line".

— RELATED PAGE —

[1.13.1 Checking intake air line on page 2-38](#)**1.14.5 Replacing engine breather hose**

- See "Checking engine breather hose".

— RELATED PAGE —

[1.13.5 Checking engine breather hose on page 2-40](#)

1.15 Service as required

1.15.1 Bleeding fuel system


Air must be removed:

- When the fuel filter or lines are removed.
- When the tank is completely empty.
- After the tractor has not been used for a long period of time.

Bleeding procedure

1. Fill the fuel tank with fuel.
2. Turn the key switch to the **ON** position for about 30 seconds.

This allows the fuel pump (1) to work and pump air out of the fuel system.



(1) Fuel pump (2) Fuel filter

3. Start the engine and run for about 30 seconds, and then stop the engine.



1.15.2 Replacing fuse

The electrical system of the tractor is protected from potential damage by fuses. A blown fuse indicates that there is an overload or short somewhere in the electrical system.

1. If any of the fuses should blow, replace with a new fuse with the same capacity.

■ IMPORTANT

- Before replacing a blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage to the electrical system of the tractor.



(1) Fuse box (2) Slow blow fuse

Protected circuit

Fuse box

Fuse No.	Capacity	Protected circuit
1	—	—
2	—	—
3	10 A	Option (3rd-function)
4	10 A	OPC
5	15 A	DC outlet
6	5 A	Fuel pump
7	—	—
8	5 A	Glow indicator
9	5 A	Meter
10	15 A	Stop solenoid
11	20 A	Lamp
12	20 A	Option (work light)

Slow blow fuse

Capacity	Protected circuit
50 A	Check circuit against wrong battery connection

1.15.3 Replacing light bulb

Light	Capacity
Head light	37.5 W × 2
Tail light	12.8 W × 2
Hazard light	27 W × 2

Head light

- Take the light bulb out of the body of the light and replace with a new one.

Other lights

- Detach the lens and replace the light bulb.


2. Mower

2.1 Check points of daily or each use

2.1.1 Retightening mower blade screw

NOTE

- To avoid injury, always handle the mower blade with care.



- (1) Wooden block (A) Loosen (Counterclockwise)
(2) Mower blade screw (B) Tighten (Clockwise)

- Tilt up the mower and turn it over to expose the mower blades.
- Wedge a wooden block (1) securely between the mower blade and mower deck.
- Retighten the mower blade screw to the specified torque.

RCK60B-23BX, RCK54-23BX, and RCK48-18BX

Tightening torque	Mower blade screw	98.0 to 117.6 N·m 10.0 to 12.0 kgf·m 72.0 to 86.8 lbf·ft
-------------------	-------------------	--

RCK54D-26BX and RCK60D-26BX

Tightening torque	Mower blade screw	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 lbf·ft
-------------------	-------------------	---

- If the mower blade screw (2) is worn or broken, replace it.

2.1.2 Checking mower blade



WARNING

To avoid serious injury or death:

- Be sure to stop the engine and remove the key.
- Blades may be sharp. When you handle blades, wear heavy gloves or wrap end of blade with a rag.


IMPORTANT

- Use the proper metric size box or socket wrench to tighten or loosen the blade mounting bolt.

NOTE


- Before checking or replacing the blade, wipe grass and mud off the top and inside of the mower.
- Especially clean up the inside of the belt cover, because otherwise the belt life will be reduced.

- The blade cutting edges must be kept sharp at all times. Sharpen the cutting edges, if they resemble blade (B). Replace the blades if they appear similar to blade (C).



- (A) New blade (C) Cracked blade
(B) Worn blade

2.1.3 Checking mower belt





1. Inspect the mower belt.
2. Replace the mower belt, if there is any damage found.

2.1.4 Checking gear box oil level

■ IMPORTANT

- Use the specified gear oil.



- (1) Check plug
(2) Oil filler plug
(3) Drain plug
[A] RCK60B-23BX,
RCK54-23BX, and
RCK48-18BX

- [B] RCK60D-26BX and
RCK54D-26BX

1. Place the mower on level ground.
2. Loosen the check plug (1), and check to see if oil seems from the opening.
3. If the oil level is low, remove the oil filler plug (2) and add new gear oil.


— RELATED PAGE —
[2.1 Lubricants on page 2-11](#)

2.1.5 Greasing spindle shafts, belt tension pivot and tension pulley


1. Grease the grease fittings (1), (2) of the spindle shafts if the amount of grease is insufficient.

[Only for RCK54D-26BX]


2. Remove the ramp bracket (5) for greasing spindle shafts. To remove the ramp bracket (5), remove the pin (6) and clevis pin (4) and slide the ramp bracket (5) to rear side. Then lift up the ramp bracket to remove from mower deck.

[A]

3TAAAFMP024A

[B]


9Y1210855GES031B

[B]

9Y1210855GES032B

- | | |
|--|---------------------------------|
| (1) Grease fitting (Spindle shaft) | (A) Rear |
| (2) Grease fitting (Belt tension pulley) | (B) Up |
| (3) Grease fitting (Belt tension pivot) | [A] RCK60B-23BX and RCK54-23BX |
| (4) Clevis pin | [B] RCK60D-26BX and RCK54P-26BX |
| (5) Ramp bracket | |
| (6) Pin | |

1. Grease the grease fitting (1) of the balance shaft if the amount of grease is insufficient.





3TAAAFMP024D

- (1) Grease fitting

2.1.6 Greasing balance shaft**RCK60B-23BX**

2.1.7 Greasing front and rear anti-scalp rollers


1. Grease the grease fitting (1), (2) of the front and rear anti-scalp rollers if the amount of grease is insufficient.



- (1) Grease fitting (Front anti-scalp roller) [B] RCK60D-26BX and RCK54P-26BX
(2) Grease fitting (Rear anti-scalp roller)
[A] RCK60B-23BX and RCK54-23BX

2.1.8 Greasing universal joint


1. Grease the internal splines (1) and grease fittings (2) of the universal joint if the amount of grease is insufficient.



- (1) Spline (2) Grease fitting

[RCK60D-26BX and RCK54D-26BX only]

2. Grease between the hole and rod (3).



- (3) Hole and rod

2.2 Check points of initial 50 hours

2.2.1 Changing gear box oil

⚠ CAUTION


- Be sure to stop the engine and remove the key before changing the oil.

■ IMPORTANT

- Use the specified gear oil.

1. Dismount the mower from the tractor, and place the mower on level ground.
2. Remove the oil filler plug (2).

3. Remove the drain plug (1), and drain the used oil completely.



- (1) Check plug
(2) Oil filler plug
(3) Drain plug
[A] RCK60B-23BX,
RCK54-23BX, and
RCK48-18BX

- [B] RCK60D-26BX and
RCK54D-26BX

4. After draining the used oil, reinstall the drain plug.
5. Fill with new oil up to the specified level.

— RELATED PAGE —
[2.1 Lubricants on page 2-11](#)

2.3 Check point of every 150 hours

2.3.1 Changing gear box oil


1. See “Changing gear box oil” in “Check points of initial 50 hours”.

— RELATED PAGE —
[2.2.1 Changing gear box oil on page 2-45](#)

2.4 Check points of every 1 year

2.4.1 Checking gear box oil seal

1. Check the gear box oil seals (1), (2) for leaks. If oil seals are leaking, replace them.




(1) Oil seal

(2) Oil seal

2.5 Check point of every 4 years

2.5.1 Replacing gear box oil seal

1. Replace the gear box oil seals (1), (2) with new ones.



(1) Oil seal

(2) Oil seal

TIRES, WHEELS, AND BALLAST

1. Tires



WARNING

To avoid serious injury or death:

- Do not attempt to mount a tire on a rim. Only a qualified person with the proper equipment should mount a tire on a rim.
- Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure shown in the *"Inflation pressure of tires"* section.

■ IMPORTANT

- Do not use tires other than those approved by KUBOTA.
- When you intend to mount different size of tires from equipped ones, consult your dealer about front drive gear ratio for details. Excessive wear of tires may occur due to improper gear ratio.

1.1 Inflation pressure of tires

Though the tire pressure is factory-set to the prescribed level, it naturally drops slowly in the course of time. Thus, check it everyday and inflate as necessary.

[BX1880]

	Tire sizes	Inflation pressure
Rear	24×12.00-12 Turf	100 kPa (1.0 kgf/cm ²) [14 psi]
	24×12.00-12 Bar	120 kPa (1.2 kgf/cm ²) [17 psi]
Front	16×7.50-8 Turf	120 kPa (1.2 kgf/cm ²) [17 psi]
	16×7.50-8 Bar	230 kPa (2.3 kgf/cm ²) [34 psi]

[BX2380 and BX2680]

	Tire sizes	Inflation pressure
Rear	26×12.00-12 Turf	100 kPa (1.0 kgf/cm ²) [14 psi]
	26×12.00-12 Bar	120 kPa (1.2 kgf/cm ²) [17 psi]
	26×12.00-12 Ind.	120 kPa (1.2 kgf/cm ²) [17 psi]
Front	18×8.50-10 Turf	120 kPa (1.2 kgf/cm ²) [17 psi]
	18×8.50-10 Bar	150 kPa (1.5 kgf/cm ²) [22 psi]
	18×8.50-10 Ind.	150 kPa (1.5 kgf/cm ²) [22 psi]

■ NOTE

- Maintain the maximum pressure in front tires, if using a front loader or when equipped with a full load of front weight.

1.2 Dual tires

Dual tires are not approved.

2. Wheel tread




WARNING

To avoid serious injury or death:

- Support the tractor securely on stands before removing a wheel.
- Never operate the tractor with a loose rim, wheel, or axle.

■ IMPORTANT

- When re-fitting or adjusting a wheel, follow the procedure.
 1. Tighten the bolts to the torques as shown in the following table.



(1) Bolt

	Tightening torques
Front	149.2 N·m to 179.0 N·m (15.2 kgf·m to 18.3 kgf·m) [110 lbf·ft to 132 lbf·ft]
Rear	108.5 N·m to 130.2 N·m (11.1 kgf·m to 13.3 kgf·m) [80 lbf·ft to 96 lbf·ft]

2. Then recheck as the following table.

Timing to recheck the bolts	After driving the tractor 200 m (200 yards), after 1 day (8 hours), and thereafter every 50 hours
-----------------------------	---

NOTE

- Use the tapered bolts for wheels with beveled or tapered holes.

2.1 Front wheels

IMPORTANT

- Do not turn the front discs to obtain wider tread.
- Always attach the front wheels as shown in the following table.

If you do not attach the front wheels as illustrated in the table, transmission parts may be damaged.

You cannot adjust width of the front tread.

Models	BX1880	BX2380 and BX2680
Tire	16×7.50-8 Turf, 16×7.50-8 Bar	18×8.50-10 Turf, 18×8.50-10 Bar, 18×8.50-10 Ind.
Tread	<p>1BXM00060A01</p> <p>(A)</p> <p>930 mm (36.6 in.)</p>	


How to jack up the front axle



WARNING

To avoid serious injury or death:

- Before jacking up the tractor, park it on a firm and level ground and chock the rear wheels.
- Fix the front axle to keep it from pivoting.
- Select jacks that withstand the machine weight and set them up at jack point (2).



(1) Front axle case

(2) Jack point


2.2 Rear wheels

IMPORTANT

- Do not turn the rear discs to obtain wider tread.
- Always attach the rear wheels as shown in the following table.

If you do not attach the rear wheels as illustrated in the table, transmission parts may be damaged.

You cannot adjust width of the rear tread.

Models	BX2380 and BX2680
Tire	26×12.00-12 Turf, 262.00-12 Bar, 26×12.00-12 Ind.
Tread	 <p>1BXM00062A01</p> <p>(B) 820 mm (32.2 in.)</p>


How to jack up rear part of the tractor



WARNING

To avoid serious injury or death:

- Before jacking up the tractor, park it on a firm and level ground and chock the front wheels.
- Fix the front axle to keep it from pivoting.
- Select jacks that withstand the machine weight and set them up as shown in the following figure.



(1) Frame

(2) Jack point

3. Ballast



WARNING

To avoid serious injury or death:

- You will need the additional ballast for transporting the heavy implements. When the implement is raised, drive slowly over rough ground, regardless of how much ballast is used.
- Do not fill the front wheels with liquid to maintain steering control.

3.1 Front ballast

■ IMPORTANT

- Do not overload tires.
- Add no more weight than indicated in the following table.

Maximum weight	125 kg (275 lbs.)
----------------	----------------------


Add weights if needed to improve traction or for stability. Heavy pulling and heavy rear mounted implements tend to lift front wheels. Add enough ballast to maintain steering control and prevent tip over. Remove weight when no longer needed.

Front end weights (option)

The front end weights can be attached to the bumper. See your implement operator's manual for required number of weights.

■ NOTE

- Besides the weight, a front weight bracket and mounting bolt kit(s) are required for mounting the weight.



(1) Front end weights (option)

(2) Front weight bracket (option)

3.2 Rear ballast

Add weight to rear wheels if needed to improve traction or for stability. The amount of rear ballast should be matched to job and the ballast should be removed when it is not needed.

Liquid ballast in rear tires

The weight should be added to the tractor in the form of liquid ballast.

Water and calcium chloride solution provides safe economical ballast. Using the liquid ballast properly will prevent tires, tubes, or rims from damaging. The addition of calcium chloride is recommended to prevent the water from freezing. The addition of calcium chloride for weighting the wheels has the full approval of the tire companies. Consult your tire dealer for addition of calcium chloride.


2. GENERAL

Liquid weight per tire (75 percent filled)

Tire sizes	26×12.00-12 [BX2380 and BX2680]
Slush free at -10 °C (14 °F) Solid at -30 °C (-22 °F) [Approx. 1 kg (2 lbs.) CaCl ₂ per 4 L (1 gal) of water]	45 kg (99 lbs.)
Slush free at -24 °C (-11 °F) Solid at -47 °C (-52 °F) [Approx. 1.5 kg (3.5 lbs.) CaCl ₂ per 4 L (1 gal) of water]	50 kg (110 lbs.)
Slush free at -47 °C (-52 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (5 lbs.) CaCl ₂ per 4 L (1 gal) of water]	56 kg (123 lbs.)

■ IMPORTANT

- Do not fill tires with water or solution more than the correct percentage of full capacity as shown in the following table to the level of valve stem at 12 o'clock position.



- (1) Air (A) Correct
(2) Water (B) Incorrect
(3) Valve stem

	Correct	Incorrect
Amount of water	75% of full capacity of tire	100% of full capacity of tire
Characteristic	Air compresses like a cushion.	Water cannot be compressed.

- To avoid damage of the transmission, do not use the rear wheel weights and liquid ballast at the same time.

IMPLEMENT LIMITATIONS

1. Weight of implements as rear ballast



WARNING

To avoid personal injury or death:

- For tractor stability and operator's safety, add the rear ballast to the rear of the tractor in the form of 3-point counter weight and the rear wheel ballast. The amount of the rear ballast will depend on the application.

Implement as counter weight	
Box blade	Approx. 190 kg (420 lbs.)
Rear blade	
Rotary tiller	
Ballast box	

2. Implement limitation tables

■ IMPORTANT

The KUBOTA tractor has been thoroughly tested for proper performance with implements sold or approved by KUBOTA.

Do not use the following implements:


- Implements which are not sold or approved by KUBOTA
- Implements which exceed the maximum specifications listed in the following table
- Implements which are otherwise unfit for use with the KUBOTA tractor

These implements may result in malfunctions or failures of the tractor, damage to other property, and injury to the operator or others.

■ NOTE

Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.

Model		BX1880, BX2380, and BX2680
Tread (max. width)	Front	930 mm (36.6 in.)
	Rear	820 mm (32.2 in.)
Lower link end max. lifting weight W_0		550 kg (1210 lbs.)
Actual figures	Implement weight W_1 and / or size	As in "Implement weight list"
	Max. hitch load W_2	250 kg (550 lbs.)
	Trailer loading weight W_3 (Max. capacity)	800 kg (1765 lbs.)
	Total weight W_4	1100 kg (2425 lbs.)



1BXM00101A01

Lower link end max. lifting weight W_0

The max. allowable load which can be put on the lower link end

Implement weight W_1

The implement's weight which can be put on the lower link

Max. hitch load W_2

The max. loading weight for hitching

Trailer loading weight W_3

The max. loading weight for trailer (without trailer's weight)

Total weight W_4

The max. loading weight for trailer with trailer's weight

■ NOTE

- Implement size may vary depending on soil operating conditions.
- Strictly follow the instructions outlined in the operator's manual of the mounted or trailed machinery or trailer, and do not operate the combination tractor-machine or tractor-trailer unless all instructions have been followed.
- When you use the forestry application, there are following hazards:
 - Toppling trees, primarily in case a rear mounted tree grab crane is mounted at the rear of the tractor
 - Penetrating objects in the operator's enclosure, primarily in case a winch is mounted at the rear of the tractor

To deal with these hazards and other related hazards, the tractor requires optional equipment such as operator protective structure (OPS), falling object protective structure (FOPS), and so on. The optional equipment, however, is not available for this tractor. Without the optional equipment such as OPS and FOPS, the use of the tractor is limited to tractor specific applications like transport and stationary work.

Implement weight list

Implement		Remarks	BX1880	BX2380 and BX2680
Mower	Mid-mount	Max. cutting width	137 cm (54 in.)	152 cm (60 in.)
		Max. weight	95 kg (210 lbs.)	134 kg (295 lbs.)
	Rotary-cutter (1 Blade)	Max. cutting width	107 cm (42 in.)	122 cm (48 in.)
		Max. weight	159 kg (350 lbs.)	181 kg (400 lbs.)
	Rear-mount (2 or 3 Blade)	Max. cutting width	122 cm (48 in.)	152 cm (60 in.)
		Max. weight	220 kg (486 lbs.)	262 kg (577 lbs.)
	Flail-mower	Max. cutting width	107 cm (42 in.)	107 cm (42 in.)
	Sickle bar	Max. cutting width	122 cm (48 in.)	122 cm (48 in.)
Rotary tiller		Max. tilling width	107 cm (42 in.)	127 cm (50 in.)
		Max. weight	183 kg (404 lbs.)	197 kg (435 lbs.)
Bottom plow		Max. size	12 × 1 in.	14 × 1 in.
Disc plow		Max. size	22 × 1 in.	22 × 1 in.
Cultivator		Max. size	122 cm (48 in.) 1 Row	122 cm (48 in.) 1 Row
Disc harrow		Max. harrowing width	122 cm (48 in.)	122 cm (48 in.)
		Max. weight	191 kg (421 lbs.)	249 kg (549 lbs.)
Sprayer		Max. tank capacity	150 L (40 U.S.gals)	150 L (40 U.S.gals)
Front blade		Max. cutting width	137 cm (54 in.)	152 cm (60 in.)
		Sub frame	Necessary	Necessary
Rear blade		Max. cutting width	152 cm (60 in.)	152 cm (60 in.)
		Max. weight	112 kg (248 lbs.)	112 kg (248 lbs.)
Front loader		Max. lifting capacity (Bucket pivot pin, max. height)	335 kg (739 lbs.)* ¹	335 kg (739 lbs.)* ¹
		Max. width	122 cm (48 in.)	122 cm (48 in.)
Box blade		Max. cutting width	152 cm (60 in.)	152 cm (60 in.)
		Max. weight	170 kg (375 lbs.)	170 kg (375 lbs.)
Snow blower (Front)		Max. working width	127 cm (50 in.)	127 cm (50 in.)
		Max. weight	160 kg (353 lbs.)	160 kg (353 lbs.)
		Sub frame	Necessary	Necessary
Post hole digger		Digging depth	114 cm (45 in.)	114 cm (45 in.)
Rotary broom		Cleaning width	119 cm (47 in.)	119 cm (47 in.)
Trailer		Max. load capacity	800 kg (1765 lbs.)* ²	800 kg (1765 lbs.)* ²
		Max. weight	1100 kg (2425 lbs.)	1100 kg (2425 lbs.)

NOTE

- You cannot attach backhoes to the tractor.
- Implement size may vary depending on soil operating conditions.

*1 The valve contains the weight of KUBOTA standard bucket.


*2 Reduce speed and trailer loads when operating in slippery conditions or when operating on slopes and using front wheel drive.

SPECIAL TOOLS

1. Special tools for engine

1.1 Special use puller set

Use exclusively to pull out bearing, gears and other parts with ease.




Code No.

- 07916-09032

1.2 Diesel engine compression tester (for injection nozzle)

Use to measure diesel engine compression and diagnostics of need for major overhaul.



- | | |
|---------------|----------------|
| (1) Gauge | (7) Adaptor F |
| (2) L joint | (8) Adaptor G |
| (3) Adaptor A | (9) Adaptor H |
| (4) Adaptor B | (10) Adaptor I |
| (5) Adaptor C | (11) Adaptor J |
| (6) Adaptor E | |


Code No.

- 07909-30208 (Assembly)
- 07909-30934 (A to F)
- 07909-31211 (E and F)
- 07909-31231 (H)

- 07909-31251 (G)
- 07909-31271 (I)
- 07909-31281 (J)

1.3 Nozzle tester

Use to check the fuel injection pressure and spray pattern of nozzle.



Code No.

- 07909-31361

Measuring range


- 0 to 50 MPa (0 to 500 kgf/cm², 0 to 7200 psi)

1.4 Injection pump pressure tester

Use for checking fuel tightness of injection pumps.

■ **NOTE**

- Since the special tools are not provided, make them referring to the figure.





A	Pressure gauge full scale: More than 29.4 MPa (300 kgf/cm ² , 4260 psi)
B	PF 1/2
C	Copper gasket
D	Flange (Material: Steel)
E	Hex. nut 27 mm (1.1 in.) across the plate
F	Adhesive application
G	Fillet welding on the enter circumference
H	Retaining nut
I	17 mm dia. (0.67 in. dia.)
J	8.0 mm dia. (0.31 in. dia.)
K	1.0 mm (0.039 in.)
L	17 mm dia. (0.67 in. dia.)
M	6.10 to 6.20 mm dia. (0.241 to 0.244 in. dia.)
N	8.0 mm (0.31 in.)
O	4.0 mm (0.16 in.)
P	11.97 to 11.99 mm dia. (0.4713 to 0.4720 in. dia.)
Q	PF 1/2
R	23 mm (0.91 in.)
S	17 mm (0.67 in.)
T	4.0 mm (0.16 in.)
U	12.00 to 12.02 mm dia. (0.4725 to 0.4732 in. dia.)
V	100 mm (3.94 in.)
W	M12 × P1.5
X	5.0 mm (0.20 in.)

1.5 Valve guide replacing tool

Use to press out and press fit the valve guide.

NOTE

- The special tools are not provided, so make them referring to the figure.



D902-E4

A	220 mm (8.66 in.)
B	80 mm (3.1 in.)
C	40 mm (1.6 in.)
D	20 mm dia. (0.79 in. dia.)
E	9.960 to 9.980 mm dia. (0.3922 to 0.3929 in. dia.)
F	5.50 to 5.70 mm dia. (0.217 to 0.224 in. dia.)
G	25 mm dia. (0.98 in. dia.)
H	6.00 to 6.10 mm dia. (0.237 to 0.240 in. dia.)
I	5.0 mm (0.20 n.)
J	18 mm dia. (0.71 in. dia.)
K	10.6 to 10.7 mm dia. (0.418 to 0.421 in. dia.)
L	6.90 to 7.10 mm (0.272 to 0.279 in.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)

D1005-E4

A	225 mm (8.86 in.)
B	70 mm (2.8 in.)
C	45 mm (1.8 in.)
D	20 mm dia. (0.79 in. dia.)
E	11.7 to 11.9 mm dia. (0.461 to 0.468 in. dia.)
F	6.50 to 6.60 mm dia. (0.256 to 0.259 in. dia.)
G	25 mm dia. (0.98 in. dia.)
H	6.70 to 7.00 mm dia. (0.264 to 0.275 in. dia.)
I	5.0 mm (0.20 in.)
J	20 mm dia. (0.79 in. dia.)
K	12.5 to 12.8 mm dia. (0.493 to 0.503 in. dia.)
L	8.90 to 9.10 mm (0.351 to 0.358 in.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)


1.6 Bushing replacing tool

Use to press out and press fit the bushing.

D902-E4

NOTE

- The special tools are not provided, so make them referring to the figure.



[For small end bushing]

A	145 mm (5.71 in.)
B	20 mm (0.79 in.)
C	100 mm (3.94 in.)
D	19.90 to 19.95 mm dia. (0.7835 to 0.7854 in. dia.)
E	21.90 to 21.95 mm dia. (0.8622 to 0.8642 in. dia.)
F	25 mm dia. (0.98 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)
a	6.3 μm (250 μin.)
b	6.3 μm (250 μin.)

[For idle gear bushing]

A	150 mm (5.91 in.)
B	23 mm (0.91 in.)
C	100 mm (3.94 in.)
D	19.90 to 19.95 mm dia. (0.7835 to 0.7854 in. dia.)
E	21.90 to 21.95 mm dia. (0.8622 to 0.8642 in. dia.)
F	25 mm dia. (0.98 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)
a	6.3 μm (250 μin.)
b	6.3 μm (250 μin.)


1.7 Bushing replacing tool

Use to press out and press fit the valve guide.

D1005-E4

NOTE

- The special tools are not provided, so make them referring to the figure.

**[For small end bushing]**

A	157 mm (6.18 in.)
B	24 mm (0.94 in.)
C	120 mm (4.72 in.)
D	21.8 to 21.9 mm dia. (0.859 to 0.862 in. dia.)
E	24.8 to 24.9 mm dia. (0.977 to 0.980 in. dia.)
F	20 mm dia. (0.79 in. dia.)
a	6.3 μm (250 μin.)
b	6.3 μm (250 μin.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.0079 in.)

[For idle gear bushing]


A	196 mm (7.72 in.)
B	26 mm (1.0 in.)
C	150 mm (5.91 in.)
D	25.80 to 25.90 mm dia. (1.016 to 1.019 in. dia.)
E	28.80 to 28.90 mm dia. (1.134 to 1.137 in. dia.)
F	20 mm dia. (0.79 in. dia.)
a	6.3 μm (250 μin.)
b	6.3 μm (250 μin.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.0079 in.)

1.8 Flywheel stopper

Use to loosen and tighten the flywheel screw.

NOTE

- The special tools are not provided, so make them referring to the figure.




A	200 mm (7.87 in.)
B	30 mm (1.18 in.)
C	20 mm (0.79 in.)
D	15 mm (0.59 in.)
E	8 mm (0.31 in.)
F	10 mm dia. (0.39 in. dia.)

1.9 Crankshaft bearing 1 replacing tool

Use to press out and press fit the crankshaft bearing 1.

NOTE

- The special tools are not provided, so make them referring to the figure.



[Press out]

	D902-E4	D1005-E4
A	135 mm (5.31 in.)	
B	72 mm (2.8 in.)	
C	40 mm radius (1.6 in. radius)	
D	10 mm dia. (0.39 in. dia.)	
E	22 mm (0.87 in.)	24 mm (0.94 in.)
F	20 mm dia. (0.79 in. dia.)	
G	47.90 to 47.95 mm dia. (1.886 to 1.887 in. dia.)	51.20 to 51.40 mm dia. (2.016 to 2.023 in. dia.)
H	43.90 to 43.95 mm dia. (1.729 to 1.730 in. dia.)	47.30 to 47.50 mm dia. (1.863 to 1.870 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)	
C2	Chamfer 2.0 mm (0.079 in.)	
C0.3	Chamfer 0.30 mm (0.012 in.)	

[Press fit]

	D902-E4	D1005-E4
A	130 mm (5.12 in.)	
B	72 mm (2.83 in.)	
C	40 mm radius (1.6 in. radius)	
D	9.0 mm (0.35 in.)	
E	24 mm (0.94 in.)	
F	20 mm dia. (0.79 in. dia.)	
G	68 mm dia. (2.7 in. dia.)	
H	43.90 to 43.95 mm dia. (1.729 to 1.730 in. dia.)	47.30 to 47.50 mm dia. (1.863 to 1.870 in. dia.)
C1	Chamfer 1.0 mm (0.039 in.)	
C2	Chamfer 2.0 mm (0.079 in.)	
C0.3	Chamfer 0.30 mm (0.012 in.)	


1.10 Governor gear holder busing replacing tool

Use to press out and press fit the governor gear holder busing.



D1005-E4

NOTE

- The special tools are not provided, so make them referring to the figure.



A	C1: Chamfer 1.0 mm (0.039 in.)
B	73.90 to 74.00 mm dia. (2.910 to 2.913 in. dia.)
C	69.80 to 69.90 mm dia. (2.748 to 2.751 in. dia.)
D	30 mm dia. (1.2 in. dia.)
E	C2: Chamfer 2.0 mm (0.079 in.)
F	18 mm (0.71 in.)
G	150 mm (5.91 in.)
H	188 mm (7.40 in.)




A	12 mm (0.47 in.)
B	25.4 mm (1.00 in.)
C	19 mm radius (0.75 in.) Hex.
D	2.7 mm (0.11 in.)
E	8 mm (0.31 in.)
F	15 mm dia. (0.59 in. dia.)
G	37 mm (1.46 in.)
H	70 mm (2.76 in.)
I	M14 × 1.5
J	R 3 mm (0.12 in.)
K	30 mm (1.18 in.)
L	17 mm (0.67 in.)
M	38 mm (1.50 in.)

2. Special tools for tractor

2.1 Tie-rod end lifter

Use to remove the tie-rod end with ease.



Code No.

- 07909-39051


2.2 Independent PTO clutch spring compression tool

Use for compressing the spring into the spline boss.

B30 series, BX50 series, BX60 series, BX24, BX25 tractor

2.3 Disassembling and assembling stand (1/2)

Use to disassembling transaxle assembly and to assembling transaxle assembly.




A	φ9 mm (φ0.35 in.) 3 holes
B	225 mm (8.86 in.)
C	φ13 mm (φ0.51 in.) 3 holes
D	140 mm (5.51 in.)
E	99.5 to 100.5 mm (3.92 to 3.95 in.)
F	59.5 to 60.5 mm (2.35 to 2.38 in.)
G	92.5 to 93.5 mm (3.65 to 3.68 in.)
H	12.5 to 13.5 mm (0.50 to 0.53 in.)
I	55 mm (2.17 in.)
J	20 mm (0.79 in.)
K	17 mm (0.67 in.)
L	30.5 to 31.5 mm (1.21 to 1.24 in.)
M	226 mm (8.90 in.)
N	125.5 to 126.5 mm (4.95 to 4.98 in.)
O	352 mm (13.86 in.)
P	25 mm (0.98 in.)
Q	9.5 mm (0.37 in.)

(Continued)

R	397 mm (15.63 in.)
S	46 mm (1.81 in.)
T	R25 mm (0.98 in.)
U	11 mm (0.43 in.)
W	20 mm (0.79 in.)

2.4 Disassembling and assembling stand (2/2)

Use to disassembling transaxle assembly and to assembling transaxle assembly.




A	311 mm (12.24 in.)
B	40 mm (1.57 in.)
C	38.1 mm (1.50 in.)
D	235 mm (9.25 in.)
E	170 mm (6.69 in.)
F	9.5 mm (0.37 in.)
G	6.4 mm (0.25 in.)
H	365 mm (14.37 in.)
I	377.8 mm (14.87 in.)

(Continued)

J	50.8 mm (2.00 in.)
K	40 mm (1.57 in.)
L	38.1 mm (1.50 in.)
M	1.9 mm (0.07 in.)
N	4.8 mm (0.19 in.)
O	200 mm (7.87 in.)
P	φ9 mm (φ0.35 in.), 3 holes
Q	25 mm (0.98 in.)
R	39.5 to 40.5 mm (1.56 to 1.59 in.)
S	140 mm (5.51 in.)
T	260 mm (10.24 in.)
U	99.5 to 100.5 mm (3.92 to 3.95 in.)
V	45 mm (1.77 in.)

2.5 Check and high pressure relief valve assembly tool

Use for readjusting relief valve pressure.



A	30 mm (1.181 in.)
B	21 mm (0.827 in.)
C	1 mm (0.039 in.)
D	0.52 rad (30°)
E	50 mm dia. (1.969 in. dia.)
F	10 mm dia. (0.394 in. dia.)
G	9.1 to 9.3 mm dia. (0.359 to 0.366 in. dia.)
H	34 mm dia. (1.336 in. dia.)
I	M36 × 1.5 mm pitch
J	10 mm (0.394 in.)
K	16 mm (0.630 in.)
L	41 mm (1.614 in.)

(Continued)


M	Chamfer 1 mm (0.039 in.)
N	Chamfer 0.4 mm (0.157 in.)
O	Chamfer 3 mm (0.118 in.)
P	Chamfer 2 mm (0.079 in.)
Q	21.4 mm (0.843 in.)
R	19 mm (0.748 in.)
S	17 mm (0.669 in.)
T	10 mm (0.393 in.)
U	50 mm dia. (1.969 in. dia.)
V	9.8 mm dia. (0.386 in. dia.)
W	16 mm dia. (0.629 in. dia.)
X	34.5 mm dia. (1.358 in. dia.)
Y	38 mm dia. (1.496 in. dia.)
Z	25 mm (0.984 in.)
a	1.05 rad (10°)
b	Chamfer 0.3 mm (0.012 in.)
c	23 mm (0.906 in.)
d	10 mm (0.394 in.)
e	1 mm (0.039 in.)
f	6.5 mm (0.256 in.)
g	Chamfer 0.5 mm (0.020 in.)
h	11.1 to 11.3 mm (0.437 to 0.445 in.)
i	18.8 to 19.0 mm (0.740 to 0.748 in.)
(1)	Spacer
(2)	Block
(3)	Cap

2.6 Quick coupler cartridge socket

Use for assembling and disassembling quick coupler.

■ NOTE

- This special tool is not provided, so make it referring to the figure.



2QYSD00362A01

A	9.61 to 9.72 mm (0.3780 to 0.3830 in.)
B	11 mm dia. (0.43 in. dia.)
C	1 mm (0.05 in.) chamfer
D	29.6 mm dia. (1.166 in. dia.)
E	13.6 mm (0.535 in.)
F	11.8 mm (0.465 in.)
G	0.48 to 0.57 rad (27° to 33°)
H	2.5 mm (0.098 in.) radius
I	5.36 to 5.56 mm (0.211 to 0.219 in.)
J	3.8 mm (0.15 in.) radius
K	19.0 mm (0.748 in.)
L	7.98 mm (0.314 in.)
M	5.08 mm (0.200 in.)
N	3.79 to 3.93 mm (0.149 to 0.155 in.)
O	1.0 mm (0.040 in.) radius

(Continued)

P	0.79 rad (45°)
Q	16.26 to 16.35 mm dia. (0.640 to 0.644 in. dia.)
R	22.1 mm dia. (0.870 in. dia.)
S	33.0 mm (1.300 in.)
T	0.51 mm (0.020 in.) chamfer
U	25.3 mm dia. (0.997 in. dia.)
V	1.6 mm (0.063 in.) radius
W	22.3 to 22.4 mm (0.8780 to 0.8830 in.)


3. ENGINE

MECHANISM

1. Engine body

1.1 Function of cylinder block

The cylinder block is the main housing of engine and supports the other main parts.




(1) Cylinder block

The cylinder block is usually of integrated cast iron construction, and includes complete passages for coolant and lubricating oil.

1.2 Function of closed breather

Closed breather system has been adopted to prevent the release of blow-by gas into the atmosphere.




(1) Breather hose
(2) Cylinder head cover
(3) Breather valve
(4) Oil shield
(5) Rubber packing

After its oil content is filtered by oil shield (4), the blow by gas is fed back to the intake manifold through breather valve (3) to be used for re-combustion.

1.3 Function of half-floating head cover

The half-floating head cover helps reduce noise coming from the cylinder head.




(1) Cylinder head cover
(2) Rubber packing

Rubber packing (2) is fitted in to keep the cylinder head cover (1) 0.5 mm (0.02 in.) or so off the cylinder head.

1.4 Function of piston


The piston creates the forces for the suction, compression, power and exhaust cycles.



(1) Molybdenum disulfide

The reciprocating motion of a piston in the engine cylinder creates the forces for the suction, compression, power and exhaust cycles. The piston's skirt is coated with molybdenum disulfide (MoS₂) which reduces the piston slap noise and thus the entire operating noise. The molybdenum disulfide (MoS₂) (1) improves the fit of the piston with the cylinder and helps to prevent scorching. This material helps resist metal wears even with little lube oil.

1.5 Function of piston ring



(1) Top compression ring (2) Second compression ring (3) Oil control ring


Piston rings are classified as compression and oil control rings. Diesel engine has two or three compression rings around the piston head and one oil ring just below them. The compression rings prevent gases from leaking by the piston during the compression and expansion strokes. They seal by expanding out against the cylinder wall. The rings expand by their own tension and also by combustion pressure behind the rings during the expansion stroke. The compression rings are split for easy assembly on the piston. The piston rings are usually made of

hardened cast iron. To reduce the wear on the ring, they are often plated with chrome on their contact faces, or are coated their contact faces with molybdenum disulfide.

- The top compression ring (1) is a keystone type ring to get durability against heavy load.
- The second compression ring (2) is an undercut ring to prevent shortage of oil.
- The main job of the oil control ring (3) is to wipe the excess oil from the cylinder walls. This oil is fed through slots in the rings to holes in the piston groove, where it returns to the crankcase. For better oil control, spring expanders are often used under the oil control ring.

1.6 Function of connecting rod

The connecting rod connects the piston to the crankshaft.




(1) Small end bushing (2) Connecting rod (3) Crankpin bushing

The connecting rod must be light and yet strong enough to transmit the thrust of the piston to crankshaft. The big end of connecting rod has a crankpin bushing (3) (split type) and the small end has a small end bushing (1) (solid type).

1.7 Function of crankshaft

The crankshaft converts the up-and-down motion of the pistons into rotary motion. It ties together the reactions

of all the pistons into one rotary force that drives the machine.




- | | |
|-------------------------------------|-----------------------------|
| (1) Front split type bearing | (3) Rear split type bearing |
| (2) Intermediate split type bearing | (4) Thrust bearings |

The crankshaft is made of tough special alloy steel, and the journals, pins and oil seal sliding portions are induction hardened to increase the hardness for higher wear resistance. The front journal is supported by a split type (1) and the intermediate journal by a split type (2), and the rear journal by a split type (3) with thrust bearings (4). The crankshaft is provided with an oil gallery, through which engine oil is fed to the crankpin portion, and lubricates it.

1.8 Function of camshaft

The camshaft controls the opening and closing of the intake and exhaust valves in the cylinder head.




- | | |
|----------------------|--------------|
| (1) Cam gear | (3) Camshaft |
| (2) Camshaft stopper | |

The camshaft (3) is normally driven by gearing from the crankshaft. This is made of special cast iron, and the journal and cam sections are chilled to resist wear. One intake and one exhaust cam is provided for each cylinder. The journal diameters are large to permit removal of the shaft from its bore. The journal sections are force lubricated.

1.9 Function of rocker arm

The rocker arm is an oscillating lever that conveys radial movement from the camshaft lobes into linear movement at the exhaust and intake valves to open and close them.




- | | |
|----------------------|---------------------|
| (1) Rocker arm shaft | (4) Intake valve |
| (2) Rocker arm | (5) Adjusting screw |
| (3) Exhaust valve | (6) Push rod |

The rocker arms (2) are mounted on a rocker arm shaft (a single hollow shaft) (1) at the top of the engine. When the push rods (6) move up, the mating rocker arm is moved down, contacting its valve stem tip and opening the valve. Lubricating oil pressurized through the rocker arm bracket to the rocker arm shaft, which serves as a fulcrum so that the rocker arm and the entire system are lubricated sufficiently.

1.10 Function of flywheel

A flywheel is a rotating mechanical device that is used to store rotational energy.



- | | |
|----------------|--------------------|
| (1) Crankshaft | (3) Flywheel screw |
| (2) Flywheel | |


The flywheel (2) is generally made of heavy cast iron or steel and has gear teeth around its outer rim, which mesh with the drive pinion of starter. The flywheel stores the rotating force in the combustion stroke as inertial energy, reduces crankshaft rotating speed fluctuation and keeps the smooth rotating conditions.

3. ENGINE

The flywheel periphery is inscribed with the marks showing fuel injection timing angle lines and top dead center mark TC. The flywheel (2) mounted on the rear of the crankshaft (1) is a stabilizer for the whole engine.

1.11 Function of timing gears

The timing gears correctly control fuel injection to the cylinders and valve timing.



- | | |
|-------------------------|-------------------|
| (1) Injection pump gear | (4) Governor gear |
| (2) Idle gear | (5) Crank gear |
| (3) Cam gear | |

The timing gears transmit torque from the crankshaft to the oil pump and injection pump and, at the same time, correctly control fuel injection to the cylinders and valve timing. Each gear has a mating mark inscribed on it for correct and easy assembly and is spherical with teeth set obliquely to the axis of rotation to rotate smoothly and reduce noise. The crankshaft is the hub around which other parts of the engine can be timed and driven. This is done by the meshing of gears as shown in the figure.

2.1 Overview of lubricating system

- | | | | |
|-------------------------|------------------|------------------|---------------------------|
| (1) Rocker arm | (5) Idle gear | (9) Relief valve | (13) Piston |
| (2) Oil pressure switch | (6) Crankshaft | (10) Push rod | (14) Connecting rod |
| (3) Rocker arm shaft | (7) Oil pump | (11) Tappet | (15) Oil filter cartridge |
| (4) Valve | (8) Oil strainer | (12) Camshaft | |

BX1880,BX2380,BX2680,RCK60B-23BX,RCK54-23BX,RCK48-18BX,RCK60D-26BX,RCK54D-26BX


3. ENGINE

The oil pump sucks lubricating oil from the oil pan through the oil strainer and the oil flows down to the filter cartridge, where it is further filtered. Then the oil is forced to crankshaft (6), connecting rods (14), idle gear (5), camshaft (12) and rocker arm shaft (3) to lubricate each part.

Some part of oil, splashed by the crankshaft or leaking and dropping from gaps of each part, lubricates these parts: piston (13), cylinders, small ends or connecting rods, tappets (11), push rods (10), inlet and exhaust valves (4) and timing gears.

2.2 Function of oil strainer

The oil strainer strains large particles from the oil.




(1) Oil strainer (2) Mesh screen

The strainer (1) has a mesh screen (2) suitable for straining large particles from the oil and yet passes a sufficient quantity of oil to the inlet side of the oil pump. The strainer is located so all oil entering the pump from the oil pan must flow through it.

2.3 Function of oil pump

The oil pump circulates engine oil under pressure to the rotating bearings, the pistons and the camshaft.




(1) Inner rotor (2) Outer rotor

The oil pump sucks lubricating oil from the oil pan through the oil strainer and the oil flows down to the oil filter. The rotor pump is driven from the crankshaft. This oil pump has an inner rotor (1) and an outer rotor (2). The inner rotor (1), which is driven by crankshaft, rotates the outer rotor (2) in the same direction. The inner rotor (1) has one less lobe than the outer rotor (2), and they are eccentrically engaged with each other.

2.4 Function of oil filter

The oil filter is responsible for filtering impurities from the oil.




(1) Filter element (b) Unfiltered oil
(2) Bypass valve [A] Bypass valve closed
(a) Filtered oil [B] Bypass valve open

In the filtration system, there is only one oil flow from the oil pump to the oil filter cartridge. After filtering, the oil goes to the lubricating portion, and is returned to the crankcase. When the filter cartridge is new, there is very little pressure drop through the filter element (1). However, if the filter gets clogged, the resulting pressure (the oil pressure in inlet line builds up by 98 kPa (1.0 kgf/cm², 14 psi) more than the outlet line) will open the bypass valve (2) and allow unfiltered oil to bypass to the lubricating portion.

2.5 Function of relief valve

The relief valve prevents the damage of the lubricating system due to high oil pressure.





- (1) Spring
(2) Poppet
(3) Gasket
(4) Plug

The valve is closed when the spring tension is greater than the oil pressure at the inlet. The spring tension holds poppet (2) securely in position. The valve opens when the oil pressure at the inlet exceeds that of the spring (1). This pushes the poppet off the inlet hole and oil flows through the valve.

2.6 Function of oil pressure switch

The oil pressure switch activates the oil warning light when the oil pressure falls below specified value.



- (1) Terminal
(2) Insulator
(3) Spring
(4) Diaphragm
(5) Contact rivet
(6) Contact
(7) Oil switch body
[A] At proper oil pressure
[B] At lower oil pressure

The oil pressure switch is mounted on the cylinder block and is led to the lubricating oil passage. When the oil pressure falls below the specified value, the oil pressure-warning lamp lights.

[A] At the proper oil pressure

When the engine is started and as the proper oil pressure builds, the diaphragm (4) is pushed up. This separates the contact rivet (5) and breaks the circuit, causing the lamp to go out.


[B] At lower oil pressure

If the oil pressure drops, the resulting deflection of the diaphragm (4) will close the contact rivet (5) and again complete the circuit. The lighted lamp warns that the pressure of the lubricating system has dropped below the pressure setting.

3. Cooling system

3.1 Overview of cooling system

The cooling system cools the engine while it operates to prevent overheating and keep a proper operating temperature. KUBOTA engines are used pressurized forced-circulation type. This system consists of a radiator (1), water pump (2), cooling fan (3), thermostat (4) and coolant temperature sensor (some models). The coolant is cooled through the radiator core, and the fan set behind the radiator pulls cooling air through the core to improve cooling. When the coolant in the engine is at a low temperature, the thermostat valve is closed so that the coolant is circulated in the engine through the bypass pipe. When the temperature of the coolant becomes the valve opening temperature of the thermostat (4), the thermostat (4) opens the valve to return the heated coolant to the radiator (1). The water pump (2) circulates the cooled coolant into the cylinder block (6) and draws out the hot coolant through the cylinder head (5). Some engines employ the bottom bypass system to improve the cooling performance of radiator and the three step valve opening type thermostat to reduce thermal shock radically.




(1) Radiator
(2) Water pump

(3) Cooling fan
(4) Thermostat

(5) Cylinder head
(6) Cylinder block

3.2 Function of water pump

The water pump circulates the coolant through the system.




- | | |
|------------------|---------------------|
| (1) Bearing unit | (3) Mechanical seal |
| (2) Pump body | (4) Impeller |

If the pump fails to circulate the coolant, heat is not removed from the engine and overheating damage may occur. KUBOTA engines use a centrifugal type, and is driven by the crankshaft via a fan belt. It consists of a pump body (2), impeller (4), mechanical seal (3) and bearing unit (1).

3.3 Function of radiator

The radiator is where heat in the coolant is released to the atmosphere.




- | | |
|-----------------|---------|
| (1) Cooling air | (3) Fin |
| (2) Tube | |

The radiator core consists of water carrying tubes (2) and fins (3) at a right angle to the tubes. KUBOTA

engines use corrugated fin type core which has a right weight and high heat transfer rate. Radiators are usually made of copper or brass. Recently, however, aluminum-made radiators are introduced for their light weight.

3.4 Function of radiator cap

The radiator cap keeps coolant from boiling out or evaporating.



- | | |
|--------------------|-------------------------|
| (1) Overflow tube | (A) Pressure valve open |
| (2) Pressure valve | (B) Vacuum valve open |
| (3) Vacuum valve | |

The pressure system permits operating the engine at a higher temperature without boiling the coolant or losing it by evaporation. The radiator cap consists of a pressure valve (2), vacuum valve (3), valve springs, gasket, and has two functions.

(A) Pressure valve open


The pressure valve (2) in the cap permits the escape of coolant or steam when the pressure reaches a certain point (88 kPa, 0.90 kgf/cm², 13 psi).

(B) Vacuum valve open

The vacuum valve (3) in the cap opens to prevent a vacuum in the cooling system.

4. Fuel system

4.1 Overview of fuel system




- | | |
|------------------------|--------------------|
| (1) Injection nozzle | (5) Fuel feed pump |
| (2) Fuel overflow pipe | (6) Fuel filter |
| (3) Fuel tank | (7) Injection pump |
| (4) Fuel filter | (8) Injection pipe |

Fuel from the fuel tank (3) passes through the fuel filter (4), and then enters the injection pump (7) after impurities such as dirt, water, etc. are removed. The fuel pressurized by the injection pump to the opening pressure (13.7 to 14.7 MPa, 140 to 150 kgf/cm², 1990 to 2133 psi), of the injection nozzle (1) is injected into the combustion chamber. Part of the fuel fed to the injection nozzle (1) lubricates the moving parts of the needle valve inside the nozzle, then returns to the fuel tank through the fuel overflow pipe (2) from the upper part of the nozzle holder.

4.2 Function of fuel filter

The fuel filter filters impurities from the fuel.




- | | |
|--------------|---------------------|
| (a) Fuel in | (c) Filtered fuel |
| (b) Fuel out | (d) Unfiltered fuel |

In-line filter is installed in the fuel line with an electromagnetic fuel feed pump and is used to filter impurities such as dirt, water, etc.

4.3 Function of fuel feed pump


An electromagnetic fuel feed pump is used when a fuel tank is set below the pump of the engine.



- | | |
|------------|-------------|
| a: Fuel in | b: Fuel out |
|------------|-------------|

An electromagnetic fuel feed pump uses a transistor that causes the pump to start pumping fuel when the main switch is turned to the **ON** position. Therefore, fuel is supplied to the injection pump regardless of engine speed. This pump is driven by the battery. It can therefore be operated even with the engine being stopped.

4.4 Function of injection nozzle



- | | |
|------------------------|-------------------|
| (1) Bar filter | (6) Retaining nut |
| (2) Nozzle holder body | (7) Nozzle piece |
| (3) Adjusting washer | (8) Needle valve |
| (4) Nozzle spring | (9) Heat seal |
| (5) Push rod | (10) Gasket |

Uses as E-TVCS system, the small-sized DENSO made OPD mini nozzle is of a flat-cut-provided double throttle type. This type of nozzle is designed to control the injection quantity when the lift rate is low at start of the injection, and to cut down on the knocking sound caused by excessive fuel injection by giving the needle valve (8) section more taper than before to prevent the rapid increase in the injection quantity when the initial injection turns into the full-force injection. Also, employed to prevent the injection quantity loss in the throttle section caused by carbon, the flat cut provided at the needle valve section helps the throttle withstand long use and reduce as much knocking sound as when it was new. The heat seal (9) is employed to improve the durability and reliability of the nozzle.

SERVICING

1. Troubleshooting for engine

Symptom	Probable cause and checking procedure	Solution	Reference page
Engine does not start	1. No fuel	Fill	2-7
	2. Air in fuel system	Vent air	2-41
	3. Fuel line clogged	Clean or replace	2-39
	4. Water in fuel system	Change fuel and repair or replace fuel system	2-39
	5. Fuel filter clogged	Replace	2-29
	6. Excessively high viscosity of fuel or engine oil at low temperature	Use specified fuel or engine oil	2-7
	7. Fuel with low cetane number	Use specified fuel	2-7
	8. Fuel leak due to loose injection pipe retaining nut	Tighten retaining nut	3-43
	9. Incorrect injection timing	Adjust	3-34
	10. Fuel camshaft worn	Replace	3-50
	11. Injection nozzle clogged	Clean or replace	3-43
	12. Injection pump malfunctioning	Repair or replace	3-49
	13. Seizure of crankshaft, camshaft, piston, cylinder or bearing	Repair or replace	3-51 3-54
	14. Compression leak from cylinder	Replace head gasket, tighten cylinder head screw glow plug and nozzle holder	3-30 3-45
	15. Improper valve timing	Correct or replace timing gear	3-50
	16. Piston ring and cylinder worn	Replace	3-52
	17. Excessive valve clearance	Adjust	3-30
Starter does not operate	1. Battery discharged	Charge	2-27
	2. Starter malfunctioning	Repair or replace	8-47
	3. Main switch malfunctioning	Replace	8-30
	4. Wiring disconnected	Connect	—
	5. Safety switch malfunctioning	Check and replace	8-33
Engine revolution is not smooth	1. Fuel filter clogged or dirty	Replace	2-29

(Continued)

3. ENGINE

Symptom	Probable cause and checking procedure	Solution	Reference page
Engine revolution is not smooth	2. Air cleaner clogged	Clean or replace	2-28
	3. Fuel leak due to loose injection pipe retaining nut	Tighten retaining nut	3-43
	4. Injection pump malfunctioning	Repair or replace	3-49
	5. Incorrect nozzle opening pressure	Adjust	3-36
	6. Injection nozzle stuck or clogged	Repair or replace	3-44
	7. Governor malfunctioning	Repair	3-49
Either white or blue exhaust gas is observed	1. Excessive engine oil	Reduce to specified amount	2-23
	2. Piston ring and cylinder worn or stuck	Repair or replace	3-52
	3. Incorrect injection timing	Adjust	3-34
	4. Deficient compression	Check	3-30
Either black or dark gray exhaust gas is observed	1. Overload	Decrease the load	—
	2. Low grade fuel used	Use specified fuel	2-7
	3. Fuel filter clogged	Replace	2-29
	4. Air cleaner clogged	Clean or replace	2-28
	5. Deficient nozzle injection	Repair or replace nozzle	3-44
Deficient output	1. Incorrect injection timing	Adjust	3-34
	2. Engine's moving parts seem to be seizing	Repair or replace	—
	3. Injection pump malfunctioning	Repair or replace	3-49
	4. Deficient nozzle injection	Repair or replace nozzle	3-44
	5. Air cleaner dirty or clogged	Clean or replace	2-28
	6. Compression leak	Replace head gasket, tighten cylinder head screws, glow plug and nozzle holder	3-45 3-44
Excessive lubricant oil consumption	1. Piston ring's gap facing the same direction	Shift ring gap direction	3-52
	2. Oil ring worn or stuck	Replace	3-52
	3. Piston ring groove worn	Replace piston	3-52
	4. Valve stem and valve guide worn	Replace	3-57
	5. Crankshaft bearing and crank pin bearing worn	Replace	3-70 3-73

(Continued)

Symptom	Probable cause and checking procedure	Solution	Reference page
Excessive lubricant oil consumption	6. Oil leaking due to damaged seals or packing	Replace	—
Fuel mixed into lubricant oil	1. Injection pump's plunger is worn	Repair or replace	3-49
	2. Deficient nozzle injection	Repair or replace nozzle	3-44
	3. Injection pump broken	Replace	3-49
Water mixed into lubricant oil	1. Head gasket damaged	Replace	3-45
	2. Cylinder block or cylinder head flawed	Replace	—
Low oil pressure	1. Engine oil insufficient	Fill	2-7
	2. Oil strainer clogged	Clean	3-47
	3. Relief valve stuck with dirt	Clean	3-78
	4. Relief valve spring weak or broken	Replace	3-78
	5. Excessive oil clearance of crankshaft bearing	Replace	3-54 3-74
	6. Excessive oil clearance of crankpin bearing	Replace	3-54 3-70
	7. Excessive oil clearance of rocker arm	Replace	3-45 3-61
	8. Oil passage clogged	Clean	—
	9. Different type of oil	Use specified type of oil	2-7
	10. Oil pump damaged	Replace	3-48
	11. Oil filter clogged	Replace	2-23
High oil pressure	1. Different type of oil	Use specified type of oil	2-7
	2. Relief valve damaged	Replace	3-31 3-78
Engine overheated	1. Engine oil insufficient	Fill	2-7
	2. Fan belt broken or elongated	Replace or adjust	3-32
	3. Coolant insufficient	Fill	2-7
	4. Radiator net and radiator fin clogged with dust	Clean	—
	5. Inside of radiator corroded	Clean or replace	2-36
	6. Coolant flow route corroded	Clean or replace	2-36
	7. Radiator cap damaged	Replace	3-32
	8. Overload operating	Reduce the load	—
	9. Head gasket damaged	Replace	3-45

(Continued)

3. ENGINE

Symptom	Probable cause and checking procedure	Solution	Reference page
Engine overheated	10. Incorrect injection timing	Adjust	3-34
	11. Unsuitable fuel used	Use specified fuel	2-7
Battery quickly discharged	1. Battery electrolyte insufficient	Fill distilled water and charge	2-27
	2. Fan belt slips	Adjust belt tension or replace	3-32
	3. Wiring disconnected	Connect	—
	4. Rectifier damaged	Replace	8-49
	5. Alternator damaged	Replace	8-48
	6. Battery damaged	Replace	—

2. Servicing specifications for engine

BX1880 (D722-E4) and BX2380 (D902-E4)

Engine body

Item		Factory specification	Allowable limit
Cylinder head surface	Flatness	—	0.005 mm 0.002 in.
Top clearance		0.55 to 0.70 mm 0.022 to 0.027 in.	—
Compression pressure [BX1880 (D722-E4)]		2.85 to 3.23 MPa 29.0 to 33.0 kgf/cm ² 413 to 469 psi	2.26 MPa 23.0 kgf/cm ² 327 psi
Compression pressure [BX2380 (D902-E4)]		3.53 to 4.02 MPa 36.0 to 41.0 kgf/cm ² 512 to 583 psi	2.55 MPa 26.0 kgf/cm ² 370 psi
Variance among cylinders		—	10% or less
Valve seat	Angle (Intake)	0.79 rad 45°	—
	Angle (Exhaust)	0.79 rad 45°	—
	Width	2.12 mm 0.0835 in.	—
Valve face	Angle (Intake)	0.79 rad 45°	—
	Angle (Exhaust)	0.79 rad 45°	—
Valve recessing	Intake and exhaust	0.10 (protrusion) to 0.10 (recessing) mm 0.0039 (protrusion) to 0.0039 (recessing) in.	0.30 (recessing) mm 0.012 (recessing) in.
Valve stem to valve guide	Clearance	0.030 to 0.057 mm 0.0012 to 0.0022 in.	0.10 mm 0.0039 in.
• Valve stem	O.D.	5.968 to 5.980 mm 0.2350 to 0.2354 in.	—
• Valve guide	I.D.	6.010 to 6.025 mm 0.2367 to 0.2372 in.	—
Valve clearance (Cold)		0.145 to 0.185 mm 0.00571 to 0.00728 in.	—
Valve spring	Free length	31.3 to 31.8 mm 1.24 to 1.25 in.	28.4 mm 1.12 in.
	Tilt	—	1.2 mm 0.047 in.
	Setting load	65 N / 27.0 mm 6.6 kgf / 27.0 mm 15 lbf / 1.06 in.	55 N / 27.0 mm 5.6 kgf / 27.0 mm 12 lbf / 1.06 in.
Rocker arm shaft to rocker arm	Clearance	0.016 to 0.045 mm 0.00063 to 0.0017 in.	0.15 mm 0.0059 in.
• Rocker arm shaft	O.D.	10.473 to 10.484 mm 0.41233 to 0.41275 in.	—
• Rocker arm	I.D.	10.500 to 10.518 mm 0.41339 to 0.41409 in.	—

(Continued)

3. ENGINE

Item		Factory specification	Allowable limit
Push rod	Alignment	—	0.25 mm 0.0098 in.
Tappet to tappet guide	Clearance	0.016 to 0.052 mm 0.00063 to 0.0020 in.	0.10 mm 0.0039 in.
• Tappet guide	I.D.	18.000 to 18.018 mm 0.70867 to 0.70937 in.	—
• Tappet	O.D.	17.966 to 17.984 mm 0.70733 to 0.70803 in.	—
Camshaft	Side clearance	0.15 to 0.31 mm 0.0059 to 0.012 in.	0.80 mm 0.031 in.
	Alignment	—	0.01 mm 0.0004 in.
Cam height	Intake	26.88 mm 1.058 in.	26.83 mm 1.056 in.
	Exhaust	26.88 mm 1.058 in.	26.83 mm 1.056 in.
Camshaft journal to cylinder block bore	Oil clearance	0.050 to 0.091 mm 0.0020 to 0.0035 in.	0.15 mm 0.0059 in.
• Camshaft journal	O.D.	32.934 to 32.950 mm 1.2967 to 1.2972 in.	—
• Camshaft block bore	I.D.	33.000 to 33.025 mm 1.2993 to 1.3001 in.	—
Timing gear			
• Crank gear to idle gear 1	Backlash	0.0430 to 0.124 mm 0.00170 to 0.00488 in.	0.15 mm 0.0059 in.
• Idle gear 1 to cam gear	Backlash	0.0470 to 0.123 mm 0.00185 to 0.00484 in.	0.15 mm 0.0059 in.
• Idle gear 1 injection pump gear	Backlash	0.0460 to 0.124 mm 0.00182 to 0.00488 in.	0.15 mm 0.0059 in.
• Crank gear to oil pump drive gear	Backlash	0.0410 to 0.123 mm 0.00162 to 0.00484 in.	0.15 mm 0.0059 in.
Idle gear shaft to gear bushing			
• Idle gear 1	Clearance	0.020 to 0.084 mm 0.00079 to 0.0033 in.	0.10 mm 0.0039 in.
• Idle gear bushing	I.D.	20.000 to 20.051 mm 0.78741 to 0.78940 in.	—
• Idle gear shaft 1	O.D.	19.967 to 19.980 mm 0.78611 to 0.78661 in.	—
Idle gear			
• Idle gear 1	Side clearance	0.20 to 0.51 mm 0.0079 to 0.020 in.	0.80 mm 0.031 in.
Piston pin bore	I.D.	20.000 to 20.013 mm 0.78741 to 0.78791 in.	20.05 mm 0.7894 in.
Piston ring to piston ring groove			
• Second ring	Clearance	0.0900 to 0.0120 mm 0.00355 to 0.00472 in.	0.15 mm 0.0059 in.
• Oil ring	Clearance	0.040 to 0.080 mm 0.0016 to 0.0031 in.	0.15 mm 0.0059 in.

(Continued)

Item		Factory specification	Allowable limit
Piston ring gap [BX1880 (D722-E4)]	Top ring	0.15 to 0.30 mm 0.0059 to 0.011 in.	1.2 mm 0.0472 in.
	Second ring	0.30 to 0.45 mm 0.012 to 0.017 in.	1.25 mm 0.0492 in.
	Oil ring	0.15 to 0.30 mm 0.0059 to 0.011 in.	1.2 mm 0.0472 in.
Piston ring gap [BX2380 (D902-E4)]	Top ring	0.20 to 0.35 mm 0.0079 to 0.013 in.	1.25 mm 0.0492 in.
	Second ring	0.35 to 0.50 mm 0.014 to 0.019 in.	1.25 mm 0.0492 in.
	Oil ring	0.20 to 0.35 mm 0.0079 to 0.013 in.	1.25 mm 0.0492 in.
Connecting rod	Alignment	—	0.05 mm 0.002 in.
Piston pin to small end bushing	Clearance	0.015 to 0.075 mm 0.0059 to 0.0029 in.	0.15 mm 0.0059 in.
• Piston pin	O.D.	20.002 to 20.011 mm 0.78748 to 0.78783 in.	—
• Small end bushing	I.D.	20.025 to 20.040 mm 0.78839 to 0.78897 in.	—
Crankshaft	Side clearance	0.15 to 0.31 mm 0.0059 to 0.012 in.	0.50 mm 0.020 in.
	Alignment	—	0.02 mm 0.0008 in.
Crankshaft to crankshaft bearing 1 [BX1880 (D722-E4)]	Oil clearance	0.0340 to 0.114 mm 0.00134 to 0.00448 in.	0.20 mm 0.0079 in.
• Crankshaft	O.D.	39.934 to 43.950 mm 1.5722 to 1.5728 in.	—
• Crankshaft bearing 1	I.D.	39.984 to 44.040 mm 1.5742 to 1.5763 in.	—
Crankshaft to crankshaft bearing 1 [BX2380 (D902-E4)]	Oil clearance	0.0340 to 0.106 mm 0.00134 to 0.00417 in.	0.20 mm 0.0079 in.
• Crankshaft	O.D.	43.934 to 43.950 mm 1.7297 to 1.7303 in.	—
• Crankshaft bearing 1	I.D.	43.984 to 44.040 mm 1.7317 to 1.7338 in.	—
Crankshaft to crankshaft bearing 2	Oil clearance	0.028 to 0.059 mm 0.0011 to 0.0023 in.	0.20 mm 0.0079 in.
• Crankshaft journal	O.D.	43.934 to 43.950 mm 1.7297 to 1.7303 in.	—
• Crankshaft bearing 2	I.D.	43.978 to 43.993 mm 1.7315 to 1.7320 in.	—
Crankshaft to crankshaft bearing 3 [BX1880 (D722-E4)]	Oil clearance	0.028 to 0.059 mm 0.0011 to 0.0023 in.	0.20 mm 0.0079 in.
• Crankshaft journal	O.D.	39.934 to 39.950 mm 1.5722 to 1.5728 in.	—
• Crankshaft bearing 3	I.D.	39.978 to 39.993 mm 1.5740 to 1.5745 in.	—
Crankshaft to crankshaft bearing 3 [BX2380 (D902-E4)]	Oil clearance	0.028 to 0.059 mm 0.0011 to 0.0023 in.	0.20 mm 0.0079 in.

(Continued)

3. ENGINE

Item		Factory specification	Allowable limit
• Crankshaft journal	O.D.	43.934 to 43.950 mm 1.7297 to 1.7303 in.	—
• Crankshaft bearing 3	I.D.	43.978 to 43.993 mm 1.7315 to 1.7320 in.	—
Crankpin to crankpin bearing	Oil clearance	0.020 to 0.051 mm 0.00079 to 0.0020 in.	0.15 mm 0.0059 in.
• Crankpin	O.D.	33.959 to 33.975 mm 1.3370 to 1.3375 in.	—
• Crankpin bearing	I.D.	33.995 to 34.010 mm 1.3384 to 1.3389 in.	—
Cylinder liner I.D. [BX1880 (D722-E4)]		67.000 to 67.019 mm 2.26378 to 2.6385 in.	67.150 mm 2.6437 in.
Cylinder liner I.D. [BX2380 (D902-E4)]		72.000 to 72.019 mm 2.8347 to 2.8353 in.	72.150 mm 2.8406 in.
Cylinder (Oversize) [BX1880 (D722-E4)]		67.250 to 67.269 mm 2.6477 to 2.6483 in.	67.400 mm 2.6535 in.
Cylinder (Oversize) [BX2380 (D902-E4)]		72.250 to 72.269 mm 2.8445 to 2.8452 in.	72.400 mm 2.8504 in.

Lubricating system

Item		Factory specification	Allowable limit
Engine oil pressure	At idle speed	More than 49 kPa 0.50 kgf/cm ² 7.1 psi	—
	At rated speed	197 to 441 kPa 2.0 to 4.50 kgf/cm ² 28.5 to 64.0 psi	147 kPa 1.50 kgf/cm ² 21.3 psi
Inner rotor to outer rotor	Clearance	0.030 to 0.14 mm 0.0012 to 0.0055 in.	—
Outer rotor to pump body	Clearance	0.070 to 0.15 mm 0.0028 to 0.0059 in.	—
Inner rotor to cover	Clearance	0.0750 to 0.135 mm 0.00296 to 0.00531 in.	—
Relief valve spring	Length	32 mm 1.26 in.	28 mm 1.10 in.

Cooling system

Item		Factory specification	Allowable limit
Thermostat	Valve opening temperature (at beginning)	69.5 to 72.5 °C 157.1 to 162.5 °F	—
	Valve opening temperature (opened completely)	85 °C 185 °F	—
Radiator	Water leakage test pressure	No leak at specified pressure	—
Radiator cap	Pressure falling time	10 seconds or more 88 → 59 kPa 0.90 → 0.60 kgf/cm ² 13 → 8.5 psi	—
Fan belt	Tension	7 to 9 mm / 98 N 0.28 to 0.35 in. / 98 N (10 kgf, 22 lbf)	—

Fuel system

Item		Factory specification	Allowable limit
Injection pump [BX1880 (D722-E4)]	Injection timing	0.3186 to 0.3447 rad (18.25 to 19.75°) before T.D.C.	—
Injection pump [BX2380 (D902-E4)]	Injection timing	0.3360 to 0.3621 rad (19.25 to 20.75°) before T.D.C.	—
Pump element	Fuel tightness	—	13.73 MPa 140.0 kgf/cm ² 1991 psi
Delivery valve	Fuel tightness	10 seconds 13.73 → 12.75 MPa 140.0 → 130.0 kgf/cm ² 1991 → 1849 psi	5 seconds 13.73 → 12.75 MPa 140.0 → 130.0 kgf/cm ² 1991 → 1849 psi
Injection nozzle	Injection pressure	13.73 to 12.75 MPa 140.0 to 150.0 kgf/cm ² 1991 to 2133 psi	—
Injection nozzle valve seat	Valve seat tightness	When the pressure is 12.75 MPa (130.0 kgf/cm ² , 1849 psi), the valve seat must be fuel tightness	—

BX2680 (D1005-E4)**Engine body**

Item		Factory specification	Allowable limit
Cylinder head surface	Flatness	—	0.005 mm 0.002 in.
Top clearance		0.55 to 0.70 mm 0.022 to 0.029 in.	—
Compression pressure		3.73 to 4.11 MPa 38.0 to 42.0 kgf/cm ² 541 to 597 psi	2.26 MPa 23.0 kgf/cm ² 370 psi 327 psi
Variance among cylinders		—	10% or less
Valve seat	Angle (Intake)	1.0 rad 60°	—
	Angle (Exhaust)	0.79 rad 45°	—
	Width	2.12 mm 0.0835 in.	—
Valve face	Angle (Intake)	1.0 rad 60°	—
	Angle (Exhaust)	0.79 rad 45°	—
Valve recessing	Intake and exhaust	0.050 (protrusion) to 0.25 (recessing) mm 0.0020 (protrusion) to 0.0098 (recessing) in.	0.40 (recessing) mm 0.016 (recessing) in.
Valve stem to valve guide	Clearance	0.035 to 0.065 mm 0.0014 to 0.0025 in.	0.10 mm 0.0039 in.
• Valve stem	O.D.	6.960 to 6.975 mm 0.2741 to 0.2746 in.	—
• Valve guide	I.D.	7.010 to 7.025 mm 0.2760 to 0.2765 in.	—

(Continued)

3. ENGINE

Item		Factory specification	Allowable limit
Valve clearance (Cold)		0.145 to 0.185 mm 0.00571 to 0.00728 in.	—
Valve spring	Free length	37.0 to 37.5 mm 1.46 to 1.47 in.	36.5 mm 1.44 in.
	Tilt	—	1.0 mm 0.039 in.
	Setting load	117.4 N / 31.0 mm 11.97 kgf / 31.0 mm 26.39 lbf / 1.22 in.	100.0 N / 31.0 mm 10.20 kgf / 31.0 mm 22.48 lbf / 1.22 in.
Rocker arm shaft to rocker arm	Clearance	0.016 to 0.045 mm 0.00063 to 0.0017 in.	0.10 mm 0.0039 in.
• Rocker arm shaft	O.D.	11.973 to 11.984 mm 0.47138 to 0.47181 in.	—
• Rocker arm	I.D.	12.000 to 12.018 mm 0.47244 to 0.47314 in.	—
Push rod	Alignment	—	0.25 mm 0.0098 in.
Tappet to tappet guide	Clearance	0.020 to 0.062 mm 0.00079 to 0.0024 in.	0.07 mm 0.003 in.
• Tappet guide	I.D.	20.000 to 20.021 mm 0.78740 to 0.78822 in.	—
• Tappet	O.D.	19.959 to 19.980 mm 0.78579 to 0.78661 in.	—
Camshaft	Side clearance	0.070 to 0.22 mm 0.0028 to 0.0086 in.	0.30 mm 0.012 in.
	Alignment	—	0.01 mm 0.0004 in.
Cam height	Intake	28.80 mm 1.134 in.	28.75 mm 1.132 in.
	Exhaust	29.00 mm 1.142 in.	28.95 mm 1.140 in.
Camshaft journal to cylinder block bore	Oil clearance	0.050 to 0.091 mm 0.0020 to 0.0035 in.	0.15 mm 0.0059 in.
• Camshaft journal	O.D.	35.934 to 35.950 mm 1.4148 to 1.4153 in.	—
• Camshaft block bore	I.D.	36.000 to 36.025 mm 1.4174 to 1.4183 in.	—
Timing gear			
• Crank gear to idle gear 1	Backlash	0.0320 to 0.115 mm 0.00126 to 0.00452 in.	0.15 mm 0.0059 in.
• Idle gear 1 to cam gear	Backlash	0.0360 to 0.114 mm 0.00142 to 0.00448 in.	0.15 mm 0.0059 in.
• Idle gear 1 injection pump gear	Backlash	0.0340 to 0.116 mm 0.00134 to 0.00456 in.	0.15 mm 0.0059 in.
Governor gear to injection pump gear (Fuel cam gear)	Backlash	0.0300 to 0.117 mm 0.00119 to 0.00460 in.	0.15 mm 0.0059 in.
Idle gear shaft to gear bushing			
• Idle gear 1	Clearance	0.020 to 0.054 mm 0.00079 to 0.0021 in.	0.10 mm 0.0039 in.

(Continued)

Item		Factory specification	Allowable limit
• Idle gear bushing	I.D.	26.000 to 26.021 mm 1.0237 to 1.0244 in.	—
• Idle gear shaft 1	O.D.	25.967 to 25.980 mm 1.0224 to 1.0228 in.	—
Idle gear			
• Idle gear 1	Side clearance	0.20 to 0.51 mm 0.0079 to 0.020 in.	0.80 mm 0.031 in.
Piston pin bore	I.D.	22.000 to 22.013 mm 0.86615 to 0.86665 in.	22.03 mm 0.8673 in.
Piston ring to piston ring groove			
• Second ring	Clearance	0.0850 to 0.112 mm 0.00335 to 0.00440 in.	0.2 mm 0.008 in.
• Oil ring	Clearance	0.020 to 0.060 mm 0.00079 to 0.0023 in.	0.15 mm 0.0059 in.
Piston ring gap	Top ring	0.30 to 0.45 mm 0.012 to 0.017 in.	1.25 mm 0.0492 in.
	Second ring	0.30 to 0.45 mm 0.012 to 0.017 in.	1.25 mm 0.0492 in.
	Oil ring	0.25 to 0.40 mm 0.0098 to 0.015 in.	1.25 mm 0.0492 in.
Connecting rod	Alignment	—	0.05 mm 0.002 in.
Piston pin to small end bushing	Clearance	0.014 to 0.038 mm 0.00056 to 0.0014 in.	0.15 mm 0.0059 in.
• Piston pin	O.D.	22.002 to 22.011 mm 0.86622 to 0.86657 in.	—
• Small end bushing	I.D.	22.025 to 22.040 mm 0.86713 to 0.86771 in.	—
Crankshaft	Side clearance	0.15 to 0.31 mm 0.0059 to 0.012 in.	0.50 mm 0.020 in.
	Alignment	—	0.02 mm 0.0008 in.
Crankshaft to crankshaft bearing 1	Oil clearance	0.0340 to 0.114 mm 0.00134 to 0.00448 in.	0.20 mm 0.0079 in.
• Crankshaft	O.D.	47.934 to 47.950 mm 1.8872 to 1.8877 in.	—
• Crankshaft bearing 1	I.D.	47.984 to 48.048 mm 1.8892 to 1.8916 in.	—
Crankshaft to crankshaft bearing 2	Oil clearance	0.034 to 0.095 mm 0.0014 to 0.0037 in.	0.20 mm 0.0079 in.
• Crankshaft journal	O.D.	47.934 to 47.950 mm 1.8872 to 1.8877 in.	—
• Crankshaft bearing 2	I.D.	47.984 to 48.029 mm 1.8892 to 1.8909 in.	—
Crankshaft to crankshaft bearing 3	Oil clearance	0.034 to 0.098 mm 0.0014 to 0.0038 in.	0.20 mm 0.0079 in.
• Crankshaft journal	O.D.	51.921 to 51.940 mm 2.0442 to 2.0448 in.	—
• Crankshaft bearing 3	I.D.	51.974 to 52.019 mm 2.0463 to 2.0479 in.	—

(Continued)

3. ENGINE

Item		Factory specification	Allowable limit
Crankpin to crankpin bearing	Oil clearance	0.029 to 0.091 mm 0.0012 to 0.0035 in.	0.20 mm 0.0079 in.
• Crankpin	O.D.	39.959 to 39.975 mm 1.5732 to 1.5738 in.	—
• Crankpin bearing	I.D.	40.040 to 40.050 mm 1.5764 to 1.5767 in.	—
Cylinder liner I.D.		76.000 to 76.019 mm 2.9922 to 2.9928 in.	76.15 mm 2.998 in.
Cylinder (oversize)		76.500 to 76.519 mm 3.0119 to 3.0125 in.	76.65 mm 3.018 in.

Lubricating system

Item		Factory specification	Allowable limit
Engine oil pressure	At idle speed	More than 49 kPa 0.50 kgf/cm ² 7.1 psi	—
	At rated speed	197 to 441 kPa 2.0 to 4.50 kgf/cm ² 28.5 to 64.0 psi	147 kPa 1.50 kgf/cm ² 21.3 psi
Inner rotor to outer rotor	Clearance	0.060 to 0.18 mm 0.0024 to 0.0071 in.	—
Outer rotor to pump body	Clearance	0.100 to 0.180 mm 0.00394 to 0.00708 in.	—
Inner rotor to cover	Clearance	0.025 to 0.075 mm 0.00099 to 0.0029 in.	—
Relief valve spring	Length	32 mm 1.26 in.	28 mm 1.10 in.

Cooling system

Item		Factory specification	Allowable limit
Thermostat	Valve opening temperature (at beginning)	69.5 to 72.5 °C 157.1 to 162.5 °F	—
	Valve opening temperature (opened completely)	85 °C 185 °F	—
Radiator	Water leakage test pressure	No leak at specified pressure	—
Radiator cap	Pressure falling time	10 seconds or more 88 → 59 kPa 0.90 → 0.60 kgf/cm ² 13 → 8.5 psi	—
Fan belt	Tension	7 to 9 mm / 98 N 0.28 to 0.35 in. / 98 N (10 kgf, 22 lbf)	—

Fuel system

Item		Factory specification	Allowable limit
Injection pump	Injection timing	0.3360 to 0.3621 rad (19.25 to 20.75°) before T.D.C.	—
Pump element	Fuel tightness	—	13.73 MPa 140.0 kgf/cm ² 1991 psi

(Continued)

Item		Factory specification	Allowable limit
Delivery valve	Fuel tightness	10 seconds 13.73 → 12.75 MPa 140.0 → 130.0 kgf/cm ² 1991 → 1849 psi	5 seconds 13.73 → 12.75 MPa 140.0 → 130.0 kgf/cm ² 1991 → 1849 psi
Injection nozzle	Injection pressure	13.73 to 12.75 MPa 140.0 to 130.0 kgf/cm ² 1991 to 2133 psi	—
Injection nozzle valve seat	Valve seat tightness	When the pressure is 12.75 MPa (130.0 kgf/cm ² , 1849 psi), the valve seat must be fuel tightness	—

3. Tightening torques for engine

Tightening torques of screws, bolts and nuts on the table below are especially specified.

■ NOTE

- In removing and applying the bolts and nuts marked with "***", a pneumatic wrench or similar pneumatic tool, if employed, must be used with enough care not to get them seized.
- For the screws, bolts and nuts with the mark "***", apply engine oil to their threads and seats before you tighten.
- The letter "M" in Dimension × Pitch shows that the screw, bolt or nut dimensions are in the metric system. The dimension is the nominal external diameter in mm of the threads. The pitch is the nominal distance in mm between two threads.

BX1880 (D722-E4) and BX2380 (D902-E4)

Item	Dimension × Pitch	N · m	kgf · m	lbf · ft
Cylinder head cover screw	M6 × 1.0	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31
Cylinder head screw	M8 × 1.25	38 to 42	3.8 to 4.3	28 to 31
*Main bearing case screw 1	M6 × 1.0	13 to 15	1.3 to 1.6	9.4 to 11
*Main bearing case screw 2	M7 × 1.0	27 to 30	2.7 to 3.1	20 to 22
*Flywheel screw	M10 × 1.25	54 to 58	5.5 to 6.0	40 to 43
*Connecting rod screw	M7 × 0.75	27 to 30	2.7 to 3.1	20 to 22
*Rocker arm bracket screw	M6 × 1.0	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31
*Fan drive pulley screw	M12 × 1.5	118 to 127	12.0 to 13.0	86.8 to 94.0
Bearing case cover mounting screw	M6 × 1.0	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31
Glow plug	M8 × 1.0	7.9 to 14	0.80 to 1.5	5.8 to 10
Nozzle holder assembly	M20 × 1.5	49 to 68	5.0 to 7.0	37 to 50
Nozzle holder	—	35 to 39	3.5 to 4.0	26 to 28
Oil pressure switch	PT 1/8	15 to 19	1.5 to 2.0	11 to 14
Injection pipe retaining nut	M12 × 1.5	25 to 34	2.5 to 3.5	18 to 25
Overflow pipe retaining nut	M12 × 1.5	20 to 24	2.0 to 2.5	15 to 18
Drain plug with copper gasket	M12 × 1.25	33 to 37	3.3 to 3.8	24 to 27
Oil filter joint	—	40 to 49	4.0 to 5.0	29 to 36

BX2680 (D1005-E4)

Item	Dimension × Pitch	N · m	kgf · m	lbf · ft
Cylinder head cover screw	M6 × 1.0	7 to 8	0.7 to 0.9	5 to 6
Cylinder head screw	M8 × 1.25	64 to 68	6.5 to 7.0	47 to 50
*Main bearing case screw 1	M7 × 1.0	30 to 34	3.0 to 3.5	22 to 25
*Main bearing case screw 2	M8 × 1.0	49 to 53	5.0 to 5.5	37 to 39
*Flywheel screw	M10 × 1.25	54 to 58	5.5 to 6.0	40 to 43
*Connecting rod screw	M7 × 0.75	42 to 46	4.2 to 4.7	31 to 33

(Continued)

Item	Dimension × Pitch	N · m	kgf · m	lbf · ft
*Rocker arm bracket nut	M7 × 1.0	22 to 26	2.2 to 2.7	16 to 19
*Fan drive pulley screw	M14 × 1.5	236 to 245	24.0 to 25.0	174 to 180
Bearing case cover mounting screw	M6 × 1.0	9.81 to 11.2	1.00 to 1.15	7.24 to 8.31
Glow plug	M8 × 1.0	7.9 to 14	0.80 to 1.5	5.8 to 10
Nozzle holder assembly	M20 × 1.5	49 to 68	5.0 to 7.0	37 to 50
Nozzle holder	—	35 to 39	3.5 to 4.0	26 to 28
Oil pressure switch	PT 1/8	15 to 19	1.5 to 2.0	11 to 14
Injection pipe retaining nut	M12 × 1.5	25 to 34	2.5 to 3.5	18 to 25
Overflow pipe retaining nut	M12 × 1.5	20 to 24	2.0 to 2.5	15 to 18
Drain plug with copper gasket	M12 × 1.25	33 to 37	3.3 to 3.8	24 to 27
Oil filter joint	—	40 to 49	4.0 to 5.0	29 to 36

— RELATED PAGE —

[TIGHTENING TORQUES on page 2-13](#)


4. Checking and adjusting

4.1 Engine body

4.1.1 Checking compression pressure

NOTE

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for performing this test.
- Variances in cylinder compression values should be under 10%.



1. Operate the engine until it is warmed up.
2. Stop the engine.
3. Remove the air cleaner, the muffler and all glow plugs (or nozzles).
4. Set a compression tester with the adapter to the glow plug hole (or nozzle hole).

Nozzle hole:

Adapter H (07909-31231)

Glow plug hole:

Adapter L (07909-31301)

5. Disconnect the connector of engine stop solenoid and keep the engine stop position (non-injection). Then, operate the engine with the starter and measure the compression pressure.
6. Repeat steps 4 and 5 for each cylinder.
7. If the measurement is below the allowable limit, apply a small amount of oil to the cylinder wall through the glow plug hole (or nozzle hole) and measure the compression pressure again.

BX1880 (D722-E4)

Compression pressure	Factory specification	2.85 to 3.23 MPa 29.0 to 33.0 kgf/cm ² 413 to 469 psi
	Allowable limit	2.26 MPa 33.0 kgf/cm ² 327 psi

BX2380 (D902-E4)

Compression pressure	Factory specification	3.53 to 4.02 MPa 36.0 to 41.0 kgf/cm ² 512 to 583 psi
	Allowable limit	2.55 MPa 26.0 kgf/cm ² 370 psi

BX2680 (D1005-E4)

Compression pressure	Factory specification	3.73 to 4.11 MPa 38.0 to 42.0 kgf/cm ² 541 to 597 psi
	Allowable limit	2.26 MPa 23.0 kgf/cm ² 327 psi

8. If the compression pressure is still less than the allowable limit, check the top clearance, valve clearance and cylinder head.
9. If the compression pressure increases after applying oil, check the cylinder wall and piston rings.





4.1.2 Checking valve clearance

IMPORTANT

- Valve clearance must be checked and adjusted when engine is cold.

NOTE

- The sequence of cylinder numbers is given as No. 1, No. 2 and No. 3 starting from the gear case side.
- After adjusting the valve clearance, secure the adjusting screw with the lock nut.



- (1) [1TC] and "timing line" (2) Alignment mark (a) Gear case side
- [A] BX2380 (D902-E4) [B] BX2680 (D1005-E4)

Adjustable cylinder location of piston	Number of cylinders Valve arrangement	
	Intake valve	Exhaust valve
No. 1	★	★
No. 2	☆	★
No. 3	★	☆

Valve clearance marked with "★" can be adjusted.

1. Remove the cylinder head cover and the glow plugs.
2. Align the [1TC] mark at [1TC] and "timing line" (1) on the flywheel and alignment mark (2) on the rear end plate so that the No. 1 piston comes to the compression top dead center.
3. Check the following valve clearance marked with "★" using a feeler gauge.
4. If the clearance is not within the factory specifications, adjust with the adjusting screw.

Intake and exhaust valve clearance (Cold)	Factory specification	0.145 to 0.185 mm 0.00571 to 0.00728 in.
---	-----------------------	---

5. Then turn the flywheel 6.28 rad (360°), and align the [1TC] mark at [1TC] and "timing line" (1) on the flywheel and alignment mark (2) on the rear end plate so that the No. 1 piston comes to the overlap position.
6. Check the following valve clearance marked with "☆" using a feeler gauge.
7. If the clearance is not within the factory specifications, adjust with the adjusting screw.

4.2 Lubricating system

4.2.1 Checking engine oil pressure



1. Remove the engine oil pressure switch, and set an oil pressure tester.
2. Start the engine. After warming up, measure the oil pressure of both idling and rated speeds.

3. ENGINE**4. Checking and adjusting**

3. If the oil pressure is less than the allowable limit, check the following.

- Engine oil insufficient
- Oil pump damaged
- Oil strainer clogged
- Oil filter cartridge clogged
- Oil gallery clogged
- Excessive oil clearance
- Foreign matter in the relief valve
- Relief valve spring length.

Engine oil pressure	At idle speed	Factory specification	More than 49 kPa 1.0 kgf/cm ² 14 psi
	At rated speed	Factory specification	197 to 441 kPa 2.00 to 4.50 kgf/cm ² 28.5 to 64.0 psi
		Allowable limit	147 kPa 1.50 kgf/cm ² 21.3 psi


(When reassembling)

- After checking the engine oil pressure, tighten the engine oil pressure switch to the specified torque.

Tightening torque	Oil pressure switch	15 to 19 N·m 1.5 to 2.0 kgf·m 11 to 14 lbf·ft
-------------------	---------------------	---

4.3 Cooling system**4.3.1 Checking fan belt tension**

1. Measure the deflection (A), depressing the belt halfway between the fan drive pulley and alternator pulley at specified force.



(A) Deflection


2. If the measurement is not within the factory specifications, loosen the alternator mounting screws and relocate the alternator to adjust.

Depressing fan belt	Specified force	98 N 10 kgf 22 lbf
---------------------	-----------------	--------------------------

Deflection (A)	Factory specification	7.0 to 9.0 mm 0.28 to 0.35 in.
----------------	-----------------------	-----------------------------------

4.3.2 Checking fan belt damage and wear


1. Check the fan belt for damage.
2. If the fan belt is damaged, replace it.



(A) Good

(B) Bad

3. Check if the fan belt is worn and sunk in the pulley groove.
4. If the fan belt is nearly worn out and deeply sunk in the pulley groove, replace it.




(A) Good

(B) Bad

4.3.3 Checking radiator cap air leakage**CAUTION**

- When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.



3TAAAAB1P060A
(1) Radiator tester (2) Adapter

1. Set a radiator tester (1) and an adapter (2) on the radiator cap.
2. Apply the specified pressure.

Specified pressure	88 kPa 0.90 kgf/cm ² 13 psi
--------------------	--

3. If the measurement is less than the factory specification, replace the radiator cap.

Pressure falling time	Factory specification	More than 10 seconds for pressure fall 88 → 59 kPa (0.90 → 0.60 kgf/cm ² , 13 → 8.5 psi)
-----------------------	-----------------------	---


4.3.4 Checking radiator water leakage

⚠ CAUTION

- When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.

■ NOTE

- The pressure of the leak test is different from each radiator specification. Thus, do the leak test referring to the test pressure of each radiator specification.
1. Pour a specified amount of water into the radiator.
 2. Set a radiator tester (1) and an adaptor (2) and raise the water pressure to the specified pressure.



3EEABAB1P161B
(1) Radiator tester (2) Adapter


Radiator water leakage test pressure	Factory specification	No leak at specified pressure
--------------------------------------	-----------------------	-------------------------------

3. Check the radiator for water leaks.
4. For water leak from the pinhole, repair with the radiator cement. When water leak is excessive, replace the radiator.

4.3.5 Checking thermostat valve opening temperature

⚠ CAUTION

- When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.



3EEABAB1P160A

1. Suspend the thermostat in the water by a string with its end inserted between the valve and seat.
2. Heating the water gradually, read the temperature when the valve opens and leaves the string.
3. Continue heating and read the temperature when the valve opens.

Valve opens	Approximately	8 mm 0.3 in.
-------------	---------------	-----------------

4. If the measurement is not within the factory specifications, replace the thermostat.





Thermostat's valve opening temperature	Factory specification	69.5 to 72.5 °C 157.1 to 162.5 °F
Temperature at which thermostat completely opens		85 °C 185 °F

4.4 Fuel system

4.4.1 Checking injection timing

NOTE


- The liquid gasket is not required for assembling.
- Shims are available in thickness of 0.20 mm (0.0079 in.), 0.25 mm (0.0098 in.), 0.30 mm (0.012 in.) and 0.175 mm (0.00689 in.). Combine these shims for adjustments.
- Addition or reduction of shim (0.05 mm, 0.002 in.) delays or advances the injection timing by approx. 0.009 rad (0.5°).
- In disassembling and replacing the injection pump, be sure to use the same number of new shims with the same thickness.
- The 0.175 mm thick shim is coated only on the lower face. Therefore, do not use the 0.175 mm thick shim as the top shim of the combination (injection pump side), because this can cause oil leakage.



- | | |
|--|--|
| (1) [1TC] and "timing line" | (6) One-hole:
0.175 mm (0.00689 in.) |
| (2) Alignment mark | (7) Without hole:
0.30 mm (0.012 in.) |
| (4) Shim (Soft metal gasket shim) | [A] BX1880 (D722-E4) |
| (5) Two-holes:
0.20 mm (0.0079 in.)
0.175 mm (0.00689 in.) | [B] BX2380 (D902-E4) |
| | [C] BX2680 (D1005-E4) |

1. Remove the injection pipes.
2. Remove the engine stop solenoid.

- Turn the flywheel counterclockwise (viewed from flywheel side) until the fuel fills up to the hole of the delivery valve holder (3) for No. 1 cylinder.



(3) Delivery valve holder

- After the fuel fills up to the hole of the delivery valve holder for No. 1 cylinder, turn back (clockwise) the flywheel around 1.6 rad (90°).
- Turn the flywheel counterclockwise to set at around 0.44 rad (25°) before T.D.C.
- Slowly turn the flywheel counterclockwise and stop turning when the fuel begins to come up, to get the present injection timing.
- Check to see the degree on flywheel.
The flywheel has mark [1TC], [10] and [20] for the crank angle before the top dead center of No. 1 cylinder.
- If injection timing is out of adjustment, readjust the timing with shims.

BX1880 (D722-E4)

Injection timing	Factory specification	0.3186 to 0.3447 rad (18.25 to 19.75°) before T.D.C.
------------------	-----------------------	--


BX2380 (D902-E4) and BX2680 (D1005-E4)

Injection timing	Factory specification	0.3360 to 0.3621 rad (19.25 to 20.75°) before T.D.C.
------------------	-----------------------	--

4.4.2 Checking fuel tightness of pump element

NOTE

- Never try to disassemble the injection pump assembly. For repairs, you are strongly requested to contact a Kubota-authorized pump service shop.



(1) Injection pump pressure tester
(2) Injection nozzle
(3) Protection cover for jetted fuel


- Remove the engine stop solenoid.
- Remove the injection pipes and glow plugs.
- Install the injection pump pressure tester to the injection pump.
- Install the injection nozzle (2) jetted with the proper injection pressure to the injection pump pressure tester (1). (Refer to the photo.)
- Set the speed control lever to the maximum speed position.
- Operate the starter to increase the pressure.
- If the pressure cannot reach the allowable limit, replace the pump with a new one or repair with a Kubota-authorized pump service shop.

Fuel tightness of pump element	Allowable limit	13.73 MPa 140.0 kgf/cm ² 1991 psi
--------------------------------	-----------------	--

4.4.3 Checking fuel tightness of delivery valve

NOTE

- Never try to disassemble the injection pump assembly. For repairs, you are strongly requested to contact a Kubota-authorized pump service shop.



- (1) Injection pump pressure tester (3) Protection cover for jetted fuel
(2) Injection nozzle


1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set a pressure tester to the fuel injection pump.
4. Install the injection nozzle (2) jetted with the proper injection pressure to the injection pump pressure tester (1).
5. Operate the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. After that, turn the flywheel by the hand and raise the pressure.
7. Now turn the flywheel back about half a turn (to keep the plunger free). Keep the flywheel at this position and clock the time taken for the pressure to drop.
8. Measure the time needed to decrease the pressure.
9. If the measurement is less than allowable limit, replace the pump with a new one or repair with a Kubota-authorized pump service shop.

Fuel tightness of delivery valve	Factory specification	10 seconds 13.73 → 12.75 MPa 140.0 → 130.0 kgf/cm ² 1991 → 1849 psi
	Allowable limit	5 seconds 13.73 → 12.75 MPa 140.0 → 130.0 kgf/cm ² 1991 → 1849 psi

4.4.4 Checking nozzle spraying condition

CAUTION

- Check the nozzle injection pressure and condition after you make sure that there is nobody standing in the direction the fume goes. If the fume from the nozzle directly contacts the human body, cells may be destroyed and blood poisoning may be caused.



- (a) Good (b) Bad

1. Set the injection nozzle to a nozzle tester, and check the nozzle spraying condition.
2. If the spraying condition is damaged, replace the nozzle piece.

4.4.5 Checking fuel injection pressure

CAUTION


- Check the nozzle injection pressure and condition after you make sure that there is nobody standing in the direction the fume goes. If the fume from the nozzle directly contacts the human body, cells may be destroyed and blood poisoning may be caused.

(Reference)

Pressure variation (0.01 mm (0.0004 in.))	Factory specification	Approximately 235 kPa 2.4 kgf/cm ² 34 psi
---	-----------------------	---


Pressure variation difference of adjusting washer thickness

1. Set the injection nozzle to a nozzle tester.



2. Slowly move the tester handle to measure the pressure at which fuel begins jetting out from the nozzle.

- If the measurement is not within the factory specifications, replace the adjusting washer (1) in the nozzle holder to adjust it.



(1) Adjusting washer


Fuel injection pressure	Factory specification	13.73 to 14.70 MPa 140.0 to 150.0 kgf/cm ² 1992 to 2133 psi
-------------------------	-----------------------	--

4.4.6 Checking valve seat tightness

⚠ CAUTION

- Check the nozzle injection pressure and condition after you make sure that there is nobody standing in the direction the fume goes. If the fume from the nozzle directly contacts the human body, cells may be destroyed and blood poisoning may be caused.

- Set the injection nozzle to a nozzle tester.



- Raise the fuel pressure, and keep at specified pressure for 10 seconds.


Valve seat tightness	Factory specification	No fuel leak at 12.75 MPa 130.0 kgf/cm ² 1849 psi
----------------------	-----------------------	---

- If any fuel leak is found, replace the nozzle piece.

4.4.7 Checking nozzle holder

⚠ CAUTION

- Check the nozzle injection pressure and condition after you make sure that there is nobody standing in the direction the fume goes. If the fume from the nozzle directly contacts the human body, cells may be destroyed and blood poisoning may be caused.



- | | |
|----------------------|--------------------------|
| (1) Nozzle holder | (5) Distance piece |
| (2) Adjusting washer | (6) Nozzle piece |
| (3) Nozzle spring | (7) Nozzle retaining nut |
| (4) Push rod | |

- Secure the nozzle retaining nut (7) with a vise.
- Remove the nozzle holder (1), and remove parts inside.

(When reassembling)

- Assemble the nozzle in clean fuel oil.
- Install the push rod (4), noting its direction.
- After assembling the nozzle, be sure to adjust the fuel injection pressure.

3. ENGINE

5. Disassembling and assembling


Tightening torque	Nozzle holder	35 to 39 N·m 3.5 to 4.0 kgf·m 26 to 28 lbf·ft
	Overflow pipe retaining nut	20 to 24 N·m 2.0 to 2.5 kgf·m 15 to 18 lbf·ft
	Nozzle holder assembly	49 to 68 N·m 5.0 to 7.0 kgf·m 37 to 50 lbf·ft

5. Disassembling and assembling

5.1 Separating engine

5.1.1 Draining engine oil

1. Start and warm up the engine for approx. 5 minutes.
2. Place an oil pan underneath the engine.
3. Remove the drain plug (1) to drain oil.



(1) Drain plug


4. After draining, reinstall the drain plug (1).

(When refilling)

■ IMPORTANT

- Never mix two different type of oil.
- Use the proper SAE engine oil according to ambient temperature.
- Fill the engine with the new engine oil through the oil inlet (2) to the upper line on the dipstick (3).

BX2380 shown



(2) Oil inlet

(3) Dipstick

BX1880 (D722-E4)

Engine oil	Capacity	2.9 L
		3.1 U.S.qts
		2.6 Imp.qts

BX2380 (D902-E4)

Engine oil	Capacity	3.1 L
		3.3 U.S.qts
		2.7 Imp.qts

BX2680 (D1005-E4)

Engine oil	Capacity	3.5 L
		3.7 U.S.qts
		3.1 Imp.qts

Tightening torque	Drain plug with copper gasket (M12, 1.25)	33 to 37 N·m 3.3 to 3.8 kgf·m 24 to 27 lbf·ft
-------------------	---	---

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

5.1.2 Removing battery



WARNING

To avoid serious injury or death:


- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.

1. Remove the under panel (1).



(1) Under panel

2. Disconnect the negative cable (3) from the battery (2).
3. Disconnect the positive cable (4) from the battery (2) and remove the battery.




(2) Battery

(3) Negative cable

(4) Positive cable

5.1.3 Removing bonnet

1. Remove the mower deck.
2. Remove the front link (1) and link brackets (2).



(1) Front link


(2) Front link bracket

(3) Bonnet guide rod

(4) L.H. bonnet bracket

(5) R.H. bonnet bracket


3. Open the bonnet.
4. Disconnect the headlight harness from the headlights and bonnet.
5. Disconnect the bonnet guide rod (3) from the bonnet.
6. Disconnect the L.H. and R.H. bonnet brackets (4), (5) from the frame.
7. Remove the bonnet (6).



(6) Bonnet


5.1.4 Disconnecting wiring harness and ground cables

1. Disconnect the starter connector and cable (1), oil pressure switch (2), alternator connector and cable (3) and coolant temperature switch (4).



- (1) Starter (4) Coolant temperature switch
(2) Oil pressure switch
(3) Alternator

2. Disconnect the stop solenoid (5) and glow plug wire (6).



- (5) Stop solenoid (6) Glow plug

3. Disconnect the ground cables (7), (8), and (9).



- (7) Ground cable (Starter to frame) (10) Ground cable (Wire harness to R.H. engine support)
(8) Ground cable (Harness to frame) (11) Nut
(9) Ground cable (Battery to L.H. engine support)


(When reassembling)

Tightening torque	Engine mounting nut	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft
-------------------	---------------------	---

5.1.5 Disconnecting fuel hoses

1. Disconnect fuel return hose (1) and fuel supply hose (2) from engine.

2. Disconnect fuel filter (3) from engine.



- (1) Fuel return hose
(2) Fuel supply hose
(3) Fuel filter

5.1.6 Disconnecting accelerator wire


1. Disconnect accelerator wire (2) from speed control lever (1).



- (1) Speed control lever
(2) Accelerator wire

5.1.7 Disconnecting propeller shaft assembly

1. Disconnect the propeller shaft assembly (1) from the propeller spacer (3).



- (1) Propeller shaft assembly
(2) Bolt
(3) Propeller spacer

(When reassembling)

Tightening torque	Propeller shaft assembly bolt	24 to 27 N · m 2.4 to 2.8 kgf · m 18 to 20 lbf · ft
-------------------	-------------------------------	---

5.1.8 Separating engine

⚠ WARNING


To avoid serious injury or death:

- The engine is heavy. Use a hoist or crane when removing the engine.

1. Remove the engine mounting nuts (1) from both sides of the engine.

■ NOTE

- The rear engine mounting nuts secure ground cables to the L.H. and R.H. engine supports. If the rear engine mounting nuts have already been removed from a previous step, just remove the front engine mounting nuts.






- (1) Engine mounting nut

3. ENGINE

5. Disassembling and assembling

- Securely attach the lifting chain to the engine hooks (2), (3) and separate the engine assembly with the radiator from the frame.



- (2) Front engine hook
(3) Rear engine hook
(4) Engine support
- [A] BX2380 and BX1880
[B] BX2680

- Remove the L.H. and R.H. engine supports (4).

(When reassembling)

Tightening torque	Engine mounting nut	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft
	Cushion mounting nut	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft
	Engine support mounting screw	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft



5.1.9 Draining coolant and removing outer engine parts

CAUTION

- Never open the radiator cap while operating or immediately after stopping. Otherwise, hot water will spout out from the radiator. Wait for more than ten minutes to cool the radiator, before opening the cap.

- Connect the engine stands (9) to the crankcase.
- Open the radiator drain plug, and remove radiator cap to completely drain the coolant.
- After all coolant is drained, close the drain plug.
- Loosen the inlet hose band and the radiator hose bands, and remove the radiator (1) with the radiator hoses (2) and the air cleaner (3).
- Loosen the fan belt. Remove the alternator (6), the starter motor (8), the fan and the fan belt.

6. Remove the heat proof cover (7), the muffler (5) and the exhaust manifold.



- | | |
|-------------------|----------------------|
| (1) Radiator | (6) Alternator |
| (2) Radiator hose | (7) Heat proof cover |
| (3) Air cleaner | (8) Starter motor |
| (4) Inlet hose | (9) Engine stand |
| (5) Muffler | |

(When reassembling)

BX1880 (D722-E4)

Coolant with re-covery tank	Capacity	2.5 L 2.6 U.S.qts 2.2 Imp.qts
-----------------------------	----------	-------------------------------------

BX2380 (D902-E4)

Coolant with re-covery tank	Capacity	2.7 L 2.9 U.S.qts 2.4 Imp.qts
-----------------------------	----------	-------------------------------------

BX2680 (D1005-E4)

Coolant with re-covery tank	Capacity	3.3 L 3.5 U.S.qts 2.9 Imp.qts
-----------------------------	----------	-------------------------------------

— RELATED PAGE —


[1.1 Lubricants, fuel, and coolant on page 2-7](#)

5.2 Disassembling engine

5.2.1 Cylinder head and valve

5.2.1.1 Removing cylinder head cover

1. Disconnect the breather hose.
2. Remove the cylinder head cover nuts.
3. Remove the cylinder head cover (1).



- (1) Cylinder head cover

(When reassembling)

- Check to see if the cylinder head cover gasket is not damaged.


BX1880 and BX2380

Tightening tor-que	Cylinder head cov-er screw	9.81 to 11.2 N·m 1.00 to 1.14 kgf·m 7.24 to 8.31 lbf·ft
--------------------	----------------------------	---

BX2680

Tightening tor-que	Cylinder head cov-er screw	7.0 to 8.0 N·m 0.72 to 0.81 kgf·m 5.2 to 5.9 lbf·ft
--------------------	----------------------------	---

5.2.1.2 Removing injection pipes



- (1) Pipe clamp (2) Injection pipe

1. Loosen the screws to the pipe clamp (1).
2. Remove the injection pipes (2).

3. ENGINE


5. Disassembling and assembling

(When reassembling)

- Send compressed air into the pipes to blow out dust. Then, reassemble the pipes in the reverse order.


Tightening torque	Injection pipe retaining nut	25 to 34 N·m 2.5 to 3.5 kgf·m 18 to 25 lbf·ft
-------------------	------------------------------	---

5.2.1.3 Removing nozzle holder assembly and glow plug



- (1) Overflow pipe
(2) Lead
(3) Glow plug
(4) Nozzle holder assembly

1. Remove the overflow pipe (1).
2. Remove the nozzle holder assemblies (4).
3. Remove the copper gasket (5) and heat seal (6).



- (5) Copper gasket
(6) Heat seal

4. Remove the lead (2) from the glow plugs (3).
5. Remove the glow plugs (3).

(When reassembling)

- Replace the copper gasket and heat seal with new ones.


Tightening torque	Overflow pipe retaining nut	20 to 24 N·m 2.0 to 2.5 kgf·m 15 to 18 lbf·ft
	Nozzle holder assembly	49 to 68 N·m 5.0 to 7.0 kgf·m 37 to 50 lbf·ft
	Glow plug	7.9 to 14 N·m 0.80 to 1.5 kgf·m 5.8 to 10 lbf·ft

5.2.1.4 Removing nozzle heat seal

■ IMPORTANT

- Use a plus (phillips head) screw driver (1) that has a diameter which is bigger than the heat seal hole.

Heat seal hole	Factory specification	Approximately 6 mm (1/4 in.)
----------------	-----------------------	------------------------------------




- (1) Plus screw driver
(2) Injection nozzle
(3) Injection nozzle gasket
(4) Heat seal

1. Drive screw driver (1) lightly into the heat seal hole.
2. Turn screw driver three or four times each way.
3. While turning the screw driver, slowly pull the heat seal (4) out together with the injection nozzle gasket (3).
4. If the heat seal drops, repeat the above procedure.

(When reassembling)

- Heat seal and injection nozzle gasket must be changed when the injection nozzle is removed for cleaning or for service.

5.2.1.5 Removing rocker arm and push rod




(1) Rocker arm assembly (2) Push rod

1. Remove the rocker arm bracket screw [BX1880 (D722-E4) and BX2380 (D902-E4)] or the rocker arm bracket nut [BX2680 (D1005-E4)].
2. Remove the rocker arm assembly (1).
3. Remove the push rods (2).

(When reassembling)

■ IMPORTANT

- After installing the rocker arm, be sure to adjust the valve clearance.
- When refitting the push rods (2) into the tappets (3), make sure the push rod locates correctly into the tappet seat.



(2) Push rod (3) Tappet



BX1880 and BX2380

Tightening torque	Rocker arm bracket screw	9.81 to 11.2 N·m 1.00 to 1.15 kgf·m 7.24 to 8.31 lbf·ft
-------------------	--------------------------	---

BX2680

Tightening torque	Rocker arm bracket screw	22 to 26 N·m 2.2 to 2.7 kgf·m 16 to 19 lbf·ft
-------------------	--------------------------	---

5.2.1.6 Removing cylinder head and cylinder head gasket




(3) Pin pipe

(n) to (a):
To loosen

(a) to (n):
To tighten

1. Loosen the pipe clamps (1), and remove the water return pipe (2).



(1) Clamp (2) Return pipe

2. Remove the cylinder head screw in the order of (n) to (a) and remove the cylinder head.
3. Remove the cylinder head gasket.

(When reassembling)**NOTE**

- Do not use O-ring on the pin pipe.
- It is not necessary to retighten the cylinder head screw and to readjust valve clearance after engine warmed up.
- Replace the cylinder head gasket with a new one.
- When mounting the gasket, set it to the pin pipe holes. Be careful not to mount it reversely.
- The cylinder head should be free of scratches and dust.
- Install the cylinder head, using care not to damage the gasket.
- After applying engine oil to the thread of screws, tighten them in several steps and specified sequence (a) to (n).

BX1880 and BX2380

Tightening torque	Cylinder head screw	38 to 42 N·m 3.9 to 4.2 kgf·m 28 to 30 lbf·ft
-------------------	---------------------	---


BX2680

Tightening torque	Cylinder head screw	64 to 68 N·m 6.6 to 6.9 kgf·m 48 to 50 lbf·ft
-------------------	---------------------	---

5.2.1.7 Removing tappets**IMPORTANT**

- Do not change the combination of tappet and tappet guide.

1. Remove the tappets (1) from the crankcase.




(1) Tappet

(When reassembling)

- Visually check the contact between tappets and cams for proper rotation. If problem is found, replace tappets.
- Before installing the tappets, apply engine oil thinly around them.

5.2.1.8 Removing valves**IMPORTANT**

- Do not change the combination of valve and valve guide.




- | | |
|---------------------------|---------------------|
| (1) Valve spring replacer | (5) Valve spring |
| (2) Valve cap | (6) Valve stem seal |
| (3) Valve spring collet | (7) Valve |
| (4) Valve spring retainer | |

1. Remove the valve caps (2).
2. Remove the valve spring collet (3), pushing the valve spring retainer (4) by valve spring replacer (1).
3. Remove the valve spring retainer (4), valve spring (5) and valve stem seal (6).
4. Remove the valve (7).

(When reassembling)

- Wash the valve stem and valve guide hole, and apply engine oil sufficiently.
- After installing the valve spring collets, lightly tap the stem to assure proper fit with a plastic hammer.

5.2.1.9 Removing thermostat assembly

- | | |
|-------------------------------------|-----------------------------|
| (1) Thermostat cover mounting screw | (3) Thermostat cover gasket |
| (2) Thermostat cover | (4) Thermostat assembly |

1. Remove the thermostat cover mounting screws (1), and remove the thermostat cover (2).



2. Remove the thermostat assembly (4).

(When reassembling)

- Apply a liquid gasket (Three Bond 1215 or equivalent) only at the thermostat cover side of the gasket (3).

5.2.2 Gear case and timing gears

5.2.2.1 Removing oil pan and oil strainer



(1) Oil strainer (2) Oil pan

1. Remove the oil pan mounting screws.
2. Remove the oil pan (2).
3. Remove the oil strainer (1).

(When reassembling)

■ IMPORTANT

- **Scrape off the old adhesive completely. Wipe the sealing surface clean using waste cloth soaked with gasoline. Now apply new adhesive thick all over the contact surface. Apply the adhesive also on the center of the flange as well as on the inner wall of each screw hole.**

New adhesive	Apply	Thickness 3.0 to 5.0 mm (0.12 to 0.19 in.)
--------------	-------	--

- **Cut the nozzle of the "liquid gasket" container at its second notch. Apply "liquid gasket" about 5.0 mm (0.19 in.) thick. Within 20 minutes after the application of fluid sealant, reassemble the**

components. Wait then for about 30 minutes, and pour oil in the crankcase.

Liquid gasket	Apply	Thickness 5.0 mm 0.19 in.
---------------	-------	---------------------------------


- After cleaning the oil strainer, check to see that the filter mesh is clean, and install it.
- Visually check the O-ring, apply engine oil, and install it.
- Securely fit the O-ring to the oil strainer.
- To avoid uneven tightening, tighten oil pan mounting screws in diagonal order from the center.

5.2.2.2 Removing fan drive pulley

1. Secure the flywheel to keep it from turning.
2. Remove the fan drive pulley screw.
3. Draw out the fan drive pulley with a puller.

(When reassembling)

- Install the pulley to crankshaft, aligning the mark (1) on them (3-cylinder engine).



(1) Aligning mark

- Apply engine oil to the fan drive pulley retaining screw. And tighten it.



BX1880 and BX2380

Tightening torque	Fan drive pulley screw	118 to 127 N·m 12.1 to 12.9 kgf·m 87.1 to 93.6 lbf·ft
-------------------	------------------------	---

BX2680

Tightening torque	Fan drive pulley screw	236 to 245 N·m 24.1 to 24.9 kgf·m 174 to 180 lbf·ft
-------------------	------------------------	---

5.2.2.3 Removing gear case




- | | |
|-----------------------------------|-----------------------------------|
| (1) Gear case | (e) Bolt length = 68 mm (2.7 in.) |
| (a) Bolt length = 45 mm (1.8 in.) | (f) Bolt length = 70 mm (2.8 in.) |
| (b) Bolt length = 50 mm (2.0 in.) | (g) Bolt length = 85 mm (3.3 in.) |
| (c) Bolt length = 55 mm (2.2 in.) | (h) Nut |
| (d) Bolt length = 65 mm (2.6 in.) | |

1. Remove the fuel feed pump.
2. Remove the gear case.

(When reassembling)

- Grease thinly to the oil seal, and install it, ensuring the lip does not come off.

5.2.2.4 Removing speed control plate





- (1) Speed control plate (2) Governor spring

1. Remove the engine stop solenoid.
2. Remove the speed control plate (1).

(When reassembling)

- Apply a liquid gasket (Three Bond 1215 or equivalent) to both sides of the solenoid cover gasket and control plate gasket.
- Be careful not to drop the governor spring (2) into the crankcase.

5.2.2.5 Removing injection pump



- | | |
|----------------------|---------------------|
| (1) Notch | (4) Start spring |
| (2) Control rack pin | (5) Thrust lever |
| (3) Injection pump | (6) Governor spring |

1. Disconnect the start spring (4) on the thrust lever (5) side.
2. Align the control rack pin (2) with the notch (1) on the crankcase, and remove the injection pump (3).
3. Remove the injection pump shims.
4. In principle, the injection pump should not be disassembled.


(When reassembling)

NOTE

- Addition or reduction of shim delays or advances the injection timing.




Shim (0.05 mm (0.002 in.))	Delays or advances the injection timing	Approximately 0.0087 rad 0.50°
-------------------------------	---	--------------------------------------

- In disassembling and replacing, be sure to use the same number or new gasket shims with the same thickness.
- When installing the injection pump, insert the control rack pin (2) firmly into the groove (7) of the thrust lever of fork lever.




(7) Groove

5.2.2.6 Removing cam gear, idle gear 1, 2 and governor gear



- | | |
|--------------------|---------------------------|
| (1) Fuel cam gear | (7) Fuel camshaft stopper |
| (2) Alignment mark | (8) Fuel camshaft |
| (3) Cam gear | (9) Ball bearing |
| (4) Idle gear 1 | (10) External circlip |
| (5) Crank gear | (11) Governor shaft |
| (6) Governor gear | (12) Set screw |

1. Remove the idle gear 1 (4).
2. Remove the fuel camshaft stopper (7).
3. Draw out the fuel cam gear (1) with fuel camshaft (8).
4. Remove the camshaft stopper bolt.
5. Remove the cam gear (3) with camshaft.



(3) Cam gear

6. Remove the external circlip (10) from the governor shaft (11).
7. Remove the governor gear (6) with governor shaft (11).

NOTE

- To remove the governor shaft, follow the procedures in 5, 6 above and never remove fork lever and the max. torque limiter.


(When reassembling)

IMPORTANT

- When replacing the ball bearing of governor shaft, securely fit the ball bearing (9) to the crankcase, apply an adhesive (Three Bond 1324B or equivalent) to the set screw (12), and fasten the screw until its tapered part contacts the circumferential end of the ball bearing.
- When installing the idle gear, be sure to align the alignment marks (2) on each gears.
- Apply engine oil thinly to the fuel camshaft before installation.
- Make sure to assemble the external circlip of the governor shaft.
- Check the governor shaft for smooth rotation.

5.2.3 Piston and connecting rod


5.2.3.1 Removing connecting rod



1. Remove the connecting rod cap.

(When reassembling)

- Align the marks (a) with each other. (Face the marks toward the injection pump.)



(a) Mark

- Apply engine oil to the connecting rod screws and lightly screw it in by hand, then tighten it to the specified torque.
If the connecting rod screw won't be screwed in smoothly, clean the threads.
If the connecting rod screw is still hard to screw in, replace it.


BX1880 and BX2380

Tightening torque	Connecting rod screw	27 to 30 N · m 2.8 to 3.0 kgf · m 20 to 22 lbf · ft
-------------------	----------------------	---

BX2680

Tightening torque	Connecting rod screw	42 to 46 N · m 4.3 to 4.6 kgf · m 31 to 33 lbf · ft
-------------------	----------------------	---

5.2.3.2 Removing pistons




1. Turn the flywheel and bring the piston to top dead center.
2. Draw out the piston upward by lightly tapping it from the bottom of the crankcase with the grip of a hammer.
3. Draw out the other piston in the same method as above.

(When reassembling)


■ IMPORTANT

- Do not change the combination of cylinder and piston. Make sure of the position of each piston by marking. For example, mark [1] on the No. 1 piston.
- When installing the piston into the cylinder, place the gaps of all the piston rings as shown in the figure.



- | | |
|---------------------|--------------------|
| (A) Top ring gap | (a) 0.79 rad (45°) |
| (B) Second ring gap | (b) 0.79 rad (45°) |
| (C) Oil ring gap | (c) 1.6 rad (90°) |
| (D) Piston pin hole | |


- Carefully insert the pistons using a piston ring compressor (1). Otherwise, their chrome-plated section may be scratched, causing trouble inside the cylinder.



(1) Piston ring compressor

- Before inserting the piston into the cylinder, apply enough engine oil to the piston.
- When inserting the piston into the cylinder, face the mark on the connecting rod to the injection pump.

5.2.3.3 Removing piston ring and connecting rod




- | | |
|------------------------|--------------------|
| (1) Top ring | (5) Piston |
| (2) Second ring | (6) Connecting rod |
| (3) Oil ring | (7) Piston pin |
| (4) Piston pin circlip | |

1. Remove the piston rings using a piston ring tool.
2. Remove the piston pin (7), and separate the connecting rod (6) from the piston (5).

(When reassembling)


NOTE

- Mark the same number on the connecting rod and the piston so as not to change the combination.
- Install the rings so that the manufacturer's mark (12) near the gap faces the top of the piston.



(12) Manufacturer's mark

- When installing the oil ring onto the piston, place the expander joint (10) on the opposite side of the oil ring gap (11).




(10) Expander joint (11) Oil ring gap

- Apply engine oil to the piston pin.
- When installing the connecting rod to the piston, immerse the piston in oil and insert the piston pin to the piston.

Temperature of oil	Factory specification	For 10 to 15 minutes 80 °C (176 °F)
--------------------	-----------------------	--

- When installing the connecting rod to the piston, align the mark (8) on the connecting rod to the fan-shaped concave (9).




(8) Mark

(9) Fan-shaped concave

5.2.4 Flywheel and crankshaft

5.2.4.1 Removing flywheel

1. Secure the flywheel to keep it from turning, using a flywheel stopper.
2. Remove all flywheel screws (1) and then remove the flywheel (2).




(1) Flywheel screw

(2) Flywheel

(When reassembling)

- Align the [1TC] mark (a) on the outer surface of the flywheel horizontally with the alignment mark (b) on the rear end plate. Now fit the flywheel in position.




(a) [1TC] mark

(b) Alignment mark

- Apply engine oil to the threads and the undercut surface of the flywheel screw and fit the screw.

Tightening torque	Flywheel screw	54 to 58 N · m 5.5 to 6.0 kgf · m 40 to 43 lbf · ft
-------------------	----------------	---

5.2.4.2 Removing bearing case cover




- (1) Bearing case cover mounting screw (Inside)
 - (2) Bearing case cover mounting screw (Outside)
 - (3) Bearing case gasket
 - (4) Bearing case cover gasket
 - (5) Oil seal
 - (6) Bearing case cover
- (a) Top mark [UP]

1. Remove the bearing case cover mounting screws.
2. Remove the bearing case cover (6).

(When reassembling)

- Fit the bearing case gasket (3) and the bearing case cover gasket (4) with correct directions.



(3) Bearing case gasket (b) Upside
(4) Bearing case cover gasket


- Install the bearing case cover (6) to position the casting mark **[UP]** on it upward.
- Apply engine oil to the oil seal (5) lip and be careful that it is not rolled when installing.
- Tighten the bearing case cover mounting screws with even force on the diagonal line.

Tightening torque	Bearing case cover mounting screw	9.81 to 11.2 N·m 1.00 to 1.15 kgf·m 7.24 to 8.31 lbf·ft
-------------------	-----------------------------------	---

5.2.4.3 Removing crankshaft assembly

■ IMPORTANT

- Be careful to protect crankshaft bearing 1 from scratches, caused by the crank gear, etc. (Wrap the gear in vinyl tape, etc.)



(1) Main bearing case screw 2

1. Remove the main bearing case screw 2 (1).
2. Pull out the crankshaft assembly.

(When reassembling)

- Clean the oil passage of the crankshaft with compressed air.
- Apply oil to the main bearing case screw 2 (1).

- Install the crankshaft assembly, aligning the screw hole of main bearing case with the screw hole of crankcase.
- Clean the oil passage of the crankshaft with compressed air.


BX1880 and BX2380

Tightening torque	Main bearing case screw 2	27 to 30 N·m 2.8 to 3.0 kgf·m 20 to 22 lbf·ft
-------------------	---------------------------	---

BX2680

Tightening torque	Main bearing case screw 2	49 to 53 N·m 5.0 to 5.4 kgf·m 37 to 39 lbf·ft
-------------------	---------------------------	---


5.2.4.4 Removing main bearing case assembly



(1) Main bearing case assembly (2) Main bearing case screw 1
(3) Thrust bearing

1. Remove the two main bearing case screws 1 (2) of each main bearing cases.
2. Remove the main bearing case from crankshaft.

(When reassembling)



(1) Main bearing case assembly (a) Alignment number
1 (b) Marking **[A]**, **[B]**, **[C]**
(2) Main bearing case screw 1

- Clean the oil passage in the main bearing cases.

- Apply clean engine oil on the bearings.
- Install the main bearing case assemblies in the original positions.
Since diameters of main bearing cases vary, install them in order of markings (b) ([A], [B], [C]) from the gear case side.
- Match the alignment numbers (a) on the main bearing case assembly 1.
- When installing the main bearing case 1 and 2, face the mark **[FLYWHEEL]** to the flywheel.
- Install the thrust bearing (3) with its oil groove facing outward.
- Make sure that the main bearing case moves smoothly after tightening the main bearing case screw 1 to the specified torque.

BX1880 and BX2380

Tightening torque	Main bearing case screw 1	13 to 15 N·m 1.4 to 1.5 kgf·m 9.6 to 11 lbf·ft
-------------------	---------------------------	--


BX2680

Tightening torque	Main bearing case screw 1	30 to 34 N·m 3.1 to 3.4 kgf·m 23 to 25 lbf·ft
-------------------	---------------------------	---

6. Servicing


6.1 Cylinder head and valve

6.1.1 Checking top clearance



(2) Crushed plastigauge (3) Scale

1. Remove the cylinder head.
2. With the piston at T.D.C., use grease to affix three or four plastigauges (1) of a diameter 1.5 mm (0.059 in.) × 5.0 to 7.0 mm (0.20 to 0.27 in.) long to the crown of the piston; keep the gauges away from the intake valve and combustion chamber fittings.



(1) Plastigauge

3. Take the piston to an intermediate position, install the cylinder head and tighten the head bolts to the specified torque.

BX1880 and BX2380

Tightening torque	Cylinder head screw	38 to 42 N·m 3.9 to 4.2 kgf·m 28 to 30 lbf·ft
-------------------	---------------------	---

BX2680

Tightening torque	Cylinder head screw	64 to 68 N·m 6.6 to 6.9 kgf·m 48 to 50 lbf·ft
-------------------	---------------------	---

4. Turn the crankshaft so the piston goes through T.D.C.
5. Remove the cylinder head and compare the width of the crushed plastigauges (2) with the scale.
6. If they are out of specification, check the oil clearance of the crank pin, journals and piston pins.

BX1880 and BX2380

Top clearance	Factory specification	0.55 to 0.70 mm 0.022 to 0.028 in.
---------------	-----------------------	---------------------------------------

NOTE

- Top clearance = Width of the crushed plastigauge (2).

BX2680

Top clearance	Factory specification	0.55 to 0.75 mm 0.022 to 0.030 in.
---------------	-----------------------	---------------------------------------

NOTE

- Top clearance = Width of the crushed plastigauge (2).


6.1.2 Checking cylinder head surface flatness

IMPORTANT


- Do not place the straightedge on the combustion chamber.

3. ENGINE

- Be sure to check the valve recessing after correcting.
1. Clean the cylinder head surface.
 2. Place a straightedge on the cylinder head's four sides and two diagonal as shown in the figure.




3. Measure the clearance with a thickness gauge.



4. If the measurement exceeds the allowable limit, correct it with a surface grinder.

Cylinder head surface flatness	Allowable limit	0.05 mm 0.002 in.
--------------------------------	-----------------	----------------------



6.1.3 Checking cylinder head flaw



- (1) Red permeative liquid (3) White developer
(2) Detergent

1. Prepare an air spray red check.
2. Clean the surface of the cylinder head with detergent (2).
3. Spray the cylinder head surface with the red permeative liquid (1). Leave it five to ten minutes after spraying.
4. Wash away the red permeative liquid on the cylinder head surface with the detergent (2).
5. Spray the cylinder head surface with white developer (3).
6. If flawed, it can be identified as red marks.

6.1.4 Checking valve recessing



(1) Cylinder head surface (B) Protrusion
(A) Recessing

1. Clean the cylinder head surface, valve face and valve seat.
2. Insert the valve into the valve guide.
3. Measure the valve recessing with a depth gauge.
4. If the measurement exceeds the allowable limit, replace the valve.

BX1880 and BX2380

Valve recessing	Factory specification	0.10 (protrusion) to 0.10 (recessing) mm 0.0039 (protrusion) to 0.0039 (recessing) in.
	Allowable limit	0.30 (recessing) mm 0.012 (recessing) in.


BX2680

Valve recessing	Factory specification	0.050 (protrusion) to 0.25 (recessing) mm 0.0020 (protrusion) to 0.0098 (recessing) in.
	Allowable limit	0.40 (recessing) mm 0.016 (recessing) in.

5. If it still exceeds the allowable limit after replacing the valve, replace the cylinder head.

6.1.5 Checking clearance between valve stem and valve guide

1. Remove carbon from the valve guide section.
2. Measure the valve stem O.D. with an outside micrometer.




BX1880 and BX2380

Valve stem O.D.	Factory specification	5.968 to 5.980 mm 0.2350 to 0.2354 in.
-----------------	-----------------------	---

BX2680

Valve stem O.D.	Factory specification	6.960 to 6.975 mm 0.2740 to 0.2746 in.
-----------------	-----------------------	---

3. Measure the valve guide I.D. with a small hole gauge, and calculate the clearance.



BX1880 and BX2380

Valve guide I.D.	Factory specification	6.010 to 6.025 mm 0.2366 to 0.2372 in.
------------------	-----------------------	---

BX2680

Valve guide I.D.	Factory specification	7.010 to 7.025 mm 0.2760 to 0.2766 in.
------------------	-----------------------	---

4. If the clearance exceeds the allowable limit, replace the valves. If it still exceeds the allowable limit, replace the valve guide.

BX1880 and BX2380


Clearance between valve stem and valve guide	Factory specification	0.030 to 0.057 mm 0.0012 to 0.0022 in.
	Allowable limit	0.10 mm 0.0039 in.

BX2680

Clearance between valve stem and valve guide	Factory specification	0.035 to 0.065 mm 0.0014 to 0.0026 in.
	Allowable limit	0.10 mm 0.0039 in.

6.1.6 Replacing valve guide**■ IMPORTANT**

- Do not hit the valve guide with a hammer during replacement.



(A) When removing

(B) When installing

(When removing)

- Press out the used valve guide using a valve guide replacing tool. (See "Special tools".)

(When installing)

- Clean a new valve guide and valve guide bore, and apply engine oil to them.
- Press in a new valve guide using a valve guide replacing tool.
- Ream precisely the I.D. of the valve guide to the specified dimension.

BX1880 and BX2380

Valve guide I.D. (Intake and exhaust)	Factory specification	6.010 to 6.025 mm 0.2366 to 0.2372 in.
---------------------------------------	-----------------------	---

BX2680



Valve guide I.D. (Intake and exhaust)	Factory specification	7.010 to 7.025 mm 0.2760 to 0.2766 in.
---------------------------------------	-----------------------	---

RELATED PAGE

- [Special tools for engine on page 2-55](#)

6.1.7 Checking valve seating

- Coat the valve face lightly with prussian blue and put the valve on its seat to check the contact.



(1) Correct

(2) Incorrect

(3) Incorrect

- If the valve does not seat all the way around the valve seat or the valve contact is less than 70%, correct the valve seating as follows.
- If the valve contact does not comply with the reference value, replace the valve or correct the contact of valve seating.


Valve seat width	Factory specification	2.12 mm 0.835 in.
------------------	-----------------------	----------------------

6.1.8 Correcting valve

NOTE

- Before correcting the valve and seat, check the valve stem and the I.D. of valve guide section, and repair them if necessary.

- Correct the valve with a valve refacer.



BX1880 and BX2380

Valve face angle	Factory specification	0.79 rad 45°
------------------	-----------------------	-----------------



BX2680

Valve face angle	Factory specification	IN.	1.0 rad 60°
		EX.	0.79 rad 45°

6.1.9 Correcting valve seat

NOTE

- Before correcting the valve and seat, check the valve stem and the I.D. of valve guide section, and repair them if necessary.



- (1) Valve seat width
(2) Identical dimensions
(A) Check contact
(B) Correct seat width
(C) Check contact
(a) 0.26 rad (15°) or 0.52 rad (30°)
(b) 0.79 rad (45°) or 1.0 rad (60°)
(c) 0.52 rad (30°) or 0.26 rad (15°)

- Slightly correct the seat surface with a 1.0 rad (60°) (intake valve) or 0.79 rad (45°) (exhaust valve) valve seat cutter.

BX1880 and BX2380

Valve seat angle	Factory specification	0.79 rad 45°
------------------	-----------------------	-----------------

BX2680

Valve seat angle	Factory specification	IN.	1.0 rad 60°
		EX.	0.79 rad 45°

- Resurface the seat surface with a 0.52 rad (30°) valve seat cutter to intake valve seat and with a 0.26 rad (15°) valve seat cutter to exhaust valve seat so that the width is close to specified valve seat width (2.12 mm, 0.0835 in.).
- After resurfacing the seat, inspect for even valve seating, apply a thin film of compound between the valve face and valve seat, and fit them with valve lapping tool.
- Check the valve seating with prussian blue. The valve seating surface should show good contact all the way around.


NOTE

- After correcting the valve seat, be sure to check the valve recessing.

6.1.10 Lapping valve


■ IMPORTANT

- When valve lapping is performed, be sure to check the valve recessing and adjust the valve clearance after assembling the valve.



- Apply compound evenly to the valve lapping surface.
- Insert the valve into the valve guide. Lap the valve onto its seat with a valve flapper or screwdriver.
- After lapping the valve, wash the compound away and apply oil, then repeat valve lapping with oil.
- Apply prussian blue to the contact surface to check the seated rate. If it is less than 70%, repeat valve lapping again.

6.1.11 Checking free length and tilt of valve spring



(A) Tilt (B) Free length

- Measure the free length (B) of valve spring with vernier calipers. If the measurement is less than the allowable limit, replace it.

BX1880 and BX2380

Free length (B)	Factory specification	31.3 to 31.8 mm 1.24 to 1.25 in.
	Allowable limit	28.4 mm 1.12 in.

BX2680

Free length (B)	Factory specification	37.0 to 37.5 mm 1.46 to 1.47 in.
	Allowable limit	36.5 mm 1.44 in.

- Put the valve spring on a surface plate, place a square on the side of the valve spring.
- Check to see if the entire side is in contact with the square. Rotate the valve spring and measure the maximum tilt (A). If the measurement exceeds the allowable limit, replace it.

BX1880 and BX2380


Tilt (A)	Allowable limit	1.2 mm 0.047 in.
----------	-----------------	---------------------

BX2680

Tilt (A)	Allowable limit	1.0 mm 0.039 in.
----------	-----------------	---------------------

- Check the entire surface of the valve spring for scratches. If there is any problem, replace it.

6.1.12 Checking valve spring setting load



- Place the valve spring on a tester and compress it to the same length it is actually compressed in the engine.
- Read the compression load on the gauge.

- If the measurement is less than the allowable limit, replace it.

BX1880 and BX2380

Setting load / Setting length	Factory specification	65 N / 27.0 mm 6.6 kgf / 27.0 mm 15 lbf / 1.06 in.
	Allowable limit	55 N / 27.0 mm 5.6 kgf / 27.0 mm 12 lbf / 1.06 in.

BX2680

Setting load / Setting length	Factory specification	117.4 N / 31.0 mm 11.97 kgf / 31.0 mm 26.39 lbf / 1.22 in.
	Allowable limit	100.0 N / 31.0 mm 10.20 kgf / 31.0 mm 22.48 lbf / 1.22 in.

6.1.13 Checking oil clearance between rocker arm and rocker arm shaft



- Measure the rocker arm shaft O.D. with an outside micrometer.

BX1880 and BX2380

Rocker arm shaft O.D.	Factory specification	10.473 to 10.484 mm 0.41233 to 0.41275 in.
-----------------------	-----------------------	---

BX2680

Rocker arm shaft O.D.	Factory specification	11.973 to 11.984 mm 0.47138 to 0.47181 in.
-----------------------	-----------------------	---

- Measure the rocker arm I.D. with an inside micrometer, and then calculate the oil clearance.

BX1880 and BX2380

Rocker arm I.D.	Factory specification	10.500 to 10.518 mm 0.41339 to 0.41409 in.
-----------------	-----------------------	---

BX2680

Rocker arm I.D.	Factory specification	12.000 to 12.018 mm 0.47244 to 0.47314 in.
-----------------	-----------------------	---

- If the oil clearance exceeds the allowable limit, replace the rocker arm and measure the oil clearance again. If it still exceeds the allowable limit, replace also the rocker arm shaft.


BX1880 and BX2380

Oil clearance between rocker arm and rocker arm shaft	Factory specification	0.016 to 0.045 mm 0.00063 to 0.0017 in.
	Allowable limit	0.15 mm 0.0059 in.

BX2680

Oil clearance between rocker arm and rocker arm shaft	Factory specification	0.016 to 0.045 mm 0.00063 to 0.0017 in.
	Allowable limit	0.10 mm 0.0039 in.


6.1.14 Checking push rod alignment



- Place the push rod on V blocks.
- Measure the push rod alignment.
- If the measurement exceeds the allowable limit, replace the push rod.

Push rod alignment	Allowable limit	0.25 mm 0.0098 in.
--------------------	-----------------	-----------------------

6.1.15 Checking oil clearance between tappet and tappet guide bore



1. Measure the tappet O.D. with an outside micrometer.

BX1880 and BX2380

Tappet O.D.	Factory specification	17.966 to 17.984 mm 0.70733 to 0.70803 in.
-------------	-----------------------	---

BX2680

Tappet O.D.	Factory specification	19.959 to 19.980 mm 0.78579 to 0.78661 in.
-------------	-----------------------	---

2. Measure the I.D. of the tappet guide bore with a cylinder gauge, and calculate the oil clearance.

BX1880 and BX2380

Tappet guide bore I.D.	Factory specification	18.000 to 18.018 mm 0.70867 to 0.70937 in.
------------------------	-----------------------	---

BX2680

Tappet guide bore I.D.	Factory specification	20.000 to 20.021 mm 0.78740 to 0.78822 in.
------------------------	-----------------------	---

3. If the oil clearance exceeds the allowable limit or the tappet is damaged, replace the tappet.

BX1880 and BX2380



Oil clearance between tappet and tappet guide bore	Factory specification	0.016 to 0.052 mm 0.00063 to 0.0020 in.
	Allowable limit	0.10 mm 0.0039 in.

BX2680

Oil clearance between tappet and tappet guide bore	Factory specification	0.020 to 0.062 mm 0.00079 to 0.0024 in.
	Allowable limit	0.07 mm 0.003 in.

6.2 Timing gears, camshaft and governor gear

6.2.1 Checking timing gear backlash



[A] D902

[B] D1005-E4

1. Set a dial indicator (lever type) with its tip on the gear tooth.
2. Move the gear to measure the backlash, holding its mating gear.

- If the backlash exceeds the allowable limit, check the oil clearance of the shafts and the gear.

BX1880 and BX2380


Backlash between idle gear and crank gear	Factory specification	0.0430 to 0.124 mm 0.00170 to 0.00488 in.
	Allowable limit	0.15 mm 0.0059 in.
Backlash between idle gear and cam gear	Factory specification	0.0470 to 0.123 mm 0.00185 to 0.00484 in.
	Allowable limit	0.15 mm 0.0059 in.
Backlash between idle gear and injection pump gear	Factory specification	0.0460 to 0.124 mm 0.00182 to 0.00488 in.
	Allowable limit	0.15 mm 0.0059 in.
Backlash between oil pump drive gear and crank gear	Factory specification	0.0410 to 0.123 mm 0.00162 to 0.00484 in.
	Allowable limit	0.15 mm 0.0059 in.

BX2680

Backlash between idle gear 1 and crank gear	Factory specification	0.0320 to 0.115 mm 0.00126 to 0.00452 in.
	Allowable limit	0.15 mm 0.0059 in.
Backlash between idle gear 1 and cam gear	Factory specification	0.0360 to 0.114 mm 0.00142 to 0.00448 in.
	Allowable limit	0.15 mm 0.0059 in.
Backlash between idle gear 1 and injection pump gear	Factory specification	0.0340 to 0.116 mm 0.00134 to 0.00456 in.
	Allowable limit	0.15 mm 0.0059 in.

- If the oil clearance is proper, replace the gear.

6.2.2 Checking idle gear 1 side clearance




- Set a dial indicator with its tip on the idle gear.

- Measure the side clearance by moving the idle gear to the front and rear.
- If the measurement exceeds the allowable limit, replace the idle gear collar.

Idle gear 1 side clearance	Factory specification	0.20 to 0.51 mm 0.0079 to 0.020 in.
	Allowable limit	0.80 mm 0.031 in.

6.2.3 Checking camshaft side clearance



- Set a dial indicator with its tip on the camshaft.
- Measure the side clearance by moving the cam gear to the front to rear.
- If the measurement exceeds the allowable limit, replace the camshaft stopper.


BX1880 and BX2380

Camshaft side clearance	Factory specification	0.15 to 0.31 mm 0.0059 to 0.012 in.
	Allowable limit	0.50 mm 0.020 in.

BX2680

Camshaft side clearance	Factory specification	0.070 to 0.22 mm 0.0028 to 0.0086 in.
	Allowable limit	0.30 mm 0.012 in.


6.2.4 Checking camshaft alignment



1. Support the camshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the camshaft alignment.
4. If the measurement exceeds the allowable limit, replace the camshaft.

Camshaft alignment	Allowable limit	0.01 mm 0.0004 in.
--------------------	-----------------	-----------------------

6.2.5 Checking cam height



1. Measure the height of the cam at its highest point with an outside micrometer.
2. If the measurement is less than the allowable limit, replace the camshaft.

BX1880 and BX2380


Cam height of intake and exhaust	Factory specification	26.88 mm 1.058 in.
	Allowable limit	26.83 mm 1.056 in.

BX2680

Cam height of intake	Factory specification	28.80 mm 1.134 in.
	Allowable limit	28.75 mm 1.132 in.
Cam height of exhaust	Factory specification	29.00 mm 1.142 in.
	Allowable limit	28.95 mm 1.140 in.

6.2.6 Checking oil clearance of camshaft journal

1. Measure the camshaft journal O.D. with an outside micrometer.




BX1880 and BX2380

Camshaft journal O.D.	Factory specification	32.934 to 32.950 mm 1.2967 to 1.2972 in.
-----------------------	-----------------------	---

BX2680

Camshaft journal O.D.	Factory specification	35.934 to 35.950 mm 1.4148 to 1.4153 in.
-----------------------	-----------------------	---

2. Measure the cylinder block bore I.D. for camshaft with a cylinder gauge, and calculate the oil clearance.



BX1880 and BX2380

Camshaft bearing I.D. (Cylinder block bore I.D.)	Factory specification	33.000 to 33.025 mm 1.2993 to 1.3001 in.
--	-----------------------	---

BX2680

Camshaft bearing I.D. (Cylinder block bore I.D.)	Factory specification	36.000 to 36.025 mm 1.4174 to 1.4183 in.
--	-----------------------	---

3. If the oil clearance exceeds the allowable limit, replace the camshaft.


BX1880 and BX2380

Oil clearance of camshaft journal	Factory specification	0.050 to 0.091 mm 0.0020 to 0.0035 in.
	Allowable limit	0.15 mm 0.0059 in.

BX2680

Oil clearance of camshaft journal	Factory specification	0.050 to 0.091 mm 0.0020 to 0.0035 in.
	Allowable limit	0.15 mm 0.0059 in.

6.2.7 Checking oil clearance between idle gear 1 shaft and idle gear bushing



1. Measure the idle gear shaft O.D. with an outside micrometer.

BX1880 and BX2380

Idle gear shaft 1 O.D.	Factory specification	19.967 to 19.980 mm 0.78611 to 0.78661 in.
------------------------	-----------------------	---

BX2680

Idle gear shaft 1 O.D.	Factory specification	25.967 to 25.980 mm 1.0224 to 1.0228 in.
------------------------	-----------------------	---

2. Measure the idle gear bushing I.D. with an inside micrometer, and calculate the oil clearance.

BX1880 and BX2380

Idle gear bushing 1 I.D.	Factory specification	20.000 to 20.051 mm 0.78741 to 0.78940 in.
--------------------------	-----------------------	---

BX2680

Idle gear bushing 1 I.D.	Factory specification	26.000 to 26.021 mm 1.0237 to 1.0244 in.
--------------------------	-----------------------	---

3. If the oil clearance exceeds the allowable limit, replace the bushing. If it still exceeds the allowable limit, replace the idle gear shaft.


BX1880 and BX2380

Oil clearance between idle gear shaft 1 and idle gear bushing	Factory specification	0.020 to 0.084 mm 0.00079 to 0.0033 in.
	Allowable limit	0.10 mm 0.0039 in.

BX2680

Oil clearance between idle gear shaft 1 and idle gear bushing	Factory specification	0.020 to 0.054 mm 0.00079 to 0.0021 in.
	Allowable limit	0.10 mm 0.0039 in.

6.2.8 Replacing idle gear bushing



(A) When removing

(B) When installing

(When removing)

1. Press out the used idle gear bushing using an idle gear bushing replacing tool.


(When installing)

1. Clean a new idle gear bushing and idle gear bore, and apply engine oil to them.
2. Press in a new bushing using an idle gear bushing replacing tool, until it is flush with the end of the idle gear.

6.3 Piston and connecting rod

6.3.1 Checking piston pin bore I.D.

1. Measure the piston pin bore I.D. in both the horizontal and vertical directions with a cylinder gauge.



2. If the measurement exceeds the allowable limit, replace the piston.


BX1880 and BX2380

Piston pin bore I.D.	Factory specification	20.000 to 20.013 mm 0.78740 to 0.78791 in.
	Allowable limit	20.05 mm 0.7894 in.

BX2680

Piston pin bore I.D.	Factory specification	22.000 to 22.013 mm 0.86615 to 0.86665 in.
	Allowable limit	22.03 mm 0.8673 in.

6.3.2 Checking oil clearance between piston pin and small end bushing



1. Measure the piston pin O.D. where it contacts the bushing with an outside micrometer.

BX1880 and BX2380

Piston pin O.D.	Factory specification	20.002 to 20.011 mm 0.78748 to 0.78783 in.
-----------------	-----------------------	---

BX2680

Piston pin O.D.	Factory specification	22.002 to 22.011 mm 0.86622 to 0.86657 in.
-----------------	-----------------------	---

2. Measure the small end bushing I.D. with an inside micrometer, and calculate the oil clearance.

BX1880 and BX2380

Small end bushing I.D.	Factory specification	20.025 to 20.040 mm 0.78839 to 0.78897 in.
------------------------	-----------------------	---

BX2680

Small end bushing I.D.	Factory specification	22.025 to 22.040 mm 0.86713 to 0.86771 in.
------------------------	-----------------------	---

- If the oil clearance exceeds the allowable limit, replace the bushing. If it still exceeds the allowable limit, replace the piston pin.



BX1880 and BX2380

Oil clearance between piston pin and small end bushing	Factory specification	0.015 to 0.075 mm 0.00059 to 0.0029 in.
	Allowable limit	0.15 mm 0.0059 in.

BX2680

Oil clearance between piston pin and small end bushing	Factory specification	0.014 to 0.038 mm 0.00056 to 0.0014 in.
	Allowable limit	0.15 mm 0.0059 in.

6.3.3 Replacing small end bushing



- (1) Seam
(2) Oil hole
(A) When removing
(B) When installing
(a) 0.79 rad (45°)

BX1880 and BX2380

Oil clearance between piston pin and small end bushing (Spare parts)	Factory specification	0.015 to 0.075 mm 0.00059 to 0.0029 in.
	Allowable limit	0.15 mm 0.0059 in.

BX2680

Oil clearance between piston pin and small end bushing (Spare parts)	Factory specification	0.015 to 0.038 mm 0.00056 to 0.0014 in.
	Allowable limit	0.15 mm 0.0059 in.

BX1880 and BX2380

Small end bushing I.D. (Spare parts)	Factory specification	20.026 to 20.077 mm 0.78843 to 0.79043 in.
--------------------------------------	-----------------------	---

BX2680

Small end bushing I.D. (Spare parts)	Factory specification	22.025 to 22.040 mm 0.86713 to 0.86771 in.
--------------------------------------	-----------------------	---

(When removing)

- Press out the used bushing using a small end bushing replacing tool. (See "Special tools".)


(When installing)

- Clean a new small end bushing and bore, and apply engine oil to them.
- Using a small end bushing replacing tool, press in a new bushing (service parts) be careful to see that the connecting rod oil hole matches the bushing hole.

6.3.4 Checking connecting rod alignment

NOTE

- Since the I.D. of the connecting rod small end bushing is the basis of this check, check bushing for wear beforehand.




- Install the piston pin into the connecting rod.
- Install the connecting rod on the connecting rod alignment tool.

- Put a gauge over the piston pin, and move it against the face plate.
- If the gauge does not fit squarely against the face plate, measure the space between the pin of the gauge and the face plate.
- If the measurement exceeds the allowable limit, replace the connecting rod.

Connecting rod alignment	Allowable limit	0.05 mm 0.002 in.
--------------------------	-----------------	----------------------

6.3.5 Checking piston ring gap

- Insert the piston ring into the lower part of the cylinder (the least worn out part) with a piston.
- Measure the ring gap with a thickness gauge.



- If the measurement exceeds the allowable limit, replace the piston ring.

BX1880

Piston ring gap	Top ring	Factory specification	0.15 to 0.30 mm 0.0059 to 0.011 in.
		Allowable limit	1.20 mm 0.0472 in.
	Second ring	Factory specification	0.30 to 0.45 mm 0.012 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.
	Oil ring	Factory specification	0.15 to 0.30 mm 0.0059 to 0.011 in.
		Allowable limit	1.20 mm 0.0472 in.

BX2380

Piston ring gap	Top ring	Factory specification	0.20 to 0.35 mm 0.0079 to 0.013 in.
		Allowable limit	1.25 mm 0.0492 in.
	Second ring	Factory specification	0.35 to 0.50 mm 0.014 to 0.019 in.
		Allowable limit	1.25 mm 0.0492 in.
	Oil ring	Factory specification	0.20 to 0.35 mm 0.0079 to 0.013 in.
		Allowable limit	1.25 mm 0.0492 in.


BX2680

Piston ring gap	Top ring	Factory specification	0.30 to 0.45 mm 0.012 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.
	Second ring	Factory specification	0.30 to 0.45 mm 0.012 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.
	Oil ring	Factory specification	0.25 to 0.40 mm 0.0099 to 0.015 in.
		Allowable limit	1.25 mm 0.0492 in.

6.3.6 Checking clearance between piston ring and piston ring groove

- Clean the rings and the ring grooves, and install each ring in its groove.

- Measure the clearance between the ring and the groove with a feeler gauge or depth gauge.



- If the clearance exceeds the allowable limit, replace the piston ring.

BX1880 and BX2380

Clearance between piston ring and piston ring groove	Second ring	Factory specification	0.0900 to 0.120 mm 0.00355 to 0.00472 in.
		Allowable limit	0.15 mm 0.0059 in.
	Oil ring	Factory specification	0.040 to 0.080 mm 0.0016 to 0.0031 in.
		Allowable limit	0.15 mm 0.0059 in.


BX2680

Clearance between piston ring and piston ring groove	Second ring	Factory specification	0.0850 to 0.112 mm 0.00335 to 0.00440 in.
		Allowable limit	0.2 mm 0.008 in.
	Oil ring	Factory specification	0.020 to 0.060 mm 0.00079 to 0.0023 in.
		Allowable limit	0.15 mm 0.0059 in.

- If the clearance still exceeds the allowable limit with new ring, replace the piston.

6.4 Crankshaft

6.4.1 Checking crankshaft side clearance




- Set a dial indicator with its tip on the end of the crankshaft.
- Measure the side clearance by moving the crankshaft to the front and rear.
- If the measurement exceeds the allowable limit, replace the thrust bearings.

Crankshaft side clearance	Factory specification	0.15 to 0.31 mm 0.0059 to 0.012 in.
	Allowable limit	0.50 mm 0.020 in.

4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an oversize one referring to the table and figure.

(Reference)



Oversize thrust bearing (BX1880 and BX2380)

Oversize	Bearing	Code number	Marking
0.20 mm 0.0079 in.	Thrust bearing 1 02	15261-23950	020 OS
	Thrust bearing 2 02	15261-23970	020 OS
0.40 mm 0.016 in.	Thrust bearing 1 04	15261-23960	040 OS
	Thrust bearing 2 04	15261-23980	040 OS

Oversize dimensions of crankshaft journal (BX1880 and BX2380)

Oversize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	46.10 to 46.30 mm 1.815 to 1.822 in.	46.30 to 46.50 mm 1.823 to 1.830 in.
Dimension B	23.40 to 23.45 mm 0.9213 to 0.9232 in.	23.80 to 23.85 mm 0.9370 to 0.9389 in.
Dimension C	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius


The crankshaft journal must be fine-finished to higher than Rmax. = 0.8S

Oversize dimensions of crankshaft journal (BX2680)

Oversize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	51.50 to 51.70 mm 2.028 to 2.035 in.	51.60 to 51.80 mm 2.032 to 2.039 in.
Dimension B	28.20 to 28.25 mm 1.111 to 1.112 in.	28.40 to 28.45 mm 1.119 to 1.120 in.
Dimension C	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius

The crankshaft journal must be fine-finished to higher than Rmax. = 0.8S

6.4.2 Checking crankshaft alignment




1. Support the crankshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the crankshaft alignment.
4. If the measurement exceeds the allowable limit, replace the crankshaft.

Crankshaft alignment	Allowable limit	0.02 mm 0.0008 in.
----------------------	-----------------	-----------------------

6.4.3 Checking oil clearance between crankpin and crankpin bearing

NOTE

- Never insert the plastigauge into the crankpin oil hole.
- Be sure not to move the crankshaft while the connecting rod screws are tightened.



BX1880 and BX2380

Crankpin O.D.	Factory specification	33.959 to 33.975 mm 1.3370 to 1.3375 in.
Crankpin bearing I.D.		33.995 to 34.010 mm 1.3384 to 1.3389 in.

BX2680

Crankpin O.D.	Factory specification	39.959 to 39.975 mm 1.5732 to 1.5738 in.
Crankpin bearing I.D.		40.040 to 40.050 mm 1.5764 to 1.5767 in.

1. Clean the crankpin and crankpin bearing.
2. Put a strip of plastigauge on the center of the crankpin.
3. Install the connecting rod cap and tighten the connecting rod screws to the specified torque, and remove the cap again.
4. Measure the amount of the flattening with the scale, and get the oil clearance.
5. If the oil clearance exceeds the allowable limit, replace the crankpin bearing.


BX1880 and BX2380

Oil clearance between crankpin and crankpin bearing	Factory specification	0.020 to 0.051 mm 0.00079 to 0.0020 in.
	Allowable limit	0.15 mm 0.0059 in.

BX2680

Oil clearance between crankpin and crankpin bearing	Factory specification	0.029 to 0.091 mm 0.0011 to 0.0036 in.
	Allowable limit	0.20 mm 0.0079 in.

6. If the same size bearing is useless because of the crankpin wear, replace it with an undersize one referring to the table and figure.



Undersize crankpin bearing (BX1880 and BX2380)

Undersize	Bearing	Code number	Marking
0.20 mm 0.0079 in.	Crankpin bearing 02	15861-22970	020 US
0.40 mm 0.016 in.	Crankpin bearing 04	15861-22980	040 US

Undersize dimensions of crankpin (BX1880 and BX2380)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	33.759 to 33.775 mm dia. 1.3291 to 1.3297 in. dia.	33.559 to 33.575 mm dia. 1.3213 to 1.3218 in. dia.

The crankshaft journal must be fine-finished to higher than Rmax. = 0.8S

* Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

Undersize dimensions of crankpin (BX2680)


Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.8 to 3.2 mm radius 0.11 to 0.12 in. radius	2.8 to 3.2 mm radius 0.11 to 0.12 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief

(Continued)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension C	39.759 to 39.775 mm dia. 1.5654 to 1.5659 in. dia.	39.559 to 39.575 mm dia. 1.5575 to 1.5580 in. dia.
The crankshaft journal must be fine-finished to higher than Rmax. = 0.8S		

6.4.4 Checking oil clearance between crankshaft journal and crankshaft bearing 1

1. Measure the O.D. of the crankshaft front journal with an outside micrometer.



BX1880

Crankshaft journal O.D.	Factory specification	39.934 to 39.950 mm 1.5722 to 1.5728 in.
-------------------------	-----------------------	---


BX2380

Crankshaft journal O.D.	Factory specification	43.934 to 43.950 mm 1.7297 to 1.7303 in.
-------------------------	-----------------------	---

BX2680

Crankshaft journal O.D.	Factory specification	47.934 to 47.950 mm 1.8872 to 1.8877 in.
-------------------------	-----------------------	---

2. Measure the I.D. of the crankshaft bearing 1 with an inside micrometer, and calculate the oil clearance.



BX1880

Crankshaft bearing 1 I.D.	Factory specification	39.984 to 40.040 mm 1.5742 to 1.5763 in.
---------------------------	-----------------------	---

BX2380

Crankshaft bearing 1 I.D.	Factory specification	43.984 to 44.040 mm 1.7317 to 1.7338 in.
---------------------------	-----------------------	---

BX2680

Crankshaft bearing 1 I.D.	Factory specification	47.984 to 48.048 mm 1.8892 to 1.8916 in.
---------------------------	-----------------------	---

3. If the oil clearance exceeds the allowable limit, replace the crankshaft bearing 1.

BX1880

Oil clearance between crankshaft journal and crankshaft bearing 1	Factory specification	0.0340 to 0.114 mm 0.00134 to 0.00448 in.
	Allowable limit	0.20 mm 0.0079 in.

BX2380


Oil clearance between crankshaft journal and crankshaft bearing 1	Factory specification	0.0340 to 0.106 mm 0.00134 to 0.00417 in.
	Allowable limit	0.20 mm 0.0079 in.

BX2680

Oil clearance between crankshaft journal and crankshaft bearing 1	Factory specification	0.0340 to 0.114 mm 0.00134 to 0.00448 in.
	Allowable limit	0.20 mm 0.0079 in.

4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and the figure.

(Reference)



Undersize crankshaft bearing 1 (BX1880)

Undersize	Bearing	Code number	Marking
0.20 mm 0.0079 in.	Crankshaft bearing 1 02	15861-23910	020 US
0.40 mm 0.016 in.	Crankshaft bearing 1 04	15861-23920	040 US

Undersize crankshaft bearing 1 (BX2380)

Undersize	Bearing	Code number	Marking
0.20 mm 0.0079 in.	Crankshaft bearing 1 02	1G460-23910	020 US
0.40 mm 0.016 in.	Crankshaft bearing 1 04	1G4601-23920	040 US

Undersize dimensions of crankshaft journal (BX1880)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	39.734 to 39.750 mm dia. 1.6544 to 1.5649 in. dia.	39.534 to 39.550 mm dia. 1.5565 to 1.5570 in. dia.
The crankshaft journal must be fine-finished to higher than Max. = 0.8S		

* Holes to be DE-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

Undersize dimensions of crankshaft journal (BX2380)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	43.734 to 43.750 mm dia. 1.7219 to 1.7224 in. dia.	43.534 to 43.550 mm dia. 1.7140 to 1.7145 in. dia.
The crankshaft journal must be fine-finished to higher than Max. = 0.8S		

Undersize dimensions of crankshaft journal (BX2680)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	47.734 to 47.750 mm dia. 1.8793 to 1.8799 in. dia.	47.534 to 47.550 mm dia. 1.8715 to 1.8720 in. dia.
The crankshaft journal must be fine-finished to higher than Max. = 0.8S		


6.4.5 Replacing crankshaft bearing 1

(When removing)

- Press out the used crankshaft bearing 1 using a crankshaft bearing 1 replacing tool.

(When installing)

- Clean a new crankshaft bearing 1 and crankshaft journal bore, and apply engine oil to them.
- Using a crankshaft bearing 1 replacing tool, press in a new bearing 1 (2) so that its seam (1) directs toward the exhaust manifold side. (See figure.)




- (1) Seam (A) Dimension
(2) Crankshaft bearing 1
(3) Cylinder block

Dimension (A)	Factory specification	0 to 0.3 mm 0 to 0.01 in.
---------------	-----------------------	------------------------------

6.4.6 Checking oil clearance between crankshaft journal and crankshaft bearing 2 and crankshaft bearing 3

NOTE

- Be sure not to move the crankshaft while the bearing case screws are tightened.



BX1880

Crankshaft journal O.D. (Flywheel side)	Factory specification	43.934 to 43.950 mm 1.7297 to 1.7303 in.
Crankshaft bearing 2 I.D.		43.978 to 43.993 mm 1.7315 to 1.7320 in.
Crankshaft journal O.D. (Intermediate)		39.934 to 39.950 mm 1.5722 to 1.5728 in.
Crankshaft bearing 3 I.D.		39.978 to 39.993 mm 1.5740 to 1.5745 in.

BX2380

Crankshaft journal O.D. (Flywheel side)	Factory specification	43.934 to 43.950 mm 1.7297 to 1.7303 in.
Crankshaft bearing 2 I.D.		43.978 to 43.993 mm 1.7315 to 1.7320 in.
Crankshaft journal O.D. (Intermediate)		43.934 to 43.950 mm 1.7297 to 1.7303 in.
Crankshaft bearing 3 I.D.		43.978 to 43.993 mm 1.7315 to 1.7320 in.

BX2680

Crankshaft journal O.D. (Flywheel side)	Factory specification	51.921 to 51.940 mm 2.0442 to 2.0448 in.
Crankshaft bearing 2 I.D.		47.984 to 48.029 mm 1.8892 to 1.8909 in.
Crankshaft journal O.D. (Intermediate)		47.934 to 47.950 mm 1.8872 to 1.8877 in.
Crankshaft bearing 3 I.D.		51.974 to 52.019 mm 2.0463 to 2.0479 in.

- Put a strip of plastigauge on the center of the journal.
- Install the bearing case and tighten the bearing case screws 1 to the specified torque, and remove the bearing case again.
- Measure the amount of the flattening with the scale and get the oil clearance.
- If the oil clearance exceeds the allowable limit, replace the crankshaft bearing 2 (crankshaft bearing 3).

BX1880 and BX2380


Oil clearance between crankshaft journal and crankshaft bearing 2 (crankshaft bearing 3)	Factory specification	0.028 to 0.059 mm 0.0011 to 0.0023 in.
	Allowable limit	0.20 mm 0.0079 in.

BX2680

Oil clearance between crankshaft journal and crankshaft bearing 2	Factory specification	0.034 to 0.095 mm 0.0014 to 0.0037 in.
	Allowable limit	0.20 mm 0.0079 in.
Oil clearance between crankshaft journal and crankshaft bearing 3	Factory specification	0.034 to 0.098 mm 0.0013 to 0.0038 in.
	Allowable limit	0.20 mm 0.0079 in.

5. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and figure.

(Reference)



Undersize crankshaft bearing 2 and 3 (0.20 mm (0.0079 in.) (BX1880))

Bearing	Code number	Marking
Crankshaft bearing 2 02	15694-23930	020 US
Crankshaft bearing 3 02	15861-23860	

Undersize crankshaft bearing 2 and 3 (0.20 mm (0.0079 in.) (BX2380))

Bearing	Code number	Marking
Crankshaft bearing 2 02	1G460-23930	020 US
Crankshaft bearing 3 02	1G460-23940	

Undersize crankshaft bearing 2 and 3 (0.40 mm (0.016 in.) (BX1880))

Bearing	Code number	Marking
Crankshaft bearing 2 04	15694-23940	040 US
Crankshaft bearing 3 04	15861-23870	

Undersize crankshaft bearing 2 and 3 (0.40 mm (0.016 in.) (BX2380))

Bearing	Code number	Marking
Crankshaft bearing 2 04	1G460-23950	040 US
Crankshaft bearing 3 04	1G460-23960	

Undersize dimensions of crankshaft journal (BX1880)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	39.734 to 39.750 mm dia. 1.5644 to 1.5649 in. dia.	39.534 to 39.550 mm dia. 1.5565 to 1.5570 in. dia.
The crankshaft journal must be fine-finished to higher than Max. = 0.8S		

* Holes to be DE-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

Undersize dimensions of crankshaft journal (BX2380)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius	1.8 to 2.2 mm radius 0.071 to 0.086 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	43.734 to 43.750 mm dia. 1.7219 to 1.7224 in. dia.	43.534 to 43.550 mm dia. 1.7140 to 1.7145 in. dia.
The crankshaft journal must be fine-finished to higher than Max. = 0.8S		

Undersize dimensions of crankshaft journal (BX2680)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.0591 in. relief	1.0 to 1.5 mm relief 0.040 to 0.0591 in. relief
Dimension C	47.734 to 47.750 mm dia. 1.8793 to 1.8799 in. dia.	47.534 to 47.550 mm dia. 1.8715 to 1.8720 in. dia.



(Continued)

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension D	51.721 to 51.740 mm dia. 2.0362 to 2.0370 in. dia.	51.521 to 51.540 mm dia. 2.0284 to 2.0291 in. dia.
The crankshaft journal must be fine-finished to higher than Max. = 0.8S		

6.5 Cylinder

6.5.1 Checking cylinder wear

1. Measure the I.D. of the cylinder at the six positions (see figure) with a cylinder gauge to find the maximum and minimum I.D.'s.



- (A) Top (a) Right-angled to piston pin
(B) Middle (b) Piston pin direction
(C) Bottom (Skirt)

2. Get the difference (maximum wear) between the maximum and the minimum I.D.'s.
3. If the wear exceeds the allowable limit, bore and hone to the oversize dimension.

BX1880

Cylinder liner I.D.	Factory specification	67.000 to 67.019 mm 2.6378 to 2.6385 in.
	Allowable limit	67.150 mm 2.6437 in.

BX2380

Cylinder liner I.D.	Factory specification	72.000 to 72.019 mm 2.8347 to 2.8353 in.
	Allowable limit	72.150 mm 2.8406 in.

BX2680


Cylinder liner I.D.	Factory specification	76.000 to 76.019 mm 2.9922 to 2.9928 in.
	Allowable limit	76.15 mm 2.998 in.

4. Visually check the cylinder wall for scratches. If deep scratches are found, the cylinder should be bored.

— RELATED PAGE —

[6.5.2 Correcting cylinder \(Oversize\) on page 3-76](#)

6.5.2 Correcting cylinder (Oversize)



- (1) Cylinder I.D. (Before correction) (2) Cylinder I.D. (Oversize)

- When the cylinder is worn beyond the allowable limit, bore and hone it to the specified dimension.

BX1880

Cylinder liner I.D.	Factory specification	67.250 to 67.269 mm 2.6477 to 2.6483 in.
	Allowable limit	67.400 mm 2.6535 in.
Finishing	Hone to 2.2 to 3.0 µm Rz (87 to 110 µin. Rz)	

BX2380

Cylinder liner I.D.	Factory specification	72.250 to 72.269 mm 2.8445 to 2.8452 in.
	Allowable limit	72.400 mm 2.8504 in.
Finishing	Hone to 2.2 to 3.0 µm Rz (87 to 110 µin. Rz)	

BX2680

Cylinder liner I.D.	Factory specification	76.500 to 76.519 mm 3.0119 to 3.0125 in.
	Allowable limit	76.65 mm 3.018 in.
Finishing	Hone to 2.2 to 3.0 µm Rz (87 to 110 µin. Rz)	

- Replace the piston and piston rings with oversize ones.

Oversize:

0.25 mm (0.0098 in.)

Marking:

025

NOTE

- When the oversize cylinder is worn beyond the allowable limit, replace the cylinder block with a new one.

6.6 Oil pump

6.6.1 Checking rotor lobe clearance

- Measure the clearance between lobes of the inner rotor and the outer rotor with a thickness gauge.




- If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Rotor lobe clearance	Factory specification	0.030 to 0.14 mm 0.0012 to 0.0055 in.
----------------------	-----------------------	--

6.6.2 Checking clearance between outer rotor and pump body


- Measure the clearance between the outer rotor and the pump body with a thickness gauge.



- If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Clearance between outer rotor and pump body	Factory specification	0.070 to 0.15 mm 0.0028 to 0.0059 in.
---	-----------------------	--

6.6.3 Checking clearance between rotor and cover





- 1. Put a strip of plastigauge onto the rotor face with grease.
- 2. Install the cover and tighten the screws.
- 3. Remove the cover carefully, and measure the amount of the flattening with the scale and get the clearance.
- 4. If the clearance exceeds the factory specifications, replace oil pump rotor assembly.

Clearance between rotor and cover	Factory specification	0.0750 to 0.135 mm 0.00296 to 0.00531 in.
-----------------------------------	-----------------------	--

6.7 Relief valve spring

6.7.1 Checking relief valve



- (1) Relief valve
- (2) Joint
- (3) Spring

- 1. Remove the oil filter base.
- 2. Check the relief valve for dirt, and the seat and ball for damage.
- 3. If damaged, replace.
- 4. Check the free length of spring.
- 5. If less than the allowable limit, replace.

Relief valve spring	Factory specification	32 mm 1.26 in.
	Allowable limit	28 mm 1.10 in.


(When reassembling)

Tightening torque	Joint	40 to 49 N·m 4.0 to 5.0 kgf·m 29 to 36 lbf·ft
-------------------	-------	---

4. TRANSAXLE

MECHANISM

1. Structure of transaxle



(1) Hydrostatic transmission
(2) PTO clutch section
(3) Range gear shift section

(4) Front wheel drive gear section
(5) Mid-PTO section
(6) PTO gear shift section

(7) Rear PTO section
(8) Differential gear section
(9) Brake section


A: Front side
B: Rear side

2. Traveling system

2.1 Hydrostatic transmission

2.1.1 Structure of hydrostatic transmission

The hydrostatic transmission consists of variable displacement piston pump, fixed displacement piston motor and valve system.



3TAAAFKP040A


- | | | | |
|--|-------------------------|-----------------------------|----------------------------|
| (1) Check and high pressure relief valve | (6) Thrust ball bearing | (12) Circlip | (18) Ball bearing |
| (2) Trunnion arm | (7) Swashplate | (13) Thrust ball bearing | (19) Pump shaft |
| (3) Center section | (8) Cradle bearing | (14) Cylinder block (Motor) | (20) Cylinder block (Pump) |
| (4) Piston spring | (9) Spring | (15) Plug | (21) Charge relief valve |
| (5) Piston | (10) Circlip | (16) Motor shaft | |
| | (11) Spring | (17) Needle bearing | |

2.1.2 Oil flow of hydrostatic transmission

The pump and motor are joined in a closed hydraulic loop and most of oil circulates within the main oil circuit. A little oil lubricates and oozes out from the clearance between the moving parts of the case. Then oil in the main oil circuit of the HST needs to be supplied a want.


The oil from the power steering circuit flows into the HST for charging.

The charge oil aids smooth operation of pistons for pump and motor. The charge oil passes through the oil filter cartridge to charge relief valve port. The rest of oil passes through the charge relief valve into the HST housing. And overflow oil from HST housing return to the transmission case.



- | | | | |
|--|--|--|-----------|
| (1) Cylinder block (Pump) | (7) High pressure relief port plug (Forward) | (13) Power steering controller | B: B port |
| (2) Swashplate | (8) Charge relief valve | (14) Hydraulic pump | C: C port |
| (3) Piston | (9) High pressure relief port plug (Reverse) | (15) Flow priority valve (Hydraulic control valve) | D: D port |
| (4) Cylinder block (Motor) | (10) PTO clutch valve | (16) Position control valve | |
| (5) Check and high pressure relief valve (Forward) | (11) PTO relief valve | (17) Oil strainer | |
| (6) Check and high pressure relief valve (Reverse) | (12) Oil filter cartridge | (18) Transmission case | |
| | | A: A port | |


When the speed control pedal is in neutral, the variable swashplate is not tilted as shown in figure. The pump pistons only rotate with cylinder block without reciprocating. Since the oil is not being pumped to the motor, the cylinder block in the motor is stationary and the output shaft does not move.



- | | | | |
|--|--|--|------------------|
| (1) Cylinder block (Pump) | (7) High pressure relief port plug (Forward) | (13) Power steering controller | B: B port |
| (2) Swashplate | | (14) Hydraulic pump | C: C port |
| (3) Piston | (8) Charge relief valve | (15) Flow priority valve (Hydraulic control valve) | D: D port |
| (4) Cylinder block (Motor) | (9) High pressure relief port plug (Reverse) | (16) Position control valve | X: High pressure |
| (5) Check and high pressure relief valve (Forward) | (10) PTO clutch valve | (17) Oil strainer | Y: Low pressure |
| (6) Check and high pressure relief valve (Reverse) | (11) PTO relief valve | (18) Transmission case | Z: Free oil |
| | (12) Oil filter cartridge | A: A port | |

2.1.2.2 Forward position

When the speed control pedal is stepped on and in forward, the variable swashplate is tilted as shown in figure. As the pump cylinder block rotates with the input shaft, oil is forced out of pump port B at high pressure. As pressure oil enters motor port D, the pistons, which align with port D, are pushed against the swashplate and slide down the inclined surface. Then the output shaft rotates with the motor cylinder block. This drives the machine forward and the angle of pump swashplate determines the output shaft speed. As the motor cylinder block continues to rotate, oil is forced out of motor port C at low pressure and returns to the pump.



- | | | | |
|--|--|--|------------------|
| (1) Cylinder block (Pump) | (7) High pressure relief port plug (Forward) | (13) Power steering controller | B: B port |
| (2) Swashplate | (8) Charge relief valve | (14) Hydraulic pump | C: C port |
| (3) Piston | (9) High pressure relief port plug (Reverse) | (15) Flow priority valve (Hydraulic control valve) | D: D port |
| (4) Cylinder block (Motor) | (10) PTO clutch valve | (16) Position control valve | X: High pressure |
| (5) Check and high pressure relief valve (Forward) | (11) PTO relief valve | (17) Oil strainer | Y: Low pressure |
| (6) Check and high pressure relief valve (Reverse) | (12) Oil filter cartridge | (18) Transmission case | Z: Free oil |
| | | A: A port | |


2.1.2.3 Reverse position

When the speed control pedal is stepped on and in reverse, the variable swashplate is tilted as shown in figure.

As the pump cylinder block rotates with the input shaft, oil is forced out of pump port A at high pressure. As pressure oil enters motor port C, the pistons, which align with port C, are pushed against the swashplate and slide down the inclined surface.

Then the output shaft rotates with the motor cylinder block. This drives the machine rearward and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port D at low pressure and returns to the pump.



- | | | | |
|--|--|--|------------------|
| (1) Cylinder block (Pump) | (7) High pressure relief port plug (Forward) | (13) Power steering controller | B: B port |
| (2) Swashplate | (8) Charge relief valve | (14) Hydraulic pump | C: C port |
| (3) Piston | (9) High pressure relief port plug (Reverse) | (15) Flow priority valve (Hydraulic control valve) | D: D port |
| (4) Cylinder block (Motor) | (10) PTO clutch valve | (16) Position control valve | X: High pressure |
| (5) Check and high pressure relief valve (Forward) | (11) PTO relief valve | (17) Oil strainer | Y: Low pressure |
| (6) Check and high pressure relief valve (Reverse) | (12) Oil filter cartridge | (18) Transmission case | Z: Free oil |
| | | A: A port | |


2.1.2.4 Relief (reverse position)

When the speed control pedal is in reverse, the variable swashplate is tilted as shown in figure.

As the pump cylinder block rotates with the input shaft, oil is forced out of pump port A at high pressure. As pressure oil enters motor port C, the pistons, which align with port C, are pushed against the swashplate and slide down the inclined surface. Since the oil pressure in the check and high pressure relief valve (reverse) increase, the high oil pressure opens the check and high pressure relief valve (reverse) and the flows through the charge relief valve to the transmission case.

Then the output shaft rotates with the motor cylinder block. This drives the machine rearward and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port D at low pressure and returns to the pump.





- | | | | |
|--|--|--|------------------|
| (1) Cylinder block (Pump) | (7) High pressure relief port plug (Forward) | (13) Power steering controller | B: B port |
| (2) Swashplate | (8) Charge relief valve | (14) Hydraulic pump | C: C port |
| (3) Piston | (9) High pressure relief port plug (Reverse) | (15) Flow priority valve (Hydraulic control valve) | D: D port |
| (4) Cylinder block (Motor) | (10) PTO clutch valve | (16) Position control valve | X: High pressure |
| (5) Check and high pressure relief valve (Forward) | (11) PTO relief valve | (17) Oil strainer | Y: Low pressure |
| (6) Check and high pressure relief valve (Reverse) | (12) Oil filter cartridge | (18) Transmission case | Z: Free oil |
| | | A: A port | |

2.1.3 Structure of HST control linkage

The speed control pedal (4) and the trunnion arm are linked with the HST pedal link (8) and the speed change rod (9). As the front of the pedal is depressed, the swashplate connected to the trunnion arm (2) rotates and forward travelling speed increases. Depressing the rear end increases reverse speed.

The trunnion arm (2) is returned to neutral position by the neutral arm and the tension of neutral spring. At the same time, the swashplate is returned to neutral, when the pedal is released. The damper (10) connected to the HST pedal link (8) restricts the movement of the linkage to prevent abrupt operation or reversing.

Moreover, the feeling of the dynamic braking can be adjusted by changing the arm (11) position of damper (10).



- | | |
|-------------------------|----------------------|
| (1) Neutral spring | (7) Cruise lock |
| (2) Trunnion arm | (8) HST pedal link |
| (3) Cruise rod | (9) Speed change rod |
| (4) Speed control pedal | (10) Damper |
| (5) Cruise arm | (11) Arm |
| (6) Cruise lock | |

(Reference)

[A]

Force of the damper is large.


[B]

Force of the damper is small.


2.1.4 Speed set linkage

2.1.4.1 Speed set

When pushing and holding the speed set rod (1) and depressing the speed control pedal (2), the desired speed is set.
When pushing the speed set rod (1), the cruise plate (5) is rotated counter clockwise.
When depressing the speed control pedal (2) forward, the HST pedal link clockwise.
Since both the cruise lock (3) of the cruise plate (5) and the cruise lock (4) of HST pedal link (6) are locked, the speed control pedal (2) is held at a selected position.



9Y1210855TXM002A



- (1) Speed set rod
- (2) Speed control pedal
- (3) Cruise lock
- (4) Cruise lock

- (5) Cruise plate
- (6) HST pedal link
- (7) Speed change rod
- (8) Damper




- (9) Trunnion arm
- (10) Release plate
- (A) Speed set rod **OFF**
- (B) Speed set rod **ON**

- (C) Speed control pedal **Forward**
- (D) Cruise lock **Locked**

2.1.4.2 When brake pedal is depressed

When the brake pedal (2) is depressed, the release plate (1) located under the brake pedal (2) is pushed down.

Since the cruise plate (3) rotates, the cruise lock (4) and (6) between the cruise plate (3) and the HST pedal link (5) are released.




- | | |
|--------------------|--|
| (1) Release plate | A: Brake pedal depressed |
| (2) Brake pedal | B: Release plate pushed down |
| (3) Cruise plate | C: Cruise plate rotates clockwise and releases the cruise lock |
| (4) Cruise lock | |
| (5) HST pedal link | |
| (6) Cruise lock | |

2.2 Range gear shift section

2.2.1 Structure of range gear shift

Two kinds of power flow are selected by operating the range gear shift lever to shift the 16T-24T shifter gear (4) on the spiral bevel pinion shaft (3).



- | | |
|-------------------------------|--------------------------|
| (1) 25T gear | (4) 16T-24T shifter gear |
| (2) 17T gear | L: Low range |
| (3) Spiral bevel pinion shaft | H: High range |

Low range

17T gear shaft (2) → Shifter gear (24T) (4) → Spiral bevel pinion shaft (3).


High range

25T gear (1) → Shifter gear (16T) (4) → Spiral bevel pinion shaft (3).

2.3 Front wheel drive section

2.3.1 Structure of front wheel drive

2-wheel drive or 4-wheel drive is selected by changing the position of 19T shifter gear (2) with the front wheel drive lever.



- | | |
|-------------------------------|--------------------------------|
| (1) Front wheel drive shaft | (4) 12T gear |
| (2) 19T shifter gear | (5) 13T-25T gear shaft |
| (3) Spiral bevel pinion shaft | A: Front wheel drive "engaged" |

Front wheel drive "disengaged"

When the front wheel drive lever is set to "disengaged" position, the 19T shifter gear (2) is neutral and power is not transmitted to the front wheel drive shaft (1).

Front wheel drive "engaged"

When the front wheel drive lever is set to "engaged" position, the 19T shifter gear (2) slides to the right to engage with 13T-25T gear shaft (5). Therefore, the power from spiral bevel pinion shaft (3) is transmitted to the front wheel drive shaft (1) through the gears.

2.4 Differential gear section

2.4.1 Structure of differential gears

During straight running


Rotation of the spiral bevel pinion is transmitted to the 37T spiral bevel gear (3), 10T final gear shaft (4), 66T final gear (7) and differential case (1). When road resistance to the right and left wheels are equal, differential pinions (2), (8) and differential side gears (5), (9) all rotate as a unit. Both rear axles received equal input, and both wheels turn at the same speed, allowing the tractor to go straight ahead.

At this time, differential pinions (2), (8) do not rotate around the differential pinion shaft (6).

During turning

When the tractor turns, the road resistance to the inside tire increases. In other words, if one of tires slows down, revolution difference is generated in the differential side gears (5), (9). When rotation of one differential side gear becomes lower than the other, differential pinions (2), (8) begin rotating around differential pinion shaft (6). The other differential side gear is increased in speed by the speed increment of differential pinion shaft (6). This means that rotation of one rear axle is slowed down and that of the other rear axle is increased. Thus, the tractor turn smoothly without power loss.

The combined number of revolutions of the right and left differential side gears is always twice that of the spiral bevel gear (3). When spiral bevel gear revolution is 100 min^{-1} (rpm), and if one of the differential side gears stops moving, the revolution of the other differential side gear becomes 200 min^{-1} (rpm) and if one rotates at 50 min^{-1} (rpm), the other rotates at 150 min^{-1} (rpm).




- | | | |
|---------------------------|-------------------------------|----------------------------|
| (1) Differential case | (4) 10T final gear shaft | (7) 66T final gear |
| (2) Differential pinion | (5) Differential side gear | (8) Differential pinion |
| (3) 37T spiral bevel gear | (6) Differential pinion shaft | (9) Differential side gear |

2.4.2 Structure of differential lock

When resistance to the right and left tires are greatly different due to ground conditions or type of work, the tire with less resistance slips and prevents the tractor from moving ahead. To compensate for this drawback, the differential lock restricts the differential action and causes both rear axles to rotate as a unit.

When the differential lock pedal is stepped on, it causes the differential lock arm (6) and differential lock shaft (7) to rotate, which will move the differential lock shift fork (8) and the differential lock shifter (2) toward the differential side gear (9). The pins on the differential lock shifter (2) go into the holes in the differential case (3) to cause the differential case (3), differential lock shifter (2) and differential side gear (9) to rotate as a unit.

Therefore, differential pinions (4), (11) are unable to rotate around differential pinion shaft (10) and identical revolutions are transmitted to the right and left rear axle (1), (5).



3TAAAFKP008B

- | | | | |
|-------------------------------|---------------------------|----------------------------------|--------------------------------|
| (1) Rear axle | (4) Differential pinion | (7) Differential lock shaft | (10) Differential pinion shaft |
| (2) Differential lock shifter | (5) Rear axle | (8) Differential lock shift fork | (11) Differential pinion |
| (3) Differential case | (6) Differential lock arm | (9) Differential side gear | |


2.5 Brake section

2.5.1 Structure of brake system

The mechanical wet disc brakes are used for the travelling brake. The brake is operated by the brake pedal (13) through the mechanical linkages and provide stable braking and require little adjustment.

The brake body is incorporated in the transmission case and axle cover filled with transmission oil.

For greater braking force, four brake discs (11) are provided at the brake shaft, and the friction plates (5) fixed to the transmission case is arranged between the brake discs (11).



9Y1210855TXM003A

- | | | |
|----------------------|---------------------|-------------------------------|
| (1) Rear axle L.H. | (6) Actuator | (11) Brake disc |
| (2) Final gear shaft | (7) Steel ball | (12) Internal circlip |
| (3) Shim | (8) Cam lever | (13) Brake pedal |
| (4) Bearing holder | (9) O-ring | (14) Parking brake lock pedal |
| (5) Friction plate | (10) Rear axle R.H. | (15) Brake rod |

A: Connects with brake cam lever and brake rod.

Travelling brake

When the brake pedal (13) is depressed, the brake rod (15) pulls the brake cam lever (8). Therefore, the cam plates also move and ride on the steel balls set in the grooves of the transmission case to press the brake disc, the final gear shaft is braked by the frictional force generated by the cam plate and brake disc.

Parking brake

When the parking brake is applied, the brake pedal (13) is locked by the parking brake lock pedal (14).

3. PTO system


3.1 Structure of PTO system

The BX 80 series equipped with hydraulic independent PTO clutch (wet multi-plates type). Therefore, the engine power engages or disengages to the PTO shafts without stopping the tractor movement.

The PTO clutch pack (2) has four clutch discs, four drive plates, pressure plate, clutch piston and so on.

The clutch piston is actuated by hydraulic oil flow from the power steering controller.

The PTO clutch valve (5) controls the hydraulic oil flow from power steering controller to the PTO clutch pack (2) by operating the PTO clutch lever through the linkage.



- (1) PTO select gear
- (2) PTO clutch pack
- (3) Rear PTO shaft


- (4) Transmission case
- (5) PTO clutch valve
- (6) PTO clutch relief valve

- (7) Oil filter cartridge
- A: From HST pump shaft
- B: To mid-PTO

- C: From power steering controller
- D: To hydrostatic transmission

3.1.1 Function of PTO clutch relief valve

The PTO clutch relief valve is provided to control the PTO operating pressure. When the oil pressure exceed the relief valve setting pressure, relief valve opens and the oil flows into PTO clutch and hydrostatic transmission.



- | | |
|-----------------------------|-----------------------------------|
| (1) Plug | (8) Poppet |
| (2) O-ring | A: From power steering controller |
| (3) Spring | B: To hydrostatic transmission |
| (4) Steel ball | C: To PTO clutch valve |
| (5) PTO clutch valve | (a) Old type |
| (6) HST charge relief valve | (b) New type |
| (7) PTO clutch relief valve | |

Relief valve setting pressure	Reference value	490 kPa 5.0 kgf/cm ² 71.2 psi
-------------------------------	-----------------	--


3.1.2 Engaged function of PTO clutch

The oil from power steering controller flows into the PTO clutch valve.

When the PTO clutch lever is set at the "engaged" position, the PTO clutch valve rotates. Oil flows from the oil line through transmission case to the PTO clutch pack.

Oil entering the clutch pack pushes the clutch piston (4) to engage the clutch pack. Power is transmitted from

the HST pump shaft (1) through the PTO clutch to the clutch gear (2) and the PTO shafts.




- | | |
|--------------------|--------------------------|
| (1) HST pump shaft | (8) Spline boss |
| (2) Clutch gear | (9) O-ring |
| (3) Clutch case | (10) Transaxle case |
| (4) Clutch piston | (11) Brake disc |
| (5) Clutch plate | A: From PTO clutch valve |
| (6) Clutch disc | B: Power to PTO shaft |
| (7) Spring | C: PTO clutch "engaged" |

3.1.3 Disengaged function of PTO clutch

When the PTO clutch lever is set at the "disengaged" position, the PTO clutch valve closes the oil passage to the PTO clutch pack. The oil in the PTO clutch pack drain into the transaxle case (10). Thus the clutch piston (4) is pushed back by the spring (7).


When the clutch piston (4) is pushed back by the spring (7), the brake plate (11) is also moved to contract the brake disc (12) so as to stop the rotation and drag of the PTO shafts.



- | | |
|--------------------|----------------------------|
| (1) HST pump shaft | (8) Spline boss |
| (2) Clutch gear | (9) O-ring |
| (3) Clutch case | (10) Transaxle case |
| (4) Clutch piston | (11) Brake plate |
| (5) Clutch plate | (12) Brake disc |
| (6) Clutch disc | C: PTO clutch "disengaged" |
| (7) Spring | |

3.2 Structure of mid and rear PTO

Three kinds of power flow are selected by operating the PTO select lever to shift the 28T PTO select gear (8) on the 11T gear shaft (9).



3TAAAFKP013A

- | | | |
|---------------------|---------------------------|-------------------------|
| (1) HST pump shaft | (4) Rear PTO shaft | (7) Mid-PTO shaft |
| (2) 12T clutch gear | (5) 23T mid-PTO gear | (8) 28T PTO select gear |
| (3) PTO clutch pack | (6) 24T mid-PTO idle gear | (9) 11T gear shaft |

Mid-PTO position "A"

PTO clutch pack (3) → 12T clutch gear (2) → 28T PTO select gear (8) → 23T mid-PTO gear (5) → 24T mid-PTO idle gear (6) → Mid-PTO shaft (7).

Rear PTO position "B"

PTO clutch pack (3) → 12T clutch gear (2) → 28T PTO select gear (8) → 11T gear shaft (9) → Rear PTO shaft (4).

Mid and rear PTO position


"A" and "B" at the same time.

4. Others

4.1 Hydraulic pump drive gear section

4.1.1 Structure of hydraulic pump drive gear

The hydraulic pump (7) is mounted to the transmission case (10) and driven by the hydraulic pump drive gear (5). The spline boss (2) mounted on the HST pump shaft drives the hydraulic pump drive gear (5) mounted on the hydraulic pump drive gear shaft (4) through the idle gear (3).



- 3TAAAFKP014A
- (1) HST pump shaft
 - (2) Spline boss
 - (3) Idle gear

- (4) Hydraulic pump drive gear shaft
- (5) Hydraulic pump drive gear

- (6) Hydraulic pump drive gear shaft
- (7) Hydraulic pump

- (8) Flow priority valve
- (9) Relief valve (3P hitch)
- (10) Transmission case

SERVICING

1. Troubleshooting for transaxle

Hydrostatic transmission

Symptom	Probable cause and checking procedure	Solution	Reference page
System will not operate in either direction	1. Oil level is low	Check oil level or fill oil to proper level	2-34
	2. Speed control pedal linkage damaged	Repair linkage	4-42
	3. Charge pressure is too low	1. Replace oil filter cartridge	2-24
		2. Check charge pressure	4-31
		3. Inspect or flush charge relief valve	4-57
	4. Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve	4-57
	5. Component parts damaged	Replace hydrostatic transmission assembly	4-43
Vibration and noise	1. Oil level is low	Check oil level or fill oil to proper level	2-34
	2. Speed control pedal linkage damaged	Repair linkage	4-42
	3. Charge pressure is too low	1. Replace oil filter cartridge	2-24
		2. Check charge pressure	4-31
		3. Inspect or flush charge relief valve	4-57
	4. Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve	4-57
	5. Component parts damaged	Replace hydrostatic transmission assembly	4-43
Loss of power	1. Oil level is low	Check oil level or fill oil to proper level	2-34
	2. Speed control pedal linkage damaged	Repair linkage	4-42
	3. Charge pressure is too low	1. Replace oil filter cartridge	2-24
		2. Check charge pressure	4-31
		3. Inspect or flush charge relief valve	4-57

(Continued)

4. TRANSAXLE

Symptom	Probable cause and checking procedure	Solution	Reference page
Loss of power	4. Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve	4-57
	5. Component parts damaged	Replace hydrostatic transmission assembly	4-43
Transmission oil over heats	1. Low transmission oil level	Fill transmission oil level up to proper level	2-24
	2. Radiator net clogged	Clean radiator net	2-21
	3. Excessive machine load	Reduce machine load	—
	4. Improper charge pressure	1. Check high relief pressure	4-32
		2. Replace transmission oil filter cartridge	2-24
		3. Replace check and high pressure relief valve	4-57
		4. Inspect and replace charge relief valve	4-31, 4-57
Machine will not stop in neutral position	1. Speed control linkage is out of adjustment or sticking	1. Repair or replace linkage	4-42
		2. Adjust neutral position	4-29
System operates in one direction only	1. Speed control linkage damaged	Repair or replace linkage	4-42
	2. Check and high pressure relief valve damaged	Replace check and high pressure relief valve	4-57, 4-57

Traveling gear shift section

Symptom	Probable cause and checking procedure	Solution	Reference page
Noise from transmission	1. Transmission oil insufficient	Refill	2-24
	2. Gear worn or broken	Replace	—
	3. Bearings worn	Replace	—
Gears do not mesh	1. Shift fork spring tension insufficient	Replace	4-55
	2. Shift fork or shifter worn	Replace	4-55
	3. Shift fork bent	Replace	4-55

Differential gear section

Symptom	Probable cause and checking procedure	Solution	Reference page
Excessive or unusual noise all the time	1. Improper backlash between spiral bevel pinion and bevel gear	Adjust	4-62
	2. Improper backlash between differential pinion and differential side gear	Adjust	4-61
	3. Bearing worn	Replace	—
	4. Insufficient or improper type of transmission fluid used	Fill or change	2-7, 2-34
Noise while turning	1. Differential pinions or differential side gears worn or damaged	Replace	4-53
	2. Differential lock binding (does not disengage)	Replace	4-53
	3. Bearing worn	Replace	—
Differential lock cannot be set	1. Differential lock shift fork damaged	Replace	4-53
	2. Differential lock shifter mounting pin damaged	Replace	4-53
	3. Differential lock pin damaged	Replace	4-53
Differential lock pedal does not return	1. Differential lock pedal return spring weaken or damaged	Replace	4-42
	2. Differential lock fork shaft rusted	Repair	4-53

4. TRANSAXLE

Brake section

Symptom	Probable cause and checking procedure	Solution	Reference page
Brake drags	1. Brake pedal free travel too small	Adjust	2-31
	2. Ball holes of actuator for uneven wear	Replace	4-63
	3. Brake pedal return spring weaken or broken	Replace	4-41
	4. Brake cam rusted	Repair	4-54
Poor braking force	1. Brake pedal free travel excessive	Adjust	2-31
	2. Brake disc worn	Replace	4-54
	3. Actuator warped	Replace	4-54
	4. Brake cam or lever damaged	Replace	4-54
	5. Transmission fluid improper	Change	2-34

PTO section

Symptom	Probable cause and checking procedure	Solution	Reference page
PTO clutch slips	1. Operating pressure is low	Check	4-35
	2. PTO clutch valve malfunctioning	Repair or replace	4-43
	3. Clutch disc or drive plate excessively worn	Replace	4-55
	4. Deformation of clutch piston	Replace	4-55
PTO shaft does not rotate	1. PTO clutch malfunctioning	Repair or replace	4-55
PTO clutch operating pressure is low	1. Transmission oil improper or insufficient	Fill or change	4-36
	2. Relief valve malfunctioning	Check or replace	4-33
PTO clutch drags	1. Brake plate excessive worn	Replace	4-55
	2. Clutch spring weaken or broken	Replace	4-55
	3. Deformation of pressure plate or steel plate	Replace	4-55

2. Servicing specifications for transaxle

Item		Factory specifications	Allowable limit
Charge relief valve [oil temperature at 50 °C (122 °F)]	Setting pressure	0.55 to 0.75 MPa 5.6 to 7.7 kgf/cm ² 80 to 100 psi	—
High pressure relief valve (forward and reverse) [oil temperature at 50 °C (122 °F)]	Setting pressure	20.1 to 21.1 MPa 205 to 215 kgf/cm ² 2920 to 3060 psi	—
PTO clutch	Operating pressure	1.0 to 1.3 MPa 11 to 13 kgf/cm ² 150 to 180 psi	—
PTO clutch disk	Thickness	1.50 to 1.70 mm 0.0591 to 0.0669 in.	1.35 mm 0.0531 in.
Separate plate	Thickness	0.9450 to 1.055 mm 0.03721 to 0.04153 in.	0.80 mm 0.031 in.
Back plate	Thickness	1.9 to 2.1 mm 0.075 to 0.082 in.	1.85 mm 0.0728 in.
Clutch piston	Flatness	—	0.15 mm 0.0059 in.
Pressure plate and steel plate	Flatness	—	0.20 mm 0.0079 in.
Clutch spring	Free length	38.5 mm 1.52 in.	34.5 mm 1.36 in.
PTO brake disk	Thickness	2.90 to 3.10 mm 0.115 to 0.122 in.	2.70 mm 0.11 in.
PTO brake plate	Thickness	1.9 to 2.1 mm 0.075 to 0.082 in.	1.85 mm 0.0728 in.
Differential case to differential side gear	Clearance	0.0500 to 0.151 mm 0.00197 to 0.00594 in.	0.30 mm 0.012 in.
• Differential case	I.D.	38.000 to 38.062 mm 1.4961 to 1.4985 in.	—
• Differential side gear	O.D.	37.911 to 37.950 mm 1.4926 to 1.4940 in.	—
Differential pinion shaft to differential pinion	Clearance	0.0800 to 0.122 mm 0.00315 to 0.00480 in.	0.30 mm 0.012 in.
• Differential pinion	I.D.	20.060 to 20.081 mm 0.78977 to 0.79059 in.	—
• Differential pinion shaft	O.D.	19.959 to 19.980 mm 0.78579 to 0.78661 in.	—
Differential pinion to differential side gear	Backlash	0.15 to 0.30 mm 0.0059 to 0.011 in.	0.40 mm 0.016 in.
Spiral bevel pinion shaft to spiral bevel gear	Backlash	0.10 to 0.30 mm 0.0040 to 0.011 in.	—
Actuator and bearing holder	Flatness	—	0.30 mm 0.012 in.
Cam plate and ball	Height	22.89 to 22.99 mm 0.9012 to 0.9051 in.	22.40 mm 0.8819 in.
Brake disk	Thickness	3.30 to 3.50 mm 0.130 to 0.137 in.	3.0 mm 0.12 in.
Friction plate	Thickness	1.92 to 2.08 mm 0.0756 to 0.0818 in.	1.52 mm 0.0598 in.

3. Tightening torques for transaxle

Item	Dimension × Pitch	N · m	kgf · m	lbf · ft
Charge relief valve checking plug	R 1/4	30 to 44	3.0 to 4.5	22 to 32
Hexagon socket head plug	R 1/4	30 to 44	3.0 to 4.5	22 to 32
Hexagon socket head screw	—	25 to 29	2.5 to 3.0	18 to 21
PTO clutch operating pressure plug	R 1/8	13 to 21	1.3 to 2.2	9.4 to 15
Lower ROPS mounting bolt and nut	—	48.0 to 55.9	4.90 to 5.70	35.5 to 41.2
Fuel tank stay mounting bolt and nut	—	48 to 55	4.9 to 5.7	36 to 41
Seat stopper bolt	—	123.5 to 147.0	12.6 to 15.0	91.2 to 108
Rear wheel mounting screw	—	109 to 129	11.1 to 13.2	80.3 to 95.4
Fender center stay mounting bolt and nut (M14)	—	98.0 to 125	11.0 to 12.8	79.6 to 92.5
Fender center stay mounting bolt and nut (M10)	—	39.2 to 45.1	4.00 to 4.60	29.0 to 33.2
Hitch plate mounting bolt and nut (M14)	—	124 to 147	12.6 to 15.0	91.2 to 108
Fender bracket mounting bolt and nut (M14)	—	124 to 147	12.6 to 15.0	91.2 to 108
Transaxle assembly mounting screw	M12	63 to 72	6.4 to 7.4	47 to 53
Transaxle assembly mounting screw	M14	124 to 147	12.6 to 15.0	91.2 to 108
Rear coupling mounting screw	M8	24 to 27	2.4 to 2.8	18 to 20
Front coupling mounting screw	M8	24 to 27	2.4 to 2.8	18 to 20
HST fan mounting screw	M8	9.8 to 11	1.0 to 1.2	7.3 to 8.6
Hydraulic control lever mounting bolt and nut	M8	18 to 20	1.8 to 2.1	13 to 15
HST front cover mounting bolt and nut	M10	18 to 20	1.8 to 2.1	13 to 15
Check and high pressure relief valve plug	—	59 to 78	6.0 to 8.0	44 to 57
Hydraulic cylinder mounting screw	—	40 to 44	4.0 to 4.5	29 to 32
Transaxle case front cover mounting bolt	M10	39 to 44	4.0 to 4.4	29 to 32
Hydraulic pump assembly mounting bolt	M6	7.9 to 8.8	0.80 to 0.90	5.8 to 6.5
Hydraulic pump assembly mounting bolt	M8	18 to 20	1.8 to 2.1	13 to 15
Rear PTO cover mounting bolt	M8	18 to 20	1.8 to 2.1	13 to 15
Rear axle case (R.H.) mounting bolt	M8	18 to 20	1.8 to 2.1	13 to 15
66T final gear mounting screw	—	61 to 70	6.2 to 7.2	45 to 52

— RELATED PAGE —


[TIGHTENING TORQUES on page 2-13](#)

4. Checking and adjusting

4.1 Adjusting maximum speed

■ IMPORTANT

- Speed control pedal should contact with adjusting bolt (A) and / or (B), when depress the speed control pedal fully.



(A) Stopper bolt length (Forward)

(B) Stopper bolt length (Reverse)

- Lift up the rear wheels safely by the rigid jacks.
- Shift the front wheel drive lever to **OFF** position.
- Depress the speed control pedal to the forward all the way and lengthen the stopper bolt (for the forward) until it touches the speed control pedal.

- Adjust the stopper bolt (for the forward) length (A) and lock it securely.

Reference

Stopper bolt length	Forward	17.0 mm 0.669 in.
---------------------	---------	----------------------

- Adjust the stopper bolt (for the reverse) length (B) and lock it securely.

Reference

Stopper bolt length	Reverse	17.5 mm 0.689 in.
---------------------	---------	----------------------

- Finally check the traveling speed or rear axle shaft rotation speed.
- If the measurement is not within the references, check the adjusting bolt length (A), (B).

Maximum rear axle shaft speed (At engine maximum speed and low range)	Reference	52.2 min ⁻¹ 52.2 rpm
--	-----------	------------------------------------

BX1880

Maximum traveling speed (At engine maximum speed)	Forward	12.0 to 13.0 km/h 7.46 to 8.07 mph
	Reverse	9.00 to 10.0 km/h 5.60 to 6.21 mph

BX2380 and BX2680

Maximum traveling speed (At engine maximum speed)	Forward	13.0 to 14.0 km/h 8.08 to 8.69 mph
	Reverse	10.0 to 11.0 km/h 6.22 to 6.83 mph


4.2 Adjusting HST neutral position

⚠ CAUTION

- Park the machine on a firm and level ground.

■ NOTE

- When adjusting the HST neutral position, loosen the locking screw approximately 2 turns counterclockwise not to drop the nut inside.



- | | |
|-----------------------------|----------------------|
| (1) Range gear shift lever | (4) Locking screw |
| (2) Front wheel drive lever | (A) 4WD off position |
| (3) Neutral adjust lever | (B) Hi position |

- Place the wooden blocks at the front and the rear side of the wheels to prevent tractor from moving.
- Lift up the rear wheels and secure with rigid jacks.
- Remove the R.H. rear wheel from the tractor.
- Shift the front wheel drive lever (2) to the 4WD off position (A).
- Start the engine.
- Operate the engine at the maximum revolution.
- Shift the range shift lever (1) to hi position (B).
- Loosen the locking screw (4).

(Forward to neutral position)

- Depress the speed control pedal to forward speed position, and release the foot from the speed control pedal. Check that the rear axle (or the wheel) stops rotating. If the rear axle (or the wheel) does not stop rotating, move the position of the locking screw (4) to the machine front side to stop rotating.



(Reverse to neutral position)

- Depress the speed control pedal to reverse speed position, and release the foot from the speed control pedal. Check the rear axle (or the wheel) stops rotating. If the rear axle (or the wheel) does not stop rotating, adjust the locking screw (4) to stop rotating.



- After adjusting the neutral position, tighten the locking screw (4) securely.

4.3 Checking and adjusting HST neutral spring (dynamic braking)




WARNING

- Do not operate if tractor moves on level ground with foot off speed control pedal.
- If tractor moves on level ground with foot off the pedal, or, if the pedal is too slow in returning to neutral position when removing the foot from the pedal, adjust the HST neutral spring.

The HST neutral spring located under the front right side of the fender can adjust returning speed of speed control pedal. Since the HST neutral spring tension is weakened, the HST tension should be checked and adjusted every 100 hours.

Checking the HST neutral spring tension

1. Start the engine and hold the maximum engine speeds.
2. Operate the machine on the concrete level ground.
3. Shift the range gear shift lever to hi position.
4. Depress the speed control pedal to forward.
5. Release the foot from the speed control pedal.
6. Check the distance (L) between the foot releasing point and the machine stopping point.
7. If the distance is more than shown below, strengthen the HST neutral spring tension so that the machine will stop in the specified distance after releasing the foot from the speed control pedal.




(A) Foot releasing point
(B) Machine stopping point

(L) Distance between foot releasing point and the machine stopping point


Distance (L) between the foot releasing point and the machine stopping point	Specification	3 m 10 ft.
--	---------------	---------------

Adjusting the HST neutral spring tension


1. Remove the step from the machine.
2. Loosen the lock nut (2).
3. Turn the adjusting nut (3) half turn to pull the HST neutral spring (1).
4. Tighten and lock the lock nut (2).
5. Start the engine and check dynamic brake as mentioned former.
6. If the machine will not stop with dynamic brake in the specified distance, adjust the neutral spring again.
 - The feeling of dynamic braking can be adjusted by changing the arm (6) position of damper (5).



9Y1210855TXS019A



9Y1210855TXS020A



9Y1210855TXS021A


- | | |
|------------------------|---------------------------------------|
| (1) HST neutral spring | (6) Arm |
| (2) Lock nut | (M) Length of adjusting rod from stay |
| (3) Adjusting nut | |
| (4) Adjusting rod | |
| (5) Damper | |

Length (M) of adjusting rod at shipping the machine from the factory	Factory specification	10 mm 0.39 in.
--	-----------------------	-------------------

4.4 Checking charge relief pressure**CAUTION**

- When checking, park the tractor on flat ground, and apply the parking brake.

1. Remove the plug (R 1/4) (1) from the front cover, then install the adaptor (R 1/4) and pressure gauge.



(1) Plug

2. Set the range gear shift lever to neutral position.
3. Start the engine and operate it at the maximum speed.
4. Read the pressure gauge to measure the charge relief pressure.
5. If the measurement is not within the factory specifications, check the charge relief valve and related hydraulic components.

Charge relief pressure	Factory specification	0.55 to 0.75 MPa 5.6 to 7.7 kgf/cm ² 80 to 100 psi
Oil temperature	Specification	50 °C 122 °F

(When reassembling)**NOTE**

- When reinstalling the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

Tightening torque	Charge relief valve checking plug (R 1/4)	30 to 44 N·m 3.0 to 4.5 kgf·m 22 to 32 lbf·ft
-------------------	---	---


4.5 Checking high relief pressure (Forward)

CAUTION

- When checking, park the tractor on flat ground, and apply the parking brake.

IMPORTANT

- Measure quickly the high relief pressure within about 10 seconds.



(1) P1 port (Reverse)

(2) P2 port (Forward)

1. Jack up the machine.
2. Remove the hexagon socket head plug (R 1/4) from P2 (2), then install the adapter, cable, and pressure gauge.
3. Start the engine and operate it at maximum speed.
4. Set the range gear shift lever to hi position.
5. Depress the speed control pedal to forward, and read the pressure gauge to measure the high relief pressure.
6. If the measurement is not the same as factory specification, check the high pressure relief valve and related hydraulic components.

High relief pressure (Forward) (Oil temperature at 50 °C, 122 °F)	Factory specification	20.1 to 21.1 MPa 205 to 215 kgf/cm ² 2920 to 3060 psi
---	-----------------------	--

(When reassembling)**NOTE**

- When reinstalling the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

Tightening torque	Hexagon socket head plug (P1 and P2 port)	30 to 44 N·m 3.0 to 4.5 kgf·m 22 to 32 lbf·ft
-------------------	---	---

4.6 Checking high relief pressure (Reverse)




CAUTION

- When checking, park the tractor on flat ground, and apply the parking brake.

IMPORTANT

- Measure quickly the high relief pressure within about 10 seconds.



(1) P1 port (Reverse) (2) P2 port (Forward)

- Jack up machine.
- Remove the hexagon socket head plug (R 1/4) from P1 (1), then install the adapter, cable and, pressure gauge.
- Start the engine and operate it at maximum speed.
- Set the range gear shift lever to hi position.
- Depress the speed control pedal to reverse, and read the pressure gauge to measure the high relief pressure.
- If the measurement is not same as factory specification, check the high pressure relief valve and related hydraulic components.

High relief pressure (Reverse) (Oil temperature at 50 °C, 122 °F)	Factory specification	20.1 to 21.1 MPa 205 to 215 kgf/cm ² 2920 to 3060 psi
---	-----------------------	--

(When reassembling)

NOTE

- When reinstalling the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

Tightening torque	Hexagon socket head plug (P1 and P2 port)	30 to 44 N · m 3.0 to 4.5 kgf · m 22 to 32 lbf · ft
-------------------	---	---

4.7 Readjusting relief valve (When HST does not work due to its loose hexagon socket head screw)





IMPORTANT

- KUBOTA does not recommend readjusting the relief valve. KUBOTA recommends replacing it with genuine parts.
- As the HST may be damaged if the pressure is set to high by mistake, be careful when adjusting it.

NOTE

- The relief pressure is set within the factory specification when shipped from the factory. But, for the purpose of after-sales services, as it is impossible to reset the pressure precisely as set in the factory, its setting range is defined as a slightly wider range within the variable specification.

Relief pressure	Factory specification	20.1 to 21.1 MPa 205 to 215 kgf/cm ² 2920 to 3060 psi
	Variable specification	15.0 to 20.0 MPa 153 to 203 kgf/cm ² 2180 to 2900 psi



1. Measure the pre-adjustment distance (A).
2. Compress the spring of the relief valve with a relief valve assembling tool (3).
3. Find the distance (A) by turning the poppet (4) with a screwdriver.

Distance (A) of relief valve (Forward)	Reference value	39.10 to 39.20 mm 1.540 to 1.543 in.
Distance (A) of relief valve (Reverse, $\phi 1.5$ mm orifice)		38.60 to 38.70 mm 1.520 to 1.523 in.

The distance (A) changes by about 0.5 mm (0.02 in.) per one turn of the poppet (4).

4. Repeat the same operation a few times to find the distance (A) as it is difficult to acquire at the first time.
5. After finding the distance (A), hold the setscrew (6) to a vice and fasten the hexagon socket head screw (2) with specified torque. On this occasion, use a copper plate, etc. for the vice jaws not to damage the setscrew (6).

Tightening torque	Hexagon socket head screw	25 to 29 N·m 2.5 to 3.0 kgf·m 18 to 21 lbf·ft
-------------------	---------------------------	---

6. Install the relief valve in the HST.
7. Check the relief pressure as indicated in "Checking high relief pressure (Forward)" and "Checking high relief pressure (Reverse)". The distance (A) is for refresh only. Make sure to check the relief pressure after readjustment.
8. If the relief pressure does not fall within the readjustment pressure range, repeat the processes of the above.

Relief valve readjusting pressure	Factory specification	15.0 to 20.0 MPa 153 to 203 kgf/cm ² 2180 to 2900 psi
-----------------------------------	-----------------------	--

The pressure changes by 1.5 MPa (15 kgf/cm², 210 psi) per 0.1 mm (0.004 in.) in distance (A).

— RELATED PAGE —

[4.5 Checking high relief pressure \(Forward\) on page 4-32](#)

[4.6 Checking high relief pressure \(Reverse\) on page 4-33](#)

- | | |
|----------------------------------|----------------|
| (1) Relief valve assembly | (5) Valve seat |
| (2) Hexagon socket head screw | (6) Setscrew |
| (3) Relief valve assembling tool | (A) Distance |
| (4) Poppet | |

4.8 Checking PTO clutch operating pressure

⚠ CAUTION

- When checking, park the tractor on flat ground, apply the parking brake.

■ IMPORTANT

- Do not connect the universal joint of the implement to the mid and rear PTO shaft.



- Lift the rear of the tractor and remove the left rear wheel.
- Remove the plug (R 1/8), then install the adapter (R 1/8), cable and pressure gauge.
- Start the engine and set at maximum speed.

Condition

Engine speed	Oil temperature
Maximum	45 to 55 °C (113 to 131 °F)

- Move the PTO clutch lever to **Engaged** position, and measure the pressure.
- If the measurement is not same as factory specifications, check the PTO relief valve and related hydraulic components.

PTO clutch operating pressure	Factory specification	1.0 to 1.3 MPa 11 to 13 kgf/cm ² 150 to 180 psi
-------------------------------	-----------------------	--

(When reassembling)

■ NOTE



- When reinstall the hexagon socket head plug, apply liquid lock (Three Bond 1324 or its equivalent) to the plug.

Tightening torque	PTO clutch valve plug (R 1/8)	13 to 21 N·m 1.3 to 2.2 kgf·m 9.4 to 15 lbf·ft
-------------------	-------------------------------	--

4.9 Adjusting brake pedal free travel

⚠ CAUTION

- Stop the engine, remove the key, lower the implement to the ground, and chock the wheels before checking brake pedal.
- Even if the brake pedal free travel is within the limitation, adjust the brake pedal following the procedure below.



- (1) Lock nut (A) Free travel
(2) Turnbuckle (B) Right rear tire

- Release the parking brake.
- Loosen the lock nut and turn the turnbuckle to adjust the rod length.
- Extend the turnbuckle one additional turn.
- Retighten the lock nut.
- Depress the brake pedal several times and make sure the brake pedal free travel is correct according to specification.

Brake pedal free travel	Factory specification	25 to 35 mm 1.0 to 1.4 in.
-------------------------	-----------------------	-------------------------------

5. Disassembling and assembling


5.1 Separating transaxle

5.1.1 Draining transmission fluid

CAUTION

- Be sure to stop the engine before checking and changing the transmission fluid.

1. Place oil pan under the tractor.
2. Remove the drain plug (1) at the bottom of the transmission case.




(1) Drain plug

3. Drain the transmission fluid and reinstall the drain plug.

(When refilling)

IMPORTANT

- Do not operate the tractor immediately after changing the transmission fluid.
- Operate the engine at medium speed for a few minutes to prevent damage to the transmission.
- Do not mix different brands oil together.
- Fill new oil from filling port after removing the filling plug (2) up to the upper notch on the dipstick (3).



(2) Filling plug

(3) Dipstick

(A) Oil level is acceptable within this range.

- After operating the engine for a few minutes, stop it and check the oil level again, if low, add oil to prescribed level.

Transmission fluid	Capacity	11.3 L 2.99 U.S.gals 2.49 Imp.gals
--------------------	----------	--

RELATED PAGE

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

5.1.2 Removing battery

WARNING

To avoid serious injury or death:

- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.


1. Remove the under panel (1).



(1) Under panel

2. Disconnect the negative cable (3) from the battery (2).


- Disconnect the positive cable (4) from the battery (2) and remove the battery.



- (2) Battery
(3) Negative cable
(4) Positive cable


5.1.3 Removing lift rod and lower link

- Remove the top link (2).
- Remove the stopper pin (6) and remove the check chain plate (3).



- (1) Lift rod L.H.
(2) Top link
(3) Check chain plate
(4) Lift rod R.H.
(5) Lower link R.H.
(6) Stopper pin
(7) Lower link L.H.

- Move the bushes (8) to inside.
- Move the shaft (9) to right side and remove the lower link as a unit.



- (8) Bush
(9) Shaft

5.1.4 Removing ROPS

- Disconnect the R.H. and L.H. hazard lamp/turn signals (3), (4) from the wire harness.
- Remove the upper ROPS (1).



- (1) Upper ROPS
(2) R.H. lower ROPS
(3) R.H. hazard lamp/turn signal
(4) L.H. hazard lamp/turn signal
(5) L.H. lower ROPS
(6) Bolt

- Remove the ROPS mounting bolts (6).
- Remove the R.H. and L.H. lower ROPS (2), (5).

(When reassembling)

Tightening torque	ROPS mounting bolt	48.0 to 55.9 N·m 4.90 to 5.70 kgf·m 35.5 to 41.2 lbf·ft
-------------------	--------------------	---

5.1.5 Removing seat

- Disconnect the seat switch connectors.


- Remove the snap pins (2) to remove the seat (1).



(1) Seat (2) Snap pin

5.1.6 Removing step

- Disconnect the upper cruise control rod (1) from the lower cruise control rod.
- Remove the R.H. and L.H. side covers (2), (7).



(1) Upper cruise control rod (5) Forward HST pedal
(2) R.H. side cover (6) Reverse HST pedal
(3) Step mat (7) L.H. side cover
(4) Step

- Remove the step mat (3).
- Remove the forward and reverse HST pedals (5), (6).
- Remove the step (4).


5.1.7 Removing fender

- Disconnect the L.H. and R.H. tail lamps (3), (7) from the wire harness.
- Disconnect the 12 V outlet (2) from the wire harness.

NOTE

- 12 V outlet connector is near the L.H. tail lamp connector.

- Remove the L.H. lever grips (3).



(1) Tail lamp (6) Lowering speed adjusting knob
(2) 12 V outlet (7) R.H. lever grip
(3) L.H. lever grip
(4) Differential lock pedal cover
(5) Cutting height adjusting dial knob

- Remove the differential lock pedal cover (4), cutting height adjusting dial knob (5), and lower speed adjusting knob (6).
- Remove the R.H. lever grips (7).
- Remove the R.H. lever guide (8) and R.H. handrail (10).
- Remove the L.H. lever guide stay nut.




(8) R.H. lever guide (10) R.H. handrail
(9) Fender

- Remove the fender (9).

5.1.8 Removing fuel tank

- Remove the and R.H. lever guide stay (1).
- Drain the fuel from the fuel tank.

3. Disconnect the fuel sensor connectors (4) and safety switch connector (7).



- (1) R.H. lever guide stay (2) Fuel tube cover (3) Seat stopper (4) Fuel sensor connector (5) Fuel tank (6) Fuel return hose (7) Connector (8) Fuel supply hose

4. Remove the fuel tube cover (2).
 5. Disconnect the fuel return hose (6) and fuel supply hose (8).
 6. Remove the seat stopper (3).
 7. Remove the R.H. and L.H. fuel tank stays (9) and cushions (10), then remove the fuel tank (5).




- (9) R.H. fuel tank stay (10) Cushion

(When reassembling)

Tightening torque	Fuel tank stay mounting bolt and nut	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft
	Seat stopper bolts	123.5 to 147.0 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft

5.1.9 Removing rear wheel

1. Remove the rear wheels (1), (2).




- (1) L.H. rear wheel (2) R.H. rear wheel

(When reassembling)

Tightening torque	Rear wheel mounting bolt	109 to 129 N·m 11.1 to 13.2 kgf·m 80.3 to 95.4 lbf·ft
-------------------	--------------------------	---

5.1.10 Removing fender center stay

1. Remove the fender center stay (1).



- (1) Fender center stay

(When reassembling)

Tightening torque	Fender center stay mounting bolt and nut (M14)	98.0 to 125 N·m 11.0 to 12.8 kgf·m 79.6 to 92.5 lbf·ft
	Fender center stay mounting bolt and nut (M10)	39.2 to 45.1 N·m 4.00 to 4.60 kgf·m 29.0 to 33.2 lbf·ft


5.1.11 Removing fender bracket and hitch plate

1. Remove the hitch plate (2).

4. TRANSAXLE

5. Disassembling and assembling

2. Remove the parking brake return spring (4) and the fender brackets (1), (3).



- (1) Fender bracket L.H. (4) Return spring
(2) Hitch plate
(3) Fender bracket R.H.


(When reassembling)

- Do not firmly tighten all screws, bolts and nuts until most components are attached.

Tightening torque	Hitch plate mounting bolt and nut (M14)	124 to 147 N · m 12.6 to 15.0 kgf · m 91.2 to 108 lbf · ft
	Fender bracket mounting bolt and nut (M14)	124 to 147 N · m 12.6 to 15.0 kgf · m 91.2 to 108 lbf · ft

5.1.12 Removing transaxle assembly

1. Remove the differential lock rod (1) and disconnect the mower link (2).





- (1) Differential lock rod (2) Mower link

2. Remove the brake rod (4).
3. Disconnect the hoses (3). (If equipped.)



- (3) Hoses (4) Brake rod

4. Disconnect the connectors (5).
5. Remove the rear coupling mounting bolt (8).
6. Disconnect the power steering pipes (9) from the transaxle.
7. Remove the speed control rod (7).




- (5) Connector (8) Rear coupling mounting bolt
(6) Front wheel drive shaft (9) Power steering pipe
(7) Speed control rod

8. Remove the wire harness clamps.
9. Remove the frame brackets (10).

Speed control rod length (7)	Reference value	373 mm 14.7 in.
------------------------------	-----------------	--------------------

(When reassembling)

- Tighten the smaller bolt (M12) first.
- Before mounting the transaxle assembly on the tractor main frame, check the flatness of the frame brackets with a straight edge securely.




(10) Frame bracket

Tightening torque	Transaxle assembly mounting bolt (M12)	63 to 72 N · m 6.4 to 7.4 kgf · m 47 to 53 lbf · ft
	Transaxle assembly mounting bolt (M14)	124 to 147 N · m 12.6 to 15.0 kgf · m 91.2 to 108 lbf · ft
	Rear coupling mounting bolt (M8)	24 to 27 N · m 2.4 to 2.8 kgf · m 18 to 20 lbf · ft


5.1.13 Removing brake pedal

1. Unhook the spring (2) and remove the parking lock (1).




- (1) Parking lock (3) Parking arm
(2) Spring

2. Remove the split pin then remove pin (5) from the brake arm (4).
3. Remove the brake pedal (6).



- (4) Brake arm (6) Brake pedal
(5) Pin

5.1.14 Removing propeller shaft

- (1) Front coupling
(2) Rear coupling
(3) HST fan

1. Disconnect the front coupling (1) from the engine.
2. Remove the propeller shaft assembly.
3. Remove the HST fan (3) from the propeller shaft.


(When reassembling)

- Apply grease to inside of the front coupling and the rear coupling.

Tightening torque	Front coupling mounting bolt (M8)	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft
	HST fan mounting bolt (M8)	9.8 to 11 N·m 1.0 to 1.2 kgf·m 7.3 to 8.6 lbf·ft

5.1.15 Removing differential lock pedal

1. Remove the differential lock return spring (1).




- (1) Spring
(2) Differential lock pedal
(3) Rue ring cotter
(4) Differential lock rod

2. Remove the rue ring cotter (3).
3. Turn and remove the differential lock pedal (2).


5.1.16 Removing speed control pedal, HST damper, and cruise rod

1. Remove the speed control pedal (1).
2. Remove the rue ring cotter (4).
3. Remove the HST dumper (2).



- (1) Speed control pedal
(2) HST dumper
(3) HST pedal link
(4) Rue ring cotter

4. Remove the cruise arm (6).
5. Remove the cruise rod (5).
6. Remove the spring pin then remove the release arm (7) and cruise plate (9).




- (5) Cruise rod
(6) Cruise arm
(7) Release arm
(8) Cruise spring
(9) Cruise plate

(When reassembling)

- Be sure to assemble the cruise spring (8) properly.


5.2 Hydrostatic transmission

5.2.1 Removing levers and mower lift arm



(1) Range gear shift lever (3) Front wheel drive lever
(2) Hydraulic control lever

1. Tap out the spring pin from the range gear shift lever (1) and front wheel drive lever (3), then remove the both levers.
2. Remove the hydraulic control lever (2).
3. Remove the PTO select lever (4) and PTO clutch control lever (5).




(4) PTO select lever (5) PTO clutch control lever

(When reassembling)

- Apply grease to inside of the front coupling and rear mounting.

Tightening torque	Hydraulic control lever mounting bolt and nut	18 to 20 N·m 1.8 to 2.1 kgf·m 13 to 15 lbf·ft
-------------------	---	---

5.2.2 Removing PTO clutch valve





(1) Stopper (3) O-ring
(2) PTO clutch valve (4) Oil passage

1. Remove the stopper (1).
2. Draw out the PTO clutch valve (2) from the transaxle assembly.

(When reassembling)

1. Clean the oil passages (4).
2. Apply the transmission fluid to the O-rings (3).

5.2.3 Removing oil cooler cover



- (1) HST front cover
(2) Transaxle assembly
(3) Bolt
(4) Internal circlip
(5) Oil seal
(6) Center section


1. Remove the HST front cover (1) not to damage the oil seal (5).
2. Remove the center section (6).

(When reassembling)

- Do not damage the oil seal (5).
- Tighten the HST mounting bolts and the nut to the factory specifications.


Tightening torque	Oil cooler cover mounting bolt (M8)	18 to 20 N·m 1.8 to 2.1 kgf·m 13 to 15 lbf·ft
	Oil cooler cover mounting nut (M8)	18 to 20 N·m 1.8 to 2.1 kgf·m 13 to 15 lbf·ft

5.2.4 Removing center section and valve plates



- (1) Center section
(2) Valve plate

1. Remove the valve plates (2).


(When reassembling)

- (2) Valve plate
(3) Groove
(4) Anchor pin

1. Check the direction of the groove (3).
2. Install the valve plates (2) to the anchor pins (4) securely.
3. Install the groove of the valve plate (pump plate) to the engine side.

5.2.5 Removing check and high pressure relief valve plug

1. Remove the check and high pressure relief plug (G 1/2).




(1) Center section
(2) Plug
(3) Plug

(When reassembling)

Tightening torque	Check and high pressure relief valve plug (G 1/2)	59 to 78 N·m 6.0 to 8.0 kgf·m 44 to 57 lbf·ft
-------------------	---	---

5.2.6 Checking check and high pressure relief valve



(1) Plug
(2) O-ring
(3) Spring
(4) Check and relief valve (Forward)
(5) Check and relief valve (Reverse)

1. After removing the plug (1), draw out the spring (3) and the check and high pressure relief valve assembly (4), (5).


(When reassembling)

- Be careful not to damage the O-ring (2) on the plug (1).

- Since there is an orifice in the check and relief valve body (reverse) (5), re-install the check and relief valve (4), (5) to their original positions.


Orifice	Factory specification	1.5 mm 0.059 in.
---------	-----------------------	---------------------

5.2.7 Removing cylinder block



(3) Pump shaft
(4) Cylinder block assembly (Pump side)
(5) Cylinder block assembly (Motor side)
(6) Cylinder block assembly (Motor side)

1. Remove the gasket (1).



(1) Gasket

- Remove the O-ring (2).



(2) O-ring

- Remove the cylinder block assembly (4), (5) from the transaxle.

(When reassembling)


- Turn the disassembling and the assembling stand vertically.
- Install the cylinder block assembly (4), (5) to the shafts not to drop the pistons from the cylinder block assembly (4), (5) carefully.

5.2.8 Removing cylinder block and piston

NOTE

- Be careful not to damage the surface of the cylinder block and the piston.

- Remove the piston (3) and the spring (2) from the cylinder block (1).



(1) Cylinder block




(3) Piston

(2) Spring

(When reassembling)

- Apply clean transmission oil to the cylinder block and the piston.

5.2.9 Removing swashplate and thrust roller bearing



(1) Motor shaft

(2) Thrust bearing

(3) Pump shaft


(4) Thrust roller bearing

(5) Swashplate

(7) Slot guide


(8) Cradle bearing

1. Remove the circlip (6) from the pump shaft (3) and the motor shaft (1).



(6) Circlip

2. Remove the thrust bearing (2).
3. Remove the swashplate (5) and the thrust roller bearing (4).



(4) Thrust roller bearing


(5) Swashplate

(When reassembling)

- Apply clean transmission oil to the cradle bearing and the trunnion arm.
- Hold the slot guide with a minus screw driver.
- Apply clean transmission oil to the thrust roller bearing.

5.2.10 Removing 4WD detent ball

1. Remove the 4WD detent bolt (1), the detent spring (2) and the detent ball (3) before removing the transaxle front case, not to drop the detent ball (3) into the transaxle case.





(1) 4WD detent bolt

(4) Transaxle front case

(2) Detent spring

(3) Detent ball

5.2.11 Removing neutral arm and trunnion arm



(1) Bolt

(2) Neutral spring

(3) Neutral arm

(4) Lock screw

(5) Neutral adjuster

(6) Trunnion arm



(7) External circlip

1. Disconnect the neutral spring (2) from the HST front cover.
2. Loosen the neutral adjuster (5).
3. Remove the external circlip (7).
4. Remove the bolts (1).

5. Remove the neutral adjuster (5) and the neutral arm (3).
6. Remove the trunnion arm (6).


(When reassembling)

- Adjust the HST neutral position. Refer to "Checking and adjusting" section.

5.3 Hydraulic cylinder**5.3.1 Removing hydraulic cylinder**

(2) Hydraulic cylinder (3) Bolt

1. Disconnect the delivery pipe (1).



(1) Delivery pipe

2. Remove the hydraulic cylinder mounting bolts (3).
3. Remove the hydraulic cylinder (2).






(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of the transaxle case to the hydraulic cylinder.

Tightening torque	Hydraulic cylinder mounting bolt	40 to 44 N·m 4.0 to 4.5 kgf·m 29 to 32 lbf·ft
-------------------	----------------------------------	---

5.4 Transaxle shafts**5.4.1 Removing transaxle case front cover****NOTE**

- Before removing the transaxle case front cover (4), remove the 4WD detent bolt (1), the detent spring (2) and the detent ball (3) from the transaxle case front cover (4).
- Remove the circlip (5) from the HST pump shaft (PTO shaft) from the HST pump shaft (6) and the HST motor shaft securely.



- (1) 4WD detent bolt
- (2) Detent spring
- (3) Detent ball
- (4) Transaxle case front cover
- (5) Circlip
- (6) HST pump shaft (PTO shaft)
- (7) Front cover mounting bolt
- (8) Front wheel drive shaft
- (9) Spiral bevel pinion shaft
- (10) HST motor shaft
- (11) Mid-PTO shaft
- (12) Mid-PTO idle gear shaft
- (13) PTO select shaft




1. Remove the transaxle case front cover mounting bolts (7).
2. Remove the transaxle case front cover (4) as an unit.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of the transaxle case to the front cover.


Tightening torque	Transaxle case front cover mounting bolt (M10)	39 to 44 N · m 4.0 to 4.4 kgf · m 29 to 32 lbf · ft
-------------------	--	---

5.4.2 Removing hydraulic pump assembly



- | | |
|-------------------------|------------|
| (2) Bolt (Through bolt) | (5) O-ring |
| (3) Bolt | (6) O-ring |
| (4) O-ring | (7) O-ring |

1. Remove the hydraulic pump assembly mounting bolt (2), (3).
2. Remove the hydraulic pump assembly (1) as an unit from the transaxle case.








(1) Hydraulic pump assembly

(When reassembling)

- Apply transmission oil to the O-rings.
- Since the mounting bolt (2) is installed through the hydraulic pump to the transaxle case, bind the sealing tape to the mounting bolt (2) securely.

Tightening torque	Hydraulic pump assembly mounting bolt (M6)	7.9 to 8.8 N · m 0.80 to 0.90 kgf · m 5.8 to 6.5 lbf · ft
	Hydraulic pump assembly mounting bolt (M8)	18 to 20 N · m 1.8 to 2.1 kgf · m 13 to 15 lbf · ft

5.4.3 Removing rear PTO cover assembly



- (1) Bolt
- (2) Rear PTO cover
- (3) Bearing
- (4) 11T PTO select shaft
- (5) Rear PTO shaft
- (6) Oil seal
- (7) Vinyl tape

1. Remove the rear PTO cover mounting bolts (1).
2. Remove the rear PTO cover (2).
3. Remove the rear PTO shaft (5) from the rear PTO cover (2).

(When reassembling)





- Pull the 11T PTO select shaft with the bearing approximately the bearing thickness.
- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of transaxle case to the rear PTO cover.
- Bind the vinyl tape to the rear PTO shaft not to damage the oil seal.

Tightening torque	Rear PTO cover mounting bolt (M8)	18 to 20 N·m 1.8 to 2.1 kgf·m 13 to 15 lbf·ft
-------------------	-----------------------------------	---

5.4.4 Disassembling rear axle (L.H.)

NOTE

- Prepare a specially bent circlip pliers.





- | | |
|----------------------|--------------------|
| (1) Rear axle | (4) Ball bearing |
| (2) Oil seal | (5) Rear axle case |
| (3) Internal circlip | |

1. Draw out the oil seal with a screw driver.
2. Remove the internal circlip from the rear axle case.
3. Draw out the rear axle from the rear axle case.

(When reassembling)


- Do not damage the oil seal.

5.4.5 Removing rear axle case (R.H.)

- | | |
|--|--------------------|
| (2) 37T spiral bevel gear | (4) 66T final gear |
| (3) 10T final gear shaft (Brake shaft) | |

1. Remove the rear axle case (R.H.) mounting bolts.

- Remove the rear axle case (R.H.) (1) as an assembly from the transaxle case.



3TAAAFKP090A

- Rear axle case (R.H.)

- Remove the 37T spiral bevel gear (2).

NOTE

- Since the adjusting shims are installed behind the 37T spiral bevel gear, check the shims.

- Remove the 10T final gear shaft (3).


- Remove the 66T final gear with the differential lock shift fork.

(When reassembling)


- Apply liquid gasket (Three Bond 1208D or equivalent) to the joint surface of transaxle case to the rear axle case (R.H.).

Tightening torque	Rear axle case (R.H.) mounting bolt (M8)	18 to 20 N·m 1.8 to 2.1 kgf·m 13 to 15 lbf·ft
-------------------	--	---


5.4.6 Removing 66T final gear



3TAAAFKP095A




3TAAAFKP096A



3TAAABKP082B

- 66T final gear
- Bearing
- Differential lock shift fork
- Bearing
- Differential lock shifter
- Differential case
- Differential pinion shaft
- Differential side gear
- Differential side gear washer
- Key
- Differential pinion
- Differential pinion washer
- Differential side gear
- Differential side gear washer
- Differential pinion
- Differential pinion washer

- Remove the bearing (2) with a puller.
- Remove the bearing (4) with a puller.
- Remove the differential lock shifter (5) and 66T final gear (6).



3TAAABKP081B

- 66T final gear

- Put parting marks on the differential pinions (12), (16) and the differential side gears (9), (14).
- Tap out the differential pinion shaft (8).

4. TRANSAXLE

5. Disassembling and assembling




6. Remove the differential pinions (12), (16), the differential pinion washers (13), (17), differential side gears (9), (14) and the differential side gear washers (10), (15).

(When reassembling)

- Install the differential pinion and differential gear, aligning the parting marks.
- Lock the differential pinion shaft (8) by setting the key (11).

Tightening torque	66T final gear mounting bolt	61 to 70 N·m 6.2 to 7.2 kgf·m 45 to 52 lbf·ft
-------------------	------------------------------	---

5.4.7 Removing rear axle case, R.H. and brake







- | | |
|----------------------|--------------------|
| (1) Internal circlip | (6) Brake disc |
| (2) Brake cam lever | (7) Friction plate |
| (3) External circlip | (8) Bearing holder |
| (4) Steel ball | (9) Shim |
| (5) Actuator | |

1. Remove the internal circlip (1).
2. Remove the shim (9), the bearing holder (8) and the other brake parts from the brake case.

(When reassembling)

- Apply grease to the steel balls.
- Be careful not to damage the O-ring on the brake cam lever.
- Check that the brake cam lever moves smoothly.

5.4.8 Removing PTO clutch assembly



- | | |
|-----------------------------------|-------------------------------|
| (1) Pump shaft (PTO clutch shaft) | (10) Brake plate |
| (2) Bearing | (11) Clutch piston |
| (3) Clutch gear | (12) Separate plate |
| (4) Clutch pack | (13) Disc plate |
| (5) Bearing | (14) Backing plate |
| (6) Seal ring | (15) Internal circlip |
| (7) Clutch case | (16) Brake spring |
| (8) O-ring | (17) Washer |
| (9) Brake disc | (18) External circlip |
| | (19) Clutch spring compressor |

1. Remove the bearing (2).
2. Remove the external circlip and the clutch gear (3).
3. Remove the seal rings (6).
4. Remove the bearing (5).
5. Remove the external circlip (18) using a clutch spring compressor.
6. Disassembling the clutch pack inner parts as show in the figure.




(When reassembling)

- Change the seal rings (6) with new ones.

5.5 Assembling shafts


5.5.1 Assembling select arms and HST pump shaft (PTO clutch shaft)

- Be careful not to damage the O-rings on the arms.



- | | |
|---------------------------------|---------------------------------------|
| (1) PTO select arm | (5) HST pump shaft (PTO clutch shaft) |
| (2) Range shift arm | (6) PTO select gear shaft |
| (3) Front wheel drive shift arm | |
| (4) Mid-PTO idle gear shaft | |

1. Install the PTO select arm (1).



- (1) PTO select arm


2. Install the range shift arm (2) and the front wheel drive shift arm (3).
3. Install the idle gear shaft.

NOTE

- Install the rear PTO cover and the PTO select gear shaft before installing HST pump shaft assembly.

4. After installing the rear PTO cover to the transaxle case, install the PTO select gear shaft (6).
5. Install the HST pump shaft (PTO clutch shaft) (5).



5.5.2 Assembling front wheel drive shaft, shifter, spiral bevel pinion shaft and mid-PTO shaft



- | | |
|-----------------------------|-------------------------------|
| (1) Front wheel drive shaft | (3) Spiral bevel pinion shaft |
| (2) Shifter | |

1. Install the front wheel drive shaft (1).
2. Install the shifter (2) and the spiral bevel pinion shaft (3) together.

3. Install the mid-PTO idle gear shaft (5) and the mid-PTO shaft (6) and the HST motor shaft (4) together.




- (4) HST motor shaft
(5) Mid-PTO idle gear shaft
(6) Mid-PTO shaft

6. Servicing

6.1 Hydrostatic transmission


6.1.1 Checking center section

1. Check the center section surface (1) for scratches or wear.



- (1) Center section surface
2. If deep scratch or excessive wear is found, replace the hydrostatic transmission assembly.

6.1.2 Checking charge relief valve



- (1) Charge relief valve
(2) Spring
(3) Plug


1. Check the charge relief valve (1) and the spring (2).
2. If damages are found, replace it.

6.1.3 Checking check and high pressure relief valve

NOTE

- Check and high pressure relief valve (reverse) has a pin hole.

Pin hole	Factory specification	1.5 mm 0.059 in.
----------	-----------------------	---------------------




- (1) Plug
(2) O-ring
(3) Spring
(4) Check and high pressure relief valve (Forward)
(5) Check and high pressure relief valve (Reverse)

1. Check the check and high pressure relief valve (4), (5) for scratches and damage.
2. Check the spring (3) for breakage and wear.
3. If anything are unusual, replace the check and high pressure relief valve as complete assembly.

6.1.4 Checking cylinder block assembly

■ IMPORTANT


- Do not interchange the pistons between the pump cylinder block and the motor cylinder block. Pistons and cylinder blocks are matched.



- | | |
|--------------------|-------------------|
| (1) Cylinder block | (3) Spring |
| (2) Piston | (4) Polished face |

- Check the cylinder blocks (1) and the pistons (2) for scratches and wear.
- If there are scratch or worn, replace the cylinder block assembly.
- Check the pistons for their free movement in the cylinder block bores.
- If the piston or the cylinder block is scored, replace the cylinder block assembly.
- Check the polished face (4) of the cylinder block for scoring. If it is scored, replace the cylinder block assembly.


6.1.5 Checking thrust washer, thrust roller bearing, thrust plate and cradle bearing



- | | |
|-------------------|--------------------|
| (1) Swashplate | (3) Thrust bearing |
| (2) Thrust washer | (4) Thrust plate |



- Check the thrust bearing (3) for scratches and excessive wear.
- If it is worn, replace it.

- Check the thrust plate (4) for scratches and excessive wear. If it is worn or scored, replace it.
- Check the cradle bearing (5) for excessive wear. If it is worn, replace it.



(5) Cradle bearing

6.1.6 Checking pump shaft (PTO clutch shaft)




- | | |
|------------------|---------------------|
| (1) Seal surface | (2) Bearing surface |
|------------------|---------------------|

- Check the seal surface (1) and the bearing surface (2).
- If the pump shaft is rough or grooved, replace it.

- If the ball bearing or the needle bearing is worn, replace it.

6.1.7 Checking needle bearing




(1) Needle bearing

- Check the needle bearings (1) for wear.
- If the needle bearings (1) are worn, replace them.

6.2 Transaxle case


6.2.1 Checking bearing



- Hold the inner race, and push and pull the outer race in all directions to check wear and roughness.
- Apply the transmission oil to the bearing, and hold the inner race.
- Turn the outer race to check rotation.
- If there is any damage, replace the bearing.

6.2.2 Checking PTO clutch disc wear

- Measure the thickness of PTO clutch disc with vernier calipers.




- If the thickness is less than the allowable limit, replace it.

Thickness of PTO clutch disc	Factory specification	1.50 to 1.70 mm 0.0591 to 0.0669 in.
	Allowable limit	1.35 mm 0.0531 in.

6.2.3 Checking separate plate and back plate wear

- Measure the thickness of pressure plate and steel back with vernier calipers.




- If the thickness is less than the allowable limit, replace it.

Thickness of separate plate	Factory specification	0.9450 to 1.055 mm 0.03721 to 0.04153 in.
	Allowable limit	0.80 mm 0.031 in.

Thickness of back plate	Factory specification	1.9 to 2.1 mm 0.075 to 0.082 in.
	Allowable limit	1.85 mm 0.0728 in.

6.2.4 Checking flatness of clutch piston, pressure plate and steel plate




1. Place the part on a surface plate.
2. Check the flatness by inserting a feeler gauge (allowable limit size) underneath it at least four points.

Flatness of clutch piston	Allowable limit	0.15 mm 0.0059 in.
Flatness of pressure plate and steel plate		0.20 mm 0.0079 in.

3. If the gauge can be inserted, replace the part.

6.2.5 Checking clutch spring free length

1. Measure the free length of spring with vernier calipers.




2. If the measurement is less than the allowable limit, replace it.

Clutch spring free length	Factory specification	38.5 mm 1.52 in.
	Allowable limit	34.5 mm 1.36 in.

6.2.6 Checking PTO brake disc wear

1. Measure the PTO brake disc thickness with a vernier caliper.




2. If the thickness is less than allowable limit, replace it.

PTO brake disc thickness	Factory specification	2.90 to 3.10 mm 0.115 to 0.122 in.
	Allowable limit	2.70 mm 0.11 in.

6.2.7 Checking PTO brake plate


1. Measure the PTO brake plate thickness with a vernier caliper.



2. If the thickness is less than allowable limit, replace it.

PTO brake plate thickness	Factory specification	1.9 to 2.1 mm 0.075 to 0.082 in.
	Allowable limit	1.85 mm 0.0728 in.

6.2.8 Checking clearance between differential case and differential side gear



1. Measure the differential side gear boss O.D. with an outside micrometer.

Differential side gear O.D.	Factory specification	37.911 to 37.950 mm 1.4926 to 1.4940 in.
-----------------------------	-----------------------	---


2. Measure the differential case I.D. with a cylinder gauge and calculate the clearance.

Differential case I.D.	Factory specification	38.000 to 38.062 mm 1.4961 to 1.4985 in.
------------------------	-----------------------	---

3. If the clearance exceeds the allowable limit, replace damaged parts.

Clearance between differential case and differential side gear	Factory specification	0.0500 to 0.151 mm 0.00197 to 0.00594 in.
	Allowable limit	0.30 mm 0.012 in.

6.2.9 Checking clearance between differential pinion shaft and differential pinion



1. Measure the differential pinion shaft O.D. with an outside micrometer.

Differential pinion shaft O.D.	Factory specification	19.959 to 19.980 mm 0.78579 to 0.78661 in.
--------------------------------	-----------------------	---


2. Measure the differential pinion I.D. with a cylinder gauge, and calculate the clearance.

Differential pinion I.D.	Factory specification	20.060 to 20.081 mm 0.78977 to 0.79059 in.
--------------------------	-----------------------	---

3. If the clearance exceeds the allowable limit, replace damaged parts.

Clearance between differential pinion shaft and differential pinion	Factory specification	0.0800 to 0.122 mm 0.00315 to 0.00480 in.
	Allowable limit	0.30 mm 0.012 in.

6.2.10 Checking backlash between differential pinion and differential side gear





1. Secure the differential case with a vise.
2. Set the dial indicator (lever type) with its finger on the tooth of the differential side gear.
3. Press differential pinion and side gear against the differential case.
4. Hold the differential pinion and move the differential side gear to measure the backlash.
5. If the backlash exceeds the allowable limit, adjust it with differential side gear shims.

Backlash between differential pinion and differential side gear	Factory specification	0.15 to 0.30 mm 0.0059 to 0.011 in.
	Allowable limit	0.40 mm 0.016 in.

(Reference)

Thickness of shims	1.5 mm 0.059 in.
	1.6 mm 0.063 in.
	1.7 mm 0.067 in.

6.2.11 Checking backlash between spiral bevel pinion gear and bevel gear




- (1) Bevel gear (5) Final gear shaft (Brake shaft)
 (2) Spiral bevel pinion gear (A) Bevel gear teeth upper surface
 (3) Shim
 (4) Shim

1. Temporarily assemble the spiral bevel pinion gear (2) and the bevel gear (1) in the transaxle case.
2. Hold the wire of solder or plastigauge on the bevel gear teeth upper surface (A).
3. Turn the front drive shaft one turn clockwise by hands.
4. Measure the backlash between the spiral bevel pinion gear and the bevel gear.

5. If the backlash exceeds the factory specifications, adjust the shims (3), (4).


Backlash between spiral bevel pinion and bevel gear	Factory specification	0.10 to 0.30 mm 0.0040 to 0.011 in.
---	-----------------------	--

6.2.12 Checking brake cam lever movement



1. Move the brake cam lever by hand to check its movement.
2. If its movement is heavy, refine the brake cam with a emery paper.

6.2.13 Checking flatness of actuator and bearing holder




1. Place a straightedge on the contacting surface of the actuator and the bearing holder.
2. Inspect the friction surface of the actuator and the bearing holder with the straightedge, and determine if a feeler gauge will fit on the part of wear.

Flatness of actuator and bearing holder	Allowable limit	0.30 mm 0.012 in.
---	-----------------	----------------------

3. If it will fit, resurface.

6.2.14 Checking height of cam plate and ball

1. Measure the height of the cam plate with the ball installed.




2. If the measurement is less than the allowable limit, replace the cam plate and balls.

Height of cam plate and ball	Factory specification	22.89 to 22.99 mm 0.9012 to 0.9051 in.
	Allowable limit	22.40 mm 0.8819 in.

3. Inspect the ball holes of cam plate for uneven wear.
4. If the uneven wear is found, replace it.

6.2.15 Checking brake disc and friction plate wear

1. Measure the brake disc thickness and the friction plate thickness with an outside micrometer.



2. If the thickness is less than the allowable limit, replace it.

Brake disc thickness	Factory specification	3.30 to 3.50 mm 0.130 to 0.137 in.
	Allowable limit	3.0 mm 0.12 in.

Friction plate thickness	Factory specification	1.92 to 2.08 mm 0.0756 to 0.0818 in.
	Allowable limit	1.52 mm 0.0598 in.

5. FRONT AXLE

MECHANISM


1. Structure of front axle

The front axle of the 4WD is constructed as shown below. Power is transmitted from the transmission through the propeller shaft to the bevel pinion shaft (9), then to the bevel gear (15) and to the differential side gear (13).

The power through the differential side gear is transmitted to the differential yoke shaft (7), (12), and to the bevel gear shaft (16) through the bevel gears (4), (6) in the bevel gear case (5).

The revolution is greatly reduced by the bevel gears (18), (3), then the power is transmitted to the axle (1).

The differential system allows each wheel to rotate at a different speed to make turning easier.



3TAAAF6P001A

- | | | | |
|---------------------|-----------------------------------|------------------------------------|-----------------------|
| (1) Axle | (6) Bevel gear | (11) Differential pinion shaft | (16) Bevel gear shaft |
| (2) Axle flange | (7) Differential yoke shaft, R.H. | (12) Differential yoke shaft, L.H. | (17) Front gear case |
| (3) Bevel gear | (8) Front axle case | (13) Differential side gear | (18) Bevel gear |
| (4) Bevel gear | (9) Bevel pinion shaft | (14) Differential pinion gear | (19) Collar |
| (5) Bevel gear case | (10) Differential gear assembly | (15) Bevel gear | |

5. FRONT AXLE

2. Front wheel alignment


To assure smooth mobility or maneuverability and enhance stable and straight running, the front wheels are mounted at an angle to the right, left and forward directions. This arrangement is referred to as the Front Wheel Alignment.

2.1 Camber of front axle

The front wheels are tilted from the vertical as viewed from the front, upper wheels are spreader than lower ones.

This inclination is called camber (a). Camber reduces bending or twisting of the front axle caused by vertical load or running resistance, and also keeps the stability in running.

Camber	0.035 rad 2°
--------	-----------------




2.2 Kingpin angle of front axle

The kingpin is tilted from the vertical as viewed from the front.

This angle is called kingpin angle (a). As with the camber, kingpin angle reduces rolling resistance of the wheels, and prevents any shimmy motion of the steering wheel.

It also reduces steering effort.

Kingpin angle	0.209 rad 12°
---------------	------------------



2.3 Caster of front axle


The kingpin is tilted forward as viewed from the side.

The point (b) of the wheel center line is behind the point (a) of the kingpin shaft center line.

This inclination is called caster (c). Caster helps provide steering stability.

As with the kingpin inclination, caster reduces steering effort.

Caster	0 rad 0°
--------	-------------



F: Front


R: Rear

2.4 Toe-in of front axle

Viewing the front wheels from above reveals that the distance between the toes of the front wheels is smaller than that between the heels.

It is called toe-in. The front wheels tend to roll outward due to the camber, but toe-in offsets it and ensures parallel rolling of the front wheels. Another purpose of toe-in is to prevent excessive and uneven wear of tires.

Toe-in	0 to 5 mm 0 to 0.19 in.
--------	----------------------------



F: Front

R: Rear

SERVICING

1. Troubleshooting for front axle

Symptom	Probable cause and checking procedure	Solution	Reference page
Front wheels wander to right or left	1. Tire pressure uneven	Adjust	2-47
	2. Improper toe-in adjustment (improper alignment)	Adjust	5-8
	3. Clearance between center pin and pin support bushing excessive	Replace	5-18
	4. Front axle rocking force too small	Adjust	5-8
	5. Tie-rod end loose	Tighten	6-11
	6. Air sucked in power steering circuit	Bleed	—
Front wheels cannot be driven	1. Front wheel driving gears in front axle gear case broken	Replace	5-14
	2. Universal joint broken	Replace	5-11
	3. Front wheel drive gears in transmission broken	Replace	—
	4. Front differential gear broken	Replace	5-15
Noise	1. Gear backlash excessive	Adjust or replace	5-16 5-17
	2. Oil insufficient	Fill	5-9
	3. Bearings damaged or broken	Replace	—
	4. Gears damaged or broken	Replace	—
	5. Spiral bevel pinion shaft turning force improper	Adjust	5-16

2. Servicing specifications for front axle

Item		Factory specification	Allowable limit
Front wheel alignment	Toe-in	0 to 5 mm 0 to 0.2 in.	—
Front axle	Rocking force	49.1 to 117 N 5.00 to 12.0 kgf 11.1 to 26.4 lbs	—
Differential case to differential side gear	Clearance	0.040 to 0.082 mm 0.0016 to 0.0032 in.	0.17 mm 0.0067 in.
• Differential case	I.D.	26.000 to 26.021 mm 1.0237 to 1.0244 in.	—
• Differential side gear	O.D.	25.939 to 25.960 mm 1.0213 to 1.0220 in.	—
Differential pinion shaft to differential pinion	Clearance	0.025 to 0.055 mm 0.0009 to 0.0021 in.	0.25 mm 0.0098 in.
• Differential pinion shaft	I.D.	9.960 to 9.975 mm 0.3922 to 0.3927 in.	—
• Differential pinion	O.D.	10.000 to 10.015 mm 0.39370 to 0.39429 in.	—
Differential pinion to differential side gear	Backlash	0.1 to 0.3 mm 0.004 to 0.01 in.	—
Bevel pinion shaft	Turning torque	0.80 to 1.0 N·m 0.082 to 0.10 kgf·m 0.59 to 0.73 lbf·ft	—
Bevel pinion shaft to bevel gear	Backlash	0.1 to 0.3 mm 0.004 to 0.01 in.	—
12T bevel gear to 15T bevel gear	Backlash	0.1 to 0.3 mm 0.004 to 0.01 in.	—
Center pin to pin support bushing	Clearance	0 to 0.231 mm 0 to 0.00909 in.	0.70 mm 0.028 in.
• Center pin	I.D.	19.850 to 20.000 mm 0.78150 to 0.78740 in.	—
• Bushing	O.D.	20.000 to 20.081 mm 0.78741 to 0.79059 in.	—

3. Tightening torques for front axle

Tightening torques of screws, bolts and nuts on the table below are especially specified.



Item	N · m	kgf · m	lbf · ft
Front wheel mounting screw	149 to 179	15.2 to 18.3	110 to 132
Tie-rod slotted nut	18 to 34	1.8 to 3.5	13 to 25
Power steering cylinder mounting screw	48 to 55	4.9 to 5.7	36 to 41
Power steering hose	24 to 27	2.4 to 2.8	18 to 20
Bevel gear case mounting screw (M10)	48 to 55	4.9 to 5.7	36 to 41
Bevel gear case mounting screw (M12)	78 to 90	7.9 to 9.2	58 to 66
Front gear case cover mounting screw	48 to 55	4.9 to 5.7	36 to 41

— RELATED PAGE —

[TIGHTENING TORQUES on page 2-13](#)

4. Checking and adjusting

4.1 Adjusting toe-in



- (1) Tie-rod (B) Wheel to wheel distance at rear
(2) Lock nut (A) Wheel to wheel distance at front
(C) Front


1. Inflate the tires to the specified pressure.
2. Turn the front wheels straight ahead.
3. Measure the toe-in ((B) - (A)).
4. If the measurement is not within the factory specifications, adjust the tie-rod length.

Toe-in ((B) - (A))	Factory specification	0 to 5 mm 0 to 0.2 in.
--------------------	-----------------------	---------------------------

Adjusting procedure

1. Loosen the lock nuts and turn the tie-rod to adjust the rod length until the proper toe-in measurement is obtained.
2. Re-tighten the lock nuts.

4.2 Adjusting front axle rocking force



- (1) Cotter pin (2) Adjusting nut

1. Jack up the front side of tractor and remove the front wheel.
2. Set a spring balance to the front gear case cover.
3. Measure the front axle rocking force.
4. If the measurement is not within the factory specifications, adjust as following.

Front axle rocking force	Factory specification	49.1 to 117 N 5.00 to 12.0 kgf 11.1 to 26.4 lbf
--------------------------	-----------------------	---

Adjusting procedure


1. Remove the cotter pin (1).
2. Tighten or loosen the adjusting nut (2) so that the measurement of rocking force comes to factory specifications.
3. If the slot and pin hole do not meet, align the nut until they do meet within factory specifications.
4. Install the new cotter pin.

(When reassembling)

- Be sure to split the cotter pin like an anchor.

Tightening torque	Adjusting nut	20 N · m 2.0 kgf · m 14 lbf · ft
-------------------	---------------	--

4.3 Adjusting front wheel steering angle




(1) Stopper bolt L.H. (2) Lock nut

(Reference)

Steering angle	Right side	0.84 to 0.87 rad 48 to 50°
	Left side	0.93 to 0.95 rad 53 to 55°

Length of adjusting bolt (L)	Right side	23 mm 0.91 in.
	Left side	16 mm 0.63 in.

1. Inflate the tires to the specified pressure.
2. Loosen the lock nut and shorten the length of stopper bolt L.H. (1).
3. Steer the wheels to the extreme left.
4. Lengthen the length of stopper bolt (1) until the stopper bolt contacts with the bevel gear case (3).




(3) Bevel gear case

5. Return the steering wheel to straight ahead and lengthen the stopper bolt 1/2 turns from above position further.
6. Lock the stopper bolt by lock nut (2).
7. For adjusting the right steering angle, perform the same procedure as mentioned in left steering angle.

5. Disassembling and assembling

5.1 Separating front axle assembly

5.1.1 Draining front axle case oil



(1) Breather plug (A) Oil level is acceptable within this range.
(2) Filling plug with dipstick
(3) Drain plug

1. Place the oil pans underneath the front axle case.
2. Remove both right and left hand side drain plugs (3) and filling plug (2) to drain the oil.
3. After draining, reinstall the drain plugs (3).

(When reassembling)

■ IMPORTANT

- After a few minutes, check the oil level again, add oil to prescribed level.
- When re-filling, remove the right and left breather plugs (1).

Front axle case oil	Capacity	4.7 L 5.0 U.S.qts 4.1 Imp.qts
---------------------	----------	-------------------------------------

— RELATED PAGE —

[1.1 Lubricants, fuel, and coolant on page 2-7](#)

5.1.2 Removing battery



WARNING

To avoid serious injury or death:


- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.

1. Remove the under panel (1).



(1) Under panel

2. Disconnect the negative cable (3) from the battery (2).
3. Disconnect the positive cable (4) from the battery (2) and remove the battery.




(2) Battery
(3) Negative cable

(4) Positive cable


5.1.3 Removing bonnet

1. Remove the mower deck.
2. Remove the front link (1) and link brackets (2).



(1) Front link
(2) Front link bracket
(3) Bonnet guide rod
(4) L.H. bonnet bracket
(5) R.H. bonnet bracket

3. Open the bonnet.
4. Disconnect the headlight harness from the headlights and bonnet.
5. Disconnect the bonnet guide rod (3) from the bonnet.
6. Disconnect the L.H. and R.H. bonnet brackets (4), (5) from the frame.
7. Remove the bonnet (6).




(6) Bonnet

5.1.4 Removing front wheel and propeller shaft cover

1. Lift up the front of tractor and place the disassembling stand under the front axle frame.
2. Remove the front wheels.

3. Remove the propeller shaft cover mounting bolt and slide the propeller shaft cover (1).




(1) Propeller shaft cover

(When reassembling)

Tightening torque	Front wheel mounting screw	149 to 179 N·m 15.2 to 18.3 kgf·m 110 to 132 lbf·ft
-------------------	----------------------------	---

5.1.5 Disconnecting propeller shaft

1. Tap out the spring pins (2) and disconnect the universal joint (1) and spiral bevel pinion shaft.



(1) Universal joint


(2) Spring pin

(When reassembling)

- Apply grease to the splines of the propeller shaft and universal joint.


5.1.6 Removing front axle assembly

1. Remove the power steering hose clamp (1).



(1) Hose clamp


2. Place the garage jack under the front axle.
3. Remove the cotter pin (3).
4. Remove the slotted nut (2) of center pin and separate the front axle from the frame.



(2) Slotted nut (Adjusting nut for front axle rocking force)

(3) Cotter pin

5. Disconnect the power steering hoses (4).



(4) Power steering hose

(When reassembling)

- After mounting the front axle assembly to the frame, be sure to adjust the front axle rocking force.
- Installing the cotter pin, be sure to split the cotter pin like an anchor.


5. FRONT AXLE

5. Disassembling and assembling

Tightening torque	Power steering hose	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft
-------------------	---------------------	---

5.2 Front axle assembly

5.2.1 Removing power steering cylinder



(1) Tie-rod (2) Power steering cylinder

1. Remove the cotter pin and remove the slotted nut for tie-rod (1).
2. Remove the power steering cylinder mounting screws and remove the power steering cylinder (2) with tie-rod.


(When reassembling)**NOTE**

- Tighten the slotted nut. If the slot and pin hole do not meet, tighten the nut until they do meet, and install the cotter pin.
- Be sure to split the cotter pin like an anchor.

Tightening torque	Tie-rod slotted nut	18 to 34 N·m 1.8 to 3.5 kgf·m 13 to 25 lbf·ft
	Power steering cylinder mounting screw	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft

5.2.2 Removing bevel gear case and front gear case

1. Remove the bevel gear case mounting screws.
2. Remove the bevel gear case (2) and front gear case (1) as a unit from the front axle case (3).




(1) Front gear case (2) Bevel gear case (3) Front axle case

(When reassembling)

- Apply grease to the O-ring and be careful not to damage it.
- Do not interchange right and left bevel gear case assemblies and right and left gear case assemblies.

Tightening torque	Bevel gear case mounting screw (M10)	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft
	Bevel gear case mounting screw (M12)	78 to 90 N·m 7.9 to 9.2 kgf·m 58 to 66 lbf·ft

5.2.3 Removing front gear case cover



(1) Front gear case cover (2) Bevel gear (3) Front gear case

1. Remove the front gear case mounting screws and remove the front gear case cover (1) with bevel gear (2).




(1) Front gear case cover

(When reassembling)

- Apply grease to the O-ring and be careful not to damage it.

Tightening torque	Front gear case cover mounting screw	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft
-------------------	--------------------------------------	---

5.2.4 Removing 36T bevel gear and front axle shaft




(1) Front gear case cover (4) 36T bevel gear
(2) Axle shaft (5) Ball bearing
(3) Collar

1. Remove the ball bearing (5).
2. Remove the 36T bevel gear (4).
3. Remove the collar (3).
4. Tap out the axle shaft (2).



(When reassembling)

- Install the oil seal (6) of front gear case cover (1), noting its direction as shown in the figure.



(1) Front gear case cover (6) Oil seal
(2) Axle shaft

5.2.5 Removing front gear case and bevel gear case



(1) Internal circlip (8) Bevel gear shaft
(2) Shim (9) Ball bearing
(3) Ball bearing (10) Internal circlip
(4) Bevel gear (11) Ball bearing
(5) Bevel gear case (12) Oil seal
(6) Front gear case (13) Ball bearing
(7) External circlip

1. Remove the internal circlip (1).
2. Remove the bevel gear with ball bearing (3) and shim (2).
3. Remove the bevel gear (4).


5. FRONT AXLE

5. Disassembling and assembling

4. Remove the external circlip (7).
5. Remove the bevel gear case (5) from front gear case (6).
6. Remove the oil seal (12) and the ball bearing (11).
7. Remove the internal circlip (10) and remove the ball bearing (9).
8. Remove the bevel gear shaft (8) with ball bearing.


(When reassembling)

- Install the oil seal (12) of bevel gear case, noting its direction as shown in the figure.





(12) Oil seal

- Install the adjusting shims (2) to their original position.



(2) Shim

5.2.6 Removing bevel pinion shaft and differential gear assembly

- | | |
|----------------------------------|----------------------------------|
| (1) Internal circlip | (7) Differential yoke shaft R.H. |
| (2) Adjusting collar | (8) Adjusting collar |
| (3) Bevel pinion shaft | (9) Taper roller bearing |
| (4) Differential yoke shaft L.H. | (10) Lock nut |
| (5) Differential gear assembly | (11) Oil seal |
| (6) Front axle case | (12) Collar |

1. Remove the differential yoke shaft (4), (7).
2. Remove the oil seal (11).
3. Remove the internal circlip (1).
4. Pull out the bevel pinion shaft (3).
5. Remove the differential gear assembly (5), from right side of front axle case (6).
6. Remove the stake of lock nut (10), and then remove the lock nut (10).
7. Remove the taper roller bearing (9).


(When reassembling)

- Apply gear oil to the taper roller bearings (9) and install them correctly, noting their direction.
- Replace the lock nut (10) and oil seal (11) with new ones.
- After tightening the lock nut (10) to the specified torque, stake it firmly.
- Install the adjusting collars (2), (8) to their original position.

5.2.7 Removing differential gear

NOTE

- Arrange the parts to know their original position.



- | | |
|----------------------------|-------------------------------|
| (1) Shim | (6) Bearing |
| (2) Differential pinion | (7) Differential gear case |
| (3) Shim | (8) Differential pinion shaft |
| (4) Differential side gear | (9) Ball bearing |
| (5) Bevel gear | (10) Spring pin |

- Remove the bevel gear (5) with bearing (6) and ball bearing (9) by puller.
- Remove the spring pin (10).
- Remove the differential pinion shaft (8).
- Remove the differential pinions (2), differential side gears (4) and shims (1), (3).

(When reassembling)

- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of the differential side gears, differential pinions and shims.

6. Servicing

6.1 Checking clearance between differential case and differential side gear



- Measure the differential side gear boss O.D.

Differential side gear O.D.	Factory specification	25.939 to 25.960 mm 1.0213 to 1.0220 in.
-----------------------------	-----------------------	---

- Measure the differential case bore I.D., and calculate the clearance.

Differential case bore I.D.	Factory specification	26.000 to 26.021 mm 1.0237 to 1.0244 in.
-----------------------------	-----------------------	---

- Measure the differential case cover bore I.D., and calculate the clearance.

- If the clearance exceeds the allowable limit, replace damaged parts.

Clearance between differential case and differential side gear	Factory specification	0.040 to 0.082 mm 0.0016 to 0.0032 in.
	Allowable limit	0.17 mm 0.0067 in.

6.2 Checking clearance between differential pinion shaft and differential pinion



- Measure the differential pinion shaft O.D.

Differential pinion shaft O.D.	Factory specification	9.960 to 9.975 mm 0.3922 to 0.3927 in.
--------------------------------	-----------------------	---

- Measure the differential pinion I.D., and calculate the clearance.

Differential pinion I.D.	Factory specification	10.000 to 10.015 mm 0.39370 to 0.39429 in.
--------------------------	-----------------------	---

- If the clearance exceeds the allowable limit, replace damaged parts.

Clearance between differential pinion shaft and differential pinion	Factory specification	0.025 to 0.055 mm 0.00099 to 0.0021 in.
	Allowable limit	0.25 mm 0.0098 in.

6.3 Checking backlash between differential pinion and differential side gear




1. Set a dial gauge (lever type) on a tooth of the differential pinion.
2. Fix the differential side gear, and move the differential pinion to measure the backlash.
3. If the measurement exceeds the factory specifications, adjust with the differential side gears shims.

Backlash between differential pinion and differential side gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.01 in.
---	-----------------------	------------------------------------

(Reference)

Thickness of adjusting shims	For side gear	0.80 mm 0.031 in.
		1.0 mm 0.039 in.
		1.2 mm 0.047 in.
	For pinion	3.30 mm 0.130 in.
		3.50 mm 0.138 in.
		3.70 mm 0.146 in.
		3.90 mm 0.154 in.

6.4 Checking turning torque of bevel pinion shaft





1. Clamp the spiral bevel pinion shaft assembly to the vise and tighten the staking nut.
2. Measure the turning torque of bevel pinion shaft.
3. If the turning torque is not within the factory specifications, adjust with the lock nut.

■ NOTE

- After turning force adjustment, be sure to stake the lock nut.

Turning torque	Factory specification	0.80 to 1.0 N · m 0.082 to 0.10 kgf · m 0.59 to 0.73 lbf · ft
----------------	-----------------------	---

6.5 Checking backlash between bevel pinion shaft and bevel gear



- (1) Bevel gear
(2) Bevel pinion shaft
(3) Adjusting collar
(4) Adjusting collar

- Put the wire of solder or plastigauge on the position where the tooth proper contact of bevel pinion shaft.

Wire of solder	Factory specification	Thickness 0.5 mm 0.02 in.
----------------	-----------------------	---------------------------------

- Fix the bevel gear and rotate the bevel pinion shaft carefully.
- Measure the backlash.
- If the backlash is not within the factory specifications, change the adjusting collar (3) and (4).


Backlash between bevel pinion shaft and bevel gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.01 in.
--	-----------------------	------------------------------------

(Reference)

Thickness of adjusting collars (3), (4)	3.40 mm 0.134 in.
	3.60 mm 0.142 in.
	3.80 mm 0.150 in.
	3.90 mm 0.154 in.
	4.00 mm 0.157 in.
	4.10 mm 0.161 in.
	4.20 mm 0.165 in.
	4.40 mm 0.173 in.
	4.50 mm 0.177 in.
	4.60 mm 0.181 in.

- Adjust the backlash properly by repeating the above procedures.

6.6 Checking backlash between 12T bevel gear and 15T bevel gear



- (1) 15T bevel gear
(2) 12T bevel gear
(3) Shim

- Stick a strip of wire of solder or plastigauge to three spots on the 15T bevel gear (1) with grease.
- Fix the front axle case, bevel gear case and front gear case.
- Turn the axle.
- Remove the bevel gear case from front axle case and measure the backlash.

5. FRONT AXLE

5. If the backlash is not within the factory specifications, adjust with shim (3).

Backlash between 12T bevel gear and 15T bevel gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.01 in.
--	-----------------------	------------------------------------

(Reference)

Thickness of adjusting shims (3)	0.8 mm 0.03 in.
	1.0 mm 0.039 in.
	1.2 mm 0.047 in.
	1.4 mm 0.055 in.
Tooth contact	More than 35%

6.7 Checking clearance between center pin and pin support bushing



1. Measure the center pin O.D. with an outside micrometer.

Center pin O.D.	Factory specification	19.850 to 20.000 mm 0.78150 to 0.78740 in.
-----------------	-----------------------	---

2. Measure the pin support bush I.D. of the front axle with a cylinder gauge.

Bush I.D.	Factory specification	20.000 to 20.081 mm 0.78741 to 0.79059 in.
-----------	-----------------------	---

3. If the clearance exceeds the allowable limit, replace it.

Clearance between center pin and pin support bush	Factory specification	0 to 0.231 mm 0 to 0.00909 in.
	Allowable limit	0.70 mm 0.028 in.


6. STEERING

MECHANISM

1. Structure of steering system

This model is provided with a full hydrostatic power steering. This steering system consists of a hydraulic pump (1), steering cylinder (2), steering controller (3), etc.

In the full hydrostatic power steering, the steering controller (3) is connected to the steering cylinder (2) with only the hydraulic hoses. This steering is actuated by oil pressure. Accordingly, it does not have mechanical transmitting parts such as steering gear, pitman arm, drag link, etc. Therefore, it is simple in construction.



The steering circuit consists of a steering controller (1), steering cylinder (2), flow priority valve (3), hydraulic control valve assembly (4), hydraulic pump (5), and oil strainer (6).

The flow priority valve then divides the oil into two directions. The priority direction is to control the oil flow to the power steering at a fixed control rate. The secondary direction is excessive flow to the control valve of the implement lift circuit.



- | | | | |
|-------------------------|--------------------------------------|------------------------|--------------------------|
| (1) Steering controller | (4) Hydraulic control valve assembly | (6) Oil strainer | C: To hydraulic cylinder |
| (2) Steering cylinder | | A: To PTO clutch valve | |
| (3) Flow priority valve | (5) Hydraulic pump | B: To HST | |

Oil flow rate	Flow priority valve	8.0 L/min. 2.1 U.S.gals/min. 1.8 Imp.gals/min.
---------------	---------------------	--

3. Steering controller

3.1 Structure of steering controller

The steering controller consists of a control valve (4), metering device (3), and relief valve (1).



- | | |
|-------------------------|---|
| (1) Relief valve | (6) Check valve |
| (2) Steering controller | P: P port (from flow priority valve) |
| (3) Metering device | T: T port (to PTO clutch valve and HST circuit) |
| (4) Control valve | |
| (5) Steering cylinder | |


3.1.1 Control valve

3.1.1.1 Structure of control valve

The control valve is a rotating spool type.

When the steering wheel is not turned, the position of the spool (7) and sleeve (9) is kept neutral by the centering spring (8). This causes the forming of a "neutral" oil circuit.

When the steering wheel is turned either clockwise or counterclockwise, the position of the spool and sleeve changes in relation to the centering spring. This allows the forming of a "right turning" or "left turning" oil circuit. At the same time, the gear pump (metering device) rotates with the spool and sends the oil to the cylinder corresponding to the rotation of the steering wheel.




- | | |
|----------------------|------------------|
| (7) Spool | (9) Sleeve |
| (8) Centering spring | A: Control valve |

3.1.2 Metering device

3.1.2.1 Structure of metering device

Oil sent from the hydraulic pump to the steering cylinder, passes through the metering device.

Namely, when the rotor is driven, two chambers suck in oil due to volumetric change in the pump chambers formed between the rotor (12) and the stator (13), while oil is discharged from other two chambers. On the other hand, rotation of the steering wheel is directly transmitted to the rotor through the spool, drive shaft (10), etc.



- | | |
|------------------------|--------------------|
| (10) Drive shaft | (13) Stator |
| (11) Distributor plate | B: Metering device |
| (12) Rotor | |

3.1.2.2 Function of metering device

The metering device serves to supply the steering cylinder with oil, amount of which corresponds to the rotation of the steering wheel. The wheels are thus turned by the angle corresponding to the rotation of the steering wheel.

When the engine stops or the hydraulic pump malfunctions, the metering device functions as a manual trochoid pump, which makes manual steering possible.

3.1.3 Relief valve

3.1.3.1 Function of relief valve

The relief valve is located in the steering controller.
It controls the maximum pressure of the power steering system.


3.1.3.2 Specification of relief valve

The setting pressure for the relief valve is as follows.

Relief valve	Operating pressure	8.33 to 8.83 MPa 85 to 90 kgf/cm ² 1209 to 1280 psi
--------------	--------------------	--

4. Steering cylinder

4.1 Structure of steering cylinder



- | | | | |
|----------------------|---------------|----------------------|--------------------|
| (1) Rod | (4) Guide | (7) Center piston | (10) Cylinder tube |
| (2) Wiper seal | (5) O-ring | (8) Piston O-ring | (11) Rod O-ring |
| (3) Internal circlip | (6) Seal ring | (9) External circlip | |

The steering cylinder is single piston both rod double-acting type. This steering cylinder is installed parallel to the front axle and connected to tie-rods.

The tie-rods connected to both knuckle arm guarantees equal steering movement to both front wheels.

The steering cylinder provides force in both directions. Depending upon direction the steering wheel is turned pressure oil enters at one end of the cylinder to extend, or the other end to retract it, thereby turning front wheel of the tractor.

SERVICING

1. Troubleshooting for steering

Symptom	Probable cause and checking procedure	Solution	Reference page
Cannot be steered	1. Steering controller malfunctioning	Replace	6-13
Hard steering	1. Power steering oil improper (Transmission fluid)	Change with specified oil	2-7
	2. Hydraulic pump malfunctioning	Replace	7-39
	3. Flow priority valve malfunctioning	Repair or replace	7-8
	4. Steering controller malfunctioning	Replace	6-13
Steering force fluctuates	1. Steering controller malfunctioning	Replace	6-13
	2. Flow priority valve malfunctioning	Repair or replace	7-8
	3. Air sucked in pump due to lack of oil	Fill	2-34
	4. Air sucked in pump from suction circuit	Repair	—
Steering wheel turns spontaneously when released	1. Steering controller malfunctioning	Replace	6-13
Front wheels wander to right or left	1. Steering controller malfunctioning	Replace	6-13
	2. Air sucked in pump due to lack of oil	Fill	2-34
	3. Air sucked in pump from suction circuit	Repair	—
	4. Insufficient bleeding	Bleed	—
	5. Cylinder malfunctioning	Repair or replace	6-12
	6. Improper toe-in adjustment	Adjust	5-8
	7. Tire pressure uneven	Inflate	2-47
Wheels are turned to a direction opposite to steering direction	1. Cylinder piping connected in reverse	Repair	6-13
Steering wheel turns idle in manual steering	1. Insufficient bleeding	Bleed	—
	2. Air sucked in due to lack of oil	Fill	2-34

(Continued)

6. STEERING

Symptom	Probable cause and checking procedure	Solution	Reference page
Noise	1. Air sucked in pump due to lack of oil	Fill	2-34
	2. Air sucked in pump from suction circuit	Repair	—
	3. Pipe deformed	Replace	—
Oil temperature increases rapidly	1. Steering controller (relief valve) malfunctioning	Replace	6-13

2. Servicing specifications for steering

Power steering body

Item		Factory specification	Allowable limit
Relief valve	Operating pressure	8.34 to 8.82 MPa 85.0 to 90.0 kgf/cm ² 1210 to 1280 psi	—

Steering cylinder

Item		Factory specification	Allowable limit
Steering cylinder	I.D.	40.000 to 40.062 mm 1.5748 to 1.5772 in.	40.100 mm 1.5787 in.
Piston rod to guide	Clearance	0.020 to 0.070 mm 0.00079 to 0.0027 in.	0.200 mm 0.00787 in.

3. Tightening torques for steering

Tightening torques of screws, bolts and nuts on the table below are especially specified.

Item	N · m	kgf · m	lbf · ft
Steering wheel mounting nut	20 to 25	2.0 to 2.6	15 to 18
Power steering hose	24 to 27	2.4 to 2.8	18 to 20
Power steering cylinder mounting screw	48 to 55	4.9 to 5.7	36 to 41
Tie-rod slotted nut	18 to 34	1.8 to 3.5	13 to 25
Tie-rod screw	74 to 84	7.5 to 8.6	55 to 62

—— RELATED PAGE ——

[TIGHTENING TORQUES on page 2-13](#)

4. Checking and adjusting

4.1 Checking relief valve operating pressure

NOTE

- After setting a pressure gauge, be sure to bleed air.
- Note that the pressure value changes by the pump action of the power steering controller when the steering operation is continued after the steering wheel is lightly locked and accurate relief valve pressure cannot be measured.



1. Disconnect the power steering hose L (or R) from steering controller, and set a pressure gauge and hose.

(Reference)

Hose and adapter size	9/16-18 UNF, 37° flare
-----------------------	------------------------

2. Start the engine and set at maximum speed.
3. Fully turn the steering wheel to the left (or right) to check the feeling which the steering wheel lightly locks. Read the relief valve operating pressure when the steering wheel to the above-mentioned lock position by operation force.


Operation force (Steering wheel)	Approximate	9.8 N 1.0 kgf 2.2 lbf
-------------------------------------	-------------	-----------------------------

Relief valve operating pressure	Factory specification	8.34 to 8.82 MPa 85.0 to 90.0 kgf/cm ² 1210 to 1280 psi
---------------------------------	-----------------------	--

5. Disassembling and assembling

5.1 Power steering cylinder

5.1.1 Removing adapter and tie-rod




- 3TAAAB7P013A
- | | |
|-----------------------|-----------------------|
| (1) Cylinder holder | (5) Cylinder |
| (2) Tie-rod R.H. | (6) Hose adapter L.H. |
| (3) Internal circlip | (7) Piston rod |
| (4) Hose adapter R.H. | (8) Tie-rod L.H. |

1. Remove the cylinder hose adapters (4), (6).
2. Remove the tie-rods (2), (8) from piston rod (7).
3. Remove the cylinder holder (1) and internal circlip (3).

(When reassembling)

- Be sure to install the hose adapters (4), (6).





- 3TAAAB7P014A
- | | |
|-----------------------|--------------------|
| (4) Hose adapter R.H. | (A) 0.26 rad (15°) |
| (5) Cylinder | (B) Front |
| (6) Hose adapter L.H. | |

- After reassembling the tie-rod, be sure to adjust the toe-in.

Tightening torque	Tie-rod screw	74 to 84 N · m 7.5 to 8.6 kgf · m 55 to 62 lbf · ft
-------------------	---------------	---

5.1.2 Disassembling steering cylinder



- | | |
|--------------------|-------------------------|
| (1) Piston rod | (7) Wiper ring |
| (2) Cylinder tube | (8) O-ring |
| (3) Guide assembly | (9) Piston rod assembly |
| (4) Circlip | (10) Center piston |
| (5) Guide | (A) Drill a hole. |
| (6) Seal ring | (B) 5.25 mm (0.207 in.) |

- Carefully clamp the cylinder in a vise.
- Push one of the guide assembly (3) to inside of cylinder tube (2).
- Drill a hole on the cylinder tube (2) just over the circlip (4).

Hole	Factory specification	2.5 mm dia. 0.098 in. dia.
------	-----------------------	-------------------------------

- Take a little screwdriver and lift off the circlip (4) from its groove. Simultaneous support this action by pushing from the outside of the cylinder tube with another little screwdriver or another tool.
- Push out the piston rod assembly (9) and take off the guide assembly (3).

(When reassembling)

NOTE

- Seals must be exchanged after disassembling.
- Apply transmission fluid to the exchanged seals.
- Enter the piston rod and block the guide assemblies with the circlips.

5.2 Separating power steering controller

5.2.1 Removing battery



WARNING

To avoid serious injury or death:


- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.

- Remove the under panel (1).



- Under panel
- Disconnect the negative cable (3) from the battery (2).


3. Disconnect the positive cable (4) from the battery (2) and remove the battery.



- (2) Battery
(3) Negative cable
(4) Positive cable

5.2.2 Removing steering wheel

1. Remove the steering wheel cap (1).
2. Remove the steering wheel mounting nut and remove the steering wheel (2).




- (1) Steering wheel cap
(2) Steering wheel

(When reassembling)

Tightening torque	Steering wheel mounting nut	20 to 25 N · m 2.0 to 2.6 kgf · m 15 to 18 lbf · ft
-------------------	-----------------------------	---

5.2.3 Removing upper panel

1. Disconnect the main switch (2) and combination switch (5).
2. Remove the hand accelerator lever grip (1), cruise control lever knob (3), and tilt lever grip (4).




- (1) Hand accelerator lever grip
(2) Main switch
(3) Cruise control lever knob
(4) Tilt lever grip
(5) Combination switch
(6) Bolt
(7) Upper panel

3. Open the bonnet, and remove the upper panel mounting bolts (6).
4. Remove the upper panel (7).

5.2.4 Removing steering controller


1. Disconnect the power steering hoses (3), (4), (5), (6) from the steering controller (1).



- (1) Steering controller
(2) Cylinder hose L.H.
(3) Cylinder hose R.H.
(4) Return hose
(5) Delivery hose
(6) Return pipe
(7) Delivery pipe
(8) Steering cylinder

6. STEERING


- Remove the steering controller mounting screws (9) and remove the steering controller.



(1) Steering controller (9) Screw

(When reassembling)

- Be sure to connect the power steering hoses to their original position, and tighten them to the specified torque.




- A: Bottom view R: R port (Connect to cylinder R.H. hose)
 P: Pump port (Connect to delivery hose) a: Right
 T: Tank port (Connect to return hose) b: Front
 L: L port (Connect to cylinder L.H. hose)

Tightening torque	Power steering hose	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft
-------------------	---------------------	---


5.3 Separating power steering cylinder**5.3.1 Removing bonnet**

- Remove the mower deck.
- Remove the front link (1) and link brackets (2).



(1) Front link (4) L.H. bonnet bracket
 (2) Front link bracket (5) R.H. bonnet bracket
 (3) Bonnet guide rod


- Open the bonnet.
- Disconnect the headlight harness from the headlights and bonnet.
- Disconnect the bonnet guide rod (3) from the bonnet.
- Disconnect the L.H. and R.H. bonnet brackets (4), (5) from the frame.
- Remove the bonnet (6).



(6) Bonnet


5.3.2 Removing front axle assembly

1. Remove the power steering hose clamp (1).




(1) Hose clamp

2. Place the garage jack under the front axle.
3. Remove the cotter pin (3).
4. Remove the slotted nut (2) of center pin and separate the front axle from the frame.



(2) Slotted nut (Adjusting nut for front axle rocking force) (3) Cotter pin

5. Disconnect the power steering hoses (4).



(4) Power steering hose


(When reassembling)

- After mounting the front axle assembly to the frame, be sure to adjust the front axle rocking force.

- Installing the cotter pin, be sure to split the cotter pin like an anchor.

Tightening torque	Power steering hose	24 to 27 N · m 2.4 to 2.8 kgf · m 18 to 20 lbf · ft
-------------------	---------------------	---

5.3.3 Removing power steering cylinder



(1) Tie-rod (2) Power steering cylinder

1. Remove the cotter pin and remove the slotted nut for tie-rod (1).
2. Remove the power steering cylinder mounting screws and remove the power steering cylinder (2) with tie-rod.

(When reassembling)

■ NOTE


- Tighten the slotted nut. If the slot and pin hole do not meet, tighten the nut until they do meet, and install the cotter pin.
- Be sure to split the cotter pin like an anchor.

Tightening torque	Tie-rod slotted nut	18 to 34 N · m 1.8 to 3.5 kgf · m 13 to 25 lbf · ft
	Power steering cylinder mounting screw	48 to 55 N · m 4.9 to 5.7 kgf · m 36 to 41 lbf · ft

6. Servicing

6.1 Checking steering cylinder I.D.


1. Measure the steering cylinder I.D. with a cylinder gauge.



2. If the cylinder I.D. exceeds the allowable limit, replace the cylinder barrel.

Steering cylinder I.D.	Factory specification	40.000 to 40.062 mm 1.5748 to 1.5772 in.
	Allowable limit	40.100 mm 1.5787 in.

6.2 Checking clearance between rod and guide



1. Measure the rod guide I.D. with a cylinder gauge.
2. Measure the rod O.D. with an outside micrometer, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace as a unit.


Clearance between rod and guide	Factory specification	0.020 to 0.070 mm 0.00079 to 0.0027 in.
	Allowable limit	0.200 mm 0.00787 in.

7. HYDRAULIC SYSTEM

MECHANISM

1. Structure of hydraulic system

The hydraulic system of this tractor consists of hydrostatic transmission, hydraulic pump, 3 point hitch and power steering.



2HMET00030A01

(1) Power steering controller
(2) Front loader control valve

(3) Hydraulic block
(4) Flow priority valve

(5) Hydraulic pump

(6) Hydrostatic transmission
(HST)


(7) Steering cylinder

2. Hydraulic circuit

The hydraulic system of this tractor consists of a hydraulic pump, control valve for front loader, 3 point hitch system and other components.

This system has the following functions:

1. Oil is supplied by hydraulic pump which is driven by pump drive shaft in the transmission case. As the pump drive shaft is connected to the propeller shaft, hydraulic pump starts operating when engine is started.
2. The hydraulic pump supplies the high pressured oil to auxiliary hydraulic control valve for front loader, control valve for 3 point hitch system, power steering controller, PTO clutch valve and hydrostatic transmission after dividing oil flow by flow priority valve.



- | | | | |
|--|-----------------------------|----------------------------------|---------------------------------|
| (1) Hydraulic pump | (6) Relief valve | (12) Power steering relief valve | (18) Bucket control valve |
| (2) Hydraulic oil filter | (7) Hydraulic oil filter | (13) Power steering controller | (19) Front loader control valve |
| (3) Charge relief valve | (8) PTO clutch relief valve | (14) Steering cylinder | (20) Bucket cylinder |
| (4) Check and high pressure relief valve | (9) PTO clutch relief valve | (15) Control valve | (21) Boom cylinder |
| (5) Hydrostatic transmission | (10) PTO clutch | (16) Hydraulic cylinder | |
| | (11) Flow priority valve | (17) Boom control valve | |

Operating pressure and oil flow

(1)	(Factory specification) 23.5 L/min. (6.2 U.S.gals/min., 5.2 Imp.gals/min.)
(3)	0.55 to 0.75 MPa (5.6 to 7.7 kgf/cm ² , 80 to 100 psi)
(4)	20.1 to 21.1 MPa (205 to 215 kgf/cm ² , 2920 to 3060 psi)
(8)	1.0 to 1.3 MPa (11 to 13 kgf/cm ² , 150 to 180 psi)
(12)	8.34 to 8.82 MPa (85.0 to 90.0 kgf/cm ² , 1210 to 1280 psi)

3. Hydraulic pump



3.1 Outline of hydraulic pump

This hydraulic pump is located on left side of transmission.

Hydraulic pump is driven by the pump drive shaft in the transmission case.

3.2 Structure of hydraulic pump

The hydraulic pump consists of the casing (1), cover (4), side plate (3), and two spur gears (drive gear (5) and driven gear (2)) that are in mesh.



- | | |
|-----------------|----------------|
| (1) Casing | (5) Drive gear |
| (2) Driven gear | (6) Pin |
| (3) Side plate | (7) Oil seal |
| (4) Cover | |

3.3 Specification of hydraulic pump

Maximum displacement of hydraulic pump is as follows.

Displacement	Engine speed	Condition
23.5 L/min. 6.2 U.S.gals/min. 5.2 Imp.gals/min.	At 3200 min ⁻¹ (rpm)	At no load

4. Control valve

4.1 Outline of control valve

This position control valve is located under the hydraulic cylinder.

This control valve is mechanically connected to the position control lever.

Since the feedback rod is not equipped to the lift arm, the neutral position adjustment is adjusted by controlling the position control lever.

The control valve controls the oil flow forced from the hydraulic pump and the oil returned back from the hydraulic cylinder.



4.2 Function of control valve

4.2.1 Control valve in neutral position

When you stop the position control lever, the spool is stopped.

The spool closes the oil flow from passage between P port and C port.

Since the oil in the hydraulic cylinder is not drained to T2 port, neutral position is kept.



- (1) Lift arm
- (2) Hydraulic cylinder
- (3) Control valve body

- (4) Spool
- (5) Lowering adjusting shaft

- C: Cylinder port
- T1: Tank port
- T2: Tank port

4.2.2 Control valve in lift position



When the control lever is set to the lift position, the spool (4) moves to the right.

The oil forced into the control valve flows through P port to C port and the hydraulic cylinder.

The oil pushes the hydraulic piston in the hydraulic cylinder to lift the implement.

Since the spool shape is step down structure, oil passes slowly through the gap between the control valve body (3) and the spool (4) to C port.

In this tractor, when you set the control lever to the slow up, implement lifts up with ease in increments of approximately 1/4 inches at lower link end.



- | | |
|------------------------|------------------------------|
| (1) Lift arm | (4) Spool |
| (2) Hydraulic cylinder | (5) Lowering adjusting shaft |
| (3) Control valve body | P: Pump port |

- | |
|------------------|
| C: Cylinder port |
| T1: Tank port |
| T2: Tank port |

4.2.3 Control valve in down position

When the control lever is set to the down position, the spool (4) moves to the left.



The oil forced from the P port flows through the gap between the control valve body and the spool to the T1 port.

The oil in the hydraulic cylinder flows through the gap between the control valve body (3) and the spool (4) to the T2 port.

Since the oil in the hydraulic cylinder drains to the transmission case, the implement lowers.

Since the spool shape is step down structure, oil pass slowly from C port through the gap between the control valve body (3) and the spool (4) to T2 port.

In this tractor, when you set the control lever to the slow down position, implement lowers down with ease in increments of approximately 1/4 inches at lower link end.



- (1) Lift arm
- (2) Hydraulic cylinder
- (3) Control valve body

- (4) Spool
- (5) Lowering adjusting shaft

- C: Cylinder port
- T1: Tank port
- T2: Tank port

5. Flow priority valve


5.1 Outline of flow priority valve

This flow priority valve is located to the left side of the transmission.

The flow priority valve is a flow divider that divides a single hydraulic source (hydraulic pump) into two circuits and actuates them simultaneously.

5.2 Structure of flow priority valve

The structure of the flow priority valve is as follows.



- (1) Hydraulic pump gear
- (2) Hydraulic pump case
- (3) Plug

- (4) Flow priority valve
- (5) Relief valve

EF: EF port (to 3 point hitch control circuit)

PF: PF port (to power steering, PTO clutch and HST circuit)
P: Pump port (Suction)
T: Tank port

5.3 Specification of flow priority valve

The oil flow of the priority valve is as follows.

Power steering oil flow	Engine speed	Condition
Above 8.0 L/min. 2.1 U.S.gals/min. 1.8 Imp.gals/min.	At 1500 min ⁻¹ (rpm)	At no load

6. Relief valve

6.1 Outline of relief valve

This relief valve is located on the left side of transmission.


The implement control system circuit has a relief valve to restrict the maximum pressure in the circuit.

The relief valve is a guide piston type with damping effect.

6.2 Structure of relief valve

Among direct acting relief valves, this type is suited to higher pressure and has large capacity. Furthermore, this type is free from unstable operation, such as chattering, which occurs often in direct acting relief valves.

As shown in the figure, the guide is attached to the poppet (7) and a valve chamber D.C. (called the damping chamber) is formed at the top of the guide piston. The inlet of the valve leads to the chamber via a clearance between the sliding portion of the guide and the seat (6), minimizing valve vibration with the damping effect of the chamber.



- (1) Hydraulic pump gear
- (2) Hydraulic pump case
- (3) Plug
- (4) Flow priority valve

- (5) Relief valve
- (6) Seat
- (7) Poppet


- EF: EF port (to 3 point hitch control circuit)
- PF: PF port (to power steering, PTO clutch and HST circuit)

- DC: Damping chamber
- P: Pump port (Suction)
- T: Tank port

6.3 Function of relief valve

When the oil pressure in the circuit is lower than the setting pressure of the relief valve, the relief valve is not operated and the oil fed to the relief valve from the hydraulic pump flows into the implement control valve.

As the oil pressure in the circuit increases, so does the pressure in the damping chamber D.C. When the pressure rises above the valve setting and overcomes the spring force, the valve opens. Oil then flows out to the transmission case through T port, preventing any further rise in pressure. The valve closes again when enough oil is released to drop pressure below the valve setting.



3TAAAF8P031A

- (1) Hydraulic pump gear
- (2) Hydraulic pump case
- (3) Plug

- (4) Flow priority valve
- (5) Relief valve

EF: EF port (to 3 point hitch control circuit)
PF: PF port (to power steering, PTO clutch and HST circuit)

DC: Damping chamber
P: Pump port (Suction)
T: Tank port

6.4 Specification of relief valve

The setting pressure of the relief valve is as follows.


Relief valve setting pressure	Engine speed	Oil temperature
12.3 to 12.7 MPa 125 to 130 kgf/cm ² 1780 to 1840 psi	Maximum	40 to 50 °C 104 to 122 °F

7. Hydraulic cylinder

7.1 Structure of hydraulic cylinder

While the lift arm (1) is rising, oil from the hydraulic pump flows into the hydraulic cylinder through the hydraulic control valve (12) and cylinder port C. Then oil pushes out the piston (5).

While the lift arm (1) is lowering, oil in the hydraulic cylinder is discharged to the transmission case through the hydraulic control valve by the weight of the implement. At this time, the lowering speed of the implement can be controlled by the ball (7) attached to the hydraulic cylinder (11). Turning the lowering speed adjusting knob clockwise decreases the lowering speed, and counterclockwise increases lowering speed. When the lowering speed adjusting valve is completely closed, the lift arm (1) is held at its position since oil in the hydraulic cylinder is sealed between the piston (5) and ball (7).



- | | | | |
|-------------------------|------------|------------------------------------|-------------------------|
| (1) Lift arm | (5) Piston | (8) Lowering speed adjusting shaft | (11) Hydraulic cylinder |
| (2) Hydraulic arm | (6) Spring | (9) Back-up ring | (12) Control valve |
| (3) Hydraulic arm shaft | (7) Ball | (10) O-ring | P: Pump port |
| (4) Hydraulic rod | | | C: Cylinder port |

8. Hydraulic block type outlet


8.1 Structure of hydraulic block type outlet

■ NOTE

- This hydraulic block type outlet uses for front loader hydraulic system on standard specification.

The hydraulic block type outlet is located on the hydraulic cylinder assembly.

This hydraulic block type outlet is provided to use power from the tractor to operate the hydraulic cylinders on the implement, such as front end loader, front snow blade and other implements.



- (1) Block cover
(2) Hydraulic cylinder
P: P port (Pump)

P.B.: P.B. port (Power beyond)
T: T port (Tank)


9. Mower linkage

9.1 Structure of mower linkage

The mower rear link (1) and the lift arm (5) are linked with the mower lift arm (2), the lift upper boss and the lift lower boss.

As the hydraulic control lever moves to lift position, lift arm (5) is raised and the lift bracket (4) is pulled to pull the lift links to the rearward. As a result, mower rear link (1) is lifted.

The cutting height adjusting dial (3) adjusts cutting height of mower by rotating the adjusting cam (7). The position of mower rear link (1) is adjusted by changing the length of the adjusting bolt (6).



2HMET00021A01

(1) Mower rear link
(2) Mower lift arm

(3) Cutting height adjusting dial
(4) Lift bracket


(5) Lift arm
(6) Adjusting bolt

(7) Cam
(8) Lift pin

10. Front loader valve

10.1 Structure


10.1.1 Structure of front loader valve and pipe



- | | | | |
|-------------------------|-----------------------------------|-----------------------------------|------------------------------------|
| (1) Control lever | (4) Pipe (Pressure) | (7) Pipe (1A) for boom cylinder | (10) Pipe (2A) for bucket cylinder |
| (2) Lock lever | (5) Pipe (Return) | (8) Pipe (1B) for boom cylinder | (11) Front loader control valve |
| (3) Pipe (Power beyond) | (6) Hydraulic outlet (Block type) | (9) Pipe (2B) for bucket cylinder | |

10.1.2 Structure of front loader control valve

The control valve assembly consists of one casting block and four major sections.



- | | | |
|--------------------------|-------------|-----------------------|
| (1) Boom control valve | 1B: 1B port | P: Pump port |
| (2) Bucket control valve | 2A: 2A port | PB: Power beyond port |
| 1A: 1A port | 2B: 2B port | T: Tank port |

(1) Boom control section

The boom control valve is of 4-position, 6-connection, detent, spring center type, consisting of a mono block valve housing, spool, load check valve, etc. This valve has A1 and B1 ports and controls oil flow to the boom cylinder.

(2) Bucket control section

The bucket control valve is of 3-position, 6-connection, no detent, spring center type, consisting of a mono block valve housing, spool, load check valve, etc. This valve has A2 and B2 ports and controls oil flow to the bucket cylinder.

Inlet (P port) and outlet (T port) section

This section has P and T ports.


The P port is connected to the outlet port of hydraulic block by the hydraulic pipe.

The T port is connected to the tank port of hydraulic block by the hydraulic pipe.

Power beyond (PB port)

This section has PB port which is connected to the inlet port of hydraulic block by the hydraulic hose, and feeds oil to the three point hydraulic control valve.

10.2 Front loader hydraulic circuit




- | | | | |
|--------------------------------|-------------|-----------------------|-----------------------|
| (1) Front loader control valve | 1A: 1A port | 2B: 2B port | T: Tank port |
| (2) Bucket control valve | 1B: 1B port | P: Pump port | a: To hydraulic block |
| (3) Boom control valve | 2A: 2A port | PB: Power beyond port | |

10.3 Function of loader control valve

10.3.1 Loader control lever in neutral position

When the loader control lever is set at neutral position, the hydraulic oil enters from P port (P), flows through the boom spool valve (3) and the bucket spool valve (2), and exits at PB port (PB).

Neutral



2HMET00024A01

- (1) Front loader control valve
- (2) Bucket spool valve
- (3) Boom spool valve
- (4) Plug (Bucket control)
- (5) Detent plug (Boom control)

- (6) Check valve
- (7) Boom cylinder
- (8) Bucket cylinder
- (9) Check valve
- 1A: 1A port


- 1B: 1B port
- 2A: 2A port
- 2B: 2B port
- P: From hydraulic pump
- PB: To 3-point hydraulic system

- T: To tank, transmission case
- a: Low pressure

10.3.2 Loader control lever in up position

1. When the loader control lever is set at up position, the boom spool valve (3) moves outward. This creates an oil passage between the boom spool valve (3) and the front loader control valve (1). The pressured oil from the pump port (P) enters to this oil passage. The pressured oil is delivered to the boom cylinder (7) through 1B port (1B). This extends and raises the boom cylinder.
2. When the boom spool valve (3) moves outward, a passage between the boom spool valve (3) and 1A port (1A) is created. The return oil from the boom cylinder enters 1A port (1A), flows through the bucket spool valve (2) and exits to PB port (PB).

Up




2HMET00025A01

- | | | | |
|----------------------------------|---------------------|---------------------------------|-------------------------------|
| (1) Front loader control valve | (6) Check valve | 1B: 1B port | T: To tank, transmission case |
| (2) Bucket spool valve | (7) Boom cylinder | 2A: 2A port | a: Low pressure |
| (3) Boom spool valve | (8) Bucket cylinder | 2B: 2B port | b: High pressure |
| (4) Detent plug (Bucket control) | (9) Check valve | P: From hydraulic pump | |
| (5) Detent plug (Boom control) | 1A: 1A port | PB: To 3-point hydraulic system | |

10.3.3 Loader control lever in down position

1. When the loader control lever is set at down position, the boom spool valve (3) moves inward. This creates an oil passage between the boom spool valve (3) and the front loader control valve (1). The pressured oil from the pump port (P) enters to the newly opened passage. The pressured oil is delivered to the boom cylinder (7) through 1A port (1A). This retracts and lowers the boom cylinder.
2. When the boom spool valve (3) moves inward, a passage between the boom spool valve (3) and 1B port (1B) is created. The return oil in the boom cylinder enters 1B port (1B), flows to the bucket spool valve (2), and exits to the PB port (PB).

Down




- | | | | |
|----------------------------------|---------------------|---------------------------------|-------------------------------|
| (1) Front loader control valve | (6) Check valve | 1B: 1B port | T: To tank, transmission case |
| (2) Bucket spool valve | (7) Boom cylinder | 2A: 2A port | a: Low pressure |
| (3) Boom spool valve | (8) Bucket cylinder | 2B: 2B port | b: High pressure |
| (4) Detent plug (Bucket control) | (9) Check valve | P: From hydraulic pump | |
| (5) Detent plug (Boom control) | 1A: 1A port | PB: To 3-point hydraulic system | |

10.3.4 Loader control lever in floating position

1. When the loader control lever is set to floating position, the boom spool valve (3) moves further inward. This creates oil passages at 1A port (1A) and 1B port (1B), as well as a passage between the boom spool valve (3) and the front loader control valve (1).
2. The low pressured oil from the pump port (P) flows through the bucket spool valve (2), and exits to the PB port (PB).
3. The low pressured return oil in the boom cylinder enters 1A port (1A), flows through the boom spool valve (3), and goes to the tank port (T). The other low pressured return oil in the boom cylinder enters 1B port (1B), flows through the boom spool valve (3), and goes to the tank port (T). As a result, the boom is floating.

Floating




2HMET00027A01

- | | | | |
|----------------------------------|---------------------|---------------------------------|-------------------------------|
| (1) Front loader control valve | (6) Check valve | 1B: 1B port | T: To tank, transmission case |
| (2) Bucket spool valve | (7) Boom cylinder | 2A: 2A port | a: Low pressure |
| (3) Boom spool valve | (8) Bucket cylinder | 2B: 2B port | b: High pressure |
| (4) Detent plug (Bucket control) | (9) Check valve | P: From hydraulic pump | |
| (5) Detent plug (Boom control) | 1A: 1A port | PB: To 3-point hydraulic system | |

10.3.5 Loader control lever in roll-back position

1. When the loader control lever is set at roll-back position, the bucket spool valve (2) moves outward. This creates oil passages at 2A port (2A) and 2B port (2B).
2. The pressured oil from the pump port (P) flows through 2B port (2B) to the bucket cylinder.
3. The low pressured return oil from the bucket cylinder enters 2A port (2A), flows through the front loader control valve (1), and goes to the tank port (T). As a result, the bucket moves to roll-back position.

Roll-back



- (1) Front loader control valve
- (2) Bucket spool valve
- (3) Boom spool valve
- (4) Detent plug (Bucket control)
- (5) Detent plug (Boom control)

- (6) Check valve
- (7) Boom cylinder
- (8) Bucket cylinder
- (9) Check valve
- 1A: 1A port


- 1B: 1B port
- 2A: 2A port
- 2B: 2B port
- P: From hydraulic pump
- PB: To 3-point hydraulic system

- T: To tank, transmission case
- a: Low pressure
- b: High pressure

10.3.6 Loader control lever in dump position

1. When the loader control lever is set to the dump position, the bucket spool valve (2) moves to the right. This creates an oil passage at 2A port (2A). The passage between 2B port (2B) and T port (T) is also opened.
2. The pressure-fed oil from P port (P) flows to the neutral passage through the boom control section. As the passage to the PB port (PB) is closed by the bucket spool valve (2), the arriving oil opens the load check valve (9) and flows to 2A port (2A) through the notched section of the bucket spool valve (2). This extends the bucket cylinder (8).
3. Return oil from the bucket cylinder (8) enters 2B port (2B) and travels throughout the valve to go to the transmission case through T port (T).

Dump



- (1) Front loader control valve
- (2) Bucket spool valve
- (3) Boom spool valve
- (4) Detent plug (Bucket control)
- (5) Detent plug (Boom control)

- (6) Check valve
- (7) Boom cylinder
- (8) Bucket cylinder
- (9) Check valve
- 1A: 1A port

- 1B: 1B port
- 2A: 2A port
- 2B: 2B port
- P: From hydraulic pump
- PB: To 3-point hydraulic system

- T: To tank, transmission case
- a: Low pressure
- b: High pressure

SERVICING

1. Troubleshooting for hydraulic system

Symptom	Probable cause and checking procedure	Solution	Reference page
Implement does not rise (no noise)	1. Control valve broken	Replace	7-44
	2. Control valve improperly assembled	Repair	7-44
	3. Relief valve spring damaged	Replace	7-34
	4. Spool sticks	Repair	7-44
	5. Piston O-ring or cylinder damaged	Replace	7-44
Implement does not rise (noise)	1. Oil filter cartridge clogged	Replace	2-24
	2. Suction pipe loosen or broken	Repair or replace	—
	3. Suction pipe connecting hose loosen or broken	Repair or replace	—
	4. Suction pipe O-ring broken	Replace	—
	5. Insufficient transmission oil	Refill	2-34
	6. Relief valve setting pressure too low	Adjust or replace	7-34
	7. Hydraulic pump broken	Replace	—
Implement does not lower	1. Control valve malfunctioning	Repair or replace	7-44
Implement drops by its weight	1. Hydraulic cylinder worn or damaged	Replace	7-51
	2. Piston O-ring worn or damaged	Replace	7-44
	3. Control valve malfunctioning	Replace	7-44

2. Servicing specifications for hydraulic system

Item		Factory specification	Allowable limit
Relief valve (Condition) • Engine speed: maximum • Oil temperature: 45 to 55 °C (113 to 131 °F)	Setting pressure	12.3 to 12.7 MPa 125 to 130 kgf/cm ² 1780 to 1840 psi	—
Hydraulic pump (Condition) • Engine Speed: 1500 min ⁻¹ (rpm) • Oil temperature: 45 to 55 °C (113 to 131 °F)	Power steering oil flow	Above 8.0 L/min. 2.1 U.S.gals/min. 1.8 Imp.gals/min.	—
Mower linkage	Clearance "L2"	0 to 0.5 mm 0 to 0.01 in.	—
[Hydraulic pump] Gear to casing	Clearance	—	0.15 mm 0.0059 in.
• Gear	O.D.	33.520 to 33.530 mm 1.3197 to 1.3200 in.	—
• Case	I.D.	33.570 to 33.577 mm 1.3217 to 1.3219 in.	—
Gear shaft to bushing	Clearance	0.020 to 0.091 mm 0.00079 to 0.0035 in.	0.12 mm 0.0047 in.
• Gear shaft	O.D.	14.970 to 14.980 mm 0.58937 to 0.58976 in.	—
• Bushing	I.D.	15.000 to 15.061 mm 0.59056 to 0.59295 in.	—
Side plate	Thickness	2.48 to 2.50 mm 0.0977 to 0.0984 in.	2.40 mm 0.094 in.
Hydraulic cylinder	I.D.	80.05 to 80.15 mm 3.152 to 3.155 in.	80.20 mm 3.157 in.
Hydraulic arm shaft	O.D. (L.H.)	31.925 to 31.950 mm 1.2569 to 1.2578 in.	—
	O.D. (R.H.)	29.925 to 29.950 mm 1.1782 to 1.1791 in.	—

3. Tightening torques for hydraulic system

Item	N · m	kgf · m	lbf · ft
ROPS mounting nut	124 to 147	12.6 to 15.0	91.2 to 108
Fuel tank stay mounting bolt and nut	48 to 55	4.9 to 5.7	36 to 41
Fender bracket mounting bolt	124 to 147	12.6 to 15.0	91.2 to 108
Hydraulic cylinder block mounting bolt	40 to 44	4.0 to 4.5	29 to 32
Hydraulic pump mounting bolt (M6)	7.9 to 9.3	0.80 to 0.95	5.8 to 6.8
Hydraulic pump mounting bolt (M8)	18 to 20	1.8 to 2.1	13 to 15

RELATED PAGE



[TIGHTENING TORQUES on page 2-13](#)

4. Checking and adjusting

4.1 Relief valve

4.1.1 Checking relief valve setting pressure

1. Disconnect the hydraulic hose (1) from the right side of the transaxle.
2. Install the hydraulic hose (6) and adaptor A (3) with pressure gauge (2).





- | | |
|-----------------------------------|----------------------------|
| (1) Hydraulic hose | (B) Adapter B |
| (2) Pressure gauge | (a) Connect pressure gauge |
| (3) Adapter tee, swivel (9/16-18) | (b) Connect hydraulic hose |
| (6) Hydraulic hose | |
| (A) Adapter tee, swivel (9/16-18) | |

3. Start the engine and set at maximum speed.

Condition

Engine speed	Oil temperature
Maximum	45 to 55 °C 113 to 131 °F

4. Move the control lever all way up to operate the relief valve and read the gauge.
5. If the pressure is not within the factory specifications, adjust with the adjusting shim (5).



(4) Relief valve (5) Shim

Relief valve setting pressure	Factory specification	12.3 to 12.7 MPa 125 to 130 kgf/cm ² 1780 to 1840 psi
-------------------------------	-----------------------	--

(Reference)

Thickness of shim (5)	0.1 mm 0.004 in.
	0.2 mm 0.008 in.
	0.4 mm 0.02 in.

0.269 MPa (2.74 kgf/cm², 39.0 psi) pressure is increased whenever the thickness of adjusting shim is increased by 0.1 mm (0.004 in.).

4.2 Pump and priority valve

4.2.1 Checking hydraulic pump oil flow




■ IMPORTANT

- Use the instruction with the flowmeter when you use the flowmeter.
- While testing, do not close the flowmeter loading valve completely.
- To measure the flow volume of pump, oil flow on the power steering system side should be stopped.

■ **NOTE**

Plug size:

**9/16-18 UNF
SAE 37° Flare**



- (1) Power steering controller hose (Inlet) (2) Power steering pipe Plug
(3) Plug

Condition

Engine speed	Oil temperature
Maximum	45 to 55 °C 113 to 131 °F

1. Disconnect the power steering controller hose (inlet) (1) from the power steering pipe (2).

2. Cap the power steering pipe (2) with plug (3).
3. Remove the hydraulic pipe behind the hydraulic cylinder and fix the flow meter hose and the flow (meter) inlet as shown in the photo.
4. Remove the transmission fluid filling plug, then fix the flow meter hose and the flowmeter (outlet).
5. If the flow volume is insufficient, replace the pump.

(Reference)

Pump oil flow


Hydraulic pump delivery at no pressure	Factory specification	Above 24.9 L/min. 6.6 U.S.gals/min. 5.5 Imp.gals/min.
--	-----------------------	--

6. After measuring the flow volume, remove the flow meter then reassembling the hydraulic pipe to the original position.

4.2.2 Checking power steering oil flow

■ **IMPORTANT**

- Use the instruction with the flowmeter when you use the flowmeter.
- While testing, do not close the flowmeter loading valve completely.



- (1) Power steering controller hose (Inlet) (2) Power steering pipe

Condition

Engine speed	Oil temperature
1500 min ⁻¹ (rpm)	45 to 55 °C 113 to 131 °F




1. Disconnect the power steering controller hose (inlet) (1) from the power steering pipe (2).
2. Fix the inlet flow meter hose to the power steering pipe (2) and the flow meter as shown in the photo.
3. Fix the flow meter return hose to the transmission fluid filling port and the flow meter as shown in the photo.
4. Measure the flow volume of power steering.
5. If the flow volume varies from the specification, replace the priority valve then take measurement again.

Power steering oil flow	Factory specification	Above 8.0 L/min. 2.1 U.S.gals/min. 1.8 Imp.gals/min.
Engine speed	Specification	1500 min ⁻¹ (rpm)

6. After measuring the flow volume, remove the flow meter then reassemble the hydraulic pipe to the original position.

4.3 Mower lift linkage**4.3.1 Adjusting mower lift linkage**

- After reassembling the mower lift linkage, be sure to adjust it as follows.



- (1) Nut L1: Length
(2) Bolt L2: Clearance
(A) Upper view

(Reference)

Length "L1"	Factory specification	17 mm 0.67 in.
-------------	-----------------------	-------------------

1. Check the lift arm free play.
2. Loosen the adjusting nut (1) and start the engine.
3. Move the hydraulic control lever to **Lift** position until the relief valve operating. (**Uppermost** position)

4. Adjusting bolt (2) until the clearance between stopper and mower rear link L.H.

Clearance "L2"	Factory specification	0 to 0.5 mm 0 to 0.01 in.
----------------	-----------------------	------------------------------

5. Secure the lock nut (1).

5. Disassembling and assembling

5.1 Hydraulic pump

5.1.1 Removing battery

WARNING

To avoid serious injury or death:


- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.

1. Remove the under panel (1).



(1) Under panel

2. Disconnect the negative cable (3) from the battery (2).
3. Disconnect the positive cable (4) from the battery (2) and remove the battery.




(2) Battery
(3) Negative cable

(4) Positive cable

5.1.2 Removing lift rod and lower link

1. Remove the top link (2).
2. Remove the stopper pin (6) and remove the check chain plate (3).



(1) Lift rod L.H.

(2) Top link

(3) Check chain plate


(4) Lift rod R.H.

(5) Lower link R.H.

(6) Stopper pin

(7) Lower link L.H.

3. Move the bushes (8) to inside.
4. Move the shaft (9) to right side and remove the lower link as a unit.



(8) Bush

(9) Shaft

5.1.3 Removing ROPS

1. Disconnect the R.H. and L.H. hazard lamp/turn signals (3), (4) from the wire harness.
2. Remove the upper ROPS (1).



- | | |
|----------------------------------|---------------------|
| (1) Upper ROPS | (5) L.H. lower ROPS |
| (2) R.H. lower ROPS | (6) Bolt |
| (3) R.H. hazard lamp/turn signal | |
| (4) L.H. hazard lamp/turn signal | |

3. Remove the ROPS mounting bolts (6).
4. Remove the R.H. and L.H. lower ROPS (2), (5).

(When reassembling)

Tightening torque	ROPS mounting bolt	48.0 to 55.9 N · m 4.90 to 5.70 kgf · m 35.5 to 41.2 lbf · ft
-------------------	--------------------	---

5.1.4 Removing seat


1. Disconnect the seat switch connectors.
2. Remove the snap pins (2) to remove the seat (1).



- | | |
|----------|--------------|
| (1) Seat | (2) Snap pin |
|----------|--------------|

5.1.5 Removing step

1. Disconnect the upper cruise control rod (1) from the lower cruise control rod.
2. Remove the R.H. and L.H. side covers (2), (7).



- | | |
|------------------------------|-----------------------|
| (1) Upper cruise control rod | (5) Forward HST pedal |
| (2) R.H. side cover | (6) Reverse HST pedal |
| (3) Step mat | (7) L.H. side cover |
| (4) Step | |

3. Remove the step mat (3).
4. Remove the forward and reverse HST pedals (5), (6).
5. Remove the step (4).


5.1.6 Removing fender

1. Disconnect the L.H. and R.H. tail lamps (3), (7) from the wire harness.
2. Disconnect the 12 V outlet (2) from the wire harness.

NOTE

- 12 V outlet connector is near the L.H. tail lamp connector.

3. Remove the L.H. lever grips (3).



- | | |
|--|-----------------------------------|
| (1) Tail lamp | (6) Lowering speed adjusting knob |
| (2) 12 V outlet | (7) R.H. lever grip |
| (3) L.H. lever grip | |
| (4) Differential lock pedal cover | |
| (5) Cutting height adjusting dial knob | |

- Remove the differential lock pedal cover (4), cutting height adjusting dial knob (5), and lower speed adjusting knob (6).
- Remove the R.H. lever grips (7).
- Remove the R.H. lever guide (8) and R.H. handrail (10).
- Remove the L.H. lever guide stay nut.




(8) R.H. lever guide (10) R.H. handrail
(9) Fender

- Remove the fender (9).

5.1.7 Removing fuel tank

- Remove the and R.H. lever guide stay (1).
- Drain the fuel from the fuel tank.
- Disconnect the fuel sensor connectors (4) and safety switch connector (7).



(1) R.H. lever guide stay (6) Fuel return hose
(2) Fuel tube cover (7) Connector
(3) Seat stopper (8) Fuel supply hose
(4) Fuel sensor connector
(5) Fuel tank

- Remove the fuel tube cover (2).
- Disconnect the fuel return hose (6) and fuel supply hose (8).
- Remove the seat stopper (3).
- Remove the R.H. and L.H. fuel tank stays (9) and cushions (10), then remove the fuel tank (5).




(9) R.H. fuel tank stay (10) Cushion

(When reassembling)

Tightening torque	Fuel tank stay mounting bolt and nut	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft
	Seat stopper bolts	123.5 to 147.0 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft

5.1.8 Removing fender center stay

- Remove the fender center stay (1).



(1) Fender center stay



(When reassembling)

Tightening torque	Fender center stay mounting bolt and nut (M14)	98.0 to 125 N·m 11.0 to 12.8 kgf·m 79.6 to 92.5 lbf·ft
	Fender center stay mounting bolt and nut (M10)	39.2 to 45.1 N·m 4.00 to 4.60 kgf·m 29.0 to 33.2 lbf·ft

5.1.9 Removing hydraulic pump

- Disconnect the mower linkage (4).


2. Remove the lift arm L.H. (2).



- (1) Hydraulic pipe (4) Mower linkage
(2) Lift arm L.H.
(3) Hydraulic pump

3. Remove the hydraulic pipes (1).

4. Remove the hydraulic pump (3).



- (3) Hydraulic pump (7) Bolt (M8)
(5) Bolt (M8) (Through bolt)
(6) Bolt (M6)

(When reassembling)

- Since the mounting bolt (5) is installed through the transaxle case to the transmission oil tank, seal the sealing tape to the mounting bolt (5) securely.

Tightening torque	Hydraulic pump mounting bolt (M6)	7.9 to 9.3 N·m 0.80 to 0.95 kgf·m 5.8 to 6.8 lbf·ft
	Hydraulic pump mounting bolt (M8)	18 to 20 N·m 1.8 to 2.1 kgf·m 13 to 15 lbf·ft

5.2 Hydraulic cylinder block**5.2.1 Removing battery****WARNING**

To avoid serious injury or death:

- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.


1. Remove the under panel (1).



- (1) Under panel

2. Disconnect the negative cable (3) from the battery (2).


3. Disconnect the positive cable (4) from the battery (2) and remove the battery.



- (2) Battery (4) Positive cable
(3) Negative cable


5.2.2 Removing lift rod and lower link

1. Remove the top link (2).
2. Remove the stopper pin (6) and remove the check chain plate (3).



- 9Y1210855TXS007A
- | | |
|-----------------------|---------------------|
| (1) Lift rod L.H. | (5) Lower link R.H. |
| (2) Top link | (6) Stopper pin |
| (3) Check chain plate | (7) Lower link L.H. |
| (4) Lift rod R.H. | |

3. Move the bushes (8) to inside.
4. Move the shaft (9) to right side and remove the lower link as a unit.



- (8) Bush (9) Shaft

5.2.3 Removing ROPS

1. Disconnect the R.H and L.H. hazard lamp/turn signals (3), (4) from the wire harness.
2. Remove the upper ROPS (1).



- 2LEQP00046A01
- | | |
|----------------------------------|---------------------|
| (1) Upper ROPS | (5) L.H. lower ROPS |
| (2) R.H. lower ROPS | (6) Bolt |
| (3) R.H. hazard lamp/turn signal | |
| (4) L.H. hazard lamp/turn signal | |

3. Remove the ROPS mounting bolts (6).
4. Remove the R.H. and L.H. lower ROPS (2), (5).

(When reassembling)

Tightening torque	ROPS mounting bolt	48.0 to 55.9 N·m 4.90 to 5.70 kgf·m 35.5 to 41.2 lbf·ft
-------------------	--------------------	---

5.2.4 Removing seat

1. Disconnect the seat switch connectors.
2. Remove the snap pins (2) to remove the seat (1).




- 2LEQP00047A01
- | | |
|----------|--------------|
| (1) Seat | (2) Snap pin |
|----------|--------------|

5.2.5 Removing step

1. Disconnect the upper cruise control rod (1) from the lower cruise control rod.

2. Remove the R.H. and L.H. side covers (2), (7).



- | | |
|------------------------------|-----------------------|
| (1) Upper cruise control rod | (5) Forward HST pedal |
| (2) R.H. side cover | (6) Reverse HST pedal |
| (3) Step mat | (7) L.H. side cover |
| (4) Step | |

3. Remove the step mat (3).
 4. Remove the forward and reverse HST pedals (5), (6).
 5. Remove the step (4).


5.2.6 Removing fender

1. Disconnect the L.H. and R.H. tail lamps (3), (7) from the wire harness.
2. Disconnect the 12 V outlet (2) from the wire harness.

NOTE

- 12 V outlet connector is near the L.H. tail lamp connector.

3. Remove the L.H. lever grips (3).



- | | |
|--|-----------------------------------|
| (1) Tail lamp | (6) Lowering speed adjusting knob |
| (2) 12 V outlet | (7) R.H. lever grip |
| (3) L.H. lever grip | |
| (4) Differential lock pedal cover | |
| (5) Cutting height adjusting dial knob | |

4. Remove the differential lock pedal cover (4), cutting height adjusting dial knob (5), and lower speed adjusting knob (6).
5. Remove the R.H. lever grips (7).
6. Remove the R.H. lever guide (8) and R.H. handrail (10).
7. Remove the L.H. lever guide stay nut.




- | | |
|----------------------|--------------------|
| (8) R.H. lever guide | (10) R.H. handrail |
| (9) Fender | |

8. Remove the fender (9).

5.2.7 Removing fuel tank

1. Remove the and R.H. lever guide stay (1).
2. Drain the fuel from the fuel tank.
3. Disconnect the fuel sensor connectors (4) and safety switch connector (7).



- | | |
|---------------------------|----------------------|
| (1) R.H. lever guide stay | (6) Fuel return hose |
| (2) Fuel tube cover | (7) Connector |
| (3) Seat stopper | (8) Fuel supply hose |
| (4) Fuel sensor connector | |
| (5) Fuel tank | |

4. Remove the fuel tube cover (2).
5. Disconnect the fuel return hose (6) and fuel supply hose (8).
6. Remove the seat stopper (3).

7. Remove the R.H. and L.H. fuel tank stays (9) and cushions (10), then remove the fuel tank (5).




(9) R.H. fuel tank stay (10) Cushion

(When reassembling)

Tightening torque	Fuel tank stay mounting bolt and nut	48 to 55 N·m 4.9 to 5.7 kgf·m 36 to 41 lbf·ft
	Seat stopper bolts	123.5 to 147.0 N·m 12.6 to 15.0 kgf·m 91.2 to 108 lbf·ft

5.2.8 Removing fender center stay

1. Remove the fender center stay (1).



(1) Fender center stay

(When reassembling)

Tightening torque	Fender center stay mounting bolt and nut (M14)	98.0 to 125 N·m 11.0 to 12.8 kgf·m 79.6 to 92.5 lbf·ft
	Fender center stay mounting bolt and nut (M10)	39.2 to 45.1 N·m 4.00 to 4.60 kgf·m 29.0 to 33.2 lbf·ft

5.2.9 Removing mower linkage and wire harness


1. Disconnect the mower linkage (2).
2. Remove the wire harness clamp and wire harness (1) from the hydraulic cylinder block.



(1) Wire harness (2) Mower linkage

5.2.10 Removing hydraulic cylinder block


1. Remove the hydraulic hose (1).



(1) Hydraulic hose

2. Remove the hydraulic cylinder block mounting bolts.

3. Remove the hydraulic cylinder block (2).




(2) Hydraulic cylinder block

(When reassembling)

Tightening torque	Hydraulic cylinder block mounting bolt	40 to 44 N·m 4.0 to 4.5 kgf·m 29 to 32 lbf·ft
-------------------	--	---

5.3 Hydraulic cylinder and control valve

5.3.1 Removing control valve




(2) Spool

(4) Internal circlip

(3) Plain washer


1. Remove the control valve (1).



(1) Control valve

2. Remove the internal circlip (4) and draw out the spool (2).

5.3.2 Removing control valve lever



(1) Pin


(2) Arm

(3) Control valve lever

1. Pull out the pin (1).

2. Remove the control valve lever (3) and arm (2).

5.3.3 Removing lift arm, hydraulic arm shaft and hydraulic arm




- | | |
|------------------------------|-----------------------|
| (1) Hydraulic cylinder block | (6) O-ring |
| (2) Lift arm L.H. | (7) Lift arm R.H. |
| (3) O-ring | (8) External circlip |
| (4) Hydraulic arm shaft | (9) Cover |
| (5) Hydraulic arm | (10) External circlip |

1. Remove the external circlips (8), (10) and remove the lift arms (2), (7).
2. Draw out the hydraulic arm shaft (4).

(When reassembling)


- Align the alignment marks of the hydraulic arm (5) and hydraulic arm shaft (4).
- Align the alignment marks of the lift arms (2), (7) and hydraulic arm shaft (4).
- Apply grease to the right and left bushings and O-rings.
- Be careful not to damage the O-ring.

5.3.4 Removing hydraulic piston



- | | |
|----------------------|------------|
| (1) Hydraulic piston | (3) O-ring |
| (2) Back-up ring | |

1. Inject the compressed air into the hydraulic cylinder, and remove the hydraulic piston (1).




3TAAAF8P017A

- (1) Hydraulic piston

(When reassembling)

- Be careful not to damage the O-ring (3) and back-up ring (2).
- Apply transmission fluid to the O-ring.
- Replace the O-ring if it is damaged, worn or scratched, which may cause oil leakage.

5.3.5 Removing lowering speed adjusting valve



- | | |
|-------------|------------------------------------|
| (1) Spring | (5) Internal circlip |
| (2) Ball | (6) Lowering speed adjusting shaft |
| (3) O-ring | |
| (4) Stopper | |


1. Remove the internal circlip (5) and remove the lowering speed adjusting shaft (6).
2. Remove the ball (2) and spring (1).

(When reassembling)

- Be careful not to damage the O-rings.

5.4 Mower lift linkage

5.4.1 Disassembling mower linkage



3TAAAAG8P017A

- | | | |
|--|----------------------------------|---------------------------|
| (1) Mower rear link, R.H. | (4) Cutting height adjusting rod | (8) Mower rear link, L.H. |
| (2) Lift link rear, R.H. | (5) Lift arm, L.H. | (9) Adjusting cam |
| (3) Cutting height adjusting dial knob | (6) Link adjusting bolt | |
| | (7) Lift link rear, L.H. | |

1. Remove the clevis pin and remove the lift link rear L.H. (7).
2. Remove the pin and remove the mower rear links (1), (8).
3. Remove both side of boss and remove the lift link rear R.H. (2).
4. Remove the cutting height adjusting dial knob (3).
5. Remove the nut and remove the adjusting cam (9) and cutting height adjusting rod (4).

(When reassembling)

- Adjust the length of the link adjusting bolt.

5.5 Control valve (Front loader)

5.5.1 Removing battery

⚠ WARNING


To avoid serious injury or death:

- When disconnecting the battery cables, disconnect the negative cable from the battery first.
- When connecting, connect the positive cable to the battery first.

1. Remove the under panel (1).



- (1) Under panel
2. Disconnect the negative cable (3) from the battery (2).
3. Disconnect the positive cable (4) from the battery (2) and remove the battery.



- (2) Battery
- (3) Negative cable
- (4) Positive cable

5.5.2 Removing ROPS

1. Disconnect the R.H and L.H. hazard lamp/turn signals (3), (4) from the wire harness.
2. Remove the upper ROPS (1).



- (1) Upper ROPS
- (2) R.H. lower ROPS
- (3) R.H. hazard lamp/turn signal
- (4) L.H. hazard lamp/turn signal
- (5) L.H. lower ROPS
- (6) Bolt

3. Remove the ROPS mounting bolts (6).

4. Remove the R.H. and L.H. lower ROPS (2), (5).

(When reassembling)

Tightening torque	ROPS mounting bolt	48.0 to 55.9 N·m 4.90 to 5.70 kgf·m 35.5 to 41.2 lbf·ft
-------------------	--------------------	---

5.5.3 Removing seat

1. Disconnect the seat switch connectors.
2. Remove the snap pins (2) to remove the seat (1).




- (1) Seat
- (2) Snap pin

5.5.4 Removing step

1. Disconnect the upper cruise control rod (1) from the lower cruise control rod.

- Remove the R.H. and L.H. side covers (2), (7).



- | | |
|------------------------------|-----------------------|
| (1) Upper cruise control rod | (5) Forward HST pedal |
| (2) R.H. side cover | (6) Reverse HST pedal |
| (3) Step mat | (7) L.H. side cover |
| (4) Step | |

- Remove the step mat (3).
- Remove the forward and reverse HST pedals (5), (6).
- Remove the step (4).


5.5.5 Removing fender

- Disconnect the L.H. and R.H. tail lamps (3), (7) from the wire harness.
- Disconnect the 12 V outlet (2) from the wire harness.

NOTE

- 12 V outlet connector is near the L.H. tail lamp connector.

- Remove the L.H. lever grips (3).



- | | |
|--|-----------------------------------|
| (1) Tail lamp | (6) Lowering speed adjusting knob |
| (2) 12 V outlet | (7) R.H. lever grip |
| (3) L.H. lever grip | |
| (4) Differential lock pedal cover | |
| (5) Cutting height adjusting dial knob | |

- Remove the differential lock pedal cover (4), cutting height adjusting dial knob (5), and lower speed adjusting knob (6).
- Remove the R.H. lever grips (7).
- Remove the R.H. lever guide (8) and R.H. handrail (10).
- Remove the L.H. lever guide stay nut.




- | | |
|----------------------|--------------------|
| (8) R.H. lever guide | (10) R.H. handrail |
| (9) Fender | |

- Remove the fender (9).

5.5.6 Removing control valve

- Disconnect the hydraulic hoses (2).
- Disconnect hydraulic pipes (4).



- | | |
|--------------------|--------------------|
| (1) Control valve | (4) Hydraulic pipe |
| (2) Hydraulic hose | (5) Valve stay |
| (3) Rod | |


- Disconnect the rods (3).
- Remove the control valve (1) from the valve stay (5).

(When reassembling)

IMPORTANT

- After reassembling a valve, check for oil leakage by starting up engine.

5.5.7 Disassembling control valve



- | | | | |
|------------------|---------------------------|----------------------|--------------------------------|
| (1) Bucket spool | (8) Collar | (15) Bucket bolt | (22) Packing |
| (2) Boom spool | (9) Spring holder 1 | (16) Spring holder 1 | (23) Plug |
| (3) Packing | (10) Return spring | (17) Return spring 2 | (24) O-ring |
| (4) Ball | (11) Spring holder 2 | (18) Spring holder 1 | (25) Load check spring |
| (5) Plug | (12) Detent bolt | (19) Collar | (26) Load check poppet |
| (6) O-ring | (13) Detent plug assembly | (20) Back up ring | (27) Load check valve assembly |
| (7) Back up ring | (14) Plug | (21) O-ring | (28) Valve body |

1. Remove the load check valve assemblies (27).
2. Remove the detent plug assembly (13) and plug (14).
3. Remove the bucket spool (1) with parts (15) to (22) from the valve body (28).
4. Remove the boom spool (2) with parts (3) to (12) from the valve body.

(When reassembling)

- Clean all parts with a suitable solvent, and dry with a lint-free cloth or air.
- Visually inspect all parts for damage.
- When installing the spools into the valve body, be careful not to damage the O-rings.


5.6 Quick coupler

5.6.1 Removing quick coupler (tractor side)

Tools required

- Cartridge socket

1. Disconnect the hydraulic pipes (1) from the cartridges (2). Hold each hydraulic pipe with a wrench and turn the cartridge counterclockwise with the cartridge socket.
2. Remove the retaining rings (3) from the bottom side of the cartridges (2) and remove the cartridges.
3. Remove the quick coupler bracket (4).



- (1) Hydraulic pipe
(2) Cartridge
(3) Retaining ring
(4) Quick coupler bracket

(When reassembling)

1. Clean the hydraulic pipe threads. Apply sealing tape 1.5 to 2 turns in the clockwise direction to the hydraulic pipe threads before reassembling.

NOTE

- **More than 2 turns of sealing tape may cause damage to the cartridge when reassembled.**
2. Insert the cartridge (2) into the quick coupler bracket (4) and install retaining ring (3).
 3. Hold the hydraulic pipe (1) with a wrench and tighten the cartridge with the cartridge socket in the sequence shown.
 - a. Tighten the cartridge by hand until finger tight.
 - b. Tighten the cartridge 2 to 3 turns using cartridge socket.

— RELATED PAGE —

[2.6 Quick coupler cartridge socket on page 2-67](#)

6. Servicing

6.1 Hydraulic pump

6.1.1 Checking clearance between tip of gear tooth and casing

1. Measure the gear O.D. with an outside micrometer.



Gear O.D.	Factory specification	33.520 to 33.530 mm 1.3197 to 1.3200 in.
-----------	-----------------------	---

2. Measure the casing I.D. with a cylinder gauge and calculate the clearance.




Case I.D.	Factory specification	33.570 to 33.577 mm 1.3217 to 1.3219 in.
-----------	-----------------------	---

3. If the clearance exceeds the allowable limit, replace the assembly.

Clearance between tip of gear tooth and casing	Allowable limit	0.15 mm 0.0059 in.
--	-----------------	-----------------------

6.1.2 Checking clearance between bushing and shaft

1. Measure the gear shaft O.D. with an outside micrometer.



Shaft O.D.	Factory specification	14.970 to 14.980 mm 0.58937 to 0.58976 in.
------------	-----------------------	---

2. Measure the bushing I.D. with a cylinder gauge and calculate the clearance.



Bushing I.D.	Factory specification	15.000 to 15.061 mm 0.59056 to 0.59295 in.
--------------	-----------------------	---

3. If the clearance exceeds the allowable limit, replace it.

Clearance between bushing and shaft	Factory specification	0.020 to 0.091 mm 0.00079 to 0.0035 in.
	Allowable limit	0.12 mm 0.0047 in.

6.1.3 Checking side plate thickness

1. Measure the side plate thickness with an outside micrometer.




2. If the thickness is less than the allowable limit, replace it.

Side plate thickness	Factory specification	2.48 to 2.50 mm 0.0977 to 0.0984 in.
	Allowable limit	2.40 mm 0.094 in.

6.2 Hydraulic cylinder

6.2.1 Checking hydraulic cylinder bore


1. Check the cylinder internal surface for scoring or damage.
2. Measure the cylinder I.D. with a cylinder gauge.



3. If the measurement exceeds the allowable limit, replace the hydraulic cylinder block.

Cylinder I.D.	Factory specification	80.05 to 80.15 mm 3.152 to 3.155 in.
	Allowable limit	80.20 mm 3.157 in.

6.2.2 Checking hydraulic arm shaft bushing



(A) Alloy thickness (L) Outside diameter

Hydraulic arm shaft O.D.	Factory specification	L.H.	31.925 to 31.950 mm 1.2569 to 1.2578 in.
		R.H.	29.925 to 29.950 mm 1.1782 to 1.1791 in.

1. Visually inspect the DX bushings for signs of wear or damage.
The DX bushing tends to show concentrated wear.
2. If the DX bushing is worn beyond the alloy thickness (A), replace it.


(Reference)

Hydraulic arm shaft bushing	Alloy thickness (A)	0.57 mm 0.022 in.
-----------------------------	---------------------	----------------------

8. ELECTRICAL SYSTEM

MECHANISM

1. Wiring diagram of BX tractor



2LEQP00078A02enUS

2. Electrical connector chart

<div>3RD_FUNC</div> <div></div> <div>AMP_EJ- 174352-2</div>	<div>FLASHER_UNIT</div> <div></div> <div>SUMITOMO_MT090 6240-5081</div>	<div>HAZARD_LAMP(L,-)</div> <div></div> <div>BULLET_TERMINAL_PLUG CA *1 055 ? 056</div>	<div>REAR_PTO_SW</div> <div></div> <div>MOLEX_MX150 33472-0801</div>	<div>STARTER_S</div> <div></div> <div>YAZAKI_CN(A) 7123-2115</div>	<div>TO_MAIN(-)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>
<div>A1_BATTERY(+)</div> <div></div> <div>YAZAKI 7106-3105</div>	<div>FUEL_PUMP</div> <div></div> <div>SUMITOMO_250 6070-2481 *1 010 ? 011</div>	<div>HAZARD_LAMP(R,+)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>RLY(GLOW)</div> <div></div> <div>BOSCH 3334-485-007</div>	<div>TAIL_LIGHT(L,+)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>TO_WORK_LIGHT(-)</div> <div></div> <div>BULLET_TERMINAL_PLUG CA</div>
<div>ALT_B</div> <div></div> <div>RING_TERMINAL LA_M6</div>	<div>FUEL_SSR(+)</div> <div></div> <div>AMP_POSITIVE_LOCK(Mark /) 154719-1</div>	<div>HAZARD_LAMP(R,-)</div> <div></div> <div>BULLET_TERMINAL_PLUG CA *1 058 ? 059</div>	<div>RLY(H/LIGHT)</div> <div></div> <div>BOSCH 3334-485-007</div>	<div>TAIL_LIGHT(L,-)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>TO_MAIN_H(OUTLET)</div> <div></div> <div>SUMITOMO_MT090 6187-2171</div>
<div>ALT_S</div> <div></div> <div>SUMITOMO_TS090 6189-0442</div>	<div>FUEL_SSR(-)</div> <div></div> <div>AMP_POSITIVE_LOCK(Mark /) 154719-0</div>	<div>HEAD_LIGHT(L)</div> <div></div> <div>DELPHI_Metri-Pack280 12124819</div>	<div>RLY(LAMP)</div> <div></div> <div>BOSCH 3334-485-007</div>	<div>TAIL_LIGHT(R,+)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>TO_OUTLET_H</div> <div></div> <div>SUMITOMO_MT090 6180-2181</div>
<div>B2_STARTER</div> <div></div> <div>EARTH_TERMINAL BA_M8</div>	<div>FUSE_BOX</div> <div></div> <div>PKC E-0433 *3 010 ? 110</div>	<div>HEAD_LIGHT(R)</div> <div></div> <div>DELPHI_Metri-Pack280 12124819</div>	<div>RLY(STARTER)</div> <div></div> <div>BOSCH 3334-485-007</div>	<div>TAIL_LIGHT(R,-)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>TO_MAIN_H(SEAT)</div> <div></div> <div>AMP_EJ- 174259-2</div>
<div>BATT(+)</div> <div></div> <div>YAZAKI_58L 7123-4113-30</div>	<div>GLOW_PLUG</div> <div></div> <div>FORK_TERMINAL LE_M4</div>	<div>MAIN_SW</div> <div></div> <div>SUMITOMO_58_250 6101-5041</div>	<div>SAFETY_SW(SEAT)</div> <div></div> <div>SUMITOMO_MT090 6187-2171</div>	<div>TIMER(OPC)</div> <div></div> <div>SUMITOMO_MT090 6180-4182</div>	<div>TO_SEAT_H</div> <div></div> <div>AMP_EJ- 174257-2</div>
<div>BODYEARTH(FRAME)</div> <div></div> <div>RING_TERMINAL LA_M8</div>	<div>GND(U1)</div> <div></div> <div>RING_TERMINAL LA_M8 *1 053 ? 061</div>	<div>NEUTRAL_SW</div> <div></div> <div>MOLEX_MX150 33472-0801</div>	<div>SAFETY_SW(SEAT_TURN_OVER)</div> <div></div> <div>DELTA 96526</div>	<div>TIMER(STOP)</div> <div></div> <div>SUMITOMO_250 6070-4481</div>	<div>WATER_TEMP_SSR</div> <div></div> <div>AMP_EJ- 2822362-2</div>
<div>BODYEARTH(STARTER)</div> <div></div> <div>RING_TERMINAL LA_M8</div>	<div>GND(U2)</div> <div></div> <div>RING_TERMINAL LA_M8 *1 053 ? 071</div>	<div>OIL_PRESS_SW</div> <div></div> <div>YAZAKI_250 7116-2030</div>	<div>SOLENOID</div> <div></div> <div>YAZAKI_CN(A) 7123-2115</div>	<div>TO_MAIN(+)</div> <div></div> <div>BULLET_TERMINAL_PLUG CA</div>	<div>WORKLIGHT_RLY</div> <div></div> <div>BOSCH 3334-485-007</div>
<div>COMBI_SW</div> <div></div> <div>SUMITOMO_MT090 6244-5121</div>	<div>HAZARD_LAMP(L,+)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>PANEL</div> <div></div> <div>JAE_MX34 MX34020SF1</div>	<div>TO_WORK_LIGHT(+)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	<div>WORK_LIGHT(L)</div> <div></div> <div>SUMITOMO_250 6070-2481</div>	
<div>DC_OUTLET</div> <div></div> <div>YAZAKI_POSITIVE_LOCK 7123-8322</div>		<div>PTO_SW</div> <div></div> <div>MOLEX_MX150 33472-0801</div>	<div>TO_MAIN(+,COIL)</div> <div></div> <div>BULLET_TERMINAL_PLUG CA</div>	<div>WORK_LIGHT(R)</div> <div></div> <div>SUMITOMO_250 6070-2481</div>	
				<div>TO_WORK_LIGHT(+)</div> <div></div> <div>BULLET_TERMINAL_RECEPTACLE CB</div>	


2LEQP00081A01

2LEQP00081A01

3. Reading electrical circuit diagrams


3.1 Electrical wiring chart symbols

Electrical wiring chart symbols for harnesses and wires



	Item	(Example) Contents of illustration	Reference
(a)	Name of part	STARTER RELAY	
(b)	Wire specification code	All use (common)	
(c)	Wire size	0.50 mm ²	
(d)	Wire color	Black/Red	Wire color page
(e)	Unit symbol	Relay	Unit symbol page
(f)	Pin name	Coil	
(g)	Pin No.	1	
(h)	Connector name	Starter relay	Connector diagram
(i)	Wire number	30 A	

Color of wiring



(a) Wire size (mm²) (b) Insulation base color (c) Stripe color

(Ex.)
1.25-Y/R means:
1.25: Wire size (mm²)
Y: Base color (yellow)
R: Stripe color (red)

Color of wiring	Color code
Black	B
Green	G
Blue	L
Pink	P
Red	R
White	W
Yellow	Y
Brown	Br
Gray	Gy
Light green	Lg
Orange	Or
Sky blue	Sb

Unit symbol

	(A)	(B)
(1)		
(2)		
(3)		
(4)		
(5)		
(6)		
(7)		
(8)		
(9)		
(10)		
(11)		
(12)		
(13)		

	(A)	(B)
(14)		
(15)		
(16)		
(17)		
(18)		
(19)		
(20)		
(21)		
(22)		
(23)		
(24)		
(25)		
(26)		


	(A)	(B)																				
(27)																						
(28)																						
(29)																						
(30)																						
(31)	<table><tr><td></td><td>(32)</td><td>(33)</td><td>(34)</td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td>1</td><td></td><td></td><td></td></tr><tr><td>2</td><td></td><td></td><td></td></tr><tr><td>3</td><td></td><td></td><td></td></tr></table> <div><div>(32)</div><div>(33)</div><div>(34)</div></div>			(32)	(33)	(34)					1				2				3			
	(32)	(33)	(34)																			
1																						
2																						
3																						

9Y1211344ELM012A

- | | | | |
|---|---------------------------------|-------------------------------|-------------------------|
| (1) Variable | (11) Heating element | (22) Auto resetting b-Contact | (33) On |
| (2) Non-linear variable | (12) Condenser | (23) Auto resetting a-Contact | (34) Start (Auto reset) |
| (3) Fixed setting | (13) Electrolytic capacitor | (24) Relay coil | (A) New symbol |
| (4) Step variable | (14) Magnetic core inductance | (25) Fuse | (B) Old symbol |
| (5) Non ionizing radiation (NIR) | (15) PNP transistor | (26) Lamp | |
| (6) Body GND | (16) NPN transistor | (27) Buzzer | |
| (7) Thermistor | (17) Semiconductor diode | (28) Horn | |
| (8) Resistor | (18) Light-emitting diode (LED) | (29) Speaker | |
| (9) Variable resistor | (19) Two-way breakdown diode | (30) AC voltage source | |
| (10) Potentiometer with sliding contact | (20) Coil | (31) Switch | |
| | (21) a-Contact | (32) Off (No auto reset) | |


3.2 Layout of connector diagrams

Connector arrangement sequence



Depiction of connectors

- NOTE
- In principle, the connector locking part is shown on the top side.
 - Female connector terminal numbers start from 1 in the top right corner, looking at the connecting face.
 - Male connector terminal numbers start from 1 in the top left corner.



(A) Female connector terminal (B) Male connector terminal (C) Not waterproof (D) Waterproof

3.3 Precautions on handling electrical connectors

1. When disconnecting connectors, grasp the body of the connector and pull it out; do not pull on the wiring harness. If the connector is the locking type, release the lock and then pull to disconnect.
2. When removing a connector's plastic cover (for water protection) to inspect it, be careful not to let any water get in the connector. If water does get in, dry it thoroughly before reassembling the connector and putting its plastic cover securely in place.
3. Straighten any bent connector terminals and make sure none are sticking out or missing. Also make sure there is no corrosion on the connector's terminals before connecting it.
4. When connecting a locking connector, be sure to press it in until you hear it click and then pull gently on the harness close to the connector and make sure the harness does not come out.

4. Starting system

4.1 Electrical circuit of starting system


When the main switch is turned to the **GLOW** position, the terminal BAT is connected to the terminal ON and AC. The glow plugs become red-hot, and the preheat indicator lamp also lights on while preheating.

When the main switch is then turned to the **START** position with the safety switches on, the terminal BAT is connected to the terminals GLOW and ST. Consequently, battery current flows to the starter motor and start the engine.




The main switch automatically returns to the **ON** position, the terminal BAT is connected only to the terminal GLOW, thereby causing the starting circuit to be opened, stopping the starter motor.

When the main switch turned from the **ON** position to the **OFF** position, the fuel cut-off solenoid moves the fuel injection pump control rack to the **no fuel injection** position and stops the engine.

The OPC timer equipped is the operator presence control (OPC) system which automatically stops the engine in approximately one second when operator stands from the seat while shifting the PTO clutch lever and range gear shift lever.



4.2 Function of relay




- | | |
|-------------------|-------------------------------|
| (1) Relay | (6) Terminal 1 |
| (2) Terminal 2 | (7) Terminal 3 |
| (3) Terminal 4 | (8) Contact lever |
| (4) Terminal 5 | (9) Mechanical contact points |
| (5) Relay winding | (10) Winding (Energized) |

A relay (1) is an electrically operated switch. Relays are used where it is necessary to control a circuit by a low-power signal (with complete electrical isolation between control and controlled circuits), or where several circuits must be controlled by one signal.

Current flowing from switch to relay winding (5) cause **ON (Close)** or **OFF (Open)** of mechanical contact points (9).

When current is applied to the winding (energized) (10), a magnetic field pushes the contact lever (8) and normally open terminal is connected.

4.3 Function of starter





- | | |
|------------------------|--------------------|
| (1) Front bracket | (6) Gear shaft |
| (2) Drive lever | (7) Internal gear |
| (3) Magnetic switch | (8) Pinion gear |
| (4) Pinion gear | (9) Armature shaft |
| (5) Overrunning clutch | |

The reduction system is used planetary gears, and the speed of gear shaft (6) is reduced to approximately one-fifth of the armature shaft (9).

The pinion gear (4) is pushed against the ring gear with the overrunning clutch (5) by the drive lever (2).

4.4 Function of glow plug



- | | |
|---|---|
| (1) Sheath tube | (6) Conventional quick-heating type glow plug |
| (2) Insulation powder | (7) Glow plug current |
| (3) Heater also functioning as a resistor | (a) Glow plug temperature (°C) |
| (4) Heater | (b) Current (A) |
| (5) Super glow plug | (c) Time (Sec.) |

This plug is a two-material type QGS (Quick Glow System) for quick temperature rise, and has self-controlling function as well as excellent durability.

The heater (4) connected in series to the heater (3), which also functions as the resistor, is incorporated in the sheath tube (1) of the super glow plug.

The resistance of this heater (3) cum resistor is small when the temperature is low, while the resistance becomes large when the temperature rises.

Therefore, because sufficient current is flown to the heater (4) during the initial period of energization, the temperature rises quickly and the resistance grows with the rise in the temperature of the resistor, the flowing current is reduced to prevent the heater (4) from being heated.

The ignition point is in the area of 2 to 3 mm (0.079 to 0.118 in.) from the tip of the plug in order to reduce its projection into the combustion chamber.


4.5 Function of safety switch

The safety switch is electrically closed in normal condition (normally closed type). The switch operates as sensor detecting and transmitting the position of

HST pedal, PTO lever, independent PTO lever, and seat to engine stop solenoid.

Type of switch	Safety switch name	Number of switch contact
Normal open type	Seat switch	1
	Seat turnover switch	1
	PTO shift lever switch	1
	Independent PTO lever switch (Rear PTO switch)	2
	HST pedal neutral switch	2

4.6 Function of fuel pump



A: Inlet

B: Outlet


An electromagnetic fuel pump uses a transistor that causes the pump to start pumping fuel when the main switch is turned to the **ON** position. Therefore, fuel is supplied to the fuel injection pump regardless of engine speed. This pump is driven by the battery. It can therefore be operated even with the engine being stopped.

5. Operator presence control (OPC) system

5.1 Electrical circuit of OPC timer

General electrical circuit of the tractor OPC timer is shown in the figure.

1. When sitting on the operator's seat with the main switch is in the **ON** position, the battery voltage passes to the seat switch and OPC timer (4), and keep the solenoid relay (8).
2. When standing up from the operator's seat, the circuit from the seat switch to the OPC timer is cut. However, if the PTO lever (or the speed control pedal) are set at **NEUTRAL** position, the circuit from the battery to the solenoid relay (8) is formed with the PTO switch (or HST switch).
3. When standing up from the operator's seat while shifting the levers, the circuit from the battery to the solenoid relay (8) is cut, and the engine is stopped by function of the solenoid (9).



(1) Slow blow fuse

(2) Main switch

(3) Fuse (10 A)

(4) OPC timer

(5) Seat switch (from seat switch
ON or OFF)

(6) Fuse (15 A)

(7) Battery

(8) Engine stop solenoid timer re-
lay

(9) Engine stop solenoid

Seat switch

The seat switch has two positions.

When the operator's seat is occupied, the switch contact point is at **ON** position. When the operator's seat is not occupied, its contact point is at **OFF** position.

OPC timer

OPC timer is located electrically at between the seat switch (5) and the solenoid relay (8).

When the current supply from the seat switch (5) is cut, the OPC timer (4) adopted for the OPC system has kept the state of **ON** position for approximately one second.

6.2 Function of IC regulator (3P connector type)



3P connector is connected to the IC regulator. 3P connector consists of three leads, L (blue) lead (1), RY (red / yellow) lead (2), and WR (white / red) lead (3).

L (blue) lead (1) is a lead to transmit the pulse from the alternator to hour meter and tachometer. When the main switch is in the **ON** position, the hour meter indicates operated hours.

While the engine operates, the tachometer indicates the present engine revolutions.


RY (red / yellow) lead (2) is a lead to chassis.

WG (white / green) lead (3) is a lead to the charge lamp.




- | | |
|-----------------------------|---------------------------------|
| (1) L (blue) lead | (7) Load |
| (2) RY (red / yellow) lead | A: To the battery |
| (3) WG (white / green) lead | B: To hour meter and tachometer |
| (4) Alternator assembly | C: To main switch |
| (5) IC regulator | D: To charge indicator |
| (6) Load | |

7.1 Electrical circuit for lighting system



8. Gauges

8.1 Electrical circuit of gauge system




8.2 Meter panel

8.2.1 Function of hour meter

The meter panel on this machine is equipped with a digital hour meter.

The hour meter indicates in five digits the operated hours when the main switch is turned to the **ON** position.



(1) Hour meter

Tractor operated hours	The step that the display operates
From 0.0 to 9999.9 Hr.	Every 0.1 Hr. step
10000 to 99999 Hr.	Every 1 Hr. step
After 99999 Hr.	99999 Hr. stays on

8.2.2 Function of tachometer


The meter panel on this machine is equipped with a tachometer.

When the key switch is in the **ON** position and the engine operates, the tachometer indicates the engine revolution per minute.

The meter picks up the voltage from the IC regulator located in the alternator.

The IC regulator sends a signal of the engine revolution to the meter.

The meter calculates the signal. It changes and indicates the signal to the engine revolution in cooperation with the voltage.



(1) Tachometer (B) Orange range
(A) Yellow range

Implement	Recommended engine speed
PTO 540	Use within the yellow range (A)
Loader	Use within the orange range (B)


8.2.3 Function of fuel gauge

The meter panel on this machine is equipped with a fuel gauge.

The fuel level gauge and fuel level sensor are connected by the wire harness.

The fuel gauge detects the resistance from the fuel level sensor and indicates the fuel level in the fuel tank.

- When the fuel is close to empty level, the low fuel indicator lamp comes on.



(1) Fuel gauge (B) Full
(A) Empty

8.2.4 Function of coolant temperature gauge

The meter panel on this machine is equipped with a coolant temperature gauge.


The coolant temperature gauge and coolant temperature sensor are connected by the wiring harness.

The coolant temperature gauge detects the resistance from the coolant temperature sensor.

The coolant temperature gauge indicates the coolant temperature in the thermostat housing.

The relationship between the resistance of coolant temperature sensor and reading on the coolant temperature gauge is as follows.


- When the coolant temperature stays at 123 °C (253 °F), the coolant temperature indicator lamp comes on.
- When the coolant temperature stays below 118 °C (244 °F), the coolant temperature indicator lamp turns off.



(1) Coolant temperature gauge

contains a thermistor (4) whose electrical resistance decreases as the temperature increases.

Current varies with changes in the coolant temperature. When the coolant temperature is increased, the electrical resistance will become small, and when the coolant temperature is decreased, it will become large.




(1) Terminal
(2) Insulator

(3) Body
(4) Thermistor

8.3 Function of fuel level sensor

The remaining fuel quantity is detected by the fuel level sensor installed in the fuel tank and indicated on the fuel gauge. For detection, a float and a resistor are used.

As the float lowers, the resistance of the variable resistor varies.




(E) Empty

(F) Full

8.4 Function of coolant temperature sensor

The coolant temperature sensor is installed to the water pump housing, and its tip is in touch with the coolant. It

8.5 Function of oil pressure switch




[A] At the proper oil pressure

When the engine is started and as the proper oil pressure builds, the diaphragm (4) is pushed up. This separates the contact rivet (5) and breaks the circuit, causing the lamp to go out.

[B] At lower oil pressure, 49 kPa (0.50 kgf/cm², 7.1 psi) or less

If the oil pressure drops, the resulting deflection of the diaphragm (4) will close the contact rivet (5) and again complete the circuit. The lighted lamp warns that the pressure of the lubricating system has dropped below the pressure setting.




- | | |
|-------------------|----------------------------|
| (1) Terminal | (6) Contact |
| (2) Insulator | (7) Oil switch body |
| (3) Spring | [A] At proper oil pressure |
| (4) Diaphragm | [B] At lower oil pressure |
| (5) Contact rivet | |

The oil pressure switch is mounted on the cylinder block and is led to the lubricating oil passage. When the oil pressure falls below the specified value, the oil pressure-warning lamp lights.

9. Others

9.1 Electrical circuit for accessory




9.2 Function of DC outlet

■ IMPORTANT

- Do not use as cigarette lighter.
- Do not use when wet.

This machine is equipped with a DC outlet. It is located inside of the L.H. lever guide compartment.

The capacity of the outlet is 12 V / 120 W. Electrical device's such as an auxiliary light, mobile phone battery charger, or other 12 V components can be used with the outlet.



(1) DC outlet

SERVICING

1. Troubleshooting for electrical system

Fuse and wiring

Symptom	Probable cause and checking procedure	Solution	Reference page
All electrical equipment do not operate	1. Battery discharged or damaged	Recharge or replace	2-27
	2. Battery positive cable disconnected or improperly connected	Repair or replace	—
	3. Battery negative cable disconnected or improperly connected	Repair or replace	—
	4. Slow blow fuse blown	Replace	2-41
Fuse blown frequently	1. Short-circuited	Repair or replace	—

Battery

Symptom	Probable cause and checking procedure	Solution	Reference page
Battery discharges too quickly	1. Battery damaged	Replace	8-29
	2. Alternator damaged	Repair or replace	8-48
	3. IC regulator damaged	Replace	8-49
	4. Wiring harness disconnected or improperly connected (between battery positive terminal and regulator B terminal)	Repair or replace	—
	5. Cooling fan belt slipping	Adjust tension	2-30

8. ELECTRICAL SYSTEM

Starting system

Symptom	Probable cause and checking procedure	Solution	Reference page
Starter motor does not operate	1. Battery discharged or damaged	Recharge or replace	2-27
	2. Slow blow fuse blown	Replace	2-41
	3. Safety switch improperly adjusted or damaged	Repair or replace	8-33
	4. Wiring harness disconnected or improperly connected (between main switch 50 terminal and safety switches, between safety switches and starter motor, between battery positive terminal and starter motor)	Repair or replace	—
	5. Starter motor damaged	Repair or replace	8-47
	6. Main switch damaged	Replace	8-30
Engine does not stop when main switch is turned OFF	1. Fuse blown (15 A)	Replace	2-41
	2. Wiring harness disconnected or improperly connected (between main switch AC terminal and engine stop solenoid)	Repair or replace	8-1
	3. Engine stop solenoid damaged	Replace	8-37
	4. Timer relay damaged	Replace	8-37
Engine does not start	1. Engine stop solenoid damaged	Replace	8-37
	2. Timer relay damaged	Replace	8-37

Operator presence control (OPC)

Symptom	Probable cause and checking procedure	Solution	Reference page
Engine does not stop	1. Solenoid fuse blown (15 A)	Replace	2-41
	2. Engine stop solenoid relay damaged	Replace	8-37
	3. Engine stop solenoid damaged	Replace	8-37
	4. PTO shift lever switch damaged	Adjust or replace	8-33
	5. HST pedal switch damaged	Adjust or replace	8-34
	6. Wiring harness disconnected or improperly connected (between key stop solenoid relay and engine stop solenoid, between engine stop solenoid relay and battery positive terminal)	Repair or replace	8-1
Starter motor does not operate	1. Solenoid fuse blown (15 A)	Replace	2-41
	2. Engine stop solenoid damaged	Replace	8-37
	3. Engine stop solenoid relay damaged	Replace	8-37
	4. Seat switch or seat turnover switch damaged	Adjust or replace	8-34
	5. PTO shift lever switch damaged	Adjust or replace	8-33
	6. HST pedal switch damaged	Adjust or replace	8-34
	7. Wiring harness disconnected or improperly connected (between key stop solenoid relay and engine stop solenoid, between engine stop solenoid relay and battery positive terminal)	Repair or replace	8-1
Engine stops when HST pedal is pushed in forward or in reverse	1. Wrong wiring of seat switch and seat turn over switch	Proper wiring	8-1
Engine stops suddenly	1. Seat reverse switch	Adjust the switch position	8-34

8. ELECTRICAL SYSTEM

Charging system

Symptom	Probable cause and checking procedure	Solution	Reference page
Charging lamp does not light when main switch is turned ON	1. Fuse blown (15 A)	Replace	2-41
	2. Wiring harness disconnected or improperly connected (between main switch AC terminal and panel board, between panel board and alternator)	Repair or replace	8-1
	3. Alternator damaged	Repair or replace	8-48
	4. IC regulator damaged	Replace	8-49
Charging lamp does not go off when engine operates	1. Wiring harness disconnected or improperly connected (between main switch 30 terminal and dynamo, between panel board and alternator)	Repair or replace	8-1
	2. Alternator damaged	Repair or replace	8-48
	3. IC regulator damaged	Replace	8-49

Lighting system

Symptom	Probable cause and checking procedure	Solution	Reference page
Head light does not light	1. Fuse blown (15 A)	Replace	2-41
	2. Bulb blown	Replace	2-42
	3. Wiring harness disconnected or improperly connected (between main switch AC terminal and head light switch, between head light switch and head light)	Repair or replace	8-1
Tail light does not light	1. Fuse blown (15 A)	Replace	2-41
	2. Bulb blown	Replace	2-42
	3. Wiring harness disconnected or improperly connected (between main switch AC terminal and head light switch, between head light switch and tail light)	Repair or replace	8-1
Illumination light does not light	1. Fuse blown (15 A)	Replace	2-41
	2. Wiring harness disconnected or improperly connected (between main switch AC terminal and head light switch, between head light switch and illumination light)	Repair or replace	8-1
Hazard lamp does not light	1. Fuse blown (15 A)	Replace	2-41
	2. Bulb blown	Replace	2-42
	3. Wiring harness disconnected or improperly connected	Repair or replace	8-1
	4. Flasher unit damaged	Replace	8-42
	5. Hazard switch damaged	Replace	8-38
Hazard indicator lamp does not light	1. Wiring harness disconnected or improperly connected	Repair or replace	8-1
Hazard lamp does not flicker	1. Flasher unit damaged	Replace	8-42
Turn signal light does not light	1. Fuse blown (15 A)	Replace	2-41
	2. Bulb blown	Replace	2-42
	3. Wiring harness disconnected or improperly connected	Repair or replace	8-1
	4. Flasher unit damaged	Replace	8-42
	5. Turn signal switch damaged	Replace	8-38
Turn signal light indicator lamp does not light	1. Wiring harness disconnected or improperly connected (turn signal switch and indicator lamp)	Repair or replace	8-1

(Continued)

8. ELECTRICAL SYSTEM

Symptom	Probable cause and checking procedure	Solution	Reference page
Turn signal light does not flicker	1. Flasher unit damaged	Replace	8-42
	2. Turn signal switch damaged	Replace	8-38
Glow lamp does not light when main switch is in PRE-HEAT position	1. Battery discharged or damaged	Recharge or replace	8-29
	2. Slow blow fuse blown	Replace	2-41
	3. Wiring harness disconnected or improperly connected (between main switch 19 terminal and PRE-HEAT indicator, between PRE-HEAT indicator and glow plugs)	Repair or replace	8-1
	4. Main switch damaged	Replace	8-30
Oil pressure lamp lights up when engine operates	1. Engine oil pressure too low	Repair engine	—
	2. Engine oil insufficient	Fill	2-7
	3. Oil pressure switch damaged	Replace	8-44
	4. Short circuit between oil pressure switch lead and chassis	Repair	8-44
Oil pressure lamp does not light when main switch is turned ON and engine is not operating	1. Oil pressure switch damaged	Replace	8-44
	2. Wiring harness disconnected or improperly connected (between panel board and oil pressure switch)	Repair or replace	8-1

Gauges

Symptom	Probable cause and checking procedure	Solution	Reference page
Fuel warning lamp does not light	1. Fuel gauge damaged	Replace	8-47
	2. Fuel level sensor damaged	Replace	8-44
	3. Wiring harness disconnected or improperly connected (between fuel gauge and fuel level sensor)	Repair or replace	8-1
Coolant temperature gauge does not function	1. Coolant temperature gauge damaged	Replace	8-45
	2. Coolant temperature sensor damaged	Replace	8-45
	3. Wiring harness disconnected or improperly connected (between coolant temperature gauge and coolant temperature sensor)	Repair or replace	8-1

2. Service specifications for electrical system

Item		Factory specification (Service specification)	Allowable limit (Service limit)
Battery	Voltage	More than 12 V	—
	Potential difference	Less than 0.1 V	—
Glow plug	Resistance	Approx. 0.9 Ω	—
Alternator	Charging current / alternator speed	14 to 15 A / 5200 min ⁻¹ (rpm)	—
	Charging voltage / alternator speed	14 to 15 V / 5200 min ⁻¹ (rpm)	—
Head light switch	Switch OFF	Infinity	—
	Switch ON	0 Ω	—
Turn signal switch	Switch OFF	Infinity	—
	Switch R	0 Ω	—
	Switch L	0 Ω	—
Hazard lamp switch	Switch OFF	Infinity	—
	Switch ON	0 Ω	—
Starter • Commutator	O.D.	30.0 mm 1.181 in.	29.0 mm 1.142 in.
	Difference of O.D.'s	Less than 0.02 mm 0.0008 in.	0.05 mm 0.0020 in.
• Mica	Undercut	0.50 to 0.80 mm 0.0197 to 0.0315 in.	0.20 mm 0.0079 in.
• Brush	Length	14.0 mm 0.551 in.	9.0 mm 0.354 in.
Alternator	No-load voltage	More than 14 V	—
• Stator	Resistance	Less than 1.0 Ω	—
• Rotor	Resistance	2.9 Ω	—
• Slip ring	O.D.	14.4 mm 0.567 in.	14.0 mm 0.551 in.
• Brush	Length	10.5 mm 0.413 in.	8.4 mm 0.331 in.
Hand throttle lever	Operating force	89.0 to 111 N 9.08 to 11.3 kgf 20 to 25 lbf	—

3. Tightening torques for electrical system


Item	N · m	kgf · m	lbf · ft
Starter B terminal nut	5.9 to 11.8	0.6 to 1.2	4.3 to 8.7
Pulley nut	58.4 to 78.9	5.95 to 80.5	43.1 to 58.2

— RELATED PAGE —
[TIGHTENING TORQUES on page 2-13](#)

4. Checking and adjusting

4.1 Battery

4.1.1 Checking battery voltage




- (2) Battery
(3) Negative cable
(4) Positive cable

1. Stop the engine and turn the main switch **OFF**.
2. Connect the COM (-) lead of the voltmeter to the battery's negative terminal post and the (+) lead to the positive terminal post, and measure the battery voltage.
3. If the battery voltage is less than the factory specification, check the battery specific gravity and recharge the battery.

Battery voltage	Factory specification	More than 12 V
-----------------	-----------------------	----------------

4.1.2 Checking battery terminal connection



1. Turn the main switch **ON**, and turn on the head light.
2. Measure the voltage with a voltmeter across the battery's positive terminal post and the cable terminal, and the voltage across the battery's negative terminal post and the chassis.



3. If the measurement exceeds the factory specification, clean the battery terminal posts and cable clamps, and tighten them firmly.

Potential difference	Factory specification	Less than 0.1 V
----------------------	-----------------------	-----------------

4.1.3 Checking battery specific gravity

NOTE

- Hold the hydrometer tube vertical without removing it from the electrolyte.
- Do not suck too much electrolyte into the tube.
- Allow the float to move freely and hold the hydrometer at eye level.
- The hydrometer reading must be taken at the highest electrolyte level.



- (a) Good
(b) Bad
(c) Bad

1. Check the specific gravity of the electrolyte in each cell with a hydrometer.

8. ELECTRICAL SYSTEM

- When the electrolyte temperature differs from that at which the hydrometer was calibrated, correct the specific gravity reading following the formula mentioned in (Reference).

(Reference)

- Specific gravity slightly varies with temperature. To be exact, the specific gravity decreases by 0.0007 with an increase of 1 °C (0.0004 with an increase of 1 °F) in temperature, and increases by 0.0007 with a decreases of 1 °C (0.0004 with a decrease of 1 °F). Therefore, using 20 °C (68 °F) as a reference, the specific gravity reading must be corrected by the following formula:
 - Specific gravity at 20 °C = Measured value + 0.0007 × (electrolyte temperature -20 °C)
 - Specific gravity at 68 °F = Measured value + 0.0004 × (electrolyte temperature -68 °F)

Specific gravity	State of charge
1.260 Sp. Gr.	100% charged
1.230 Sp. Gr.	75% charged
1.200 Sp. Gr.	50% charged
1.170 Sp. Gr.	25% charged
1.140 Sp. Gr.	Very little useful capacity
1.110 Sp. Gr.	Discharged

At an electrolyte temperature of 20 °C (68 °F)

- If the specific gravity is less than 1.215 (after it is corrected for temperature), charge or replace the battery.
- If the specific gravity differs between any two cells by more than 0.05, replace the battery.

4.2 Main switch


4.2.1 Checking main switch connector voltage

- Remove the under cover panel.
- Disconnect the 4P connector and remove the main switch (1).



(1) Main switch


- Measure the voltage with a voltmeter across the 4P connector 3 terminal and the chassis.



- If the voltage differs from the battery voltage (11 to 14 V), the wiring harness is damaged.

Voltage	Connector 3 terminal - Chassis	Approx. battery voltage
---------	--------------------------------	-------------------------

4.2.2 Checking main switch continuity at off position




- Set the main switch to the **OFF** position.

- Measure the resistance with an ohmmeter across the B terminal and the ACC terminal, B terminal and ST terminal, B terminal and G terminal.
- If infinity is not indicated, the contacts of the main switch are damaged.

Resistance	B terminal - ACC terminal	Infinity
	B terminal - ST terminal	
	B terminal - G terminal	

4.2.3 Checking main switch continuity at on position




- (1) B terminal (2) ST terminal (3) ACC terminal (4) G terminal

- Set the main switch to the **ON** position.
- Measure the resistance with an ohmmeter across the B terminal and the ACC terminal.
- If 0 ohm is not indicated, the B - ACC contact of the main switch is damaged.

Resistance	B terminal - ACC terminal	0 Ω
------------	---------------------------	-----

4.2.4 Checking main switch continuity at preheat position




- (1) B terminal (2) ST terminal (3) ACC terminal (4) G terminal

- Set and hold the main switch key at the **PREHEAT** position.
- Measure the resistance with an ohmmeter across the B terminal and the G terminal, and measure the resistance across the B terminal and the ACC terminal.
- If 0 ohm is not indicated, these contacts of the main switch are damaged.

Resistance	B terminal - G terminal	0 Ω
	B terminal - ACC terminal	

4.2.5 Checking main switch continuity at start position



- (1) B terminal (2) ST terminal (3) ACC terminal (4) G terminal

- Set and hold the main switch key at the **START** position.

- Measure the resistance with an ohmmeter across the B terminal and the G terminal, across the B terminal and the ST terminal, and across the B terminal and the ACC terminal.
- If 0 ohm is not indicated, these contacts of the main switch are damaged.


Resistance	B terminal - G terminal	0 Ω
	B terminal - ST terminal	
	B terminal - ACC terminal	

4.3 Starter

4.3.1 Checking motor

CAUTION

- Secure the starter to prevent it from jumping up and down while testing the motor.




(1) C terminal (2) Connecting lead

- Disconnect the battery negative cable from the battery.
- Disconnect the battery positive cable and the leads from the starter.
- Remove the starter from the engine.
- Disconnect the connecting lead (2) from the starter C terminal (1).
- Connect a jumper lead from the connecting lead (2) to the battery positive terminal post.
- Connect a jumper lead momentarily between the starter motor housing and the battery negative terminal post.
- If the motor does not operate, check the motor.

4.3.2 Testing starter magnet switch (pull-in, holding coils)

IMPORTANT

- Testing time must be 3 to 5 sec.




(A) To negative terminal (C) C terminal
(B) To positive terminal (S) S terminal

- Remove the motor from the starter housing.
- Prepare a 6 V battery for the test.
- Connect jumper leads from the battery negative terminal to the housing and the starter C terminal. The plunger should be attracted and the pinion gear should pop out when a jumper lead is connected from the battery positive terminal to the S terminal.
- Disconnect the jumper lead to the starter C terminal. Then the pinion gear should remain popped out.

4.4 Glow plug

4.4.1 Checking glow plug lead terminal voltage

- Disconnect the wiring lead (2) from the glow plug (1) after turning the main switch **OFF**.




(1) Glow plug (2) Wiring lead (Positive)

- Turn the main switch key to the **PREHEAT** position, and measure the voltage between the lead terminal and the chassis.

- Turn the main switch key to the **START** position, and measure the voltage with a voltmeter between the lead terminal and the chassis.
- If the voltage at either position differs from the battery voltage, the wiring harness or main switch is damaged.

Voltage (Lead terminal - Chassis)	Main switch key at PRE-HEAT	Approx. battery voltage
	Main switch key at START	Approx. battery voltage

4.4.2 Checking glow plug continuity





- Disconnect the lead from the glow plugs.
- Measure the resistance with an ohmmeter between the glow plug terminal and the chassis.
- If 0 ohm is indicated, the screw at the tip of the glow plug and the housing are short-circuited.
- If the factory specification is not indicated, the glow plug is damaged.

Glow plug	Factory specification	Approx. 0.9 Ω
-----------	-----------------------	---------------

4.5 Safety switch

4.5.1 Checking PTO shift lever switch continuity



- | | |
|----------------------------|----------------|
| (1) PTO shift lever switch | (4) 8 terminal |
| (2) Plunger | (5) 5 terminal |
| (3) 4 terminal | (6) 1 terminal |

- Remove the left rear wheel.
- Remove the PTO shift lever switch (1).



- (1) PTO shift lever switch

- Measure the resistance with an ohmmeter across the switch terminals.

8. ELECTRICAL SYSTEM

4. If the resistance values specified below are not indicated, the safety switch is damaged.



Plunger is pushed into the switch body.

Resistance	4 terminal (3) - 8 terminal (4)	0 Ω
	5 terminal (5) - 1 terminal (6)	0 Ω

Plunger is released.

Resistance	4 terminal (3) - 8 terminal (4)	Infinity
	5 terminal (5) - 1 terminal (6)	Infinity

4.5.2 Checking HST neutral switch continuity



- (1) HST neutral switch (4) 8 terminal
(2) Plunger (5) 5 terminal
(3) 4 terminal (6) 1 terminal

1. Remove the right rear wheel.
2. Remove the HST neutral switch (1).



(1) HST neutral switch

3. Measure the resistance with an ohmmeter across the HST neutral switch terminals.
4. If the resistance values specified below are not indicated, the safety switch is damaged.

Plunger is pushed into the switch body.

Resistance	4 terminal (3) - 8 terminal (4)	0 Ω
	5 terminal (5) - 1 terminal (6)	0 Ω

Plunger is released.

Resistance	4 terminal (3) - 8 terminal (4)	Infinity
	5 terminal (5) - 1 terminal (6)	Infinity

4.6 Operator presence control (OPC) system


4.6.1 Checking seat switch and seat turnover switch continuity

1. Disconnect the 2P connectors (2), (3) from the seat switch and the seat turnover switch (1).



- (1) Seat switch / seat turnover switch
(2) Seat turnover switch 2P connector
(3) Seat switch 2P connector
(4) Seat

2. Remove the seat switch and seat turnover switch (1).
3. Connect the circuit tester to the terminals (5).



- (1) Seat switch / seat turnover switch
(5) Terminal switch

(When switch is not pushed / when operator leaves the seat)

1. Measure the resistance between terminals (5).
2. If continuity is not as shown below, the switch is damaged. Replace it.

Resistance	When switch is not pushed. / when operator leaves the seat.	Infinity
------------	---	----------

[A]



[A] Seat switch is not pushed.

(When switch is pushed / when operator sits on the seat)

1. Measure the resistance between terminals (5).
2. If continuity is not as shown below, the switch is damaged. Replace it.



Resistance	When switch is pushed. / when operator sits on the seat.	0 Ω
------------	--	-----

[B]



[B] Seat switch is pushed.

4.6.2 Checking OPC timer



- (2) Orange / white terminal (from battery)
- (3) Yellow terminal (from OPC switch)
- (4) Red terminal (to key stop solenoid)
- (5) Black terminal (to frame earth)
- (6) Bulb (Load)
- (7) Battery

1. Remove the OPC timer.
The OPC timer is located under the upper panel.




- (1) OPC timer
2. Connect the jumper leads across the battery terminal and the red / white terminal (2), and across the battery positive terminal and the yellow terminal (3).
3. Connect the jumper lead across the battery negative terminal and the black terminal (5), and

across the battery negative terminal and the bulb terminal.

4. Connect the jumper lead across the red terminal (4) and the bulb terminal.
5. If the bulb lights up when disconnecting the jumper lead from the red / white terminal (2), the OPC timer (1) is proper.

4.7 Fuel pump


4.7.1 Checking fuel pump connector voltage



1. Disconnect the 2P connector from the fuel pump.
2. Turn the main switch key to the **ON** position, and measure the voltage with a voltmeter between the connector terminals.
3. If the voltage differs from the battery voltage, the wiring harness or main switch is damaged.

Voltage	Between connector terminals	Approx. battery voltage
---------	-----------------------------	-------------------------


4.7.2 Checking fuel pump continuity



1. Disconnect the 2P connector from the fuel pump.
2. Check the continuity between the connector terminals with an ohmmeter.
3. If it does not conduct, the fuel pump is damaged.

4.8 Engine stop solenoid

4.8.1 Testing engine stop solenoid




(1) Battery (12 V)

1. Disconnect the 1P connector from the engine stop solenoid.
2. Remove the engine stop solenoid from the engine.
3. Connect the jumper leads from the battery positive terminal to the 1P connector, and from the battery negative terminal to the engine stop solenoid body.
4. If the solenoid plunger is not attracted, the engine stop solenoid is damaged.

4.9 Timer relay

4.9.1 Checking timer relay connector voltage




(1) Timer relay

1. Disconnect the connector from the timer relay after turning the main switch **OFF**.
2. Measure the voltage with a voltmeter across the connector terminal 4 and chassis.
3. Turn the main switch **ON**, and measure the voltage across the connector terminal 3 and chassis.
4. If these voltages differ from the battery voltage, the wiring harness or main switch is damaged.

Voltage	Connector terminal 4 - Chassis	Approx. battery voltage
	Connector terminal 3 - Chassis	Approx. battery voltage

4.9.2 Testing timer relay



(1) Timer relay
(2) Load (Lamp)

(3) Battery (12 V)

1. Remove the timer relay (1).



(1) Timer relay

2. Connect jumper leads across the battery positive terminal and the timer relay terminal 3, and across the battery positive terminal and the timer relay terminal 4.
3. Connect jumper leads across the battery negative terminal and the timer relay terminal 2, and across the battery negative terminal and the bulb terminal.
4. Connect jumper lead across the timer relay terminal 1 and the bulb terminal.
5. If the bulb lights up when disconnecting a jumper lead from the terminal 3 and goes off 6 to 13 seconds later, the timer relay is proper.

4.10 Charging system


4.10.1 Checking battery charging current

NOTE

- Connect an ammeter only after starting the engine.
- When the electrical loads is considerably low or the battery is fully charged, the specified reading may not be obtained.

Current	Factory specification	14 to 15 A
Voltage		14 to 15 V
Alternator speed		5200 min ⁻¹ (rpm)

1. After starting the engine, disconnect the battery positive cord (+), and connect an ammeter and voltmeter. Then switch on all electrical loads (such as head lights) and measure the charging current.



(1) Battery positive cord

4.11 Combination switch

4.11.1 Removing combination switch




(1) Combination switch

1. Remove the under panel, and disconnect the combination switch connector.
2. Remove the combination switch (1).

4.11.2 Checking combination switch connector voltage


1. Measure the voltage with a voltmeter across the connector 2 terminal and chassis when the main switch is in the **ON** position.



2. If the voltage differs from the battery voltage, the wiring harness and main switch is damaged.

Voltage	Main switch at on position	2 terminal - Chassis	Battery voltage
---------	----------------------------	----------------------	-----------------

4.11.3 Checking head light switch continuity when setting switch at OFF position





- (1) Red / yellow lead
(2) Blue / white lead
(3) Yellow lead
(4) Orange lead
(5) Red / white lead
(A) Head light OFF position

1. Set the light switch to the **OFF** position.
2. Measure the resistance with an ohmmeter across the red / yellow lead (1) to the orange lead (4), the red / yellow lead (1) to the yellow lead (3).
3. If infinity is not indicated, the head light switch is damaged.

Resistance (Switch at OFF position)	Red / yellow lead (1) - Orange lead (4)	Infinity
	Red / yellow lead (1) - Yellow lead (3)	


4.11.4 Checking head light switch continuity when setting switch at ON position



- (1) Red / yellow lead
(2) Blue / white lead
(3) Yellow lead
(4) Orange lead
(5) Red / white lead
(A) Head light OFF position
(B) Head light ON position

1. Set the light switch to the **ON** position.
2. Measure the resistance with an ohmmeter across the red / yellow lead (1) to the orange lead (4) and the red / yellow lead (1) to the yellow lead (3).
3. If infinity is not indicated, the head light switch is damaged.


Resistance (Switch at ON position)	Red / yellow lead (1) - Orange lead (4)	0 Ω
	Red / yellow lead (1) - Yellow lead (3)	

4.11.5 Checking turn signal light switch continuity when setting switch knob at OFF position

- (1) Green lead
(2) Red / white lead
(3) Green / white lead
- (A) Turn signal light switch **OFF** position

1. Set the turn signal switch knob to the **OFF** position.
2. Measure the resistance with an ohmmeter across the green lead (1) and red / white lead (2), and across to the green lead (1) and green / white lead (3).
3. If infinity is not indicated, the combination switch is damaged.

Resistance (Switch knob at OFF position)	Green lead (1) - Red / white lead (2)	Infinity
	Green lead (1) - Green / white lead (3)	


4.11.6 Checking turn signal light switch continuity when setting switch knob at RIGHT position

- (1) Green lead
(2) Red / white lead
(3) Green / white lead
- (A) Turn signal light switch **RIGHT** position

1. Set the turn signal switch knob to the **RIGHT** position.
2. Measure the resistance with an ohmmeter across the green lead (1) and red / white lead (2), and across to the green lead (1) and green / white lead (3).
3. If 0 Ω is not indicated, the combination switch is damaged.

Resistance (Switch knob at RIGHT position)	Green lead (1) - Red / white lead (2)	0 Ω
	Green lead (1) - Green / white lead (3)	Infinity

4.11.7 Checking turn signal light switch continuity when setting switch knob at **LEFT** position





- (1) Green lead
(2) Red / white lead
(3) Green / white lead
- (A) Turn signal light switch **LEFT** position

1. Set the turn signal switch knob to the **LEFT** position.
2. Measure the resistance with an ohmmeter across the green lead (1) and red / white lead (2), and across to the green lead (1) and green / white lead (3).
3. If 0 Ω is not indicated, the combination switch is damaged.

Resistance (Switch knob at LEFT position)	Green lead (1) - Red / white lead (2)	Infinity
	Green lead (1) - Green / white lead (3)	0 Ω



4.11.8 Checking hazard switch continuity when setting switch knob at **OFF** position



- (1) Black / blue lead
(2) Blue / white lead
- (A) Hazard switch **OFF** position

1. Set the hazard switch knob to the **OFF** position.
2. Measure the resistance with an ohmmeter across the black / blue lead (1) and blue / white lead (2).
3. If infinity is not indicated, the combination switch is damaged.

Resistance (Hazard switch at OFF position)	Black / blue lead (1) - Blue / white lead (2)	Infinity
---	---	----------

4.11.9 Checking hazard switch continuity when setting switch knob at ON position

- (1) Black / blue lead (A) Hazard switch **ON** position
(2) Blue / white lead


1. Set the hazard switch knob to the **ON** position.
2. Measure the resistance with an ohmmeter across the black / blue lead (1) and blue / white lead (2).
3. If 0 Ω is not indicated, the combination switch is damaged.

Resistance (Hazard switch at ON position)	Black / blue lead (1) - Blue / white lead (2)	0 Ω
--	---	------------



- (1) Flasher unit

3. Measure the voltage with a voltmeter across the connector terminal h and chassis.




4. If the voltage differs from the battery voltage, the wiring harness is damaged.

Voltage	Terminal h - Chassis	Approx. battery voltage
---------	----------------------	-------------------------

4.11.10 Checking flasher unit connector voltage

1. Remove the under panel.
2. Disconnect the connector from the flasher unit (1).

4.11.11 Testing flasher unit actuation





- (1) Hazard lamp switch (3) Flasher unit
(2) Turn signal light switch

1. Set the hazard switch to the **ON** position, and make sure the hazard lamp gives 60 to 85 flashes for a minute.
2. With the main switch and the hazard switch at the **ACC** and **ON** positions, respectively, move the turn signal light switch to the left. Make sure that the right-hand light stays on and the left-hand light gives flashes earlier (by about 20 flashes) than when the hazard lamp is activated. Then move the turn signal light switch to the right and make sure the corresponding actions take place.
3. Now set the main switch to the **ACC** position and move the turn signal switch alone. Make sure the same actions as above result.
4. If both the hazard switch and the turn signal light switch function but the above actions do not take place, replace the flasher unit with a new one.

4.12 Gauge

4.12.1 Checking charge lamp (charging circuit)



- (1) Alternator (2) 3P connector (3) L (blue) terminal (4) RY (red / yellow) terminal (5) WG (white / green) terminal
- A: To the battery
B: To hour meter and tachometer
C: To main switch
D: To charge indicator


1. Disconnect the 3P connector from the alternator after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the wiring harness connector terminal (white / green) to the chassis.

NOTE

- If you connect the jumper lead from the wiring harness connector terminal (white / green) to the chassis, 15 A fuse will be blown. Do not connect the lead to red / yellow terminal.

3. If the charge lamp does not light, the wiring harness or fuse is damaged.


4.12.2 Checking engine oil pressure lamp



- (1) Engine oil pressure switch (a) From oil pressure lamp
(2) Lead

1. Disconnect the lead (2) from the engine oil pressure switch (1) after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the lead to the chassis.
3. If the engine oil pressure indicator lamp does not light, the wiring harness is damaged.

4.12.3 Checking engine oil pressure switch continuity



- (1) Engine oil pressure switch (2) Lead


1. Disconnect the lead (2) from the engine oil pressure switch (1).
2. Measure the resistance with an ohmmeter across the switch terminal and the chassis.
3. If 0 ohm is not indicated in the normal state, the switch is damaged.

Resistance (Switch terminal - Chassis)	In normal state	0 Ω
--	-----------------	------------

4. If infinity is not indicated at pressure, the switch is damaged.

Resistance (Switch terminal - Chassis)	At pressure over approx. 49 kPa 0.50 kgf/cm ² 7.1 psi	Infinity
--	--	----------

4.12.4 Checking fuel level sensor continuity




- (E) Empty (F) Full

1. Remove the fuel level sensor from the fuel tank.
2. Measure the resistance with an ohmmeter across the sensor terminal and its body.

3. If the reference values are not indicated, the sensor is damaged.

Resistance (Sensor terminal - Sensor body)	Reference value	Float at upper-most position (Full)	2.75 to 3.15 Ω
		Float at lower-most position (Empty)	97 to 113 Ω


4.12.5 Checking coolant temperature sensor connector voltage



1. Disconnect the 2P connector from the coolant temperature sensor after turning the main switch **OFF**.
2. Turn the main switch **ON** and measure the voltage with a voltmeter across the 2 terminal (W/Y) and the chassis.
3. If the voltage differs from the reference voltage, the wiring harness, fuse or coolant temperature gauge is damaged.

Voltage	2 terminal (W/Y) - Chassis	4.9 to 5.1 V
---------	----------------------------	--------------

4.12.6 Checking coolant temperature sensor continuity






(1) Coolant temperature sensor (2) Coolant

1. Measure the resistance with an ohmmeter across the sensor 1 terminal and 2 terminal.
2. If the reference value is not indicated, the sensor is damaged.

Resistance (1 terminal - 2 terminal)	Reference value	Approx. 11.08 Ω at 120 °C (248 °F)
		Approx. 18.36 Ω at 100 °C (212 °F)
		Approx. 31.8 Ω at 80 °C (176 °F)
		Approx. 81.1 Ω at 50 °C (122 °F)

4.12.7 Checking hour meter and tachometer



- (1) L (blue) lead
(2) RY (red / yellow) lead
(3) WG (white / green) lead
(4) 3P connector
(5) Alternator
(6) Hour meter and tachometer terminal
(7) Ground terminal
(8) Charge lamp terminal
(9) IC regulator
(A) To the battery
(B) To hour meter and tachometer
(C) To main switch
(D) To charge indicator


1. Disconnect the 3P connector (4) from the IC regulator (9) located in the alternator (5) after starting the engine.
2. Measure the voltage with a voltmeter across the hour meter terminal (6) and the alternator body when the hour meter or tachometer does not indicated the proper value.

3. If the measured voltages differ from the specified voltage, the hour meter and tachometer are damaged.

Voltage while engine operates at idling speeds	Hour meter terminal - Alternator body	Approx. battery voltage
--	---------------------------------------	-------------------------

4.13 Accessory


4.13.1 Checking DC outlet connector voltage



1. Disconnect the connector from the DC outlet and turn the main switch **ON**.
2. Measure the voltage with a voltmeter across the connector 1 terminal (R/L) and the chassis.
3. If the voltage differs from the battery voltage the wiring harness is damaged.

DC outlet connector voltage	1 terminal (R/L) - Chassis	Battery voltage
-----------------------------	----------------------------	-----------------

4.13.2 Checking DC outlet continuity



- (1) 1 terminal
(2) 2 terminal
(3) DC outlet



1. Remove the DC outlet from the machine.
2. Measure the resistance with an ohmmeter across outlet 1 terminal and 2 terminal.

3. If infinity is not indicated, the outlet is damaged.

DC outlet continuity	1 terminal - 2 terminal	Infinity
----------------------	-------------------------	----------

4.14 Meter panel

4.14.1 Checking connector voltage, sensor resistance and switch



- (1) Meter panel
 (2) 20P connector meter panel side
 (3) 20P connector wire harness side


1. Disconnect the 20P connector (3) from the meter panel (1).
2. Check the main voltage (battery voltage) first and check the connector voltage, sensor resistance or switch continuity which related for damaged indication of meter panel as table below.

Terminal No.	Color of wiring	Terminal name (Related item)
T1	R / B	Glow plug
T2	—	—
T3	—	—
T4	W / G	Charge warning
T5	G	Oil warning
T6	—	—
T7	—	—
T8	L / W	Left turn
T9	R / W	Right turn
T10	—	—
T11	—	CAN L
T12	—	CAN H
T13	—	—
T14	Or / W	Low beam
T15	L	Tachometer
T16	R / L	Ignition
T17	Y / L	Fuel
T18	B	Ground
T19	W / Y	Temperature
T20	R / G	Battery

5. Disassembling and assembling

5.1 Starter

5.1.1 Disassembling starter motor



- (1) Armature
 (2) Yoke
 (3) Brush holder
 (4) End frame
 (5) Screw
 (6) Screw
 (7) Nut
 (8) Magnet switch
 (9) Connecting lead
 (A) Spline teeth

8. ELECTRICAL SYSTEM

5. Disassembling and assembling


1. Disconnect the connecting lead (9) from the magnet switch (8).
2. Remove the screws (6), and then separate the end frame (4), yoke (2) and armature (1).
3. Remove the two screws (5), and then remove the brush holder (3) from the end frame (4).

(When reassembling)

- Apply grease to the spline teeth (A) of the armature (1).

Tightening torque	Nut (7)	5.9 to 11.8 N · m 0.6 to 1.2 kgf · m 4.3 to 8.7 lbf · ft
-------------------	---------	--

5.1.2 Removing magnet switch




- | | |
|------------------------|--------------|
| (1) Drive end frame | (5) Gear |
| (2) Overrunning clutch | (6) Roller |
| (3) Ball | (7) Retainer |
| (4) Spring | |

1. Remove the drive end frame (1) mounting screws.
2. Remove the overrunning clutch (2), ball (3), spring (4), gears (5), rollers (6) and retainer (7).

(When reassembling)

- Apply grease to the gear teeth of the gears (5) and overrunning clutch (2), and ball (3).

5.1.3 Removing plunger




- (1) End cover (2) Plunger

1. Remove the end cover (1).
2. Remove the plunger (2).

5.2 Alternator

5.2.1 Removing pulley


1. Secure the hexagonal end of the pulley shaft with a double-ended ratchet wrench as shown in the figure, loosen the pulley nut with a socket wrench and remove it.

**(When reassembling)**

Tightening torque	Pulley nut	58.4 to 78.9 N · m 5.95 to 8.05 kgf · m 43.1 to 58.2 lbf · ft
-------------------	------------	---


5.2.2 Removing rear end cover

1. Remove the three rear end cover screws and the B terminal nut, and remove the rear end cover.



5.2.3 Removing brush holder


1. Remove the two screws holding the brush holder, and remove the brush holder (1).



(1) Brush holder

5.2.4 Removing IC regulator


1. Remove the three screws holding the IC regulator, and remove the IC regulator (1).



(1) IC regulator

5.2.5 Removing rectifier


1. Remove the four screws holding the rectifier and the stator lead wires.
2. Remove the rectifier (1).



(1) Rectifier

5.2.6 Removing rear end frame

1. Remove the two nuts and two screws holding the drive end frame and the rear end frame.
2. Remove the rear end frame (1).




(1) Rear end frame

5.2.7 Removing rotor

IMPORTANT

- Be careful not to drop the rotor and damage the slip ring or fan, etc.


- Press out the rotor (1) from drive end frame (3).



- (1) Rotor
(2) Block
(3) Drive end frame

5.2.8 Removing retainer plate


- Remove the four screws holding the retainer plate, and remove the retainer plate (1).



- (1) Retainer plate

5.2.9 Removing bearing on drive end side


- Press out the bearing from drive end frame (3) with a press and jig (1).



- (1) Jig
(2) Block
(3) Drive end frame

5.2.10 Removing bearing at slip ring side

- Lightly secure the rotor (1) with a vise to prevent damage, and remove the bearing (2) with a puller (3).




- (1) Rotor
(2) Bearing
(3) Puller

6. Servicing

6.1 Starter


6.1.1 Checking overrunning clutch




1. Inspect the pinion for wear or damage.
2. If there is any problem, replace the overrunning clutch assembly.
3. Check that the pinion turns freely and smoothly in the overrunning direction and does not slip in the cranking direction.
4. If the pinion slips or does not rotate in the both directions, replace the overrunning clutch assembly.

6.1.2 Checking commutator and mica

1. Check the contact face of the commutator for wear, and grind the commutator with emery paper if it is slightly worn.



2. Measure the commutator O.D. with an outside micrometer at several points.




3. If the minimum O.D. is less than the allowable limit, replace the armature.

Commutator O.D.	Factory specification	30.0 mm 1.181 in.
	Allowable limit	29.0 mm 1.142 in.

4. If the difference of the O.D.'s exceeds the allowable limit, correct the commutator on a lathe to the factory specification.

Difference of O.D.'s	Factory specification	Less than 0.02 mm 0.0008 in.
	Allowable limit	0.05 mm 0.0020 in.

5. Measure the mica undercut.




- | | |
|--------------|---------------|
| (1) Segment | (a) Correct |
| (2) Undercut | (b) Incorrect |
| (3) Mica | |

6. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

Mica undercut	Factory specification	0.50 to 0.80 mm 0.0197 to 0.0315 in.
	Allowable limit	0.20 mm 0.0079 in.

6.1.3 Checking brush wear

1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length (A) with vernier calipers.




3. If the length is less than the allowable limit, replace the yoke assembly and brush holder.

Brush length (A)	Factory specification	14.0 mm 0.551 in.
	Allowable limit	9.0 mm 0.354 in.

6.1.4 Checking brush holder


1. Check the continuity across the brush holder and the holder support with an ohmmeter.




2. If it conducts, replace the brush holder.

6.1.5 Checking armature coil

1. Check the continuity across the commutator and armature coil core with an ohmmeter.




2. If it conducts, replace the armature.
3. Check the continuity across the segments of the commutator with an ohmmeter.



4. If it does not conduct, replace the armature.


6.1.6 Checking field coil

1. Check the continuity across the lead (1) and brush (2) with an ohmmeter.



- (1) Lead (2) Brush

2. If it does not conduct, replace the yoke assembly.
3. Check the continuity across the brush (2) and yoke (3) with an ohmmeter.




- (2) Brush (3) Yoke

4. If it conducts, replace the yoke assembly.

6.2 Alternator

6.2.1 Checking bearing


1. Check the bearing for smooth rotation.



2. If it does not rotate smoothly, replace it.

6.2.2 Checking stator

1. Measure the resistance across each lead of the stator coil with resistance range of circuit tester.




2. If the measurement is not within service specification, replace it.

Resistance	Service specification	Less than 1.0 Ω
------------	-----------------------	------------------------

3. Check the continuity across each stator coil lead and core with resistance range of circuit tester.
4. If infinity is not indicated, replace it.

6.2.3 Checking rotor




1. Measure the resistance across the slip rings.
2. If the resistance is zero or infinity, replace it.

Resistance	Service specification	2.9 Ω
------------	-----------------------	--------------

3. Check the continuity across the slip ring and core with resistance range of circuit tester.
4. If infinity is not indicated, replace it.

6.2.4 Checking slip ring

1. Check the slip ring for score.
2. If scored, correct with an emery paper or on a lathe.
3. Measure the O.D. of slip ring with vernier calipers.




4. If the measurement is less than the service limit, replace it.

Slip ring O.D.	Service specification	14.4 mm 0.567 in.
	Service limit	14.0 mm 0.551 in.

6.2.5 Checking brush wear

- 1. Measure the brush length with vernier calipers.





- 2. If the measurement is less than allowable limit, replace it.

Brush length	Factory specification	10.5 mm 0.413 in.
	Allowable limit	8.4 mm 0.331 in.

- 3. Make sure that the brush moves smoothly.
- 4. If the brush is damaged, replace it.

6.2.6 Checking rectifier

- 1. Check the continuity across each diode of rectifier with resistance range of circuit tester. The rectifier is normal if the diode in the rectifier conducts in one direction and does not conduct in the reverse direction.



9. MOWER

MECHANISM

1. Structure of power transmission of mower


The power is transmitted from mid-PTO to blades as follows.

Center blade

Mid-PTO shaft (5) → Universal joint (4) → Pinion shaft (3) → Bevel gear (1) → Bevel gear (2) → Bevel gear shaft (8) → Center blade (6)

Outer blade

Mid-PTO shaft (5) → Universal joint (4) → Pinion shaft (3) → Bevel gear (1) → Bevel gear (2) → Bevel gear shaft (8) → Center pulley (7) → Mower belt (9) → Outer pulley (11) → Blade shaft (10) → Outer blade (12)



- | | | | |
|------------------|---------------------|----------------------|-------------------|
| (1) Bevel gear | (4) Universal joint | (7) Center pulley | (10) Blade shaft |
| (2) Bevel gear | (5) Mid-PTO shaft | (8) Bevel gear shaft | (11) Outer pulley |
| (3) Pinion shaft | (6) Center blade | (9) Mower belt | (12) Outer blade |

CAUTION


- Never operate mower in transport position.

The lifting of mower is performed by the hydraulic system installed on the tractor.

The mower should be kept lift when traveling. When the position control lever is moved to **LIFT** position, the lift arm (6) is lifted up by the oil pressure of hydraulic system, and the rear lift link (L.H.) (5) is pulled rearward.

Therefore, rear lift links (4), (5) rotate and the mower is lifted by the lift links (3) and rear links (2).

As this link system is a parallel linkage, the mower can be kept parallel at every position.



(1) Front link
(2) Rear link

(3) Lift link
(4) Rear lift link (R.H.)

(5) Rear lift link (L.H.)
(6) Lift arm

3. Structure of self-balancer system of mower



This system reduces the stepped differences in cutting height when mowing rolling terrain.

NOTE

- Always keep the anti-scalp roller with specified position (Refer to Operator's Manual).

Self-balancer


- The mower deck is held in place via the balancer plate (4) and the support by the rear link (1), (2).
- The mower deck is suspended by, and is tilted to the right and left by, the balancer support (5). The balancer springs (3) at both sides adjust themselves for suitable tension to keep the mower deck out of excessive tilt.



- | | |
|----------------------|-----------------------|
| (1) Rear link (R.H.) | (5) Balancer support |
| (2) Rear link (L.H.) | (6) Anti-scalp roller |
| (3) Balancer spring | (7) Mower deck |
| (4) Balancer plate | |

Without self-balancer type (A)


- When working on a wavy ground, the tractor itself, with the mower deck, goes along the curves of the terrain. If not equipped with the self-balancer, the tractor tends to tilt itself greater than the ground's waves by its own weight. This may cause an uneven mowing. The wider the mower is, the more unevenness is caused.



- | | |
|-----------------------|---------------------------|
| (6) Anti-scalp roller | (c) Ground |
| (a) Tilt: Tractor | (d) Grass |
| (b) Tilt: Mower deck | (A) Without self-balancer |

With self-balancer type (B)

- When working on a wavy ground, the tractor itself goes along the curves of the terrain like with the tractor that is not equipped with the self-balancer. The balancer springs (3), however, serve to keep the mower deck in parallel with the ground's curves until the anti-scalp roller (6) comes in contact with the ground.
- If the tractor temporarily tilts itself more than the ground's slope or the like, the anti-scalp roller (6) touches the ground. Now the mower deck is brought back in parallel with the ground by the counter force of the roller (6) just hitting the ground as well as the tension of the balancer springs (3). This helps reduce an uneven mowing.



- | | |
|----------------------|------------------------|
| (a) Tilt: Tractor | (c) Ground |
| (b) Tilt: Mower deck | (B) With self-balancer |

SERVICING

1. Troubleshooting for mower

Symptom	Probable cause and checking procedure	Solution	Reference page
Blade does not turn	1. Mid-PTO system malfunctioning	Check transmission	4-56
	2. Mower belt broken	Replace belt	9-19
Blade speed is slow	1. Mower belt loose	Replace belt or tension spring	9-19
	2. Grass clogged	Remove grass	—
	3. Cup washer flattened or worn out	Replace cup washer	9-20
	4. Engine RPM too low	Mow at full throttle, check and reset engine RPM	—
Cutting is poor	1. Mower blade worn or broken	Sharpen or replace mower blade	9-20
	2. Mower blade screw loose	Re tighten mower blade screw	9-20
	3. Cutting height improper	Adjust cutting height	9-15 to 9-18
	4. Ground speed too fast	Slow down	—
	5. Low tire pressure	Add air to correct	2-47
	6. Anti-scalp rollers not adjusted correctly	Adjust anti-scalp rollers	9-18
Mower is not lifted	1. Linkage system broken	Replace linkage system	9-14
	2. Trouble of hydraulic system	Check hydraulic system	—

2. Servicing specifications for mower

Item		Factory specification	Allowable limit
Stopper and rear link	Clearance	0 to 0.5 mm 0 to 0.01 in.	—
Front tip and rear tip of blade	Difference	0.0 to 5.0 mm 0.0 to 0.20 in.	—
Left tip and right tip of blade	Difference	Less than 3 mm 0.12 in.	—
Balancer spring	Length	55.0 mm 2.17 in.	—
Input shaft (without mower belt)	Turning torque	Less than 0.7 N·m 0.07 kgf·m 0.52 lbf·ft	—
Bevel gears in gear box	Backlash	0.10 to 0.20 mm 0.0040 to 0.0078 in.	0.40 mm 0.016 in.

3. Tightening torques for mower




Item	N · m	kgf · m	lbf · ft
Gear box mounting screw	78 to 90	7.9 to 9.2	58 to 66
Mower blade screw	103 to 117	10.5 to 12.0	76.0 to 86.7
Center pulley holder bolt and nut	78 to 90	7.9 to 9.2	58 to 66
Outer pulley mounting nut	197 to 225	20.0 to 23.0	145 to 166
Gear box bracket mounting bolt an nut	78 to 90	7.9 to 9.2	58 to 66
Pulley boss mounting nut	24 to 27	2.4 to 2.8	18 to 20
Outer pulley holder mounting bolt and nut	78 to 90	7.9 to 9.2	58 to 66

RELATED PAGE

[TIGHTENING TORQUES on page 2-13](#)

4. Setting up mower [RCK48-18BX, RCK54-23BX, and RCK60B-23BX]

4.1 Assembling mower



- | | |
|-----------------------|-------------------------|
| (1) Anti-scalp roller | (6) Discharge pin |
| (2) Block | (7) Discharge deflector |
| (3) Clevis pin | (8) Spring |
| (4) Circlip | (9) Cotter pin |
| (5) Deck | |



1. Place the mower on blocks as illustrated. Turn the anti-scalp rollers sideways and attach to the arms of the deck at the upper position with clevis pins and circlips. Remove the blocks.

2. Attach the discharge deflector to the deck with the spring, discharge pin and cotter pin. Secure the spring to the discharge deflector as illustrated.

4.2 Setting mower

CAUTION



- Park the tractor on a firm, flat and level surface, set the parking brake, stop the engine and remove the key.



- (1) Hydraulic control lever

1. Start the engine and move the hydraulic lever (1) rearward to raise the mower rear link to the highest position.
2. Stop the engine and remove the key.
3. Roll the mower under the tractor from right side.

4.3 Installing universal joint





- (1) Mid-PTO shaft
 - (2) Universal joint
 - (3) Coupler
 - (A) Tug
1. Pull back the coupler (3) of the universal joint (2).
 2. Push the universal joint (2) onto the mid-PTO shaft (1), until the coupler locks.
 3. Slide the universal joint back and forward to make sure the universal joint is locked securely.

■ IMPORTANT

- Finally, tug on the universal joint to make sure it is locked on the PTO shaft.

4.4 Mounting rear link





- (1) Cutting height control dial
- (2) Hydraulic control lever
- (3) Rear link
- (4) L pin

1. Set the cutting height control dial (1) to zero inch position.
2. Operate the tractor's hydraulic control lever (2) forward to lower the mower rear links (3). Attach the rear links (3) to the mower with the L pins (4).

4.5 Mounting front link

1. Hook the front link (1) to the front bracket groove (2) as shown in the figure.



- (1) Front link
- (2) Front bracket groove
- (L) Adjusting length

9. MOWER

4. Setting up mower [RCK48-18BX, RCK54-23BX, and RCK60B-23BX]

2. Check length (L) and make sure it is set at the factory specification.

Length (L) from rear lock nut to from end of front link	Factory specification	47 mm 1.85 in.
---	-----------------------	-------------------



4.6 Mounting front link

■ IMPORTANT

- Check that the front lever is locked securely with the L pin.

■ NOTE

- When hooking the front link to the lever fulcrum, normal position of the lever fulcrum groove is open to downward.



- | | |
|------------------------|--------------------------|
| (1) L pin | (4) Front lever |
| (2) Lever fulcrum | (5) Lever fulcrum groove |
| (3) Front link bracket | (6) Front link |

- Position the front lever to the front link bracket.
- Pull and lock the L pin. Then lower the front lever.
- Hook the front link to the lever fulcrum, and lift the front lever.
- Release the L pin to lock the front lever.



5. Setting up mower [RCK54D-26BX and RCK60D-26BX]

5.1 Assembling mower

**DANGER**

To avoid serious injury or death:


- Do not operate the mower without the discharge deflector properly in position.



- | | |
|-----------------------|--------------|
| (1) Anti-scalp roller | (5) F spring |
| (2) Block | (6) Ramp F |
| (3) Clevis pin | (7) Ramp R |
| (4) Circlip | |

- Place the mower on blocks as illustrated.
- Attach all the anti-scalp rollers to the arms of the deck. Put clevis pins from outside and circlips inside in the F position. 4.5 holes (X) must be visible.

3. Attach the discharge deflector to the deck with the spring (9), discharge pin (10) and cotter pin (11). Secure the spring to the discharge deflector as illustrated.



- (8) Deck
(9) Spring
(10) Discharge pin
(11) Cotter pin
(12) Discharge deflector


5.2 Setting mower

⚠ WARNING

To avoid serious injury:



- Park the tractor on a firm, flat and level surface, set the parking brake, stop the engine and remove the key.
- Clean up mower deck, slope and frame link. Make sure there is no debris inside the universal joint. Check all functions work correctly.
- Remove the front loader, front attachment and 3 point hitch attachment.

1. Adjust all the anti-scalp rollers to the F position. 4.5 holes (X) must be visible.
2. Unlock the lever (1) to lift up the rear anti-scalp roller.



- (1) Lever

3. Pull the L-pin (2) and extend the ramp (3) to front and rear sides.



- (2) L-pin
(3) Ramp

— RELATED PAGE —

[5.1 Assembling mower on page 9-10](#)

5.3 Mounting front link


⚠ CAUTION

To avoid personal injury:

- Attach the stay link left and right. Do not loosen both left and right side nuts at the same time.

1. Place all front link and frame link under the tractor.


- Attach the stay link (1) with the nut (2) on the tractor front frame.



(1) Stay link (2) Nut


Tightening torque	Stay link nut	43.3 to 50.3 N·m 4.4 to 5.1 kgf·m 32 to 37 lbf·ft
-------------------	---------------	---

- Attach the front link (6) to the stay link (1) with joint pin (3), washer (4) and snap pin (5).




(3) Joint pin (4) Washer (5) Snap pin (6) Front link

- Before attaching the mower links, adjust lengths (L1) to 22 mm.




(L1) 22 mm


5.4 Mounting frame link



9Y1210855MOS014A



9Y1210855MOS015A




9Y1210855MOS016A

- (1) Block (A) 160 mm (6.3 in.)
(2) Link arm (B) 120 mm (4.7 in.)
(3) Universal joint

- Place blocks below the frame link if one person does the setting. Heights of blocks are recommended value for attaching.
- Start engine. Set the cutting height to 0 mm (0 in.) and lower the frame link. Then stop the engine.
- Attach the frame link to the link arm.
- Joint the front link and frame link with joint pin and circlip.
- Attach the universal joint to tractor.


5.5 Setting tractor

1. Make sure that the frame link (1) is lifted up to the **TOP** position when tractor is traveling without mower. Stop the tractor behind the mower. Set the parking brake.



(1) Frame link


2. Set the cutting height to 0" and lower the frame link (1). Then stop the engine.
3. Make sure that the rear lock (2) is unlocked.



(2) Rear lock
(A) NG

(B) OK

4. Make sure that the universal joint (3) is in rear position.



(3) Lever guide (Universal joint)
(A) NG

(B) OK

5. Make sure that the frame link (1) is fully down.


5.6 Mounting mower

! WARNING

To avoid serious injury:

- If mower moves forward before the tractor rides on, there is less grip between the ground and mower. Change area and try again.

1. Start the engine and engage 4WD. Set the range gear shift lever to **LOW**. Release the parking brake.
2. With the right front tire, make a driving target to the guide (1).




(1) Guide

3. Drive over the ramp of mower along the guide (1). Keep the front tire side touching the guide rod.
4. Just after the tractor drove over the mower, stop the engine. Make sure frame link is connected to mower. Set the parking brake.
5. Lock the rear lock (2).

! WARNING

To avoid serious injury:


- Double check that frame link is locked to mower deck.



(2) Rear lock

(B) OK

6. Set the PTO select lever to **Rear-PTO** position.
7. Connect the universal joint by the lever guide (3).



- (3) Lever guide (A) Engage
(4) Lock lever


8. Lock the lever guide by the lock lever (4).

**WARNING**

To avoid serious injury:


- Double check that lever guide is locked.

9. Set the PTO select lever to **Mid-PTO** position.
10. Put front and rear ramps (5) back to the ramp bracket (6). Lock the L-pin (7).



- (5) Ramp (7) L-pin
(6) Ramp bracket

11. Start the engine. Lift up the mower to the **TOP** position. Lock the dial gauge and set the parking brake. And then, stop the engine.
12. Lock the rear anti-scalp roller (8).



- (8) Anti-scalp roller

13. Adjust the anti-scalp roller (8).

— RELATED PAGE —

[6.1.6 Adjusting cutting height on page 9-18](#)

6. Checking and adjusting

6.1 Mower adjustment




**CAUTION**

- Park the tractor on a firm, flat and level surface and set the parking brake.
- Stop the engine, remove the key, and allow the blades to stop before making adjustments.
- Wear heavy gloves or wrap end of blade with a rag when you handle blades.
- Before starting the engine, set the PTO clutch lever to off position and range gear shift lever to the neutral position.

6.1.1 Adjusting mower link

■ IMPORTANT

- Park the machine on a firm, flat and level surface and set the parking brake.
- Before adjusting mower deck, make sure the tire pressure is correct.



- | | |
|---------------|---------------------------------|
| (1) Bolt | (L) 0 to 0.5 mm (0 to 0.01 in.) |
| (2) Lock nut | (A) Adjustment point |
| (3) Stopper | (B) Check point |
| (4) Rear link | |

1. Move the hydraulic control lever rearward to raise the mower to the highest position.
2. Stop the engine and remove the key.
3. Adjust the left side links with bolt so that the clearance (L) is as follows.




Clearance (L) between stopper and rear link	Factory specification	0 to 0.5 mm 0 to 0.01 in.
---	-----------------------	------------------------------

6.1.2 Adjusting front and rear cutting height

RCK48-18BX, RCK54-23BX, and RCK60B-23BX

■ IMPORTANT

- Park the machine on a firm, flat and level surface and set the parking brake.
- Before adjusting mower deck, make sure the tire pressure is correct.



- | | |
|---------------------------------|---------------------------------|
| (1) Cutting height control dial | (L) Length of front link |
| (2) Hydraulic control lever | (F) Height of blade tip (Front) |
| (3) Lock nut | (R) Height of blade tip (Rear) |

9. MOWER

- Turn the cutting height control dial (1) to **2.0** and adjust the anti-scalp roller's height to factory specified clearance between the rollers and the ground.

Clearance between rollers and ground	Factory specification	6.0 to 13 mm 0.25 to 0.50 in.
--------------------------------------	-----------------------	----------------------------------

- Align the ends of the right side blade towards the front and rear of the machine. Turn blade by hand in either direction.
- Adjust (L) of front links with lock nuts (3) so that (A) is within factory specification ((A) = (R) - (F)).

Difference (R) - (F) ((R) ≥ (F)) between front tip and rear tip of blade	Factory specification	0.0 to 5.0 mm 0.0 to 0.20 in.
---	-----------------------	----------------------------------



- If the difference between front tip and rear tip of blade is not within the factory specification, adjust the length (L) of front link with lock nuts (3). The height of rear blade tip (R) should be bigger than the front.
- Tighten lock nuts securely.

6.1.3 Adjusting front and rear cutting height

RCK54D-26BX and RCK60D-26BX

■ IMPORTANT

- Park the machine on a firm, flat and level surface and set the parking brake.
- Before adjusting mower deck, make sure the tire pressure is correct.



- (1) Spring lock washer (3) Lock nut
(2) Lock nut

- Turn the cutting height control dial to **2.0** and adjust the anti-scalp roller's height to factory specified clearance between the rollers and the ground.

Clearance between rollers and ground	Factory specification	6.0 to 13 mm 0.25 to 0.50 in.
--------------------------------------	-----------------------	----------------------------------

- Align the ends of the right side blade towards the front and rear of the machine. Turn blade by hand in either direction.
- Adjust (L1) of the front links with lock nuts (2), (3) so that (A) is within factory specification ((A) = (Y) - (X)).

Difference (Y) - (X) ((Y) ≥ (X)) between front tip and rear tip of blade	Factory specification	0.0 to 5.0 mm 0.0 to 0.20 in.
---	-----------------------	----------------------------------





- To adjust (L1), loosen lock nuts (2) then turn lock nuts (3). Rotate both lock nuts (3) at the same time to set L.H. and R.H. (L2) in even length.
- Tighten lock nuts securely.

Tightening torque	Front link lock nut	60 to 70 N · m 6.2 to 7.1 kgf · m 45 to 51 lbf · ft
-------------------	---------------------	---

6.1.4 Adjusting left and right cutting height

■ IMPORTANT

- Park the machine on a firm, flat and level surface and set the parking brake.
- Before adjusting mower deck, make sure the tire pressure is correct.



- | | |
|--------------------------------------|--------------------------------------|
| (1) Cutting height control dial | (L) Left blade measurement position |
| (2) Hydraulic control lever | (R) Right blade measurement position |
| (3) Cutting height fine turning bolt | (A) Blade height |
| (4) Lock nut | |

1. Operate the hydraulic control lever (2) rearward to raise the mower deck to the highest position.
2. Stop the engine and remove the key.
3. Turn the cutting height control dial to the desired height.
4. Set the anti-scalp roller's height to keep clearance between rollers and the ground inside specification shown below.

Clearance between rollers and ground	Specification	6 to 13 mm 0.2 to 0.5 in.
--------------------------------------	---------------	------------------------------

5. Lower the mower deck by moving the hydraulic control lever forward.
6. Turn left blade by hand parallel to tractor axle and turn right blade parallel to axle to measure from the outside blade tip at (L) and (R) to the level surface. The difference between measurement should be less than the factory specification.

Difference (L) - (R) between left tip and right tip of blade	Factory specification	Less than 3 mm 0.12 in.
--	-----------------------	----------------------------


7. If the difference between measurement is more than the factory specification, loosen the lock nut of the left side.
8. Adjust the cutting height fine turning bolts so that the difference between measurement (L) and (R) is less than the factory specification. Then lock the nut.

6.1.5 Adjusting self-balance suspended linkage

RCK60B-23BX

NOTE

- Check the left and right cutting height difference after adjusting the self-balancer linkage.



- (1) Self-balancer
(2) Balancer spring
(3) Lock nut
(4) Plain washer
(5) Mower deck
(L) Balancer spring length

1. Check the length (L) of balancer spring (2).
2. If the length (L) is not within the factory specification, adjust the length of balancer spring (2) with lock nut (3).

Balancer spring length (L) (Right and left)	Factory specification	55.0 mm 2.17 in.
---	-----------------------	---------------------



6.1.6 Adjusting cutting height

! DANGER

- Never operate the mower in transport position.

■ IMPORTANT



- (for self-balance suspended linkage)
To reduce the stepped difference in cutting height when mowing rolling terrain, follow the procedure below.



- (1) Cutting height control dial (2) Hydraulic control lever

1. To set the cutting height, move the hydraulic control lever rearward to raise the mower to the highest position. Turn the cutting height control dial (1) to adjust height.
2. Set the anti-scalp roller's (3) height as shown to keep clearance between rollers and ground.


Clearance between rollers and ground	Factory specification	6.0 to 13 mm 0.25 to 0.50 in.
--------------------------------------	-----------------------	----------------------------------



- (3) Anti-scalp roller
[A] RCK60B-23BX,
RCK54-23BX,
RCK60D-26BX,
RCK54D-26BX

[B] RCK48-18BX

- Lower the mower deck by moving the hydraulic control lever (2) forward.
- Use the higher settings for mowing in a rough area or when mowing tall grass. Lower settings should be used only for smooth lawns where short grass is desired.
- To set the cutting height, move the hydraulic control lever (2) rearward to raise the mower to the highest position. Turn the cutting height control dial to adjust height.
- Set the anti-scalp roller's (3) position as shown to have the same cutting height.




Dial (Cutting height)	Anti-scalp roller
25 mm (1.0 in.) 32 mm (1.25 in.)	(G)
38 mm (1.5 in.) 45 mm (1.75 in.)	(F)
51 mm (2.0 in.) 57 mm (2.25 in.)	(E)
64 mm (2.5 in.) 70 mm (2.75 in.)	(D)
76 mm (3.0 in.) 83 mm (3.25 in.)	(C)
89 mm (3.5 in.) 95 mm (3.75 in.)	(B)
102 mm (4.0 in.)	(A)

6.2 Checking mower blade and belt

6.2.1 Checking mower blade

- Check the cutting edge of mower blade.



- (1) New blade
(2) Worn blade
(3) Cracked blade

- Sharpen the cutting edges, if the mower blades are as shown in figure (2).

NOTE

- To sharpen the mower blades by yourself, clamp the mower blade securely in a vise and use a large mill file along the original bevel.
- To balance the mower blade, place a small rod through the center hole and check to see if the blade balance evenly. File heavy side of the blade until it balance out even.

- Replace the mower blades, if they are as shown in figure (3).

IMPORTANT


- Never forget to set the dust cover, cup washer(s) and lock washer, when reassembling the mower blades.

RELATED PAGE

[7.3 Removing mower blades on page 9-20](#)

6.2.2 Checking mower belt

- Check to see the mower belt.



9. MOWER


7. Disassembling and assembling

- Replace the mower belt with a new one, if there is found surface split at more than 3 positions.

(When replacing mower belt)

■ IMPORTANT

- After setting the gear box bracket mounting screws on the deck without tightening, then mount the other screws on the gear box. And finally tighten them.



- (1) Tension pulley
(2) Mower belt
(3) Gear box bracket (Right)


- Dismount the mower from the tractor.
- Remove the left and right ramp brackets. (RCK54D-26BX and RCK60D-26BX only)
- Remove the left and right hand belt cover from the mower deck.
- Clean around the gear box.
- Remove the gear box bracket (right) (3) which mounts the gear box to the mower deck.
- Remove the mower belt (2) from the tension pulley (1). Slip the mower belt over the top of the gear box.
- To install a new belt, reverse the above procedure.

Tightening torque	Gear box bracket mounting bolt and nut	78 to 90 N·m 7.9 to 9.2 kgf·m 58 to 66 lbf·ft
	Gear box mounting screw	78 to 90 N·m 7.9 to 9.2 kgf·m 58 to 66 lbf·ft

7. Disassembling and assembling

7.1 Removing universal joint and belt cover

RCK48-18BX, RCK54-23BX, and RCK60B-23BX




- (1) Universal joint
(2) Belt cover (Left)
(3) Belt cover (Right)

- Remove the universal joint screw.
- Remove the universal joint (1).
- Remove the left and right belt covers (2), (3).

7.2 Removing ramps and belt covers

RCK54D-26BX and RCK60D-26BX



- (1) Ramp (Left)
(2) Ramp (Right)
(3) Belt cover (Right)
(4) Belt cover (Left)

- Remove left and right ramp bracket pins.
- Remove left and right ramps (1), (2).
- Remove the left and right belt covers (3), (4).

7.3 Removing mower blades

■ NOTE

- To remove the blade securely, wedge a block of wood between one blade and the mower deck in such position that it will hold the blade safely while loosening or tightening the blade screw.





(a) Loosen

1. Turn over the mower.
2. Remove the mower blade screw (5), and remove the lock washer (4), cup washer(s) (3), mower blade (2) and dust cover (1).

(When reassembling)

■ IMPORTANT

- Make sure the cup washer is not flattened out or worn, causing blade to slip easily. Replace cup washer(s) if either is damaged.




- (1) Dust cover
- (2) Mower blade
- (3) Cup washer
- (4) Lock washer
- (5) Mower blade screw

- [A] RCK48-18BX and RCK54-23BX
[B] RCK60B-23BX, RCK54D-26BX, and RCK60D-26BX

- Install the blade in position together with the dust cover and the cup washer(s). Tighten them up with the screw.

Tightening torque	Mower blade screw	103 to 117 N·m 10.5 to 12.0 kgf·m 76.0 to 86.7 lbf·ft
-------------------	-------------------	---


7.4 Removing blade boss



- (1) Blade boss
- (2) External circlip

1. Remove the external circlip (2).
2. Remove the blade boss (1).

7.5 Removing gear box and mower belt



- (1) Gear box
- (2) Gear box mounting screw (Reamer screw)
- (3) Mower belt
- (4) Gear box mounting screw
- (5) Tension pulley
- (6) Tension spring

1. Turn over the mower.

9. MOWER

7. Disassembling and assembling


- Remove the mower belt (3) from the tension pulley (5).
- Remove the left and right gear box mounting screws (2), (4) and remove the gear box (1) from the mower deck.

(When reassembling)

- Install the reamer screws (2) at their original positions as shown in the figure.

Tightening torque	Gear box mounting screw	78 to 90 N·m 7.9 to 9.2 kgf·m 58 to 66 lbf·ft
-------------------	-------------------------	---

7.6 Disassembling gear box



- | | |
|--|-----------------------|
| (1) Drain plug | (8) Ball bearing |
| (2) Breather | (9) Shim |
| (3) Ball bearing | (10) Oil seal |
| (4) 21T bevel gear [RCK48-18BX] | (11) Internal circlip |
| 19T bevel gear [RCK54-23BX and RCK54D-26BX] | (12) Shim |
| 18T bevel gear [RCK60B-23BX and RCK60D-26BX] | (13) Ball bearing |
| (5) Gear box cap | (14) Pinion shaft |
| (6) External circlip | (15) Oil filler plug |
| (7) 16T bevel gear [RCK48-18BX, RCK54-23BX, and RCK54D-26BX] | (16) Gear box |
| 17T bevel gear [RCK60B-23BX and RCK60D-26BX] | (17) Oil seal |
| | (18) Feather key |
| | (19) Bevel gear shaft |
| | (20) Center pulley |

- Remove the drain plug (1), and drain the gear box oil.
- Remove the center pulley (20) with a puller, and remove the feather key (18) on the bevel gear shaft (19).

- Remove the gear box cap (5).
- Remove the oil seal (10), internal circlip (11) and shim (12).
- Tap out the pinion shaft (14) with the ball bearing (13), and remove the bevel gear (4).
- Remove the ball bearing (3) and shims (if installed).
- Remove the external circlip (6), and draw out the bevel gear shaft (19).
- Remove the bevel gear (7), ball bearing (8), shim (9) and oil seal (17).


(When reassembling)

- Replace the oil seals (10), (17) and gear box cap (5) with new ones.
- Check the backlash and turning torque. If not proper, adjust with the shims.

— RELATED PAGE —

[8.1 Adjusting turning torque of pinion shaft on page 9-25](#)

7.7 Removing center pulley holder



- | | |
|-------------------------------|---------------------------------------|
| (1) Center pulley holder bolt | (10) Gear box bracket (Left) |
| (2) Ball bearing | (11) Nut |
| (3) Circlip | (12) Gear box reamer screw |
| (4) Oil seal | (13) O-ring |
| (5) Nut | (14) Center pulley holder |
| (6) Oil seal | (15) Center pulley holder reamer bolt |
| (7) O-ring | (16) Collar |
| (8) Gear box mounting screw | |
| (9) Gear box bracket (Right) | |

- Remove the center pulley holder bolt (1), (15) / center pulley nut (5), (11).
- Remove the upper oil seal (6) and lower oil seal (4).
- Remove the internal circlip (3) and ball bearing (2).


(When reassembling)


■ NOTE

- When reassembling the center pulley holder (14), gear box and gear box bracket (9), (10), tighten the bolts and nuts in the order as below, to prevent the incline the gear box.
- Tighten the reamer screw (12) to the gear box first, then tighten the reamer bolts (15) and nut (11) to the center pulley holder (14) with specified torque.
- Tighten the gear box screws (8) to the gear box and then tighten the center pulley holder bolts (1) and nut (5) with specified torque.
- Replace the oil seals (4), (6) with new ones.
- Install the reamer screw (12) / reamer bolt (15) at their original positions as shown in the figure.
- Be sure to fix the O-rings (7), (13) to the original position.

Tightening torque	Center pulley holder bolt and nut	78 to 90 N · m 7.9 to 9.2 kgf · m
	Gear box mounting screw	58 to 66 lbf · ft

7.8 Removing outer pulley and blade shaft





- | | |
|---------------------------------------|---|
| (1) Grease fitting | (14) Ball bearing |
| (2) Outer pulley mounting nut | (15) Collar |
| (3) Spring washer | (16) Outer pulley holder |
| (4) Plain washer | (17) Outer pulley holder mounting bolt |
| (5) Outer pulley boss | (18) Ball bearing |
| (6) Outer pulley | (19) Oil seal |
| (7) Nut | (20) Blade shaft |
| (8) Spring washer | [A] RCK48-18BX |
| (9) Pulley boss mounting bolt | [B] RCK54-23BX, RCK60B-23BX, RCK54D-26BX, and RCK60D-26BX |
| (10) Nut | |
| (11) Spring washer | |
| (12) Pulley holder plate [RCK48-18BX] | |
| (13) Oil seal | |

1. Remove the outer pulley mounting nut (2), and remove the outer pulley (6).
2. Remove the outer pulley holder mounting nut (10), and remove the outer pulley holder (16).
3. Remove the oil seal (13) and tap out the blade shaft (20) with the ball bearing (18) and (14), being careful not to damage the grease fitting (1).
4. Remove the ball bearing (14), and collar (15) from the blade shaft (20).
5. Remove the ball bearing (18), and oil seal (19).

(When reassembling)

- Replace the oil seals (13) and (19) with new ones.



Tightening torque	Outer pulley mounting nut	197 to 225 N·m 20.0 to 23.0 kgf·m 145 to 166 lbf·ft
	Pulley boss mounting nut	24 to 27 N·m 2.4 to 2.8 kgf·m 18 to 20 lbf·ft

(RCK54-23BX, RCK60B-23BX, RCK54D-26BX, RCK60D-26BX)

Tightening torque	Outer pulley holder mounting bolt and nut	78 to 90 N·m 7.9 to 9.2 kgf·m 58 to 66 lbf·ft
-------------------	---	---

(RCK48-18BX)

Tightening torque	Outer pulley holder mounting bolt and nut	48.0 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 lbf·ft
-------------------	---	---

7.9 Removing balancer**RCK60B-23BX**

- | | |
|---------------------|---------------------|
| (1) Lock nut | (4) Balancer plate |
| (2) Plain washer | (5) Center pin |
| (3) Balancer spring | (6) Center pin bolt |

1. Remove the lock nut (1) both side.
2. Remove the plain washer (2) and balancer spring (3).
3. Remove the center pin bolt (6).
4. Remove the center pin (5) and balancer plate (4).


(When reassembling)

- Apply grease to the center pin (5).
- Adjust the balancer spring (3) length to the factory specification, with lock nut (1).

Balancer spring length (L) (Right and left)	Factory specification	55.0 mm 2.17 in.
---	-----------------------	---------------------

8. Servicing

8.1 Adjusting turning torque of pinion shaft




- (1) Adjusting shim (3) Adjusting shim
(2) Adjusting shim (4) Blade screw

1. Set the blade screw (4) for the blade shaft to measure the turning torque.
2. Turn the blade screw (4) clockwise with torque wrench and measure the turning torque.

Turning torque	Factory specification	Less than 0.7 N · m 0.07 kgf · m 0.52 lbf · ft
----------------	-----------------------	---

Thickness of adjusting shims (1), (2)	0.2 mm 0.0079 in.
	0.3 mm 0.0118 in.
Thickness of adjusting shims (3)	0.2 mm 0.0079 in.
	0.3 mm 0.0118 in.

8.2 Adjusting backlash between bevel gears



- (1) Shim (3) Gear box cap
(2) 21T bevel gear (4) Shim
[RCK48-18BX] (5) Input shaft
19T bevel gear (6) Shim
[RCK54-23BX, RCK54D-26BX] (7) External circlip
18T bevel gear
[RCK60B-23BX, RCK60D-26BX]

1. Remove the gear box cap (3).
2. Place the plastigauges or wire of solder the bevel gear (2) on the input shaft (5).
3. Turn the input shaft (5).
4. Remove the plastigauges or wire of solder, and measure the thickness with the gauge or an outside micrometer.

5. If the backlash exceeds the allowable limit, adjust it with shims (1), (4), (6).

Backlash between bevel gears	Factory specification	0.10 to 0.20 mm 0.0040 to 0.0078 in
	Allowable limit	0.40 mm 0.016 in.

Thickness of adjusting shims (1), (4)	0.2 mm 0.0079 in.
	0.3 mm 0.0118 in.
Thickness of adjusting shims (6)	0.1 mm 0.0039 in.
	0.2 mm 0.0079 in.

INDEX

Symbols

12T bevel gear and 15T bevel gear	
checking backlash.....	5-17
36T bevel gear	
removing.....	5-13
4WD detent ball	
removing.....	4-47
66T final gear	
removing.....	4-53

A

accelerator wire	
disconnecting.....	3-41
accessory	
electrical circuit.....	8-19
acid burns	
prevent.....	1-4
actuator	
checking flatness.....	4-62
adapter	
removing.....	6-11
air cleaner	
removing.....	3-42
air cleaner element	
cleaning.....	2-28
replacing.....	2-36
alternator	
removing.....	3-42
antifreeze.....	2-37
armature coil	
checking.....	8-52
axial force.....	2-3

B

back plate	
checking wear.....	4-59
balance shaft	
greasing.....	2-44
balancer (RCK60B-23BX)	
removing.....	9-24
ballast.....	2-49
battery	
checking charging current.....	8-38
checking condition.....	2-27
checking specific gravity.....	8-29
checking terminal connection.....	8-29
checking voltage.....	8-29
removing.....	3-38,4-36,5-9,6-12,7-37,7-40,7-47
battery cables	
checking and cleaning.....	2-22
BDF	
overview.....	2-9

bearing	
checking.....	4-59,8-53
bearing at slip ring side	
removing.....	8-50
bearing case cover	
removing.....	3-53
bearing holder	
checking flatness.....	4-62
bearing on drive end side	
removing.....	8-50
belt cover (RCK48-18BX)	
removing.....	9-20
belt cover (RCK54-23BX)	
removing.....	9-20
belt cover (RCK54D-26BX)	
removing.....	9-20
belt cover (RCK60B-23BX)	
removing.....	9-20
belt cover (RCK60D-26BX)	
removing.....	9-20
belt tension pivot	
greasing.....	2-43
bevel gear case	
removing.....	5-12,5-13
bevel gears	
adjusting backlash.....	9-25
bevel pinion shaft	
checking turning torque.....	5-16
removing.....	5-14
bevel pinion shaft and bevel gear	
checking backlash.....	5-17
biodiesel fuel	
overview.....	2-9
blade boss	
removing.....	9-21
blade shaft	
removing.....	9-23
bolts.....	2-13
bonnet	
opening.....	2-19
removing.....	3-39,5-10,6-14
brake	
removing.....	4-54
brake cam lever	
checking movement.....	4-62
brake disc	
checking wear.....	4-63
brake pedal	
adjusting.....	2-31
adjusting free travel.....	4-35
checking.....	2-22
depressed.....	4-12
removing.....	4-41
brake system	
structure.....	4-17

brush	
checking wear.....	8-51,8-54
brush holder	
checking.....	8-52
removing.....	8-49
bushing and shaft	
checking clearance.....	7-51
bushing replacing tool	
D1005-E4.....	2-58
D902-E4.....	2-57
BX tractor	
coolant.....	2-7
dimensions.....	1-21
fuel.....	2-7
lubricant.....	2-7
safety labels.....	1-7
service intervals.....	2-15
specification.....	1-15
wiring diagram.....	8-1

C

cam	
checking height.....	3-64
cam gear	
removing.....	3-50
cam plate and ball	
checking height.....	4-63
camshaft	
checking alignment.....	3-64
checking side clearance.....	3-63
function.....	3-3
camshaft journal	
checking oil clearance.....	3-64
center pin and pin support bushing	
checking clearance.....	5-18
center pulley holder	
removing.....	9-22
center section	
checking.....	4-57
removing.....	4-44
charge lamp	
checking.....	8-43
charge relief valve	
checking.....	4-57
checking charge relief pressure.....	4-31
charging circuit	
checking.....	8-43
charging system	
electrical circuit.....	8-12
check and high pressure relief valve	
checking.....	4-45,4-57
check and high pressure relief valve assembly tool.....	2-65
check and high pressure relief valve plug	
removing.....	4-45
circlip.....	2-3
closed breather	
function.....	3-1

clutch piston	
checking flatness.....	4-60
clutch spring	
checking free length.....	4-60
combination switch	
checking connector voltage.....	8-38
removing.....	8-38
commutator	
checking.....	8-51
compression pressure	
checking.....	3-30
connecting rod	
checking alignment.....	3-67
function.....	3-2
removing.....	3-51,3-52
control valve.....	6-3
disassembling.....	7-49
down position.....	7-7
lift position.....	7-6
neutral position.....	7-5
outline.....	7-4
removing.....	7-44,7-48
structure.....	6-3
control valve lever	
removing.....	7-44
coolant	
changing.....	2-36
checking level.....	2-21
draining.....	3-42
coolant temperature gauge	
function.....	8-16
coolant temperature sensor	
checking connector voltage.....	8-45
checking continuity.....	8-45
function.....	8-17
cooling system	
flushing.....	2-36
overview.....	3-9
cradle bearing	
checking.....	4-58
crankpin and crankpin bearing	
checking oil clearance.....	3-70
crankshaft	
checking alignment.....	3-70
checking side clearance.....	3-69
function.....	3-2
crankshaft assembly	
removing.....	3-54
crankshaft bearing 1	
replacing.....	3-73
crankshaft bearing 1 replacing tool.....	2-59
crankshaft journal and crankshaft bearing 1	
checking oil clearance.....	3-72
crankshaft journal and crankshaft bearing 2 and	
crankshaft bearing 3	
checking oil clearance.....	3-74
cruise rod	
removing.....	4-42

cylinder	
checking wear.....	3-76
cylinder (oversize)	
correcting.....	3-76
cylinder block	
function.....	3-1
removing.....	4-45,4-46
cylinder block assembly	
checking.....	4-58
cylinder head	
checking flaw.....	3-56
checking surface flatness.....	3-55
checking top clearance.....	3-55
removing.....	3-45
cylinder head cover	
removing.....	3-43
cylinder head gasket	
removing.....	3-45
cylinder number.....	2-2

D

daily check.....	2-19
DC outlet	
checking connector voltage.....	8-46
checking continuity.....	8-46
function.....	8-20
delivery valve	
checking fuel tightness.....	3-35
diesel engine compression tester (for injection nozzle)..	
.....	2-55
differential case and differential side gear	
checking clearance.....	4-61,5-15
differential gear	
removing.....	5-15
structure.....	4-14
differential gear assembly	
removing.....	5-14
differential lock	
structure.....	4-16
differential lock pedal	
removing.....	4-42
differential pinion and differential side gear	
checking backlash.....	4-61,5-16
differential pinion shaft and differential pinion	
checking clearance.....	4-61,5-15
disassembling and assembling stand	
(1/2).....	2-61
(2/2).....	2-63
dual tires.....	2-47

E

Easy Checker™	
checking.....	2-22
electrical connector	
chart.....	8-2
electrical connectors	
handling precautions.....	8-7

layout diagram.....	8-6
electrical part	
handling precaution.....	2-5
electrical system	
service specifications.....	8-27
tightening torques.....	8-28
troubleshooting.....	8-21
electrical wiring	
checking and cleaning.....	2-22
electrical wiring chart symbols.....	8-3
engine	
separating.....	3-41
servicing specifications.....	3-19
tightening torques.....	3-28
troubleshooting.....	3-15
engine breather hose	
checking.....	2-40
replacing.....	2-40
engine oil.....	2-8
changing.....	2-23,2-32
checking level.....	2-20
checking pressure.....	3-31
draining.....	3-38
engine oil filter	
replacing.....	2-23,2-31
engine oil pressure lamp	
checking.....	8-44
engine oil pressure switch	
checking continuity.....	8-44
engine start system	
checking.....	2-26
engine stop solenoid	
testing.....	8-37
engine valve	
adjusting clearance.....	2-36

F

fan belt	
adjusting tension.....	2-30
checking damage.....	3-32
checking tension.....	3-32
checking wear.....	3-32
fan drive pulley	
removing.....	3-47
fender	
removing.....	4-38,7-38,7-42,7-48
fender bracket	
removing.....	4-39
fender center stay	
removing.....	4-39,7-39,7-43
field coil	
checking.....	8-52
fire.....	1-4
flasher unit	
checking connector voltage.....	8-42
testing actuation.....	8-43

flow priority valve	
outline.....	7-8
specification.....	7-10
structure.....	7-9
fluids correctly	
discarding.....	1-4
flywheel	
function.....	3-3
removing.....	3-53
flywheel stopper.....	2-58
force.....	2-3
frame link	
mounting.....	9-12
friction plate	
checking wear.....	4-63
front anti-scalp rollers	
greasing.....	2-45
front axle	
adjusting pivot.....	2-33
adjusting rocking force.....	5-8
camber.....	5-2
caster.....	5-2
kingpin angle.....	5-2
servicing specifications.....	5-6
structure.....	5-1
tightening torques.....	5-7
toe-in.....	5-2
troubleshooting.....	5-5
front axle assembly	
removing.....	5-11,6-15
front axle case oil	
changing.....	2-35
draining.....	5-9
front axle shaft	
removing.....	5-13
front ballast.....	2-49
front gear case	
removing.....	5-12,5-13
front gear case cover	
removing.....	5-12
front link	
mounting.....	9-9-9-11
front loader	
hydraulic circuit.....	7-19
front loader control valve	
structure.....	7-18
front loader pipe	
structure.....	7-17
front loader valve	
structure.....	7-17
front wheel.....	2-48
adjusting steering angle.....	5-9
checking bolt torque.....	2-26
removing.....	5-10
front wheel drive	
structure.....	4-13
front wheel drive lever	
removing.....	4-43

front wheel drive shaft	
assembling.....	4-56
fuel.....	2-8
fuel feed pump	
function.....	3-12
fuel filter	
checking.....	2-29
function.....	3-12
fuel filter element	
replacing.....	2-35
fuel gauge	
checking.....	2-19
function.....	8-16
fuel hose	
disconnecting.....	3-40
replacing.....	2-40
fuel injection nozzle	
checking injection pressure.....	2-36
fuel injection pressure	
checking.....	3-36
fuel level sensor	
checking continuity.....	8-44
function.....	8-17
fuel line	
checking.....	2-39
fuel pump	
checking connector voltage.....	8-36
checking continuity.....	8-37
function.....	8-10
fuel system	
bleeding.....	2-41
overview.....	3-12
fuel tank	
removing.....	4-38,7-39,7-42
fuse	
replacing.....	2-41

G

gauge	
checking.....	2-22
gauge system	
electrical circuit.....	8-15
gear box	
disassembling.....	9-22
removing.....	9-21
gear box oil	
changing.....	2-45,2-46
checking level.....	2-43
gear box oil seal	
checking.....	2-46
replacing.....	2-46
gear case	
removing.....	3-48
gear tooth and casing	
checking clearance.....	7-50
glow plug	
checking continuity.....	8-33

checking lead terminal voltage.....	8-32
function.....	8-10
removing.....	3-44
governor gear	
removing.....	3-50
governor gear holder busing replacing tool.....	2-59
grease.....	2-3
greasing.....	2-24
ground cable	
disconnecting.....	3-40

H

half-floating head cover	
function.....	3-1
hazard light	
checking.....	2-22
hazard switch	
checking continuity when setting switch knob at OFF position.....	8-41
checking continuity when setting switch knob at ON position.....	8-42
head light	
checking.....	2-22
head light switch	
checking continuity when setting switch at OFF position.....	8-39
checking continuity when setting switch at ON position.....	8-39
high relief pressure (forward)	
checking.....	4-32
high relief pressure (reverse)	
checking.....	4-33
hitch plate	
removing.....	4-39
hose clamp	
checking.....	2-38
hour meter	
checking.....	2-1, 8-46
function.....	8-16
HST	
adjusting neutral position.....	4-29
HST control linkage	
structure.....	4-8
HST damper	
removing.....	4-42
HST neutral spring	
adjusting.....	2-30, 4-30
checking.....	4-30
HST neutral switch	
checking continuity.....	8-34
HST pedal neutral switch	
function.....	8-10
HST pump shaft	
assembling.....	4-55
hydraulic arm	
removing.....	7-45

hydraulic arm shaft	
removing.....	7-45
hydraulic arm shaft bushing	
checking.....	7-52
hydraulic block type outlet	
structure.....	7-15
hydraulic circuit.....	7-2
steering.....	6-2
hydraulic control lever	
removing.....	4-43
hydraulic cylinder	
checking bore.....	7-51
removing.....	4-48
structure.....	7-14
hydraulic cylinder block	
removing.....	7-43
hydraulic piston	
removing.....	7-45
hydraulic pump	
checking oil flow.....	7-34
outline.....	7-4
removing.....	7-39
specification.....	7-4
structure.....	7-4
hydraulic pump assembly	
removing.....	4-50
hydraulic pump drive gear	
structure.....	4-22
hydraulic system	
servicing specifications.....	7-32
structure.....	7-1
tightening torque.....	7-33
troubleshooting.....	7-31
hydrostatic transmission	
forward position.....	4-5
neutral position.....	4-4
oil flow.....	4-3
relief (reverse position).....	4-7
reverse position.....	4-6
structure.....	4-2

I

IC regulator	
function.....	8-13
removing.....	8-49
idle gear 1	
checking side clearance.....	3-63
removing.....	3-50
idle gear 1 shaft and idle gear bushing	
checking oil clearance.....	3-65
idle gear 2	
removing.....	3-50
idle gear bushing	
replacing.....	3-66
implement limitation	
table.....	2-52
independent PTO clutch spring compression tool....	2-60

independent PTO lever switch	
function.....	8-10
injection nozzle	
function.....	3-12
injection pipe	
removing.....	3-43
injection pump	
checking.....	2-38
removing.....	3-49
injection pump pressure tester.....	2-55
injection timing	
checking.....	3-34
intake air line	
checking.....	2-38
replacing.....	2-40

L

lever	
checking.....	2-23
lift arm	
removing.....	7-45
lift rod	
removing.....	4-37,7-37,7-41
light bulb	
replacing.....	2-42
lighting system	
electrical circuit.....	8-14
loader control lever	
down position.....	7-23
dump position.....	7-29
floating position.....	7-25
neutral position.....	7-20
roll-back position.....	7-27
up position.....	7-21
lock lever shaft	
cleaning.....	2-27
lower link	
removing.....	4-37,7-37,7-41
lowering speed adjusting valve	
removing.....	7-45
lubricating system	
overview.....	3-5

M

magnet switch	
removing.....	8-48
main bearing case assembly	
removing.....	3-54
main switch	
checking connector voltage.....	8-30
checking continuity at off position.....	8-30
checking continuity at on position.....	8-31
checking continuity at preheat position.....	8-31
checking continuity at start position.....	8-31
maximum speed	
adjusting.....	4-29

meter	
checking.....	2-22
meter panel	
checking connector voltage.....	8-47
checking sensor resistance.....	8-47
checking switch continuity.....	8-47
metering device	
function.....	6-3
structure.....	6-3
mica	
checking.....	8-51
mid and rear PTO	
structure.....	4-21
mid-PTO shaft	
assembling.....	4-56
motor	
checking.....	8-32
mower	
adjusting cutting height.....	9-18
adjusting left and right cutting height.....	9-16
assembling.....	9-8,9-10
checking identification.....	2-2
lubricants.....	2-11
mounting.....	9-13
safety labels.....	1-12
service intervals.....	2-17
servicing specifications.....	9-6
setting.....	9-8,9-11
tightening torques.....	9-7
troubleshooting.....	9-5
mower (RCK48-18BX)	
adjusting front and rear cutting height.....	9-15
specifications.....	1-17
mower (RCK54-23BX)	
adjusting front and rear cutting height.....	9-15
specifications.....	1-17
mower (RCK54D-26BX)	
adjusting front and rear cutting height.....	9-16
specifications.....	1-18
mower (RCK60B-23BX)	
adjusting front and rear cutting height.....	9-15
specifications.....	1-17
mower (RCK60D-26BX)	
adjusting front and rear cutting height.....	9-16
specifications.....	1-18
mower belt	
checking.....	2-43,9-19
removing.....	9-21
mower blade	
checking.....	2-42,9-19
removing.....	9-20
mower blade screw	
retightening.....	2-42
mower lift arm	
removing.....	4-43
mower lift linkage	
adjusting.....	7-36

mower lifting mechanism	
structure.....	9-2
mower link	
adjusting.....	9-14
mower linkage	
disassembling.....	7-46
removing.....	7-43
structure.....	7-16
mower power transmission	
structure.....	9-1
mower self-balancer system	
structure.....	9-3
muffler	
removing.....	3-42

N

needle bearing	
checking.....	4-59
neutral arm	
removing.....	4-47
nozzle	
checking spraying condition.....	3-36
nozzle heat seal	
removing.....	3-44
nozzle holder	
checking.....	3-37
nozzle holder assembly	
removing.....	3-44
nozzle tester.....	2-55
nuts.....	2-13

O

oil cooler cover	
removing.....	4-44
oil filter.....	3-7
oil pan	
removing.....	3-47
oil pressure switch	
function.....	3-8,8-18
oil pump	
function.....	3-7
oil strainer	
function.....	3-7
removing.....	3-47
OPC system	
checking.....	2-26
OPC timer	
checking.....	8-36
electrical circuit.....	8-11
operator presence control system	
checking.....	2-26
outer pulley	
removing.....	9-23
outer rotor and pump body	
checking clearance.....	3-77
overrunning clutch	
checking.....	8-50

P

panel	
cleaning.....	2-21
pedal	
checking.....	2-23
pinion shaft	
adjusting turning torque.....	9-25
piston	
function.....	3-2
removing.....	3-51,4-46
piston pin	
checking bore I.D.....	3-66
piston pin and small end bushing	
checking oil clearance.....	3-66
piston ring	
checking gap.....	3-68
function.....	3-2
removing.....	3-52
piston ring and piston ring groove	
checking clearance.....	3-68
plunger	
removing.....	8-48
power steering	
checking oil flow.....	7-35
power steering cylinder	
removing.....	5-12,6-15
power steering hose	
replacing.....	2-40
power steering line	
checking.....	2-39
pressure plate	
checking flatness.....	4-60
propeller shaft	
disconnecting.....	5-11
removing.....	4-42
propeller shaft assembly	
disconnecting.....	3-41
propeller shaft cover	
removing.....	5-10
PTO brake disc	
checking wear.....	4-60
PTO brake plate	
checking.....	4-60
PTO clutch	
checking operating pressure.....	4-35
disengaged function.....	4-20
engaged function.....	4-20
PTO clutch assembly	
removing.....	4-55
PTO clutch control lever	
removing.....	4-43
PTO clutch disc	
checking wear.....	4-59
PTO clutch relief valve	
function.....	4-20
PTO clutch shaft	
assembling.....	4-55

checking.....	4-58
PTO clutch valve	
removing.....	4-43
PTO select arm	
assembling.....	4-55
PTO select lever	
removing.....	4-43
PTO shift lever switch	
checking continuity.....	8-33
function.....	8-10
PTO system	
structure.....	4-19
pulley	
removing.....	8-48
pump element	
checking fuel tightness.....	3-35
pump shaft	
checking.....	4-58
push rod	
checking alignment.....	3-61
removing.....	3-45

Q

quick coupler (tractor side)	
removing.....	7-50
quick coupler socket.....	2-67

R

radiator	
checking water leakage.....	3-33
function.....	3-11
removing.....	3-42
radiator cap	
checking air leakage.....	3-32
function.....	3-11
radiator hose	
checking.....	2-38
replacing.....	2-40
radiator screen	
cleaning.....	2-21
ramp (RCK54D-26BX)	
removing.....	9-20
ramp (RCK60D-26BX)	
removing.....	9-20
range gear shift	
structure.....	4-12
range gear shift lever	
removing.....	4-43
rear anti-scalp rollers	
greasing.....	2-45
rear axle (L.H.)	
disassembling.....	4-51
rear axle case (R.H.)	
removing.....	4-52,4-54
rear ballast.....	2-49
weight.....	2-51

rear end cover	
removing.....	8-49
rear end frame	
removing.....	8-49
rear link	
mounting.....	9-9
rear PTO cover assembly	
removing.....	4-51
rear PTO switch	
function.....	8-10
rear wheel.....	2-48
checking bolt torque.....	2-26
removing.....	4-39
rectifier	
checking.....	8-54
removing.....	8-49
refueling.....	2-19
relay	
function.....	8-9
relief valve	
checking.....	3-78
checking operating pressure.....	6-11
checking setting pressure.....	7-34
function.....	3-8,6-4,7-12
outline.....	7-10
readjusting.....	4-33
specification.....	6-4,7-13
structure.....	7-11
retainer plate	
removing.....	8-50
rocker arm.....	3-3
removing.....	3-45
rocker arm and rocker arm shaft	
checking oil clearance.....	3-61
rod and guide	
checking clearance.....	6-16
ROPS	
checking.....	2-22
removing.....	4-37,7-38,7-41,7-47
rotating movement.....	2-3
rotor	
checking.....	8-53
removing.....	8-50
rotor and cover	
checking clearance.....	3-78
rotor lobe	
checking clearance.....	3-77

S

safety first.....	1-1
safety switch	
function.....	8-10
screws.....	2-13
seat	
removing.....	4-37,7-38,7-41,7-47
seat belt	
checking.....	2-22

seat switch		
checking continuity.....	8-34	
function.....	8-10	
seat turnover switch		
checking continuity.....	8-34	
function.....	8-10	
self-balance suspended linkage		
adjusting.....	9-17	
separate plate		
checking wear.....	4-59	
serial number		
checking.....	2-1	
sharp edge.....	2-3	
shifter		
assembling.....	4-56	
side plate		
checking thickness.....	7-51	
slip ring		
checking.....	8-53	
small end bushing		
replacing.....	3-67	
special use puller set.....	2-55	
speed control pedal		
removing.....	4-42	
speed control plate		
removing.....	3-48	
speed set.....	4-9	
spindle shaft		
greasing.....	2-43	
spiral bevel pinion gear and bevel gear		
checking backlash.....	4-62	
spiral bevel pinion shaft		
assembling.....	4-56	
start safely.....	1-2	
starter		
disassembling motor.....	8-47	
function.....	8-9	
removing.....	3-42	
starter magnet switch		
testing.....	8-32	
starting system		
electrical circuit.....	8-8	
stator		
checking.....	8-53	
steel plate		
checking flatness.....	4-60	
steering		
servicing specifications.....	6-9	
tightening torque.....	6-10	
troubleshooting.....	6-7	
steering controller		
removing.....	6-13	
structure.....	6-3	
steering cylinder		
checking I.D.....	6-16	
disassembling.....	6-12	
structure.....	6-5	
steering system		
structure.....	6-1	
steering wheel		
removing.....	6-13	
step		
removing.....	4-38,7-38,7-41,7-47	
stud bolts		
tightening torque.....	2-13	
swashplate		
removing.....	4-46	
T		
tachometer		
checking.....	8-46	
function.....	8-16	
tail light		
checking.....	2-22	
tappet		
removing.....	3-46	
tappet and tappet guide bore		
checking oil clearance.....	3-62	
tension pulley		
greasing.....	2-43	
thermostat assembly		
removing.....	3-46	
thermostat valve		
checking opening temperature.....	3-33	
thrust plate		
checking.....	4-58	
thrust roller		
checking.....	4-58	
thrust washer		
checking.....	4-58	
tie-rod		
removing.....	6-11	
tie-rod end lifter.....	2-60	
timer relay		
checking connector voltage.....	8-37	
testing.....	8-37	
timing gear		
checking backlash.....	3-62	
timing gears		
function.....	3-4	
tires.....	2-47	
inflation pressure.....	2-47	
toe-in		
adjusting.....	2-33,5-8	
tractor		
setting.....	9-13	
transaxle		
servicing specifications.....	4-27	
structure.....	4-1	
tightening torque.....	4-28	
troubleshooting.....	4-23	
transaxle assembly		
removing.....	4-40	

transaxle case front cover	
removing.....	4-48
transmission fluid	
changing.....	2-34
checking level.....	2-20
draining.....	4-36
transmission oil.....	2-8
transmission oil filter	
replacing.....	2-24,2-33
transmission strainer	
cleaning.....	2-35
traveling speeds.....	1-19
trunnion arm	
removing.....	4-47
trust roller bearing	
removing.....	4-46
turn signal light switch	
checking continuity when setting switch knob at LEFT position.....	8-41
checking continuity when setting switch knob at OFF position.....	8-40
checking continuity when setting switch knob at RIGHT position.....	8-40

U

universal joint	
greasing.....	2-45
installing.....	9-9
universal joint (RCK48-18BX)	
removing.....	9-20
universal joint (RCK54-23BX)	
removing.....	9-20
universal joint (RCK60B-23BX)	
removing.....	9-20
upper panel	
removing.....	6-13

V

valve	
checking clearance.....	3-30
checking recessing.....	3-57
checking seating.....	3-58
correcting.....	3-59
lapping.....	3-60
removing.....	3-46
valve guide	
replacing.....	3-58
valve guide replacing tool.....	2-56
valve plate	
removing.....	4-44
valve seat	
checking tightness.....	3-37
correcting.....	3-59
valve spring	
checking free length.....	3-60
checking setting load.....	3-60
checking tilt.....	3-60

valve stem and valve guide	
checking clearance.....	3-57

W

walk around inspection.....	2-19
water pump	
function.....	3-11
wheel tread.....	2-47
wire harness	
removing.....	7-43
wiring	
handling precaution.....	2-5
wiring harness	
disconnecting.....	3-40

Editor : Tractor and Agricultural Implement Service Dept.
Address : 64, Ishizu-Kitamachi, Sakai-Ku, Sakai-City, Osaka, 590-0823, Japan
Phone : +81-72-241-1129
Fax : +81-72-245-2484
E-mail : kbt_g.ag-sv@kubota.com

Editor : Harvester, Transplanter and Farm Machinery Products Service Dept.
Address : 64, Ishizu-Kitamachi, Sakai-Ku, Sakai-City, Osaka, 590-0823, Japan
Phone : +81-72-241-6554
Fax : +81-72-241-1751
E-mail : kbt_g.ag-sv@kubota.com
