

WSM

WORKSHOP MANUAL
TRACTOR

B2301, B2601

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the B2301 and B2601. It contains 4 parts: "**Information**", "**General**", "**Mechanism**" and "**Servicing**".

■ **Information**

This section primarily contains information below.

- Safety First
- Safety Decal
- Specifications
- Dimensions

■ **General**

This section primarily contains information below.

- Engine Identification
- Model Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

■ **Mechanism**

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the diesel engine / tractor mechanism that this workshop manual does not include.

■ **Servicing**

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

I INFORMATION

INFORMATION

CONTENTS

1. SAFETY FIRST	I-1
2. SAFETY DECALS	I-4
3. SPECIFICATIONS	I-7
4. TRAVELING SPEEDS	I-8
5. DIMENSIONS	I-9

1. SAFETY FIRST

SAFETY FIRST

- This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.
- It is essential that you read the instructions and safety regulations before you try to repair or use this unit.

DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.


■ IMPORTANT

- Indicates that equipment or property damage could result if instructions are not followed.

■ NOTE

- Gives helpful information.

WSM000001INI0001US1




IBM001A

BEFORE YOU START SERVICE

- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a stable and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, then remove the key.
- Disconnect the battery negative cable.
- Hang a "DO NOT OPERATE" tag in the operator station.

WSM000001INI0010US0




IBM002A

START SAFELY

- Do not do the procedures below when you start the engine.
 - short across starter terminals
 - bypass the safety start switch
- Do not alter or remove any part of machine safety system.
- Before you start the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Do not start the engine when you stay on the ground. Start the engine only from operator's seat.


WSM000001INI0015US0




IBM003A



IBM004A



IBM005A



IBM006A

OPERATE SAFELY


- Do not use the machine after you consume alcohol or medication or when you are tired.
- Put on applicable clothing and safety equipment.
- Use applicable tools only. Do not use alternative tools or parts.
- When 2 or more persons do servicing, make sure that you do it safely.
- Do not operate below the machine that only a jack holds. Always use a safety stand to hold the machine.
- Do not touch the hot parts or parts that turn when the engine operates.
- Do not remove the radiator cap when the engine operates, or immediately after it stops. If not, hot water can spout out from the radiator. Only remove the radiator cap when it is at a sufficiently low temperature to touch with bare hands. Slowly loosen the cap to release the pressure before you remove it fully.
- Released fluid (fuel or hydraulic oil) under pressure can cause damage to the skin and cause serious injury. Release the pressure before you disconnect hydraulic or fuel lines. Tighten all connections before you apply the pressure.
- Do not open a fuel system under high pressure. The fluid under high pressure that stays in fuel lines can cause serious injury. Do not disconnect or repair the fuel lines, sensors, or any other components between the fuel pump and injectors on engines with a common rail fuel system under high pressure.
- Put on an applicable ear protective device (earmuffs or earplugs) to prevent injury against loud noises.
- Be careful about electric shock. The engine generates a high voltage of more than DC100 V in the ECU and is applied to the injector.

WSM000001INI0012US0

PREVENT A FIRE

- Fuel is very flammable and explosive under some conditions. Do not smoke or let flames or sparks in your work area.
- To prevent sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- The battery gas can cause an explosion. Keep the sparks and open flame away from the top of battery, especially when you charge the battery.
- Make sure that you do not spill fuel on the engine.


WSM000001INI0005US0



KEEP A GOOD AIRFLOW IN THE WORK AREA

- If the engine is in operation, make sure that the area has good airflow. Do not operate the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.


WSM000001INI0006US0



DISCARD FLUIDS CORRECTLY

- Do not discard fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you discard oil, fuel, coolant, electrolyte and other dangerous waste.


WSM000001INI0007US0



PREVENT ACID BURNS

- Keep electrolyte away from your eyes, hands and clothing. Sulfuric acid in battery electrolyte is poisonous and it can burn your skin and clothing and cause blindness. If you spill electrolyte on yourself, clean yourself with water, and get medical aid immediately.

WSM000001INI0008US0



PREPARE FOR EMERGENCIES

- Keep a first aid kit and fire extinguisher ready at all times.
- Keep the emergency contact telephone numbers near your telephone at all times.



WSM000001INI0009US0

2. SAFETY DECALS

The following safety decals are installed on the machine. If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

WSM000001INI0013US0

(1) Part No. TA240-9848-2



	<p align="center">⚠ WARNING</p> <p>TO AVOID INJURY OR DEATH FROM ROLL-OVER:</p> <ul style="list-style-type: none"> • Keep Roll-Over Protective Structures (ROPS) in the upright and locked position. • Fasten SEAT BELT before operating. <p>THERE IS NO OPERATOR PROTECTION WHEN THE ROPS IS IN THE FOLDED POSITION:</p> <ul style="list-style-type: none"> • Check the operating area and fold the ROPS only when absolutely necessary. • Do not wear SEAT BELT if ROPS is folded. • Raise and lock ROPS as soon as vertical clearance allows. • Read ROPS related instructions and warnings.
	

1AGAEBMAP071E

(2) Part No. TC420-4956-1

Diesel fuel only

No fire

	
ULTRA LOW SULFUR DIESEL FUEL ONLY	



1AGAI DHAP154E

(3) Part No. 6C090-4958-2

Do not get your hands close to engine fan and fan belt.



1AGAI AZAP110A



9Y1211156ICI001US

9Y1211156INI0004US0

(1) Part No. 6C200-4959-1

⚠ WARNING	TO AVOID PERSONAL INJURY: 1. Attach pulled or towed loads to the drawbar only. 2. Use the 3-point hitch only with equipment designed for 3-point hitch usage.
	⚠ WARNING TO AVOID PERSONAL INJURY: 1. Keep PTO shield in place at all times. 2. Do not operate the PTO at speeds faster than the speed recommended by the implement manufacturer. 3. For trailing PTO-driven implements, set drawbar at towing position. (see operator's manual)

1AGAECEAP013E

(3) Part No. 6C430-4965-1

	
⚠ DANGER	
TO AVOID POSSIBLE INJURY OR DEATH FROM A MACHINE RUNAWAY. 1. Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed. 2. Start engine only from operator's seat with transmission and PTO OFF. Never start engine while standing on the ground.	


1AGAEAAAP033A

(2) Part No. 6C540-9554-1

⚠ WARNING Never modify or repair a ROPS because welding, grinding, drilling or cutting any portion may weaken the structure.
⚠ WARNING TO AVOID PERSONAL INJURY OR DEATH WHEN RAISING OR FOLDING ROPS: • Set parking brake and stop engine. • Remove any obstruction that may prevent raising or folding of the ROPS. • Do not allow any bystanders. • Always perform function from a stable position at the rear of the tractor. • Hold the top of the ROPS securely when raising or folding. • Make sure all pins are installed and locked.

1AGAEIAP038A

(4) Part No. 6C430-4959-1
Do not touch hot surface like muffler, etc.



1AGAEAAAP002A

(6) Part No. 6C300-4744-1



⚠ WARNING Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

1AGAIHFAP069A

(5) Part No. 6C090-4958-2
Do not get your hands close to engine fan and fan belt.



1AGAIAZAP110A



(1) Part No. 6C300-3012-2

<p>S.O.C. INDICATOR</p> <ul style="list-style-type: none"> OK CHARGE BATTERY REPLACE BATTERY 		<p>DANGER</p> <p>• DUE TO HYDROGEN GAS GENERATED FROM BATTERY, HANDLING WITHOUT CARE CAN CAUSE FIRE AND EXPLOSION. • THIS 12V BATTERY IS ONLY FOR STARTING ENGINE. DO NOT APPLY THIS PRODUCT FOR OTHER USES. • CHARGE THIS BATTERY ONLY AT WELL VENTILATED PLACES, AND AVOID SHORTS OR SPARKS. • REFER TO THE INSTRUCTION MANUAL OF VEHICLE OR BATTERY BEFORE USING BOOSTER CABLE. • SULFURIC ACID MAY CAUSE BLINDNESS OR SEVERE BURN IN CASE EYES, SKIN, CLOTHES OR ANY ARTICLES ARE STAINED WITH ACID. FLUSH OBJECTS IMMEDIATELY WITH WATER. IF ACID BEING SWALLOWED, DRINK PLenty OF WATER PROPERLY. IN CASE OF ACCIDENTAL CONTACT, CONSULT A DOCTOR IMMEDIATELY. • BATTERY FILLED WITH ACID (DO NOT TILT OR SPILL) • FLAMMABLE DO NOT CHARGE NEAR FIRE OR SPARKS • DO NOT CHARGE RAPIDLY • DO NOT DISASSEMBLE THE BATTERY (SEALED TYPE)</p>
<p>55B24LS 430CCA (SAE) 360CCA (EN) 12V 45Ah(20HR) RC 80(MIN)</p>		<p>PROPOSITION 65 WARNING BATTERY POSTS, TERMINALS, AND RELATED ACCESSORIES CONTAIN LEAD AND LEAD COMPOUNDS, CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND REPRODUCTIVE HARM. WASH HANDS AFTER HANDLING.</p> <p>DK 85495</p>

1AGAEBQAP107A

(2) Part No. 6C540-4742-1

WARNING

TO AVOID PERSONAL INJURY OR DEATH:

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismounting, lower the implement to the ground, set the parking brake, stop the engine and remove the key.
12. Securely support tractor and implements before working underneath.

1AGAEEIAP035A



(3) Part No. 6C150-4743-1

WARNING

BEFORE DISMOUNTING TRACTOR:

1. ALWAYS SET PARKING BRAKE.
2. PARK ON LEVEL GROUND WHENEVER POSSIBLE. If parking on a slope, position tractor across the slope.
3. LOWER ALL IMPLEMENTS TO THE GROUND.
4. STOP THE ENGINE.

1AGAEBMAP059E



9Y1211156ICI003US

9Y1211156INI0006US0

CARE OF DANGER, WARNING AND CAUTION LABELS

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning and caution label(s) affixed is replaced with new part, make sure new label(s) is (are) attached in the same location(s) as the replace component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

9Y1211156INI0007US0

3. SPECIFICATIONS

Model			B2301	B2601
PTO power *1			17.5 kW (13.0 HP)	19.5 kW (14.5 HP)
Engine	Maker		KUBOTA	
	Model		D1005-E4-D32	D1105-E4-D32
	Type		E-TVCS. Liquid-cooled, 3-cylinder diesel	
	Number of cylinders		3	
	Bore and stroke		76 × 73.6 mm (3.0 × 2.9 in.)	78 × 78.4 mm (3.1 × 3.1 in.)
	Total displacement		1001 cc (61.1 cu.in.)	1123 cc (68.5 cu.in.)
	Engine gross power *1		22 kW (16.4 HP)	25.5 kW (19.0 HP)
	Rated revolution		2800 min ⁻¹ (rpm)	
	Low idling revolution		1000 to 1100 min ⁻¹ (rpm)	
	Maximum torque		60 N·m (6.1 kgf·m, 44 lbf·ft)	71 N·m (7.2 kgf·m, 52 lbf·ft)
	Battery		12 V, RC: 80 min, CCD: 430 A	
Capacities	Fuel tank		23 L (6.1 U.S.gals, 5.1 Imp.gals)	
	Engine crankcase (with filter)		3.1 L (3.3 U.S.qts, 2.7 Imp.qts)	
	Engine coolant		3.8 L (4.0 U.S.qts, 3.3 Imp.qts)	
	Transmission case		15 L (4.0 U.S.gals, 3.3 Imp.gals)	
Dimensions	Overall length (without 3P)		2380 mm (93.7 in.)	2410 mm (94.9 in.)
	Overall width (min. tread)		1150 mm (45.3 in.)	1245 mm (49.0 in.)
	Overall height		2130 mm (83.9 in.)	2160 mm (85.0 in.)
	Wheel base		1560 mm (61.4 in.)	
	Minimum ground clearance		305 mm (12.0 in.)	325 mm (12.8 in.)
	Tread	Front	800 mm (31.5 in.)	815 mm (32.1 in.)
Rear		900 mm (35.5 in.)	950 mm (37.4 in.)	
Weight			710 kg (1566 lbs)	740 kg (1632 lbs)
Clutch			Not applicable	
Traveling system	Tires	Front	6-12	7-12
		Rear	9.5-16	11.2-16
	Steering		Hydraulic type power steering	
	Transmission		HST (3 range)	
	Brake		Wet disk type	
Minimum turning radius (with brake)		2.1 m (6.9 feet)		
Hydraulic unit	Hydraulic control system		Position Control Valve	
	Pump capacity		31.4 L/min (8.3 gals/min)	
	3-point hitch		SAE Category 1	
	Max. lift force	At lift points	820 kg (1808 lbs)	
24 in. behind lift point		640 kg (1411 lbs)		
PTO	Rear-PTO		SAE 1-3/8, 6 splines	
		PTO / Engine speed	540 min ⁻¹ (rpm) / 2768 min ⁻¹ (rpm)	
	Mid-PTO		USA No.5 (KUBOTA 10-tooth) involute spline	
		PTO / Engine speed	2500 min ⁻¹ (rpm) / 2753 min ⁻¹ (rpm)	

■ **NOTE**

- * Manufacturer's estimate

The company reserves the right to change the specifications without notice.

9Y1211156INI0001US0

4. TRAVELING SPEEDS

(At rated engine rpm)


Model		B2301HSD
Tire size (Rear)		9.5-16 Farm / 33 × 12.5-15 Turf / 12-16.5 Industry
	Range gear shift lever	km/h (mile/h)
Forward	Low	0 to 5.6 (0 to 3.5)
	Middle	0 to 8.8 (0 to 5.5)
	High	0 to 19.1 (0 to 11.8)
Reverse	Low	0 to 4.2 (0 to 2.6)
	Middle	0 to 6.6 (0 to 4.1)
	High	0 to 14.3 (0 to 8.9)

Model		B2601HSD	
Tire size (Rear)		11.2-16 Farm	33 × 12.5-15 Turf / 12-16.5 Industry
	Range gear shift lever	km/h (mile/h)	
Forward	Low	0 to 6.0 (0 to 3.7)	0 to 5.6 (0 to 3.5)
	Middle	0 to 9.5 (0 to 5.9)	0 to 8.8 (0 to 5.5)
	High	0 to 20.4 (0 to 12.7)	0 to 19.1 (0 to 11.8)
Reverse	Low	0 to 4.5 (0 to 2.8)	0 to 4.2 (0 to 2.6)
	Middle	0 to 7.1 (0 to 4.4)	0 to 6.6 (0 to 4.1)
	High	0 to 15.3 (0 to 9.5)	0 to 14.3 (0 to 8.9)

The company reserves the right to change the specification without notice.

9Y1211156INI0002US0

5. DIMENSIONS



9Y1211156IFI001US

9Y1211156INI0003US0



G GENERAL

GENERAL

CONTENTS

1. TRACTOR IDENTIFICATION	G-1
2. GENERAL PRECAUTIONS.....	G-2
3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING	G-3
[1] WIRING	G-3
[2] BATTERY	G-5
[3] FUSE	G-5
[4] CONNECTOR	G-5
[5] HANDLING OF CIRCUIT TESTER	G-6
[6] COLOR OF WIRING	G-7
4. LUBRICANTS, FUEL AND COOLANT	G-8
5. TIGHTENING TORQUES	G-11
[1] GENERAL USE SCREWS, BOLTS AND NUTS	G-11
[2] STUD BOLTS	G-11
[3] METRIC SCREWS, BOLTS AND NUTS	G-12
[4] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS	G-12
[5] PLUGS	G-12
6. MAINTENANCE CHECK LIST	G-13
7. CHECK AND MAINTENANCE	G-15
[1] DAILY CHECK.....	G-15
[2] CHECK POINTS OF EVERY 50 HOURS	G-19
[3] CHECK POINTS OF EVERY 100 HOURS	G-21
[4] CHECK POINTS OF EVERY 200 HOURS	G-25
[5] CHECK POINTS OF EVERY 400 HOURS	G-28
[6] CHECK POINT OF EVERY 800 HOURS.....	G-30
[7] CHECK POINT OF EVERY 1500 HOURS.....	G-30
[8] CHECK POINT OF EVERY 3000 HOURS.....	G-30
[9] CHECK POINT OF EVERY 1 YEAR	G-30
[10]CHECK POINTS OF EVERY 2 YEARS	G-31
[11]OTHERS.....	G-33
8. SPECIAL TOOLS	G-35
[1] SPECIAL TOOLS FOR ENGINE.....	G-35
[2] SPECIAL TOOLS FOR TRACTOR	G-42
9. TIRES	G-45
[1] TIRE PRESSURE.....	G-45
[2] WHEEL ADJUSTMENT.....	G-46
(1) Front Wheels	G-46
(2) Rear Wheels.....	G-48
[3] BALLAST	G-50
10. IMPLEMENT LIMITATIONS	G-52

1. TRACTOR IDENTIFICATION




When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.

- (1) Tractor Identification Plate
- (2) Tractor Serial Number
- (3) Engine Serial Number
- (4) ROPS Identification Plate (ROPS Serial Number)

9Y1211156GEG0001US0

2. GENERAL PRECAUTIONS




- When you disassemble, carefully put the parts in a clean area to make it easy to find the parts. You must install the screws, bolts and nuts in their initial position to prevent the reassembly errors.
- When it is necessary to use special tools, use KUBOTA special tools. Refer to the drawings when you make special tools that you do not use frequently.
- Before you disassemble or repair machine, make sure that you always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before you measure.
- Use only KUBOTA genuine parts for replacement to keep the machine performance and to make sure of safety.
- You must replace the gaskets and O-rings when you assemble again. Apply grease **(1)** to new O-rings or oil seals before you assemble.
- When you assemble the external or internal snap rings, make sure that the sharp edge **(3)** faces against the direction from which force **(2)** is applied.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.
- Clean the parts before you measure them.
- Tighten the fittings to the specified torque. Too much torque can cause damage to the hydraulic units or the fittings. Not sufficient torque can cause oil leakage.
- When you use a new hose or pipe, tighten the nuts to the specified torque. Then loosen (approx. by 45 °) and let them be stable before you tighten to the specified torque (This is not applied to the parts with seal tape).
- When you remove the two ends of a pipe, remove the lower end first.
- Use two pliers in removal and installation. One to hold the stable side, and the other to turn the side you remove to prevent twists.
- Make sure that the sleeves of flared connectors and tapers of hoses are free of dust and scratches.
- After you tighten the fittings, clean the joint and apply the maximum operation pressure 2 to 3 times to check oil leakage.

- (1) Grease
- (2) Force
- (3) Sharp Edge
- (4) Axial Force
- (5) Rotating Movement

- (A) External Circlip**
- (B) Internal Circlip**

WSM000001GEG0106US0

3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING



To ensure safety and prevent damage to the machine and surrounding equipment, obey the following precautions in handling electrical parts and wiring.


■ IMPORTANT

- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not try to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

- (1) Negative Terminal (2) Positive Terminal

WSM000001GEG0062US0


[1] WIRING



- Securely tighten wiring terminals.

- (1) Correct (Securely Tighten) (2) Incorrect (Loosening Leads to Faulty Contact)


WSM000001GEG0063US0



- Do not let wiring contact dangerous part.

- (1) Dangerous Part (Sharp Edge) (2) Wiring (Incorrect) (3) Wiring (Correct) (4) Dangerous Part


WSM000001GEG0064US0



- Repair or change torn or aged wiring immediately.

- (1) Aged (2) Torn (3) Insulating Vinyl Tape


WSM000001GEG0065US0



- Securely insert grommet.

- (1) Grommet
- (A) Correct
- (B) Incorrect


WSM000001GEG0066US0



- Securely clamp, being careful not to damage wiring.

- (1) Clamp (Wind Clamp Spirally)
- (2) Wire Harness
- (3) Clamp
- (4) Welding Dent


WSM000001GEG0067US0



- Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.

- (1) Wiring
- (2) Clamp
- (A) Correct
- (B) Incorrect


WSM000001GEG0068US0



- In installing a part, be careful not to get wiring caught by it.

- (1) Wiring
- (A) Incorrect

WSM000001GEG0069US0




- After installing wiring, check protection of terminals and clamped condition of wiring.

- (1) Cover (Securely Install Cover)

WSM000001GEG0070US0

[2] BATTERY



- Be careful not to confuse positive and negative terminal posts.
- When you remove battery cables, disconnect negative cable first. When you install battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After you connect cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.


! DANGER

To avoid serious injury or death:

- Be careful not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before you recharge the battery, remove it from the machine.
- Before you recharge, remove cell caps.
- Recharge in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

WSM000001GEG0071US0

[3] FUSE




- Use fuses with specified capacity. Neither too large nor small capacity fuse is acceptable.
- Never use steel nor copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse
(2) Fusible Link

(3) Slow Blow Fuse

WSM000001GEG0072US0


[4] CONNECTOR



- For connector with lock, push lock to separate.

(A) Push

WSM000001GEG0073US0




- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect


WSM000001GEG0074US0



- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make sure that there is no terminal being exposed or displaced.

- (1) Exposed Terminal
- (2) Deformed Terminal
- (3) Sandpaper
- (4) Rust


WSM000001GEG0075US0



- Make sure that there is no female connector being too open.

- (A) Correct
- (B) Incorrect

WSM000001GEG0076US0




- Make sure that plastic cover is large enough to cover whole connector.

- (1) Cover
- (A) Correct
- (B) Incorrect

WSM000001GEG0077US0


[5] HANDLING OF CIRCUIT TESTER



- Use tester correctly following manual provided with tester.
- Check for polarity and range.

WSM000001GEG0078US0

[6] COLOR OF WIRING



- Colors of wire are specified to the color codes.
- This symbol of "/" shows color with stripe(s).

(An example)

Red stripe on white color: W/R

Color of wiring	Color code
Black	B
Brown	Br
Green	G
Gray	Gy or Gr
Blue	L
Light Green	Lg
Orange	Or
Pink	P
Purple	Pu or V
Red	R
Sky Blue	Sb
White	W
Yellow	Y

(1) Wire Color

(2) Stripe

WSM000001GEG0079US0

4. LUBRICANTS, FUEL AND COOLANT

No.	Place	Capacity		Lubricants, fuel and coolant
		B2301	B2601	
1	Fuel tank	23 L 6.1 U.S.gals 5.1 Imp.gals		<ul style="list-style-type: none"> No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below -10°C (14°F)
2	Coolant (with recovery tank)	3.8 L 4.0 U.S.qts 3.3 Imp.qts		Fresh clean soft water with anti-freeze
3	Engine crankcase (with filter)	3.1 L 3.3 U.S.qts 2.7 Imp.qts		Engine oil: Refer to next page <ul style="list-style-type: none"> Above 25°C (77°F) SAE30, SAE10W-30 or 15W-40 -10 to 25°C (14 to 77°F) SAE20, SAE10W-30 or 15W-40 Below -10°C (14°F) SAE10W-30
4	Transmission case	15 L 4.0 U.S.gals 3.3 Imp.gals		KUBOTA SUPER UDT-2 fluid*
5	Front axle case	3.5 L 3.7 U.S.qts 3.1 Imp.qts		KUBOTA SUPER UDT-2 fluid* or SAE80 - SAE90 gear oil

	Greasing	No. of greasing point	Capacity	Type of grease
6	Top link	1	Until grease overflows	Multipurpose type grease NLGI-2 or NLGI-1 (GC-LB)
	Lift rod [RH]	1		
	Brake pedal	1		
	Battery terminal	2	Moderate amount	

■ NOTE

- *KUBOTA UDT or SUPER UDT fluid --- KUBOTA original transmission hydraulic fluid

9Y1211156GEG0002US0

■ **NOTE**

<For North American market>

Engine Oil

- Oil used in the engine should have an American Petroleum Institute (API) service classification and Proper SAE Engine Oil according to the ambient temperatures as shown above :
- Refer to the following table for the suitable API classification engine oil according to the engine type (with internal EGR, external EGR or non-EGR) and the fuel (low-sulfur or high-sulfur fuel).

Fuel used	Engine oil classification (API classification)	
	Oil class of engines except external EGR	Oil class of engines with external EGR
Ultra Low Sulfur Fuel [< 0.0015 % (15 ppm)]	CF, CF-4, CG-4, CH-4 or CI-4	CF or CI-4 (Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR type engines)

EGR: Exhaust Gas Re-circulation

- **The CJ-4 engine oil is intended for DPF (Diesel Particulate Filter) type engines, and cannot be used on this tractor.**

	except external EGR	With external EGR
Models	B2301 / B2601	–

Fuel

- Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below –20 °C (–4 °F) or elevations above 1500 m (5000 ft).
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engine in industrial and heavy mobile service. (SAE J313 JUN87)

Transmission oil

- **KUBOTA Super UDT-2: For an enhanced ownership experience, we highly recommend Super UDT-2 to be used instead of standard hydraulic/transmission fluid.**
Super UDT-2 is a proprietary KUBOTA formulation that delivers superior performance and protection in all operating conditions.
Regular UDT is also permitted for use in this machine.

- Indicated capacities of water and oil are manufacturer's estimate.

<For other than North American market>

Engine Oil

- Oil used in the engine should have an American Petroleum Institute (API) service classification and Proper SAE Engine Oil according to the ambient temperatures as shown above :
- With the emission control now in effect, the CF-4 and CG-4 lubricating oils have been developed for use of a low-sulfur fuel on on-road vehicle engines. When an off-road vehicle engine runs on a high-sulfur fuel, it is advisable to employ the "CF or better" lubricating oil with a high Total Base Number (TBN of 10 minimum).
- Refer to the following table for the suitable API classification engine oil according to the engine type (with internal EGR, external EGR or non-EGR) and the fuel (low-sulfur or high-sulfur fuel).

Fuel used	Engine oil classification (API classification)	
	Oil class of engines except external EGR	Oil class of engines with external EGR
High Sulfur Fuel [≥ 0.05 % (500 ppm)]	CF (If the "CF-4, CG-4, CH-4, or CI-4" lubricating oil is used with a high-sulfur fuel, change the lubricating oil at shorter intervals. (approximately half))	–
Low Sulfur Fuel [(< 0.05 % (500 ppm)) or Ultra Low Sulfur Fuel [< 0.0015 % (15 ppm)]	CF, CF-4, CG-4, CH-4 or CI-4	CF or CI-4 (Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR type engines)

EGR: Exhaust Gas Re-circulation

- **The CJ-4 engine oil is intended for DPF (Diesel Particulate Filter) type engines, and cannot be used on this tractor.**

	except external EGR	With external EGR
Models	B2301 / B2601	–

Fuel

- Cetane number of 45 minimum. Cetane number greater than 50 is preferred, especially for temperatures below –20 °C (–4 °F) or elevations above 1500 m (5000 ft).
- If diesel fuel with sulfur content greater than 0.5 % (5000 ppm) sulfur content in used, reduce the service interval for engine oil and filter by 50 %.
- NEVER use diesel fuel with sulfur content greater than 0.05 % (500 ppm) for EXTERNAL EGR type engine.
- DO NOT use diesel fuel with sulfur content greater than 1.0 % (10000 ppm).
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engine in industrial and heavy mobile service. (SAE J313 JUN87)

Transmission oil

- The oil used to lubricate the transmission is also used as hydraulic fluid. To insure proper operation of the hydraulic system and to complete lubrication of the transmission, it is important that a multi-grade transmission fluid is used in this system. We recommend the use of KUBOTA UDT or SUPER UDT fluid for optimum protection and performance.
Do not mix different brands together.

■ Indicated capacities of water and oil are manufacturer's estimate.









9Y1211156GEG0003US0

5. TIGHTENING TORQUES

Tighten screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual according to the table below.

WSM000001GEG0116US0

[1] GENERAL USE SCREWS, BOLTS AND NUTS

Indication on top of bolt	 4 No-grade or 4T						 7T						 9T		
Indication on top of nut	  No-grade or 4T												   6T		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M6	7.9	0.80	5.8	7.9	0.80	5.8	9.81	1.00	7.24	7.9	0.80	5.8	12.3	1.25	9.05
	to 9.3	to 0.95	to 6.8	to 8.8	to 0.90	to 6.5	to 11.2	to 1.15	to 8.31	to 8.8	to 0.90	to 6.5	to 14.2	to 1.45	to 10.4
M8	18	1.8	13	17	1.7	13	24	2.4	18	18	1.8	13	30	3.0	22
	to 20	to 2.1	to 15	to 19	to 2.0	to 14	to 27	to 2.8	to 20	to 20	to 2.1	to 15	to 34	to 3.5	to 25
M10	40	4.0	29	32	3.2	24	48	4.9	36	40	4.0	29	61	6.2	45
	to 45	to 4.6	to 33	to 34	to 3.5	to 25	to 55	to 5.7	to 41	to 44	to 4.5	to 32	to 70	to 7.2	to 52
M12	63	6.4	47	–	–	–	78	7.9	58	63	6.4	47	103	10.5	76.0
	to 72	to 7.4	to 53	–	–	–	to 90	to 9.2	to 66	to 72	to 7.4	to 53	to 117	to 12.0	to 86.7
M14	108	11.0	79.6	–	–	–	124	12.6	91.2	–	–	–	167	17.0	123
	to 125	to 12.8	to 92.5	–	–	–	to 147	to 15.0	to 108	–	–	–	to 196	to 20.0	to 144
M16	167	17.0	123	–	–	–	197	20.0	145	–	–	–	260	26.5	192
	to 191	to 19.5	to 141	–	–	–	to 225	to 23.0	to 166	–	–	–	to 304	to 31.0	to 224
M18	246	25.0	181	–	–	–	275	28.0	203	–	–	–	344	35.0	254
	to 284	to 29.0	to 209	–	–	–	to 318	to 32.5	to 235	–	–	–	to 402	to 41.0	to 296
M20	334	34.0	246	–	–	–	368	37.5	272	–	–	–	491	50.0	362
	to 392	to 40.0	to 289	–	–	–	to 431	to 44.0	to 318	–	–	–	to 568	to 58.0	to 419

WSM000001GEG0117US0

[2] STUD BOLTS

Material of opponent part	Ordinariness			Aluminum		
Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M8	12	1.2	8.7	8.9	0.90	6.5
	to 15	to 1.6	to 11	to 11	to 1.2	to 8.6
M10	25	2.5	18	20	2.0	15
	to 31	to 3.2	to 23	to 25	to 2.6	to 18
M12	30	3.0	22	31	3.2	23
	to 49	to 5.0	to 36	–	–	–
M14	62	6.3	46	–	–	–
	to 73	to 7.5	to 54	–	–	–
M16	98.1	10.0	72.4	–	–	–
	to 112	to 11.5	to 83.1	–	–	–
M18	172	17.5	127	–	–	–
	to 201	to 20.5	to 148	–	–	–

WSM000001GEG0002US0

[3] METRIC SCREWS, BOLTS AND NUTS

Grade	8.8 Property class 8.8			10.9 Property class 10.9			
	Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
M8		24 to 27	2.4 to 2.8	18 to 20	30 to 34	3.0 to 3.5	22 to 25
M10		48 to 55	4.9 to 5.7	36 to 41	61 to 70	6.2 to 7.2	45 to 52
M12		78 to 90	7.9 to 9.2	58 to 66	103 to 117	10.5 to 12.0	76.0 to 86.7
M14		124 to 147	12.6 to 15.0	91.2 to 108	167 to 196	17.0 to 20.0	123 to 144
M16		197 to 225	20.0 to 23.0	145 to 166	260 to 304	26.5 to 31.0	192 to 224



WSM000001GEG0003US0

[4] AMERICAN STANDARD SCREWS, BOLTS AND NUTS WITH UNC OR UNF THREADS

Grade	SAE GR.5			SAE GR.8			
	Unit	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
1/4		11.7 to 15.7	1.20 to 1.60	8.63 to 11.5	16.3 to 19.7	1.67 to 2.00	12.0 to 14.6
5/16		23.1 to 27.7	2.36 to 2.82	17.0 to 20.5	33 to 39	3.4 to 3.9	25 to 28
3/8		48 to 56	4.9 to 5.7	36 to 41	61 to 73	6.3 to 7.4	45 to 53
1/2		110 to 130	11.3 to 13.2	81.2 to 95.8	150 to 178	15.3 to 18.1	111 to 131
9/16		150 to 178	15.3 to 18.1	111 to 131	217 to 260	22.2 to 26.5	160 to 191
5/8		204 to 244	20.8 to 24.8	151 to 179	299 to 357	30.5 to 36.4	221 to 263

WSM000001GEG0008US0

[5] PLUGS

Shape	Size	Material of opponent part					
		Ordinariness			Aluminum		
		N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
Tapered screw 	R1/8	13 to 21	1.3 to 2.2	9.4 to 15	13 to 19	1.3 to 2.0	9.4 to 14
	R1/4	25 to 44	2.5 to 4.5	18 to 32	25 to 34	2.5 to 3.5	18 to 25
	R3/8	49 to 88	5.0 to 9.0	37 to 65	49 to 58	5.0 to 6.0	37 to 43
	R1/2	58.9 to 107	6.00 to 11.0	43.4 to 79.5	59 to 78	6.0 to 8.0	44 to 57
Straight screw 	G1/4	25 to 34	2.5 to 3.5	18 to 25	–	–	–
	G3/8	62 to 82	6.3 to 8.4	46 to 60	–	–	–
	G1/2	49 to 88	5.0 to 9.0	37 to 65	–	–	–

WSM000001GEG0005US0

6. MAINTENANCE CHECK LIST

No.	Item		Indication on hour meter														Interval	Reference page			
			50	100	150	200	250	300	350	400	450	500	550	600	650	700					800
1	Engine oil	Change	★			☆				☆					☆		☆	every 200 Hr	G-26		
2	Engine oil filter	Replace	★			☆				☆					☆		☆	every 200 Hr	G-25		
3	Transmission oil filters [HST]	Replace	★			☆				☆					☆		☆	every 200 Hr	G-26		
4	Hydraulic oil filter	Replace	★							☆							☆	every 400 Hr	G-29		
5	Transmission fluid	Change								☆							☆	every 400 Hr	G-28		
6	Front axle case oil	Change								☆							☆	every 400 Hr	G-29		
7	Front axle pivot	Adjust								☆							☆	every 400 Hr	G-30		
8	Engine start system	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-19		
9	Greasing	–	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-20		
10	Wheel bolt torque	Check	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	every 50 Hr	G-20		
11	Battery condition	Check		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-21	*4	
12	Air cleaner element [Double element type] Primary element	Clean		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-23	*1	@
		Replace																every 1 year	G-30	*2	
	Air cleaner element [Double element type] Secondary element	Replace																every 1 year	G-30		
13	Fuel filter element	Clean		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-24		@
		Replace								☆							☆	every 400 Hr	G-30		
14	Fan belt	Adjust		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-24		
15	Brake	Adjust		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-25		
16	Radiator hose and clamp	Check				☆				☆							☆	every 200 Hr	G-27		
		Replace																every 2 years	G-33		
17	Fuel line	Check		☆		☆		☆		☆		☆		☆		☆	☆	every 100 Hr	G-25		@
		Replace																every 2 years	G-33	*3	
18	Intake air line	Check				☆				☆							☆	every 200 Hr	G-27		@
		Replace																every 2 years	G-33	*3	
19	Toe-in	Adjust				☆				☆							☆	every 200 Hr	G-28		
20	Engine valve clearance	Adjust															☆	every 800 Hr	G-30		
21	Fuel injection nozzle injection pressure	Check																every 1500 Hr	G-30		@
22	Injection pump	Check																every 3000 Hr	G-30		@
23	Cooling system	Flush																every 2 years	G-31		

No.	Item		Indication on hour meter														Interval	Refer- ence page				
			50	100	150	200	250	300	350	400	450	500	550	600	650	700					800	
24	Coolant	Change																	every 2 years	G-31		
25	Fuel system	Bleed																	Service as re- quired	G-33		
26	Clutch housing water	Drain																G-33				
27	Fuse	Replace																G-34				
28	Light bulb	Replace																G-34				

■ **IMPORTANT**

- The jobs indicated by ★ must be done after the first 50 hours of operation.
 - *1 Air cleaner should be cleaned more often in severe dusty conditions.
 - *2 Every year or after 6 cleanings.
 - *3 Replace only if necessary.
 - *4 When the battery is used for less than 100 hours per year, check the fluid level annually.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction.
Please see the Warranty Statement in detail.

9Y1211156GEG0004US0

7. CHECK AND MAINTENANCE

[1] DAILY CHECK




WARNING

To avoid personal injury or death:

Take the following precautions when checking the tractor.

- Park the machine on firm and level ground.
- Set the parking brake.
- Lower the implement to the ground.
- All residual pressure of the hydraulic system released.
- Stop the engine and remove the key.



9Y1211156GES003A

9Y1211156GEG0005US0

Walk Around Inspection

1. Look around and under the tractor for such items as loose bolts, trash build-up, oil or coolant leaks, broken or worn parts.

9Y1211156GEG0006US0

Checking and Refueling



WARNING


To avoid personal injury or death:

- Do not smoke while refueling.
 - Be sure to stop the engine before refueling.
1. Turn the key switch to "ON", check the amount of fuel by fuel gauge.
 2. Fill fuel tank when fuel gauge shows 1/4 or less fuel in tank.
 3. Use grade No.2-Diesel fuel at temperatures above -10°C (14°F).
Use grade No.1-Diesel fuel at temperatures below -10°C (14°F).
- **IMPORTANT**
- Do not permit dirt or trash to get into the fuel system.
 - Be careful not to let the fuel tank become empty, otherwise air will enter the fuel system, necessitating bleeding before next engine start.
 - Be careful not to spill during refueling. If you should spill, wipe it off at once, or it may cause a fire.
 - To prevent condensation (water) accumulation in the fuel tank, fill the tank before parking overnight.

Fuel tank capacity	23 L 6.1 U.S.gals 5.1 Imp.gals
--------------------	--------------------------------------

(1) Fuel Tank Cap

9Y1211156GEG0007US0



Checking Engine Oil Level

WARNING

To avoid personal injury:

- **Be sure to stop the engine before checking the oil level.**
1. Park the machine on a flat surface.
 2. Check engine oil before starting the engine or 5 minutes or more after the engine has stopped.
 3. To check the oil level, draw out the dipstick, wipe it clean, replace it, and draw it out again. Check to see that the oil level lies between the two notches.

If the level is too low, add new oil to the prescribed level at the oil inlet.


IMPORTANT

- **When using an oil of different maker or viscosity from the previous one, remove all of the old oil. Never mix two different types of oil.**
- **If oil level is low, do not run engine.**

- (1) Oil Inlet
- (2) Dipstick

A: Oil level is acceptable within this range.

9Y1211156GEG0008US0



Checking Transmission Fluid Level

1. Park the machine on a flat surface, lower the implement and shut off engine.
2. To check the oil level, draw out the dipstick, wipe it clean, replace it, and draw it out again. Check to see that the oil level lies within the cross hatched area.

If the level is too low, add new oil to the prescribed level at the oil inlet.


IMPORTANT

- **If oil level is low, do not run engine.**

- (1) Oil Inlet
- (2) Dipstick

A: Oil level is acceptable within this range.

9Y1211156GEG0009US0



Checking Coolant Level

WARNING

To avoid personal injury or death:

- **Do not remove radiator cap while coolant is hot. When cool, slowly rotate cap to the first stop and allow sufficient time for excess pressure to escape before removing the cap completely.**

1. Check to see that the coolant level is between the "FULL" and "LOW" marks of recovery tank.
2. When the coolant level drops due to evaporation, add soft water only up to the full level.

In case of leakage, add anti-freeze and soft water in the specified mixing ratio up to the full level.


IMPORTANT

- **If the radiator cap has to be removed, follow the caution above and securely retighten the cap.**
- **Use clean, fresh soft water and anti-freeze to fill the recovery tank.**

- (1) Recovery Tank

A: "FULL"
B: "LOW"

9Y1211156GEG0010US0




Cleaning Evacuator Valve

1. Open the evacuator valve to get rid of large particles of dust and dirt.

(1) Evacuator Valve

9Y1211156GEG0011US0



Cleaning Grill and Radiator Screen

⚠ WARNING

To avoid personal injury or death:

- Be sure to stop the engine and remove the key before removing the screen.
1. Check front grill and side screens to be sure they are clean of debris.
 2. Detach the screen and remove all foreign material and clean the front of radiator completely.

■ IMPORTANT

- Grill and screen must be clean from debris to prevent engine from overheating and to allow good air intake for the air cleaner.

(1) Radiator Screen

(A) "DETACH"

9Y1211156GEG0012US0

Checking Brake Pedal

1. Inspect the brake pedals for free travel, and smooth operation.
2. Adjust if incorrect measurement is found.

9Y1211156GEG0013US0

Checking Gauges, Meter and Easy Checker™

1. Inspect the instrument panel for broken gauge(s), meter(s) and Easy Checker™.
2. Replace if broken.

9Y1211156GEG0014US0

Checking Head Light, Hazard Light etc.

1. Inspect the light for broken bulbs and lenses.
2. Replace if broken.

9Y1211156GEG0015US0

Checking Seat Belt and ROPS

1. Always check condition of seat belt and ROPS attaching hardware before operating tractor.
2. Replace if damaged.

9Y1211156GEG0016US0

Checking and Cleaning of Electrical Wiring and Battery Cables



WARNING

To avoid personal injury or death:

- A loosened terminal or connector, or damaged wire may affect the performance of electrical components or cause short circuits. Leakage of electricity could result in a fire hazard, a dead battery or damage to electrical components.
- Replace damaged wires or connections promptly.
- If a fuse blows soon after replacement, **DO NOT USE A LARGER THAN RECOMMENDED FUSE OR BYPASS THE FUSE SYSTEM.**
- Many wiring connections are protected by waterproof plugs, plug and unplug these connections carefully and make sure they are sealed correctly after assembly.
- Accumulation of dust, chaff or spilled fuel deposits around the battery, electrical wiring, engine or exhaust system are a fire hazard.

CLEAN THESE AREAS BEFORE STARTING WORK.

To avoid premature electrical malfunctions **DO NOT APPLY high pressure water directly to battery, wiring, connectors, electrical components or instrument panel.**

Inspect the following regularly:

1. Check wiring for chafed or cracked insulation.
2. Check wiring harness clamps. Replace if necessary.
3. Check connectors and terminals for looseness, contamination or overheated (discolored) connectors.
4. Check instrument panel for correct operation of switches and gauges.

9Y1211156GEG0017US0

Checking Movable Parts


1. If any of the movable parts, such as levers and pedals, is not smoothly moved because of rust or anything sticky, do not attempt to force it into motion.

In the above case, remove the rust or sticky thing, and apply oil or grease on the relevant spot.

Otherwise, the machine may get damaged.

9Y1211156GEG0018US0

[2] CHECK POINTS OF EVERY 50 HOURS



Checking Engine Start System

⚠ WARNING

To avoid personal injury or death:

- Do not allow anyone near the tractor while testing.
- If the tractor does not pass the test do not operate the tractor.
- Detach an implement before testing.

■ Preparation before testing.

1. Sit on operator's seat.
2. Set the parking brake and stop the engine.
3. Shift the range gear shift lever to "**NEUTRAL**" position.
4. Place the speed control pedal in "**NEUTRAL**" position.
5. Shift the PTO clutch lever to "**OFF**" position.

■ Test: Switch for the speed control pedal.

1. Depress the speed control pedal.
2. Turn the key to "**START**" position.
3. The engine must not crank.

■ Test: Switch for the PTO clutch lever.

1. Place the speed control pedal in "**NEUTRAL**" position.
2. Shift the PTO clutch lever to "**ON**" position.
3. Turn the key to "**START**" position.
4. The engine must not crank.





■ Test: Switches for the operator's seat and the PTO clutch lever.

1. Sit on the operator's seat.
2. Start the engine.
3. Shift the PTO clutch lever to "**ON**" position.
4. Release the parking brake.
5. Stand up. (Do not get off the machine.)
6. The engine must shut off after approximately 1 second.

- (1) Range Gear Shift Lever
(2) PTO Clutch Lever

- (3) Speed Control Pedal
(4) Operator's Seat

9Y1211156GEG0019US0



Lubricating Grease Fittings

1. Apply a small amount of multipurpose grease to the following points every 50 hours:
If you operated the machine in extremely wet and muddy conditions, lubricate grease fittings more often.

- (1) Grease Fitting (Brake Pedals)
- (2) Grease Fitting (Top Link)
- (3) Grease Fitting (Lifting Rod, Right)
- (4) Battery Terminals

9Y1211156GEG0020US0

Checking Wheel Mounting Nuts Tightening Torque

⚠ WARNING

To avoid personal injury or death:

- Never operate tractor with a loose rim, wheel or axle.
- Any time bolts and nuts are loosened, retighten to specified torque.
- Check all bolts and nuts frequently and keep them tight.


1. Check wheel bolts and nuts regularly especially when new. If they are loose, tighten them as follows.

Tightening torque	Front wheel mounting nut	78 to 90 N·m 8.0 to 9.1 kgf·m 58 to 66 lbf·ft
	Rear wheel mounting nut	145 to 150 N·m 14.8 to 15.2 kgf·m 107 to 110 lbf·ft

- (1) Front Wheel Mounting Nut
- (2) Rear Wheel Mounting Nut and Bolt

9Y1211156GEG0021US0

[3] CHECK POINTS OF EVERY 100 HOURS



Checking Battery Condition

⚠ DANGER

To avoid the possibility of battery explosion:

For the refillable type battery, follow the instructions below.

- Do not use or charge the refillable type battery if the fluid level is below the LOWER (lower limit level) mark. Otherwise, the battery component parts may prematurely deteriorate, which may shorten the battery's service life or cause an explosion. Check the fluid level regularly and add distilled water as required so that the fluid level is between the UPPER and LOWER levels.

⚠ WARNING

To avoid personal injury or death:

- Never remove the battery cap while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are splattered with it, wash it away completely with water immediately and get medical attention.
- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.
- Wear eye protection and rubber gloves when working around battery.

The factory-installed battery is of non-refillable type. If the indicator turns white, do not charge the battery but replace it with new one.

1. Mishandling the battery shortens the service life and adds to maintenance costs.
2. The original battery is maintenance free, but needs some servicing.
3. If the battery is weak, the engine will be difficult to start and the lights will be dim. It is important to check the battery periodically.

■ How to read the indicator


Check the battery condition by reading the indicator.

State of indicator display	
Green	Specific gravity of electrolyte and quality of electrolyte are both in good condition.
Black	Needs charging battery.
White	Needs replacing battery.

(1) Battery

(2) Indicator

9Y1211156GEG002US0



Battery Charging

⚠ WARNING

To avoid personal injury or death:

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.
- When charging the battery, ensure the vent caps are securely in place. (if equipped)
- When disconnecting the cable from the battery, start with the negative terminal first.
When connecting the cable to the battery, start with the positive terminal first.
- Never check battery charge by placing a metal object across the posts.
Use a voltmeter or hydrometer.

1. To slow charge the battery, connect the battery positive terminal to the charger positive terminal and the negative to the negative, then recharge in the standard fashion.
2. A boost charge is only for emergencies. It will partially charge the battery at a high rate and in a short time.
When using a boost-charged battery, it is necessary to recharge the battery as early as possible.
Failure to do this will shorten the battery's service life.
3. The battery is charged if the indicator display turns green from black.
4. When exchanging an old battery into new one, use battery of equal specification shown in table 1.

Table 1


Battery Type	Volt (V)	Capacity at 5 H.R.	Reserve at (min.)	Cold Cranking Amps (A)	Normal Charging Rate (A)
55B24L (S)-MF	12	36	80	430	4.5

■ Direction for Storage

1. When storing the tractor for long periods of time, remove the battery from tractor, adjust the electrolyte to the proper level and store in a dry place out of direct sunlight.
2. The battery self-discharges while it is stored.
Recharge it once every three months in hot seasons and once every six months in cold seasons.

(1) Battery

9Y1211156GEG0023US0



Cleaning Air Cleaner Primary Element [Double Element Type]

⚠ WARNING

To avoid personal injury or death:

- Be sure to stop the engine and remove the key before cleaning air filter element.

1. Remove the air cleaner cover and primary element.
2. Clean the primary element:
 - a) When dry dust adheres to the element, blow compressed air from the inside, turning the element. Pressure of compressed air must be under 205 kPa (2.1 kgf/cm², 30 psi).
 - b) When carbon or oil adheres to the element, soak the element in detergent for 15 minutes then wash it several times in water, rinse with clean water and dry it naturally. After element is fully dried, inspect inside of the element with a light and check if it is damaged or not.
3. Replace air cleaner primary element:
Once yearly or after every sixth cleaning, whichever comes first.

■ NOTE

- Check to see if the evacuator valve is blocked with dust.

■ IMPORTANT

- The air cleaner uses a dry element, never apply oil.
- Do not run the engine with filter element removed.
- Be sure to refit the cover with the arrow ↑ (on the cover) upright. If the cover is improperly fitted, evacuator valve will not function and dust will adhere to the element.
- Do not touch the secondary element except in cases where replacing is required.



(See "Replacing Air Cleaner Primary Element and Secondary Element" in "EVERY 1 YEAR".)

■ Evacuator Valve

Open the evacuator valve once a week under ordinary conditions - or daily when used in a dusty place - to get rid of large particles of dust and dirt.

- | | |
|--------------------------------|---------------------|
| (1) Secondary (Safety) Element | (3) Cover |
| (2) Primary Element | (4) Evacuator Valve |

9Y1211156GEG0025US0



Cleaning Fuel Filter

WARNING

To avoid personal injury or death:

- Stop the engine and remove the key before checking fuel lines and fuel filter.
- Check the fuel lines periodically. The fuel lines are subject to wear and aging. Fuel may leak out onto the running engine, causing a fire.
- Protect your hands when using kerosene to clean components.

This job should not be done in the field, but in a clean place.

1. Loosen and remove the filter bowl, and rinse the inside with kerosene.
2. Take out the element and dip it in the kerosene to rinse.
3. After cleaning, reassemble the fuel filter, keeping out dust and dirt.
4. Bleed the fuel system. (See "SERVICE AS REQUIRED".)

IMPORTANT

- When the fuel filter bowl has been removed, fuel stops flowing from the fuel tank. If the fuel tank is almost full, however, the fuel will flow back from the fuel return pipe to the fuel filter. Before checking, make sure the fuel tank is less than half-full.
- If dust, dirt or water enters the fuel system, the fuel pump and injection nozzles are subject to premature wear. To prevent this, be sure to clean the fuel filter bowl and element periodically.

- | | |
|----------------------|-------------|
| (1) Fuel Filter Bowl | (A) Loosen |
| (2) Filter Bracket | (B) Tighten |
| (3) O-ring | |
| (4) Filter Element | |
| (5) O-ring | |


9Y1211156GEG0026US0

Adjusting Fan Belt Tension

WARNING

To avoid personal injury or death:




- Be sure to stop engine before checking belt tension.
1. Stop the engine and remove the key.
 2. Apply moderate thumb pressure to belt between pulleys.
 3. If tension is incorrect, loosen the dynamo mounting bolts and, using a lever placed between the dynamo and the engine block, pull the dynamo out until the deflection of the belt falls within acceptable limits.
 4. Replace fan belt if it is damaged.




Fan belt tension	Factory specification	A deflection of between 7.0 to 9.0 mm (0.28 to 0.35 in.) when the belt is pressed in the middle of the span.
------------------	-----------------------	--

- | | |
|----------|----------------------------|
| (1) Bolt | (A) Check the belt tension |
| | (B) To Tighten |

9Y1211156GEG0027US0



[4] CHECK POINTS OF EVERY 200 HOURS



Adjusting Brake Pedal

⚠ WARNING

To avoid personal injury or death:

- **Stop the engine and chock the wheels before checking brake pedal.**
1. Release the parking brake.
 2. Slightly depress the right and left brake pedals and measure free travel at the top of pedal stroke.
 3. If adjustment is needed, turn the lock nut and adjust nut, adjust free travel.
 4. Retighten the lock nut.

Proper brake pedal free travel	30 to 40 mm (1.2 to 1.5 in.) on the pedal Keep the free travel in the right and left brake pedals equal.
--------------------------------	---

- (1) Lock Nut (Both Sides)
- (2) Turnbuckle (Both Sides)

A: Free Travel

9Y1211156GEG0028US0

Checking Fuel Line

1. Check to see that all line and hose clamps are tight and not damaged.
2. If hoses and clamps are found worn or damaged, replace or repair them at once.

■ NOTE

- **If the fuel line is removed, be sure to properly bleed the fuel system.**

- (1) Fuel Hoses
- (2) Hose Clamps

9Y1211156GEG0029US0

Replacing Engine Oil Filter

⚠ WARNING

To avoid personal injury or death:





- **Be sure to stop the engine before changing the oil filter cartridge.**
 - **Allow engine to cool down sufficiently, oil can be hot and can burn.**
1. Remove the oil filter.
 2. Put a film of clean engine oil on the rubber seal of the new filter.
 3. Tighten the filter quickly until it contacts the mounting surface. Tighten filter by hand an additional 1/2 turn only.
 4. After the new filter has been replaced, the engine oil normally decreases a little. Make sure that the engine oil does not leak through the seal and be sure to check the oil level on the dipstick. Then, replenish the engine oil up to the prescribed level.

■ IMPORTANT

- **To prevent serious damage to the engine, use only a KUBOTA genuine filter.**

- (1) Engine Oil Filter

9Y1211156GEG0030US0



Changing Engine Oil

⚠ WARNING

To avoid personal injury or death:

- Be sure to stop the engine before changing the oil.
- Allow engine to cool down sufficiently, oil can be hot and can burn.

1. To drain the used oil, remove the drain plug at the bottom of the engine and drain the oil completely into the oil pan. All the used oil can be drained out easily when the engine is still warm.
2. After draining reinstall the drain plug.
3. Fill with the new oil up to the upper notch on the dipstick.

Oil capacity with filter	3.1 L 3.3 U.S.qts 2.7 Imp.qts
--------------------------	-------------------------------------

- (1) Oil Inlet
- (2) Dipstick
- (3) Drain Plug (Both Sides)

A: Oil level is acceptable within this range

9Y1211156GEG0031US0

Replacing Transmission Oil Filter [HST]

⚠ WARNING

To avoid personal injury or death:

- Be sure to stop the engine before changing the oil filter cartridge.
- Allow engine to cool down sufficiently, oil can be hot and can burn.

1. Place the oil pan underneath the transmission oil filter and remove the filter. Do not remove the hydraulic oil filter. Otherwise, the oil comes out.
2. Put a film of clean transmission oil on the rubber seal of the new filter.
3. Quickly tighten the filter until it contacts the mounting surface, then, with a filter wrench, tighten it an additional 1 turn only.
4. After the new filter has been replaced, fill the transmission oil up to the upper limit on the dipstick.
5. After running the engine for a few minutes, stop the engine and check the oil level again, add oil to the prescribed level.
6. Make sure that the transmission fluid doesn't leak past the seal on the filter.

■ IMPORTANT


- To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.
- Do not operate the tractor immediately after changing the transmission fluid.

Run the engine at medium speed for a few minutes to prevent damage to the transmission.

- (1) Transmission Oil Filter [HST]
- (2) Oil Inlet
- (3) Dipstick

A: Oil level is acceptable within this range

9Y1211156GEG0032US0




Checking Intake Air Line

1. Check to see that hoses and hose clamps are tight and not damaged.
2. If hoses and clamps are found worn or damaged, replace or repair them at once.

(1) Hose

(2) Hose Clamp

9Y1211156GEG0033US0



Checking Radiator Hose and Hose Clamp

⚠ WARNING

To avoid personal injury or death:

- Be sure to stop the engine and remove the key before checking radiator hose and clamp.
- Allow engine and coolant to cool down sufficiently before checking.

Check to see if radiator hoses are properly fixed every 200 hours of operation or six months, whichever comes first.

1. If hose clamps are loose or water leaks, tighten bands securely.
2. Replace hoses and tighten hose clamps securely, if radiator hoses are swollen, hardened or cracked. Replace hoses and hose clamps every 2 years or earlier if checked and found that hoses are swollen, hardened or cracked.

■ **Precaution at Overheating**



Take the following actions in the event the coolant temperature is nearly or more than the boiling point, what is called "Overheating".

1. Stop the machine operation in a safe place and keep the engine unloaded idling.
2. Don't stop the engine suddenly, but stop it after about 5 minutes of unloaded idling.
3. Keep yourself well away from the machine for further 10 minutes or while the steam blown out.
4. Checking that there gets on danger such as burn, get rid of the causes of overheating according to the manual, see "Troubleshooting" section, and then, start again the engine.

(1) Radiator Hose (2 Hoses)

(2) Clamp (4 Clamps)

9Y1211156GEG0034US0



Adjusting Toe-in

1. Park tractor on a flat place.
2. Turn steering wheel so front wheels are in the straight ahead position.
3. Lower the implement, lock the park brake and stop the engine.
4. Measure distance between tire beads at front of tire, hub height.
5. Measure distance between tire beads at rear of tire, hub height.
6. Front distance should be 0 to 10 mm (0 to 0.39in.) less than rear distance. If not, adjust tie-rod length.

■ **Adjusting procedures**



1. Loosen the tie-rod nut.
2. Turn the tie-rod to adjust the rod length until the proper toe-in measurement is obtained.
3. Retighten the tie-rod nut.

- (1) Tie-rod Nut
- (2) Tie-rod

- (A) Wheel-to-wheel distance at rear
- (B) Wheel-to-wheel distance at front
- (C) "FRONT"

9Y1211156GEG0035US0

[5] CHECK POINTS OF EVERY 400 HOURS



Changing Transmission Fluid

WARNING

To avoid personal injury or death:

- Allow engine to cool down sufficiently, oil can be hot and can burn.
1. To drain the used oil, remove the drain plug at the bottom of the transmission case and drain the oil completely into the oil pan.
 2. After draining reinstall the drain plug.
 3. Fill with new KUBOTA SUPER UDT fluid up to the upper notch on the dipstick.
 4. After running the engine for a few minutes, stop it and check the oil level again; add oil to prescribed level.
 5. Properly dispose of used oil.

Oil capacity	15 L 4.0 U.S.gals 3.3 Imp.gals
--------------	--------------------------------------





■ **IMPORTANT**

- If the 3-point hitch can not be raised by setting the hydraulic control lever to the UP position after long term storage or when changing the transmission oil, turn steering wheel to the right and left several times to bleed air from the system.
- Do not operate the tractor immediately after changing the transmission fluid.

- (1) Oil Inlet
- (2) Dipstick
- (3) Drain Plug
- (4) Drain Plug (Both Sides)

A: Oil level is acceptable within this range

9Y1211156GEG0037US0



Replacing Hydraulic Oil Filter

⚠ WARNING

To avoid personal injury or death:

- Be sure to stop the engine before changing the oil filter cartridge.
 - Allow engine to cool down sufficiently, oil can be hot and can burn.
1. Remove the drain plugs at the bottom of the transmission case and drain the oil completely into the oil pan.
 2. After draining reinstall the drain plugs.
 3. Remove the oil filter.
 4. Put a film of clean transmission oil on the rubber seal of the new filter.
 5. Quickly tighten the filter until it contacts the mounting surface, then tighten it by hand an additional 1/2 turn only.
 6. After the new filters have been replaced, fill the transmission oil up to the upper notch on the dipstick.
 7. After running the engine for a few minutes, stop the engine and check the oil level again, add oil to the prescribed level.
 8. Make sure that the transmission fluid does not leak past the seal on the filter.

■ IMPORTANT

- To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.

- (1) Drain Plug
- (2) Drain Plug (Both Sides)
- (3) Transmission Oil Filter
- (4) Oil Inlet
- (5) Dipstick

A: Oil level is acceptable within this range.

9Y1211156GEG0038US0

Changing Front Axle Case Oil


1. Park the tractor on a firm, flat and level surface.
 2. To drain the used oil, remove the right and left drain plugs and filling plug at the front axle case and drain the oil completely into the oil pan.
 3. After draining, reinstall the drain plugs.
 4. Fill with new oil up to the upper notch on the dipstick.
- ### ■ IMPORTANT
- After ten minutes, check the oil level again; add oil to prescribed level.
5. After filling, reinstall the filling plug.
 6. Properly dispose of used oil.

Oil capacity	3.5 L 3.7 U.S.qts 3.1 Imp.qts
--------------	-------------------------------------

- (1) Filling Plug with Dipstick
- (2) Drain Plug

A: Oil level is acceptable within this range.

9Y1211156GEG0039US0



Adjusting Front Axle Pivot [4WD]



WARNING

To avoid personal injury or death:

- Park the tractor on a flat place.
 - Lower the implement, lock the parking brake and stop the engine.
1. If the front axle pivot pin adjustment is not correct, front wheel vibration can occur causing vibration in the steering wheel.

■ **Adjusting procedure**

1. Loosen the lock nut, and tighten the adjusting screw so that the oscillating load is 50 to 100 N (5.1 to 10.2 kgf, 11.2 to 22.5 lbf). (If the adjusting screw is tightened, loosened and retightened, apply liquid gasket to its tip.)
2. Retighten the lock nut.

(1) Adjusting Screw

(2) Lock Nut

9Y1211156GEG0040US0

Replacing Fuel Filter Element

- See page G-24.

9Y1211156GEG0041US0

[6] CHECK POINT OF EVERY 800 HOURS

Adjusting Engine Valve Clearance

- See page 1-S13.

9Y1211156GEG0042US0

[7] CHECK POINT OF EVERY 1500 HOURS

Checking Fuel Injection Nozzle Injection Pressure

- See page 1-S19.

9Y1211156GEG0043US0

[8] CHECK POINT OF EVERY 3000 HOURS

Checking Injection Pump

- See page 1-S30.

9Y1211156GEG0044US0

[9] CHECK POINT OF EVERY 1 YEAR

Replacing Air Cleaner Primary Element and Secondary Element



- See page G-23.

■ **IMPORTANT**

- To prevent serious damage to the engine, use only a KUBOTA genuine filter.

9Y1211156GEG0046US0

[10] CHECK POINTS OF EVERY 2 YEARS



Flushing Cooling System and Changing Coolant

⚠ WARNING

To avoid personal injury or death:

- Do not remove radiator cap while coolant is hot. When cool, slowly rotate cap to the first stop and allow sufficient time for excess pressure to escape before removing the cap completely.
1. Stop the engine, remove the key and let it cool down.
 2. To drain the coolant, disconnect the radiator hose (engine side) and remove the radiator cap. The radiator cap must be removed to completely drain the coolant.
 3. After all coolant is drained, close the drain plug.
 4. Fill with clean water and cooling system cleaner.
 5. Follow directions of the cleaner instruction.
 6. After flushing, fill with clean water and anti-freeze until the coolant level is just below the radiator cap. Install the radiator cap securely.
 7. Fill with coolant up to the "FULL" mark on the recovery tank.
 8. Start and operate the engine for few minutes.
 9. Stop the engine, remove the key and let cool.
 10. Check coolant level of recovery tank and add coolant if necessary.
 11. Properly dispose of used coolant.

■ IMPORTANT

- Do not start engine without coolant.
- Use clean, fresh water and anti-freeze to fill the radiator and recovery tank.
- When the anti-freeze is mixed with water, the anti-freeze mixing ratio must be less than 50 %.
- Securely tighten radiator cap. If the cap is loose or improperly fitted, water may leak out and the engine could overheat.

Coolant capacity (with recover tank)	3.8 L
	4.0 U.S.qts
	3.3 Imp.qts

- (1) Radiator Hose
 (2) Radiator Cap
 (3) Recovery Tank

A: FULL
 B: LOW

(To be continued)

(Continued)

■ Anti-Freeze



WARNING

To avoid personal injury or death:

- When using antifreeze, put on some protection such as rubber gloves (Antifreeze contains poison.)
- If it is swallowed, seek immediate medical help.
Do NOT make a person throw up unless told to do so by poison control or a health care professional. Use standard first aid and CPR for signs of shock or cardiac arrest. Call your local Poison Control Center or your local emergency number for further assistance.
- When antifreeze comes in contact with the skin or clothing, wash it off immediately.
- Do not mix different types of Antifreeze.
The mixture can produce chemical reaction causing harmful substances.
- Antifreeze is extremely flammable and explosive under certain conditions. Keep fire and children away from antifreeze.
- When draining fluids from the engine, place some container underneath the engine body.
- Do not pour waste onto the grounds, down a drain, or into any water source.
- Also, observe the relevant environmental protection regulations when disposing of antifreeze.

Always use a 50/50 mix of long-life coolant and clean soft water in KUBOTA engines.

1. Long-life coolant (hereafter LLC) comes in several types. Use ethylene glycol (EG) type for this engine.
2. Before employing LLC-mixed cooling water, fill the radiator with fresh water and empty it again.
Repeat this procedure 2 or 3 times to clean up the inside.
3. Mixing the LLC
Premix 50 % LLC with 50 % clean soft water. When mixing, stir it up well, and then fill into the radiator.
4. The procedure for the mixing of water and antifreeze differs according to the make of the antifreeze and the ambient temperature. Refer to SAE J1034 standard, more specifically also to SAE J814c.

Vol % Anti-freeze	Freezing Point		Boiling Point*	
	°C	°F	°C	°F
50	-37	-34	108	226

*At 1.013×10^5 Pa (760 mmHg) pressure (atmospheric). A higher boiling points is obtained by using a radiator pressure cap which permits the development of pressure within the cooling system.

(To be continued)

(Continued)

5. Adding the LLC
 - a) Add only water if the mixture reduces in amount by evaporation.
 - b) If there is a mixture leak, add the LLC of the same manufacture and type in the same mixture percentage.
*Never add any long-life coolant of different manufacture. (Different brands may have different additive components, and the engine may fail to perform as specified.)
6. When the LLC is mixed, do not employ any radiator cleaning agent. The LLC contains anticorrosive agent. If mixed with the cleaning agent, sludge may build up, adversely affecting the engine parts.
7. Kubota's genuine long-life coolant has a service life of 2 years. Be sure to change the coolant every 2 years.

NOTE

- The above data represent industry standards that necessitate a minimum glycol content in the concentrated anti-freeze.

9Y1211156GEG0047US0

Replacing Radiator Hoses (Water Pipes)

- See page G-27.

9Y1211156GEG0048US0

Replacing Fuel Hoses

- See page G-25.

9Y1211156GEG0049US0

Replacing Intake Air Hoses

- See page G-27.

9Y1211156GEG0050US0

[11] OTHERS**Bleeding Fuel System****Air must be removed:**

1. When the fuel filter or lines are removed.
2. When the tank is completely empty.
3. After the tractor has not been used for a long period of time.

Bleeding procedure is as follows.

1. Fill the fuel tank with fuel.
2. Start the engine and run for about 30 seconds, and then stop the engine.

9Y1211156GEG0052US0


Draining Clutch Housing Water**NOTE**

- The tractor is equipped with a water drain plug (1) under the clutch housing.
- After operating in rain, snow or tractor has been washed, water may get into the clutch housing.


1. Remove the drain plug and drain the water, then install the plug again.

(1) Water Drain Plug

9Y1211156GEG0053US0



9Y1211156GES018B



FLASHER HAZARD	10A	(1)
SOLENOID	30A	(2)
OUTLET (RIGHT SIDE) (MAX. 120W)	10A	(3)
HEAD LIGHT PANEL	10A	(4)
WORK LIGHT (MAX. 35W)	5A	(5)
GLOW PLUG	5A	(6)

9Y1211156GES024A

Replacing Fuse

1. The tractor electrical system is protected from potential damage by fuses.
A blown fuse indicates that there is an overload or short somewhere in the electrical system.
2. If any of the fuses should blow, replace with a new one of the same capacity.

■ **IMPORTANT**

- **Before replacing a blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage to the tractor electrical system.**

Protected circuit

Fuse No.	Capacity (A)	Protected circuit
(1)	15	Flasher / Hazard
(2)	30	Solenoid
(3)	10	Outlet (Right side)
(4)	10	Head light / Panel
(5)	5	Work light
(6)	5	Glow lamp
(7)	Slow blow fuse	Check circuit against wrong battery connection

9Y1211156GEG0054US0

Replacing Light Bulb


1. Head lights:
Take the bulb out of the light body and replace with a new one.
2. Other lights:
Detach the lens and replace the bulb.

Light	Capacity
Head light	23 W
Tail light / Turn signal	21 W / 5 W
Hazard light / Turn signal	32 CP

9Y1211156GEG0055US0

8. SPECIAL TOOLS

[1] SPECIAL TOOLS FOR ENGINE



Special Use Puller Set


Code No.

- 07916-09032

Application

- Use exclusively to pull out bearing, gears and other parts with ease.

WSM000001GEG0011US0



Piston Ring Compressor


Code No.

- 07909-32111

Application

- Use exclusively to push in the piston with piston rings into the cylinder.

WSM000001GEG0012US0



Piston Ring Tool


Code No.

- 07909-32121

Application

- Use exclusively to remove or install the piston ring with ease.

WSM000001GEG0013US0



Diesel Engine Compression Tester (for Glow Plug)

Code No.

- 07909-39081 (Assembly)
- 07909-31291 (K)
- 07909-31301 (L)
- 07909-31311 (M)


Application

- Use to measure diesel engine compression and diagnosis of need for major overhaul.

- (1) Gauge
 (2) Hose Assembly
 (3) L Joint

- (4) Adaptor K
 (5) Adaptor L
 (6) Adaptor M

WSM000001GEG0096US0



Diesel Engine Compression Tester (for Injection Nozzle)

Code No.


- 07909-30208 (Assembly)
- 07909-30934 (A to F)
- 07909-31211 (E and F)
- 07909-31231 (H)
- 07909-31251 (G)
- 07909-31271 (I)
- 07909-31281 (J)

Application

- Use to measure diesel engine compression and diagnostics of need for major overhaul.

- | | |
|---------------|----------------|
| (1) Gauge | (7) Adaptor F |
| (2) L Joint | (8) Adaptor G |
| (3) Adaptor A | (9) Adaptor H |
| (4) Adaptor B | (10) Adaptor I |
| (5) Adaptor C | (11) Adaptor J |
| (6) Adaptor E | |

WSM000001GEG0014US0



Oil Pressure Tester

Code No.


- 07916-32032

Application

- Use to measure lubricating oil pressure.

- | | |
|--------------------|---------------|
| (1) Gauge | (5) Adaptor 2 |
| (2) Cable | (6) Adaptor 3 |
| (3) Threaded Joint | (7) Adaptor 4 |
| (4) Adaptor 1 | (8) Adaptor 5 |

WSM000001GEG0015US0



Valve Seat Cutter

Code No.

- 07909-33102

Application

- Use to reseal valves.


Angle

- 0.79 rad (45 °)
- 0.26 rad (15 °)

Diameter

- 28.6 mm (1.13 in.)
- 31.6 mm (1.24 in.)
- 35.0 mm (1.38 in.)
- 38.0 mm (1.50 in.)
- 41.3 mm (1.63 in.)
- 50.8 mm (2.00 in.)

WSM000001GEG0016US0



Radiator Tester

Code No.

- 07909-31551

Application


- Use to check of radiator cap pressure, and leaks from cooling system.

Remarks

- Adaptor (1) BANZAI Code No. RCT-2A-30S.

- (1) Adaptor

WSM000001GEG0017US0



Connecting Rod Alignment Tool

Code No.

- 07909-31661


Application

- Use to check the connecting rod alignment.

Applicable range

- Connecting rod big end I.D.
30 to 75 mm dia. (1.2 to 2.9 in. dia.)
- Connecting rod length
65.0 to 300 mm (2.56 to 11.8 in.)

WSM000001GEG0020US0



Nozzle Tester

Code No.

- 07909-31361


Application

- Use to check the fuel injection pressure and spray pattern of nozzle.

Measuring range

- 0 to 50 MPa (0 to 500 kgf/cm², 0 to 7200 psi)

WSM000001GEG0021US0



Plastigauge

Code No.

- 07909-30241


Application

- Use to check the oil clearance between crankshaft and bearing, etc..

Measuring range

- Green: 0.03 to 0.07 mm (0.001 to 0.003 in.)
- Red: 0.05 to 0.1 mm (0.002 to 0.006 in.)
- Blue: 0.1 to 0.2 mm (0.004 to 0.009 in.)

WSM000001GEG0022US0



Red Check


Code No.

- 07909-31371

Application

- Use to check cracks on cylinder head, cylinder block, etc..

WSM000001GEG0023US0



Flywheel Puller

Code No.

- 07916-32011

Application



- Use exclusively to remove the flywheel with ease.

WSM000001GEG0018US0

■ **NOTE**

- The following special tools are not provided, so make them referring to the figure.

WSM000001GEG0026US0



Valve Guide Replacing Tool

Application


- Use to press out and press fit the valve guide.

■ **NOTE**

- The following special tools are not provided, so make them referring to the figure.

A	225 mm (8.86 in.)
B	70 mm (2.8 in.)
C	45 mm (1.8 in.)
D	20 mm dia. (0.79 in. dia.)
E	11.7 to 11.9 mm dia. (0.461 to 0.469 in. dia.)
F	6.50 to 6.60 mm dia. (0.256 to 0.260 in. dia.)
G	25 mm (0.98 in.)
H	6.70 to 7.00 mm dia. (0.264 to 0.276 in. dia.)
I	5 mm (0.2 in.)
J	20 mm dia. (0.79 in. dia.)
K	12.5 to 12.8 mm dia. (0.493 to 0.503 in. dia.)
L	8.90 to 9.10 mm (0.351 to 0.358 in.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.01 in.)

9Y1211156GEG0056US0



Injection Pump Pressure Tester

Application


- Use to check fuel tightness of injection pumps.

NOTE

- The following special tools are not provided, so make them referring to the figure.

A	Pressure gauge full scale: More than 29.4 MPa (300 kgf/cm ² , 4267 psi)
B	Copper gasket
C	Flange (Material: Steel)
D	Hex. nut 27 mm (1.1 in.) across the plat
E	Injection pipe
F	PF 1/2
G	5 mm (0.2 in.)
H	17 mm dia. (0.67 in. dia.)
I	8 mm dia. (0.3 in. dia.)
J	1.0 mm (0.039 in.)
K	17 mm dia. (0.67 in. dia.)
L	6.10 to 6.20 mm dia. (0.241 to 0.244 in. dia.)
M	8 mm (0.3 in.)
N	4 mm (0.2 in.)
O	11.97 to 11.99 mm dia. (0.4713 to 0.4720 in. dia.)
P	PF 1/2
Q	23 mm (0.91 in.)
R	17 mm (0.67 in.)
S	4 mm (0.2 in.)
T	12.00 to 12.02 mm dia. (0.4725 to 0.4732 in. dia.)
U	100 mm (3.94 in.)
V	M12 × 1.5
a	Adhesive application
b	Fillet welding on the enter circumference

9Y1211156GEG0057US0



Flywheel Stopper

Application


- Use to loosen and tighten the flywheel screw.

NOTE

- The following special tools are not provided, so make them referring to the figure.

A	20 mm (0.79 in.)
B	15 mm (0.59 in.)
C	10 mm dia. (0.39 in. dia.)
D	30 mm (1.2 in.)
E	8 mm (0.3 in.)
F	200 mm (7.87 in.)

9Y1211156GEG0058US0



Crankshaft Bearing 1 Replacing Tool

Application

- Use to press out and press fit the crankshaft bearing 1.

NOTE

- The following special tools are not provided, so make them referring to the figure.


[1] Extracting tool

A	135 mm (5.31 in.)
B	72 mm (2.8 in.)
C	40 mm radius (1.6 in. radius)
D	10 mm (0.39 in.)
E	20 mm (0.79 in.)
F	20 mm dia. (0.79 in. dia.)
G	56.80 to 56.90 mm dia. (2.237 to 2.240 in. dia.)
H	51.80 to 51.90 mm dia. (2.040 to 2.043 in. dia.)

[2] Inserting tool

A	130 mm (5.12 in.)
B	72 mm (2.8 in.)
C	40 mm radius (1.6 in. radius)
D	9 mm (0.4 in.)
E	24 mm (0.2 in.)
F	20 mm (0.79 in.)
G	20 mm dia. (0.79 in. dia.)
H	68 mm dia. (2.7 in. dia.)
I	51.80 to 51.90 mm dia. (2.040 to 2.043 in. dia.)
J	56.80 to 56.90 mm dia. (2.237 to 2.240 in. dia.)

9Y1211156GEG0059US0



Bushing Replacing Tool

Application

- Use to press out and press in the bushing.


1. For small end bushing

A	157 mm (6.18 in.)
B	24 mm (0.94 in.)
C	120 mm (4.72 in.)
D	21.8 to 21.9 mm dia. (0.859 to 0.862 in. dia.)
E	24.8 to 24.9 mm dia. (0.977 to 0.980 in. dia.)
F	20 mm dia. (0.79 in. dia.)
a	6.3 μm (250 μin.)
b	6.3 μm (250 μin.)

2. For idle gear bushing

A	196 mm (7.72 in.)
B	26 mm (1.0 in.)
C	150 mm (5.91 in.)
D	25.80 to 25.90 mm dia. (1.016 to 1.019 in. dia.)
E	28.80 to 28.90 mm dia. (1.134 to 1.137 in. dia.)
F	20 mm dia. (0.79 in. dia.)
a	6.3 μm (250 μin.)
b	6.3 μm (250 μin.)

9Y1211156GEG0060US0



Socket

Application

- Use to loosen and tighten the idle gear 2 bearing lock nut.


NOTE

- The following special tools are not provided, so make them referring to the figure.

A	28.5 to 28.8 mm (1.12 to 1.13 in.)
B	3.5 to 3.7 mm (0.14 to 0.15 in.)
C	28.5 to 28.8 mm (0.12 to 1.13 in.)
D	38 mm dia. (1.50 in. dia.)
E	28.5 to 29.0 mm dia. (1.12 to 1.14 in. dia.)
F	47.5 mm (1.87 in.)
G	17.5 mm (0.69 in.)
H	30 mm (1.18 in.)
I	18 mm dia. (0.71 in. dia.)
J	24.5 mm dia. (0.96 in. dia.)
K	5.0 mm (0.21 in.)
L	16 mm (0.63 in.)
M	12.8 to 13.0 mm (0.50 to 0.51 in.)
C1	Chamfer 1.0 mm (0.039 in.)
R5	5.0 mm radius (0.20 in. radius)

9Y1211156GEG0061US0

[2] SPECIAL TOOLS FOR TRACTOR



Tie-rod End Lifter


Code No.

- 07909-39051

Application

- Use to remove the tie-rod end with ease.

WSM000001GEG0029US0



Toe-in Gauge


Code No.

- 07909-31681

Application

- This allows easy measurement of toe-in for all machine models.

WSM000001GEG0034US0



Relief Valve Pressure Tester

Code No.


- 07916-50045

Application

- This allows easy measurement of relief set pressure.

- | | |
|--|---------------------------------------|
| (1) Gauge (07916-50322) | (6) Adaptor C (PS3/8) (07916-50371) |
| (2) Cable (07916-50331) | (7) Adaptor D (PT1/8) (07916-50381) |
| (3) Threaded Joint (07916-50401) | (8) Adaptor E (PS3/8) (07916-50392) |
| (4) Threaded Joint (07916-50341) | (9) Adaptor F (PF1/2) (07916-62601) |
| (5) Adaptor B (M18 × P1.5) (07916-50361) | (10) Adaptor 58 (PT1/4) (07916-52391) |

WSM000001GEG0027US0



Flow Meter

Code No.


- 07916-52791 (Flow Meter)
- 07916-52651 (Hydraulic Test Hose)

Application

- This allows easy testing of hydraulic system.

- | | |
|----------------|-------------------------|
| (1) Flow Meter | (2) Hydraulic Test Hose |
|----------------|-------------------------|

WSM000001GEG0036US0



Steering Wheel Puller


Code No.

- 07916-51090

Application

- Use to remove the steering wheel without damage to the steering shaft.

WSM000001GEG0030US0



Injector CH3


Code No.

- 07916-52501

Application

- Use to put calcium chloride solution into a rear wheel and to remove it.

WSM000001GEG0031US0



PTO Shift Arm Ball Guide



Application

- Use for compressing the ball and spring into the transmission case.

A	0.51 rad (30 °)
B	29.95 to 29.98 mm dia. (1.179 to 1.180 in. dia.)
C	35 mm (1.38 in.)
D	20 mm (0.79 in.)
C1	Chamfer 1 mm (0.039 in.)

(1) PTO Shift Arm Ball Guide

9Y1211156GEG0062US0




Independent PTO Clutch Spring Compression Tool

Application

- Use for compressing the spring into the spline boss.

A	12 mm (0.47 in.)
B	25.4 mm (1.00 in.)
C	19 mm radius (0.75 in.) Hex.
D	2.7 mm (0.11 in.)
E	8 mm (0.3 in.)
F	15 mm dia. (0.59 in. dia.)
G	37 mm (1.5 in.)
H	70 mm (2.76 in.)
I	M14 ×1.5
J	R 3.0 mm (0.12 in.)
K	30 mm (1.18 in.)
L	17 mm (0.67 in.)
M	38 mm (1.50 in.)


9Y1211156GEG0063US0



Check and High Pressure Relief Valve Assembly Tool

Application

- Use for readjusting relief valve pressure.



3XVAAAB0P055A

A	30.0 mm (1.18 in.)	N	Chamfer 0.4 mm (0.12 in.)	a	1.05 rad (60.0 °)
B	21.0 mm (0.827 in.)	O	Chamfer 3.0 mm (0.12 in.)	b	Chamfer 0.3 mm (0.01 in.)
C	1 mm (0.04 in.)	P	Chamfer 2.0 mm (0.079 in.)	c	23.0 mm (0.906 in.)
D	0.52 rad (30 °)	Q	21.4 mm (0.843 in.)	d	10.0 mm (0.394 in.)
E	50.0 mm dia. (1.97 in. dia.)	R	19.0 mm (0.748 in.)	e	1 mm (0.039 in.)
F	10.0 mm dia. (0.39 in. dia.)	S	17.0 mm (0.669 in.)	f	6.5 mm (0.26 in.)
G	9.10 to 9.30 mm dia. (0.359 to 0.366 in.)	T	10.0 mm (0.394 in.)	g	Chamfer 0.5 mm (0.02 in.)
H	34.0 mm dia. (1.34 in. dia.)	U	50.0 mm dia. (1.97 in. dia.)	h	11.1 to 11.3 mm (0.437 to 0.444 in.)
I	M36 x 1.5 mm Pitch	V	9.8 mm dia. (0.39 in. dia.)	i	18.8 to 19.0 mm (0.741 to 0.748 in.)
J	10.0 mm (0.39 in.)	W	16.0 mm dia. (0.630 in. dia.)		
K	16.0 mm (0.63 in.)	X	34.5 mm dia. (1.36 in. dia.)	(1)	Spacer
L	41.0 mm (1.61 in.)	Y	38.0 mm dia. (1.50 in. dia.)	(2)	Block
M	Chamfer 1 mm (0.04 in.)	Z	25.0 mm (0.984 in.)	(3)	Cap

9Y1211156GEG0064US0

9. TIRES

[1] TIRE PRESSURE



WARNING

To avoid personal injury or death:

- Do not attempt to mount a tire on a rim. This should be done by a qualified person with the proper equipment.
- Always maintain the correct tire pressure. Do not inflate tires above the recommended pressure shown in the operator's manual.

■ IMPORTANT

- Do not use tires other than those approved by KUBOTA.

Though the tire pressure is factory-set to the prescribed level, it naturally drops slowly in the course of time. Thus, check it everyday and inflate as necessary.

	Tire sizes	Inflation Pressure
Rear	9.5-16, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	9.5-18, 4PR	160 kPa (1.6 kgf/cm ² , 23 psi)
	315/75D-15, 4PR	100 kPa (1.0 kgf/cm ² , 14 psi)
	11.2-16, 4PR	130 kPa (1.3 kgf/cm ² , 18 psi)
	12-16.5, 4PR	270 kPa (2.7 kgf/cm ² , 40 psi)
	31 × 13.5-15, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	31 × 15.5-15, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	33 × 12.5-15, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
Front	6-12, 4PR	200 kPa (2.0 kgf/cm ² , 28 psi)
	7-12, 4PR	170 kPa (1.7 kgf/cm ² , 24 psi)
	21 × 8.00-10, 4PR	160 kPa (1.6 kgf/cm ² , 23 psi)
	22 × 8.50-12, 4PR	160 kPa (1.6 kgf/cm ² , 23 psi)
	23 × 8.50-12 Turf, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	23 × 8.50-12 Ind., 4PR	250 kPa (2.5 kgf/cm ² , 35 psi)
	24 × 8.50-12., 4PR	160 kPa (1.6 kgf/cm ² , 23 psi)

■ Dual Tires

Dual tires are not approved.

9Y1211156GEG0065US0

[2] WHEEL ADJUSTMENT


WARNING

To avoid personal injury or death:

- When working on slopes or when working with trailer, set the wheel tread as wide as practical for maximum stability.
- Support tractor securely on stands before removing a wheel.
- Do not work under any hydraulically supported devices. They can settle, suddenly leak down, or be accidentally lowered. If necessary to work under tractor or any machine elements for servicing or adjustment, securely support them with stands or suitable blocking beforehand.
- Never operate tractor with a loose rim, wheel, or axle.

9Y1211156GEG0066US0

(1) Front Wheels



9Y1210982GES048A

Front Wheels

Front tread width can not be adjusted.

■ IMPORTANT

- Do not turn front discs to obtain wider tread. In setting up the front wheels, make sure that the inflation valve stem of the tires face outward.
- When re-fitting or adjusting a wheel, tighten the bolts to the following torques then recheck after driving the tractor 200 m (200 yards) and 10 times of shuttle movement by 5 m (5 yards), and thereafter according to service interval. (See "MAINTENANCE" section.)

WARNING

To avoid personal injury or death:





- Before jacking up the tractor, park it on a firm and level ground and chock the rear wheels.
- Fix the front axle to keep it from swinging.
- Select jacks that withstand the machine weight and set them up as shown below.

(1) Jack Point





9Y1211156GEG0067US0

Front Wheels Treads

[USA Models]




Model	B2301	B2601	B2301, B2601		B2301, B2601
Tires	6-12 Farm	7-12 Farm	23 × 8.50-12 Turf	23 × 8.50-12 Ind.	21 × 8.00-10 Bar
	 9Y0211304GES003B	 9Y0211304GES003B	 9Y0211304GES003B	 9Y0211304GES003B	
Tread (a)	800 mm (31.5 in.)	815 mm (32.1 in.)	835 mm (32.9 in.)		905 mm (35.6 in.)

[Except USA Models]

Model	B2301	B2601	B2301	B2601
Tires	6-12 Farm	7-12 Farm	22 × 8.50-12 Turf	24 × 8.50-12 Turf
	 9Y0211304GES003B	 9Y0211304GES003B	 9Y0211304GES003B	 9Y0211304GES003B
Tread (a)	795 mm (31.3 in.)	815 mm (32.1 in.)	835 mm (32.9 in.)	835 mm (32.9 in.)

9Y1211156GEG0068US0

(2) Rear Wheels



Rear Wheels

Rear tread width can not be adjusted.

■ IMPORTANT

- Always attach tires as shown in the drawings.
- If not attached as illustrated, transmission parts may be damaged.
- When re-fitting or adjusting a wheel, tighten the bolts to the following torques then recheck after driving the tractor 200 m (200 yards) and 10 times of shuttle movement by 5 m (5 yards), and thereafter according to service interval. (See "MAINTENANCE" section.)

⚠ WARNING

To avoid personal injury or death:

- Before jacking up the tractor, park it on a firm and level ground and chock the front wheels.
- Fix the front axle to keep it from swinging.
- Select jacks that withstand the machine weight and set them up as shown below.

[A] Wheels with beveled or tapered holes

Use the tapered side of lug nut.

[B] Wheels without beveled or tapered holes

Use the flat side of lug nut. Make sure to apply the spring washer.




- (1) Jack Point
- (2) Lug Nut

- (3) Spring Washer





9Y1211156GEG0069US0

Rear Wheels Tread

[USA Models]

Model	B2301	B2601	B2301, B2601
Tires	9.5-16 Farm	11.2-16 Farm	33 × 12.5-15 Turf 31 × 15.5-15 Bar 12-16.5 Ind.
	 9Y1210982GES050A	 9Y1210982GES050A	 9Y1210982GES050A
Tread A	900 mm (35.4 in.)	950 mm (37.4 in.)	950 mm (37.4 in.)

[Except USA Models]

Model	B2301	B2601	B2301	B2601
Tires	9.5-16 Farm	9.5-18 Farm	31 × 13.5-15 Turf	315/75D-15 Turf
	 9Y0211304GES003B	 9Y0211304GES003B	 9Y0211304GES003B	 9Y0211304GES003B
Tread (a)	900 mm (35.4 in.)	920 mm (36.2 in.)	970 mm (38.2 in.)	970 mm (38.2 in.)

9Y1211156GEG0070US0


[3] BALLAST

⚠ WARNING

To avoid personal injury or death:

- Additional ballast will be needed for transporting heavy implements. When the implement is raised, drive slowly over rough ground, regardless of how much ballast is used.
- Do not fill the front wheels with liquid.

9Y1211156GEG0071US0



Front Ballast

Add weights if needed for stability and improving traction.

Heavy pulling and heavy rear mounted implements tend to lift front wheels. Add enough ballast to maintain steering control and prevent tip over.

Remove weight when no longer needed.

■ **Front End Weights (option)**

The front end weights can be attached to the bumper.

■ **NOTE**

[For installation of up to 3 weights]

- Besides the weight, mounting bolt kit(s) are required for mounting the weight.

[For installation of up to 5 weights]

- Besides the weight, a front weight bracket and mounting bolt kit(s) are required for mounting the weight.

■ **IMPORTANT**


- Do not overload tires.
- Add no more weight than indicated in chart.

Maximum weight	25 kg (55 lbs) x 5 pieces [125 kg (276 lbs)]
----------------	---

(1) Front End Weights

(2) Front Weight Bracket (Option)

9Y1211156GEG0072US0



Rear Ballast

Add weight to rear wheels if needed to improve traction or for stability. The amount of rear ballast should be matched to job and the ballast should be removed when it is not needed.

The weight should be added to the tractor in the form of liquid ballast.

■ **Liquid Ballast in Rear Tires**

Water and calcium chloride solution provides safe economical ballast. Used properly, it will not damage tires, tubes or rims. The addition of calcium chloride is recommended to prevent the water from freezing. Use of this method of weighting the wheels has the full approval of the tire companies.

Liquid weight per tire (75 Percent filled)

Tire sizes	9.5-16	11.2-16
Slush free at -10 °C (14 °F) Solid at -30 °C (-22 °F) [Approx. 1 kg (2 lbs) CaCl ₂ per 4 L (1 gal) of water]	54 kg (120 lbs)	70 kg (150 lbs)
Slush free at -24 °C (-11 °F) Solid at -47 °C (-53 °F) [Approx. 1.5 kg (3.3 lbs) CaCl ₂ per 4 L (1 gal) of water]	57 kg (130 lbs)	74 kg (160 lbs)
Slush free at -47 °C (-53 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (4.96 lbs) CaCl ₂ per 4 L (1 gal) of water]	60 kg (130 lbs)	78 kg (170 lbs)

■ **IMPORTANT**

- **Do not fill tires with water or solution more than 75 % of full capacity (to the level of valve stem at 12 o'clock position).**

- (1) Air
- (2) Water

- (A) **Correct: 75 % Full**
Air compresses like a cushion
- (B) **Incorrect: 100 % Full**
Water can not be compressed

9Y1211156GEG0073US0

10. IMPLEMENT LIMITATIONS

The KUBOTA Tractor has been thoroughly tested for proper performance with implements sold or approved by KUBOTA. Use with implements which are not sold or approved by KUBOTA and which exceed the maximum specifications listed below, or which are otherwise unfit for use with the KUBOTA Tractor may result in malfunctions or failures of the tractor, damage to other property and injury to the operator or others. [Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.]

9Y1211156GEG0074US0

	Tread (max. width) with farm tires		Lower link end max. loading weight W0
	Front	Rear	
B2301HSD	800 mm (31.5 in.)	900 mm (35.4 in.)	300 kg (660 lbs)
B2601HSD	815 mm (32.1 in.)	950 mm (37.4 in.)	

	Actual figures		
	Implement weight W1 and / or size	Max. drawbar load W2	Trailer loading weight W3 Max. capacity
B2301 B2601	As in the following list (Shown on the next page)	300 kg (660 lbs)	1000 kg (2210 lbs)


Lower link end max. hydraulic lifting capacity **W0**

The max. allowable load which can be put on the lower link end

Implement weight **W1**: The implement's weight which can be put on the lower link

Max. drawbar load **W2**

Trailer loading weight **W3**: The max. loading weight for trailer (without trailer's weight)



3TMABAB0P109A

■ **NOTE**

- Implement size may vary depending on soil operating conditions.

9Y1211156GEG0075US0

No.	Implement	Remarks	B2301	B2601
1	Mower	Mid-mount	Max. cutting width	152 cm (60 in.)
			Max. load capacity	140 kg (300 lbs)
		Rotary cutter (1 Blade)	Max. cutting width	122 cm (48 in.)
			Max. load capacity	204 kg (450 lbs)
		Rear-mount (2 or 3 Blade)	Max. cutting width	152 cm (60 in.)
			Max. load capacity	227 kg (500 lbs)
		Flail-mower	Max. cutting width	122 cm (48 in.)
Sickle bar	Max. cutting width	152 cm (60 in.)		
2	Rotary tiller	Max. cutting width	127 cm (50 in.)	
		Max. load capacity	213 kg (470 lbs)	
			Necessary	
3	Bottom plow	Max. size	36 cm (14 in.) × 1	
4	Disc plow	Max. size	56 cm (22 in.) × 1	
5	Cultivator	Max. size	137 cm (54 in.) 1 Row	
6	Disc harrow	Max. harrowing width	152 cm (60 in.)	
		Max. weight	190 kg (420 lbs)	
7	Sprayer	Max. tank capacity	190 L (50 U.S.gals)	
8	Front blade	Max. cutting width	152 cm (60 in.)	
		Sub frame	Necessary	
9	Rear blade	Max. cutting width	152 cm (60 in.)	
		Max. weight	160 kg (350 lbs)	
10	Front loader	Max. lifting capacity (Bucket center)	360 kg (794 lbs)	
		Max. width	127 cm (50 in.)	
		Sub frame	Necessary	
11	Box blade	Max. cutting width	137 cm (54 in.)	
		Max. weight	227 kg (500 lbs)	
12	Back hoe	Max. digging depth	198 cm (78 in.)	
		Max. weight	320 kg (705 lbs)	
		Sub frame	Necessary	
13	Snow blower	Max. digging depth	152 cm (60 in.)	
		Max. weight	200 kg (450 lbs)	
		Sub frame	Necessary	
14	Trailer	Max. load capacity	1000 kg (2200 lbs)	
		Max. drawbar load	300 kg (660 lbs)	

■ **NOTE**

- Implement size may vary depending on soil operating conditions.

9Y1211156GEG0076US0

1 ENGINE

MECHANISM

CONTENTS

1. ENGINE BODY	1-M1
[1] CLOSED BREATHER	1-M1
[2] GOVERNOR.....	1-M2

1. ENGINE BODY

[1] CLOSED BREATHER




Closed breather system has been adopted to prevent the release of blow-by gas into the atmosphere.




After its oil content is filtered by oil shield (4), the blow by gas in fed back to the intake manifold through breather valve (3) to be used for re-combustion.

- | | |
|-------------------------|--------------------|
| (1) Breather Tube | (4) Oil Shield |
| (2) Cylinder Head Cover | (5) Rubber Packing |
| (3) Breather Valve | |

9Y1211156ENM0001US0



[2] GOVERNOR



Three Lever Type Fork Lever

The governor system is a mechanical governor that used the flyweight (5).

The flyweight (5) is mounted on the governor shaft that rotates at the same speed as the crankshaft.

Because the feature of this mechanism takes out the engine speed directly as a centrifugal force of weight, the speed control that the change in the engine rotational speed is sensitively transmitted to fork lever assembly (A) and accuracy is high is enabled.

The fork lever assembly of this engine consists of fork lever 1 (6), for lever 2 (9), and the floating lever (7). A slide plate is installed in fork lever 1. The governor spring (3) is hooked to fork lever 2 (9).

The floating lever (7) installs the torque pin (8) of the output drop prevention at the overload. The start spring (2) is hooked to a slide plate, and holds the control rack in the direction of the full fuel position.

Fork lever 2 (9) and the floating lever are installed in fork lever 1 (6) with the fork lever shaft (4). The max torque limitation (1) device limits the amount of the fuel injection at the overload with the torque pin.

- | | |
|------------------------|--------------------|
| (1) Max Torque Limiter | (7) Floating Lever |
| (2) Start Spring | (8) Torque Pin |
| (3) Governor Spring | (9) Fork Lever 2 |
| (4) Fork Lever Shaft | |
| (5) Flyweight | |
| (6) Fork Lever 1 | |

(A) Fork Lever Assembly

9Y1211156ENM0002US0

(At Rated Operation)



When the engine operates, the fork lever 2 (9) and the floating lever (7) are moving with the fork lever 1 (6) due to the tension of the governor spring (3).

During the time, the torque pin (8) is pressed into the floating lever by centrifugal force of the governor weight (5).

The fork lever 2 (9) comes in contact with the fuel limitation bolt (10), and the fuel injection pump supplies a fuel necessary for rated operation.

- | | |
|------------------------|---------------------------|
| (1) Max Torque Limiter | (9) Fork Lever 2 |
| (6) Fork Lever 1 | (10) Fuel Limitation Bolt |
| (7) Floating Lever | |

9Y1211156ENM0003US0



(Overloaded Operation)

The amount of the movement of the fork lever assembly is limited with the fuel limitation bolt (10) and can not be moved in the direction of the fuel increase.

As overload reduces the centrifugal force of the governor weight, which is pressing the torque pin (8) into the floating lever (7), the floating lever pushes the fork lever 1 (6) in the way to increase the fuel supply with the help of the torque spring tension.

The fuel supply increases **(b)** in relation to the degree of the torque pin motion, thus preventing the engine speed from dropping.

At the time, the maximum torque limiter (1) prevents superfluous fuel supply and suppresses the generation of black smoke.

- (1) Max Torque Limiter
- (6) Fork Lever 1
- (7) Floating Lever
- (8) Torque Pin
- (9) Fork Lever 2
- (10) Fuel Limitation Bolt
- (a) Distance to which torque pin (8) pushes fork lever 1 (6) out
- (b) Increase of fuel

9Y1211156ENM0004US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	1-S1
2. SERVICING SPECIFICATIONS	1-S5
3. TIGHTENING TORQUES	1-S11
[1] TRACTOR SECTION	1-S11
[2] ENGINE SECTION.....	1-S11
4. CHECKING, DISASSEMBLING AND SERVICING	1-S12
[1] CHECKING AND ADJUSTING.....	1-S12
(1) Engine Body	1-S12
(2) Lubricating System.....	1-S14
(3) Cooling System	1-S14
(4) Fuel System.....	1-S17
[2] PREPARATION	1-S21
(1) Draining Lubricants and Coolant	1-S21
(2) Separating Engine from Clutch Housing	1-S23
(3) Separating Engine from Front Axle Frame	1-S24
[3] DISASSEMBLING AND ASSEMBLING	1-S25
(1) External Components	1-S25
(2) Cylinder Head and Valve and Oil Pan	1-S25
(3) Gear Case	1-S28
(4) Piston and Connecting Rod.....	1-S32
(5) Crankshaft	1-S35
[4] SERVICING	1-S37
(1) Cylinder Head and Valves	1-S37
(2) Idle Gear and Camshaft	1-S42
(3) Piston and Connecting Rod.....	1-S44
(4) Crankshaft	1-S47
(5) Cylinder	1-S51
(6) Oil Pump.....	1-S51

1. TROUBLESHOOTING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Engine Does Not Start	1. No fuel	Check fuel	G-8
	2. Air in the fuel system	Bleed air	G-33
	3. Water in the fuel system	Solution order 1. Repair or replace fuel system	1-S17
		2. Change fuel	G-8
	4. Fuel hose clogged	Clean or replace fuel hose	G-25
	5. Fuel filter clogged	Solution order 1. Replace fuel filter	G-24
		2. Check or change fuel	G-8
	6. Excessively high viscosity of fuel or engine oil at low temperature	Check fuel or engine oil	G-8
	7. Fuel with low cetane number	Check fuel	G-8
	8. Fuel leak due to loose injection pipe retaining nut	Repair retaining nut	1-S26
	9. Incorrect injection timing	Solution order 1. Check injection timing	1-S17
		2. Adjust injection timing	
	10. Fuel camshaft worn	Solution order 1. Inspect camshaft	1-S31
		2. Replace camshaft	
	11. Injection nozzle clogged	Solution order 1. Inspect injection nozzle	1-S17
		2. Replace or clean injection nozzle	
	12. Injection pump malfunctioning	Repair or replace injection pump	1-S30
13. Seizure of crankshaft, camshaft, piston, cylinder or bearing	Solution order 1. Inspect crankshaft, camshaft, piston, cylinder or bearing	1-S43 to 1-S51	
	2. Replace crankshaft, camshaft, piston, cylinder or bearing	1-S31 to 1-S36	
14. Compression leak from cylinder	Solution order 1. Check compression pressure	1-S12	
	2. Inspect or replace head gasket	1-S27	
	3. Inspect or replace piston or piston ring	1-S34, 1-S46	
	4. Inspect or replace cylinder	1-S51	
15. Improper valve timing	Check or replace timing gear	1-S31	
16. Piston ring and cylinder worn	Solution order 1. Inspect piston ring and cylinder	1-S46, 1-S51	
	2. Replace piston ring or cylinder	1-S34, 1-S51	
17. Excessive valve clearance	Solution order 1. Check and adjust valve clearance	1-S13	

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Engine Does Not Start	18. Stop solenoid malfunctioning	Solution order 1. Check or replace stop solenoid	8-S15
		2. Check or repair wire harness	8-M1
Starter Does Not Operate	1. Battery discharged	Charge battery	8-S10
	2. Starter malfunctioning	Solution order 1. Check or replace starter	8-S15
	3. Key switch malfunctioning	Check or replace key switch	8-S13
Engine Revolution Is Not Smooth	1. Fuel filter clogged or dirty	Solution order 1. Replace fuel filter	G-24
		2. Check or change fuel	G-8
	2. Air cleaner clogged	Clean or change air cleaner	G-23
	3. Fuel leak due to loose injection pipe retaining nut	Repair retaining nut	1-S26
	4. Injection pump malfunctioning	Replace injection pump	1-S30
	5. Incorrect nozzle injection pressure	Solution order 1. Check injection pressure	1-S19
		2. Repair or clean injection nozzle	1-S20
	6. Injection nozzle stuck or clogged	Solution order 1. Check injection pressure	1-S19
		2. Repair or clean injection nozzle	1-S20
	7. Governor malfunctioning	Solution order 1. Check governor spring or fuel cam shaft	1-S30
2. Replace governor spring or fuel cam shaft		1-S30	
Either White or Blue Exhaust Gas Is Observed	1. Excessive engine oil	Reduce to specified level	G-8
	2. Piston ring and cylinder worn or stuck	Solution order 1. Inspect piston ring and cylinder	1-S46, 1-S51
		2. Replace piston ring or cylinder	1-S34, 1-S51
	3. Incorrect injection timing	Solution order 1. Check injection timing	1-S17
		2. Adjust injection timing	
	4. Deficient compression	Solution order 1. Check compression pressure	1-S12
		2. Inspect or replace head gasket	1-S27
		3. Inspect or replace piston or piston ring	1-S34, 1-S46
4. Inspect or replace cylinder		1-S51	
Oil Leak into Suction Pipe	1. Waste oil pipe clogged or deformed	Repair or replace pipe	1-S25
	2. Piston ring seal is damaged	Replace piston ring	1-S34

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Either Black or Dark Gray Exhaust Gas Is Observed	1. Low grade fuel used	Check fuel	G-8
	2. Fuel filter clogged	Solution order 1. Replace fuel filter	G-24
		2. Check or change fuel	G-8
	3. Air cleaner clogged	Clean or change air cleaner	G-23
	4. Deficient nozzle injection	Solution order 1. Inspect injection nozzle	1-S27
2. Replace or clean injection nozzle			
Deficient Output	1. Incorrect injection timing	Solution order 1. Check injection timing	1-S17
		2. Adjust injection timing	
	2. Injection pump malfunctioning	Replace injection pump	1-S30
	3. Uneven fuel injection	Replace injection pump	1-S30
	4. Deficient nozzle injection	Solution order 1. Inspect injection nozzle	1-S17
		2. Replace or clean injection nozzle	
	5. Compression leak	Solution order 1. Check compression pressure	1-S12
		2. Check or replace head gasket	1-S27
		3. Inspect or replace piston or piston ring	1-S34, 1-S46
		4. Inspect or replace cylinder	1-S51
6. Gas leak from exhaust system	Repair or replace exhaust system	1-S25	
7. Air cleaner dirty or clogged	Clean or change air cleaner	G-23	
Excessive Lubricant Oil Consumption	1. Piston ring's gap facing the same direction	Repair piston ring gap	1-S46
	2. Oil ring worn or stuck	Solution order 1. Inspect piston ring and cylinder	1-S46, 1-S51
		2. Replace piston ring or cylinder	1-S34, 1-S51
	3. Piston ring groove worn	Replace piston	1-S44
	4. Valve stem and valve guide worn	Inspect or replace valve stem and valve guide	1-S38
5. Crankshaft bearing and crank pin bearing worn	Inspect or replace crankshaft and crank pin	1-S47	
Fuel Mixed into Lubricant Oil	1. Injection pump's plunger worn	Repair or replace injection pump	1-S30
	2. Deficient nozzle injection	Repair or replace nozzle	1-S20
	3. Injection pump broken	Replace injection pump	1-S30
Water Mixed into Lubricant Oil	1. Head gasket damaged	Replace head gasket	1-S27
	2. Cylinder block or cylinder head flawed	Replace cylinder head	1-S27

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Low Oil Pressure	1. Engine oil insufficient	Check engine oil	G-8
	2. Oil filter cartridge clogged	Replace oil filter cartridge	G-25
	3. Oil pump damaged	Replace oil pump	1-S51
	4. Excessive oil clearance of crankshaft bearing	Inspect or replace crankshaft bearing	1-S49, 1-S50
	5. Excessive oil clearance of crankpin bearing	Inspect or replace crankshaft	1-S47
High Oil Pressure	1. Different type of oil	Check engine oil	G-8
Engine Overheated	1. Engine oil insufficient	Check engine oil	G-8
	2. Fan belt broken or elongated	Adjust or replace fan belt	1-S25
	3. Coolant insufficient	Check coolant	G-8
	4. Radiator net and radiator fin clogged with dust	Clean radiator net and fin	G-17
	5. Inside of radiator corroded	Clean or replace radiator	G-17
	6. Coolant flow route corroded	Clean coolant flow route	G-31
	7. Radiator cap damaged	Inspect or replace radiator cap	1-S16
	8. Radiator hose damaged	Check or replace radiator hose	G-27
	9. Thermostat valve damaged	Inspect or replace thermostat	1-S15
	10. Unsuitable fuel used	Check fuel	G-8
	11. Head gasket damaged	Replace head gasket	1-S27
	12. Incorrect injection timing	Solution order 1. Check injection timing 2. Adjust injection timing	1-S17
Battery Quickly Discharged	1. Battery electrolyte insufficient	Check or charge battery	8-S10
	2. Fan belt slips	Adjust or replace fan belt	1-S25
	3. Dynamo damaged	Solution order 1. Check dynamo	8-S17
		2. Replace dynamo	8-S24

9Y1211156ENS0001US0

2. SERVICING SPECIFICATIONS

ENGINE BODY

Item		Factory Specification	Allowable Limit
Compression Pressure		3.73 to 4.11 MPa 38.0 to 42.0 kgf/cm ² 541 to 597 psi	2.26 MPa 23.0 kgf/cm ² 327 psi
• Variance Among Cylinders		–	10 % or less
Valve Clearance (Cold)		0.145 to 0.185 mm 0.0057 to 0.0073 in.	–
Top Clearance		0.55 to 0.75 mm 0.022 to 0.029 in.	–
Cylinder Head Surface	Flatness	–	0.05 mm 0.002 in.
Valve Recessing	Intake and Exhaust	0.050 to 0.25 mm 0.0020 to 0.0098 in.	0.40 mm 0.016 in.
Valve Stem to Valve Guide	Clearance	0.035 to 0.065 mm 0.0014 to 0.0025 in.	0.10 mm 0.0039 in.
• Valve Stem	O.D.	6.960 to 6.975 mm 0.2741 to 0.2746 in.	–
• Valve Guide	I.D.	7.010 to 7.025 mm 0.2760 to 0.2765 in.	–
Valve Guide (Intake and Exhaust)		7.010 to 7.025 mm 0.2760 to 0.2765 in.	–
Valve Face	Angle (Intake)	1.0 rad 60 °	–
	Angle (Exhaust)	0.79 rad 45 °	–
Valve Seat	Angle (Intake)	1.0 rad 60 °	–
	Angle (Exhaust)	0.79 rad 45 °	–
	Width	2.12 mm 0.0835 in.	–
Valve Spring	Free Length	37.0 to 37.5 mm 1.46 to 1.47 in.	36.5 mm 1.44 in.
	Tilt	–	1.0 mm 0.039 in.
	Setting Load	117.4 N / 31.0 mm 11.97 kgf / 31.0 mm 26.39 lbf / 1.22 in.	100.0 N / 31.0 mm 10.20 kgf / 31.0 mm 22.48 lbf / 1.22 in.

Item		Factory Specification	Allowable Limit	
Rocker Arm Shaft to Rocker Arm	Clearance	0.016 to 0.045 mm 0.00063 to 0.0017 in.	0.10 mm 0.0039 in.	
	• Rocker Arm Shaft	O.D.	11.973 to 11.984 mm 0.47138 to 0.47181 in.	–
	• Rocker Arm	I.D.	12.000 to 12.018 mm 0.47244 to 0.47314 in.	–
Push Rod	Alignment	–	0.25 mm 0.0098 in.	
Tappet to Tappet Guide Bore	Clearance	0.020 to 0.062 mm 0.00079 to 0.0024 in.	0.07 mm 0.003 in.	
	• Tappet	O.D.	19.959 to 19.980 mm 0.78579 to 0.78661 in.	–
	• Tappet Guide	I.D.	20.000 to 20.021 mm 0.78740 to 0.78822 in.	–
Idle Gear	• Crank Gear to Idle Gear 1	Backlash	0.0320 to 0.115 mm 0.00126 to 0.00452 in.	0.15 mm 0.0059 in.
	• Idle Gear 1 to Cam Gear	Backlash	0.0360 to 0.114 mm 0.00142 to 0.00448 in.	0.15 mm 0.0059 in.
	• Idle Gear 1 to Injection Pump Gear	Backlash	0.0340 to 0.116 mm 0.00134 to 0.00456 in.	0.15 mm 0.0059 in.
	• Idle Gear 1 to Idle Gear 2	Backlash	0.0330 to 0.117 mm 0.00130 to 0.00460 in.	0.15 mm 0.0059 in.
Idle Gear	• Idle Gear 1	Side Clearance	0.20 to 0.51 mm 0.0079 to 0.020 in.	0.80 mm 0.031 in.
	• Idle Gear 2	Side Clearance	0.20 to 0.51 mm 0.0079 to 0.020 in.	0.80 mm 0.031 in.
Camshaft	Side Clearance	0.070 to 0.22 mm 0.0028 to 0.0086 in.	0.30 mm 0.012 in.	
	Alignment	–	0.01 mm 0.0004 in.	
Cam Height	Intake	28.80 mm 1.134 in.	28.75 mm 1.132 in.	
	Exhaust	29.00 mm 1.142 in.	28.95 mm 1.140 in.	
Camshaft Journal to Cylinder Block Bore	Oil Clearance	0.050 to 0.091 mm 0.0020 to 0.0035 in.	0.15 mm 0.0059 in.	
	• Camshaft Journal	O.D.	35.934 to 35.950 mm 1.4147 to 1.4153 in.	–
	• Cylinder Block Bore	I.D.	36.000 to 36.025 mm 1.4173 to 1.4183 in.	–

Item		Factory Specification	Allowable Limit
Piston Pin Bore	I.D.	22.000 to 22.013 mm 0.86615 to 0.86665 in.	22.03 mm 0.8673 in.
Piston Pin to Small End Bushing	Clearance	0.014 to 0.038 mm 0.00055 to 0.0014 in.	0.15 mm 0.0059 in.
	• Piston Pin O.D.	22.002 to 22.011 mm 0.86622 to 0.86657 in.	–
	• Small End Bushing I.D.	22.025 to 22.040 mm 0.86713 to 0.86771 in.	–
Piston Pin to Small End Bushing (Spare Parts)	Clearance	0.014 to 0.038 mm 0.00056 to 0.0014 in.	0.15 mm 0.0059 in.
	• Small End Bushing I.D.	22.025 to 22.040 mm 0.86713 to 0.86771 in.	–
Piston Ring Gap [D1005]			
• Top Ring		0.30 to 0.45 mm 0.012 to 0.017 in.	1.25 mm 0.0492 in.
• Second Ring		0.30 to 0.45 mm 0.012 to 0.017 in.	1.25 mm 0.0492 in.
• Oil Ring		0.25 to 0.45 mm 0.0099 to 0.017 in.	1.25 mm 0.0492 in.
Piston Ring Gap [D1105]			
• Top Ring		0.15 to 0.25 mm 0.0059 to 0.0098 in.	1.20 mm 0.0472 in.
• Second Ring		0.40 to 0.55 mm 0.016 to 0.021 in.	1.20 mm 0.0472 in.
• Oil Ring		0.25 to 0.45 mm 0.0091 to 0.017 in.	1.25 mm 0.0492 in.
Piston Ring to Piston Ring Groove			
• Second Ring		Clearance 0.0950 to 0.122 mm 0.00374 to 0.00480 in.	0.2 mm 0.008 in.
• Oil Ring		Clearance 0.020 to 0.060 mm 0.00079 to 0.0023 in.	0.15 mm 0.0059 in.
Connecting Rod	Alignment	–	0.05 mm 0.002 in.
Crankshaft	Side Clearance	0.15 to 0.31 mm 0.0059 to 0.012 in.	0.50 mm 0.020 in.
	Alignment	–	0.02 mm 0.0008 in.
Crankpin to Crankpin Bearing			
Oil Clearance		0.029 to 0.091 mm 0.0011 to 0.0036 in.	0.20 mm 0.0079 in.
• Crankpin	O.D.	39.959 to 39.975 mm 1.5732 to 1.5738 in.	–
• Crankpin Bearing	I.D.	40.040 to 40.050 mm 1.5750 to 1.5767 in.	–

Item		Factory Specification	Allowable Limit
Crankshaft to Crankshaft Bearing 1	Oil Clearance	0.0340 to 0.114 mm 0.00134 to 0.00448 in.	0.20 mm 0.0079 in.
	• Crankshaft	O.D. 47.934 to 47.950 mm 1.8872 to 1.8877 in.	–
	• Crankshaft Bearing 1	I.D. 47.984 to 48.048 mm 1.8892 to 1.8916 in.	–
Crankshaft to Crankshaft Bearing 2	Oil Clearance	0.034 to 0.095 mm 0.0014 to 0.0037 in.	0.20 mm 0.0079 in.
	• Crankshaft Journal	O.D. 47.934 to 47.950 mm 1.8872 to 1.8877 in.	–
	• Crankshaft Bearing 2	I.D. 47.984 to 48.029 mm 1.8892 to 1.8909 in.	–
Crankshaft to Crankshaft Bearing 3	Oil Clearance	0.034 to 0.103 mm 0.00134 to 0.00405 in.	0.20 mm 0.0079 in.
	• Crankshaft Journal	O.D. 51.921 to 51.940 mm 2.0442 to 2.0448 in.	–
	• Crankshaft Bearing 3	I.D. 51.974 to 52.024 mm 2.0463 to 2.0481 in.	–
Cylinder [D1005]	I.D.	76.000 to 76.019 mm 2.9922 to 2.9929 in.	76.15 mm 2.998 in.
	[D1105]	I.D. 78.000 to 78.019 mm 3.0709 to 3.0716 in.	78.15 mm 3.077 in.
Cylinder Liner (Oversized) [D1005]	I.D.	76.500 to 76.519 mm 3.0119 to 3.0125 in.	76.65 mm 3.018 in.
	[D1105]	I.D. 78.500 to 78.519 mm 3.0906 to 3.0912 in.	78.65 mm 3.096 in.

LUBRICATING SYSTEM

Item		Factory Specification	Allowable Limit
Engine Oil Pressure	At Idle Speed	–	49 kPa 0.5 kgf/cm ² 7 psi
	At Rated Speed	196 to 441 kPa 2.0 to 4.5 kgf/cm ² 28.5 to 64 psi	147 kPa 1.5 kgf/cm ² 21.3 psi
Inner Rotor to Outer Rotor	Clearance	0.060 to 0.18 mm 0.0024 to 0.0071 in.	–
Outer Rotor to Pump Body	Clearance	0.100 to 0.180 mm 0.00394 to 0.00708 in.	–
Inner Rotor to Cover	Clearance	0.025 to 0.075 mm 0.00099 to 0.0029 in.	–

COOLING SYSTEM

Item		Factory Specification	Allowable Limit
Fan Belt	Tension	7.0 to 9.0 mm 0.28 to 0.35 in.	–
Thermostat	Valve Opening Temperature (At Beginning)	69.5 to 72.5 °C 157.1 to 162.5 °F	–
	Valve Opening Temperature (Opened Completely)	85 °C 185 °F	–
Radiator Cap	Pressure Falling Time	More than 10 seconds for pressure fall from 88 to 59 kPa (from 0.89 to 0.61 kgf/cm ² , from 12 to 8.6 psi)	–
Radiator	Water Leakage Test Pressure	137 kPa 1.4 kgf/cm ² 20 psi	–

FUEL SYSTEM

Item		Factory Specification	Allowable Limit
Injection Pump	Injection Timing [D1005]	0.2837 to 0.3097 rad (16.25 to 17.75 °) after T.D.C.	–
	Injection Timing [D1105]	0.2662 to 0.3272 rad (17.25 to 18.75 °) before T.D.C.	–
Pump Element	Fuel Tightness	–	13.73 MPa 140 kgf/cm ² 1991 psi
Delivery Valve	Fuel Tightness	10 seconds 13.73 → 12.75 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi	5 seconds 13.73 → 12.75 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi
Injection Nozzle	Injection Pressure	13.73 to 14.71 MPa 140 to 150 kgf/cm ² 1990 to 2130 psi	–
Injection Nozzle Valve Seat	Valve Seat Tightness	No fuel leak at 12.75 MPa 130 kgf/cm ² 1849 psi	–

9Y1211156ENS0002US0

3. TIGHTENING TORQUES

Tightening torque of screws, bolts and nuts on the table below are specially specified. (For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)

■ NOTE

- In removing and applying the bolts and nuts marked with "*", a pneumatic wrench or similar pneumatic tool, if employed, must be used with enough care not to get them seized.
- For "*" marked screws, bolts and nuts on the table, apply engine oil to their threads and seats before tightening.
- The letter "M" in Size × Pitch means that the screw, bolt or nut dimension stands for metric. The size is the nominal outside diameter in mm of the threads. The pitch is the nominal distance in mm between two threads.

9Y1211156ENS0003US0

[1] TRACTOR SECTION

Item	N·m	kgf·m	lbf·ft
Power steering hose 2	24 to 28	2.5 to 2.8	18 to 20
Engine mounting screw	59 to 69	6.1 to 7.0	44 to 50

9Y1211156ENS0004US0

[2] ENGINE SECTION


Item	Size × Pitch	N·m	kgf·m	lbf·ft
Oil pressure switch	–	15 to 19	1.5 to 2.0	11 to 14
Nozzle holder	–	35 to 39	3.5 to 4.0	26 to 28
Overflow pipe nut	–	35 to 39	3.5 to 4.0	26 to 28
Nozzle holder assembly	–	49 to 68	5.0 to 7.0	36 to 50
*Cylinder head cover nuts	M7 × 1.0	7 to 8	0.7 to 0.9	5 to 6
Injection pipe retaining nuts	M12 × 1.5	25 to 34	2.5 to 3.5	18 to 25
*Rocker arm bracket nuts	M7 × 1.0	22 to 26	2.2 to 2.7	16 to 19
*Cylinder head screw	M10 × 1.25	64 to 68	6.5 to 7.0	47 to 50
*Fan drive pulley screw	M14 × 1.5	236 to 245	24.0 to 25.0	174 to 180
*Connecting rod screw	M8 × 1.0	42 to 46	4.2 to 4.7	31 to 33
*Flywheel screw	M10 × 1.25	53.9 to 58.8	5.5 to 6.0	39.8 to 43.4
*Bearing case cover screws	M6 × 1.0	10.8 to 12.2	1.10 to 1.25	7.96 to 9.04
*Main bearing case screw 2	M9 × 1.25	49 to 53	5.0 to 5.5	37 to 39
*Main bearing case screw 1	M8 × 1.25	30 to 34	3.0 to 3.5	22 to 25

9Y1211156ENS0005US0

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING

(1) Engine Body



Compression Pressure



1. Operate the engine until it is warmed up.
2. Stop the engine.
3. Remove the air cleaner, the muffler and all glow plugs (or nozzles).
4. Set a compression tester with the adaptor to the glow plug hole (or nozzle hole).
Nozzle Hole: Adaptor **H**
Glow Plug Hole: Adaptor **L**
5. After making sure that the stop lever is set at the stop position (non-injection), operate the engine with the starter and measure the compression pressure.
6. Repeat steps 4 and 5 for each cylinder.
7. If the measurement is below the allowable limit, apply a small amount of oil to the cylinder wall through the glow plug hole (or nozzle hole) and measure the compression pressure again.
8. If the compression pressure is still less than the allowable limit, check the top clearance, valve clearance and cylinder head.
9. If the compression pressure increases after applying oil, check the cylinder wall and piston rings.

■ NOTE

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for performing this test.
- Variances in cylinder compression values should be under 10 %.

Compression pressure	Factory specification	3.73 to 4.11 MPa 38.0 to 42.0 kgf/cm ² 541 to 597 psi
	Allowable limit	2.26 MPa 23.0 kgf/cm ² 327 psi

9Y1211156ENS0006US0



Valve Clearance 1

IMPORTANT

- Valve clearance must be checked and adjusted when engine is cold.
1. Remove the head cover, the glow plugs and the timing window cover on the clutch housing.
 2. Align the "1TC" mark line on the flywheel and center of timing window so that the No. 1 piston comes to the compression top dead center.
 3. Check the following valve clearance marked with "☆" using a feeler gauge.
 4. If the clearance is not within the factory specifications, adjust with the adjusting screw.

Valve clearance	Factory specification	0.145 to 0.185 mm 0.0057 to 0.0073 in.
-----------------	-----------------------	---

NOTE

- The "TC" marking line on the flywheel is just for No. 1 cylinder. There is no "TC" marking for the other cylinders.
- No. 1 piston comes to the T.D.C. position when the "TC" marking line is aligned with center of timing window on front case. Turn the flywheel 0.26 rad (15 °) clockwise and counterclockwise to see if the piston is at the compression top dead center or the overlap position. Now referring to the table below, readjust the valve clearance. (The piston is at the compression top dead center when both the IN. and EX. valves do not move; it is at the overlap position when both the valves move.)
- Finally turn the flywheel 6.28 rad (360 °) and align the "TC" marking line and the center of timing window. Adjust all the other valve clearance as required.
- After turning the flywheel counterclockwise twice or three times, recheck the valve clearance, firmly tighten the lock nut of the adjusting screw.

Adjustable cylinder location of piston		Number of cylinders Valve arrangement			
		3-cylinder		4-cylinder	
		IN.	EX.	IN.	EX.
When No. 1 piston comes to compression top dead center	No. 1	☆	☆	☆	☆
	No. 2		☆	☆	
	No. 3	☆			☆
	No. 4				
When No. 1 piston comes to overlap position	No. 1				
	No. 2	☆			☆
	No. 3		☆	☆	
	No. 4			☆	☆


☆: Valve clearance is adjustable.

- (1) Timing Window
- (2) TC Mark Line

A: Valve Clearance

9Y1211156ENS0007US0

(2) Lubricating System



Engine Oil Pressure

1. Remove the engine oil pressure switch, and set an oil pressure tester.
2. Start the engine. After warming up, measure the oil pressure of both idling and rated speeds.
3. If the oil pressure is less than the allowable limit, check the following.
 - Engine oil insufficient
 - Oil pump damaged
 - Oil strainer clogged
 - Oil filter cartridge clogged
 - Oil gallery clogged
 - Excessive oil clearance
 - Foreign matter in the relief valve

Engine oil pressure	At idle speed	Allowable limit	49 kPa 0.5 kgf/cm ² 7 psi
	At rated speed	Factory specification	196 to 441 kPa 2.0 to 4.5 kgf/cm ² 28.5 to 64 psi
		Allowable limit	147 kPa 1.5 kgf/cm ² 21.3 psi


(When reassembling)

- After checking the engine oil pressure, tighten the engine oil pressure switch to the specified torque.

Tightening torque	Oil pressure switch	15 to 19 N·m 1.5 to 2.0 kgf·m 11 to 14 lbf·ft
-------------------	---------------------	---

9Y1211156ENS0008US0

(3) Cooling System



Fan Belt Tension

1. Measure the deflection **(A)**, depressing the belt halfway between the fan drive pulley and dynamo pulley at specified force (98 N, 10 kgf, 22 lbf).
2. If the measurement is not within the factory specifications, loosen the dynamo mounting screws and relocate the dynamo to adjust.

Deflection (A)	Factory specification	7.0 to 9.0 mm 0.28 to 0.35 in.
-----------------------	-----------------------	-----------------------------------

9Y1211156ENS0009US0





Fan Belt Damage and Wear

1. Check the fan belt for damage.
2. If the fan belt is damaged, replace it.
3. Check if the fan belt is worn and sunk in the pulley groove.
4. If the fan belt is nearly worn out and deeply sunk in the pulley groove, replace it.

(A) Good

(B) Bad

9Y1211156ENS0010US0



Thermostat Valve Opening Temperature

1. Suspend the thermostat in the water by a string with its end inserted between the valve and seat.
2. Heating the water gradually, read the temperature when the valve opens and leaves the string.
3. Continue heating and read the temperature when the valve opens approx. 8 mm (0.3 in.).
4. If the measurement is not within the factory specifications, replace the thermostat.


Thermostat's valve opening temperature	Factory specification	69.5 to 72.5 °C 157.1 to 162.5 °F
Temperature at which thermostat completely open	Factory specification	85 °C 185 °F

9Y1211156ENS0011US0

CAUTION

- When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.

9Y1211156ENS0012US0



Radiator Cap Air Leakage


- Set a radiator tester (1) and adaptor (2) on the radiator cap.
- Apply the specified pressure 88 kPa (0.89 kgf/cm², 12 psi), and measure the time for the pressure to fall to 59 kPa (0.61 kgf/cm², 8.6 psi).
- If the measurement is less than the factory specification, replace the radiator cap.

Pressure falling time	Factory specification	More than 10 seconds for pressure fall from 88 to 59 kPa (from 0.89 to 0.61 kgf/cm ² , from 12 to 8.6 psi)
-----------------------	-----------------------	---

(1) Radiator Tester

(2) Adaptor

9Y1211156ENS0013US0



Radiator Water Leakage

- Pour a specified amount of water into the radiator.
- Set a radiator tester (1) and an adaptor (2) and raise the water pressure to the specified pressure.
- Check the radiator for water leaks.
- For water leak from the pinhole, repair with the radiator cement. When water leak is excessive, replace the radiator.



Radiator water leakage test pressure	Factory specification	137 kPa 1.4 kgf/cm ² 20 psi
--------------------------------------	-----------------------	--

(1) Radiator Tester

(2) Adaptor

9Y1211156ENS0014US0

(4) Fuel System



Injection Timing

1. Remove the injection pipes.
2. Remove the engine stop solenoid.
3. Turn the flywheel counterclockwise (facing the flywheel) until fuel flows from the delivery valve holder.
4. Continue to turn the flywheel slowly, and stop it as soon as the fuel level at the tip of the delivery valve holder begins to increase.
5. Check to see if the timing angle lines on the flywheel is aligned with the alignment mark (2).
6. If the injection timing is out of adjustment, readjust the timing with shims.

Injection timing [D1005]	Factory specification	0.2837 to 0.3097 rad (16.25 to 17.75 °) after T.D.C.
Injection timing [D1105]	Factory specification	0.2662 to 0.3272 rad (17.25 to 18.75 °) before T.D.C.


NOTE

- The sealant is applied to both sides of the shim (soft metal gasket shim). The liquid gasket is not required for assembling.
- Shims are available in thickness of 0.20 mm (0.0079 in.), 0.25 mm (0.0098 in.), 0.30 mm (0.012 in.), 0.35 mm (0.014 in.) and 0.175 mm (0.00689 in.). Combine these shims for adjustments.
- Addition or reduction of shim (0.025 mm, 0.00098 in.) delays or advances the injection timing by approx. 0.0044 rad (0.25 °).
- In disassembling and replacing the injection pump, be sure to use the same number of new shims with the same thickness.
- Refer to figure below to check the thickness of the shims.

- (1) Timing Line
- (2) Alignment Mark
- (3) Shim (Soft Metal Gasket Shim)
- (4) Two-holes: 0.20 mm (0.0079 in.)
Two-holes: 0.175 mm (0.00689 in.)
- (5) One-hole: 0.25 mm (0.0098 in.)
- (6) Without hole: 0.30 mm (0.012 in.)
- (7) Three-holes: 0.35 mm (0.014 in.)

- (A) Engine mounted on the tractor
(B) Engine only

9Y1211156ENS0015US0



Fuel Tightness of Pump Element

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Install the injection pump pressure tester to the injection pump.
4. Install the injection nozzle (1) jetted with the proper injection pressure to the injection pump pressure tester (2). (Refer to the photo.)
5. Set the speed control lever to the maximum speed position.
6. Operate the starter to increase the pressure.
7. If the pressure can not reach the allowable limit, replace the pump with new one or repair with a Kubota-authorized pump service shop.


Fuel tightness of pump element	Allowable limit	13.73 MPa 140 kgf/cm ² 1991 psi
--------------------------------	-----------------	--

NOTE

- **Never try to disassemble the injection pump assembly. For repairs, you are strongly requested to contact a Kubota-authorized pump service shop.**

- (1) Injection Nozzle (3) Protection Cover for Jetted Fuel
 (2) Injection Pump Pressure Tester

9Y1211156ENS0016US0



Fuel Tightness of Delivery Valve

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set a pressure tester to the fuel injection pump.
4. Install the injection nozzle (1) jetted with the proper injection pressure to the injection pump pressure tester (2).
5. Operate the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. After that, turn the flywheel by the hand and raise the pressure to approx. 13.73 MPa (140 kgf/cm², 1991 psi).
7. Now turn the flywheel back about half a turn (to keep the plunger free). Keep the flywheel at this position and clock the time taken for the pressure to drop from 13.73 to 12.75 MPa (from 140 to 130 kgf/cm², from 1991 to 1849 psi).
8. Measure the time needed to decrease the pressure from 13.73 to 12.75 MPa (from 140 to 130 kgf/cm², from 1991 to 1849 psi).
9. If the measurement is less than allowable limit, replace the pump with new one or repair with a Kubota-authorized pump service shop.


Fuel tightness of delivery valve	Factory specification	10 seconds 13.73 → 12.75 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi
	Allowable limit	5 seconds 13.73 → 12.75 MPa 140 → 130 kgf/cm ² 1991 → 1849 psi

NOTE

- **Never try to disassemble the injection pump assembly. For repairs, you are strongly requested to contact a Kubota-authorized pump service shop.**

- (1) Injection Nozzle (3) Protection Cover for Jetted Fuel
 (2) Injection Pump Pressure Tester

9Y1211156ENS0017US0



Nozzle Spraying Condition


CAUTION

- Check the injection pressure and condition after you make sure that there is nobody standing in the direction the fume goes.
 - If the fume from the nozzle directly injects the human body, cells may be destroyed and blood poisoning may be caused.
 - Use eyes protector on eyes before inspecting the high pressure fuel from the fuel injection nozzle temporarily.
 - Set the protection board for jetted fuel near the tractor before inspecting the high pressure fuel from the injection nozzle temporarily.
 - Use face protector on face before inspecting the high pressure fuel from the fuel injection nozzle temporarily.
 - Use leather gloves or protector on hands, arm covers on arms and protector on body before inspecting the high pressure fuel from the fuel injection nozzle temporarily.
1. Set the injection nozzle to a nozzle tester, and check the nozzle spraying condition.
 2. If the spraying condition is damaged, replace the nozzle piece.

(a) Good

(b) Bad

9Y1211156ENS0018US0



Fuel Injection Pressure

1. Set the injection nozzle to a nozzle tester.
2. Slowly move the tester handle to measure the pressure at which fuel begins jetting out from the nozzle.
3. If the measurement is not within the factory specifications, replace the adjusting washer (1) in the nozzle holder to adjust it.


Fuel injection pressure	Factory specification	13.73 to 14.71 MPa 140 to 150 kgf/cm ² 1990 to 2130 psi
-------------------------	-----------------------	--


(Reference)

- Pressure variation with 0.01 mm (0.0004 in.) difference of adjusting washer thickness:
Approx. 235 kPa (2.4 kgf/cm², 34 psi)

(1) Adjusting Washer

9Y1211156ENS0019US0






Valve Seat Tightness

1. Set the injection nozzle to a nozzle tester.
2. Raise the fuel pressure, and keep at 12.75 MPa (130 kgf/cm², 1849 psi) for 10 seconds.
3. If any fuel leak is found, replace the nozzle piece.

Valve seat tightness	Factory specification	No fuel leak at 12.75 MPa 130 kgf/cm ² 1849 psi
----------------------	-----------------------	---

9Y1211156ENS0020US0



Nozzle Holder

1. Secure the nozzle retaining nut (7) with a vise.
2. Remove the nozzle holder (1), and remove parts inside.

(When reassembling)

- Assemble the nozzle in clean fuel oil.
- Install the push rod (4), noting its direction.
- After assembling the nozzle, be sure to adjust the fuel injection pressure.



Tightening torque	Nozzle holder	35 to 39 N·m 3.5 to 4.0 kgf·m 26 to 28 lbf·ft
	Overflow pipe nut	35 to 39 N·m 3.5 to 4.0 kgf·m 26 to 28 lbf·ft
	Nozzle holder assembly	49 to 68 N·m 5.0 to 7.0 kgf·m 36 to 50 lbf·ft

- | | |
|----------------------|--------------------------|
| (1) Nozzle Holder | (5) Distance Piece |
| (2) Adjusting Washer | (6) Nozzle Piece |
| (3) Nozzle Spring | (7) Nozzle Retaining Nut |
| (4) Push Rod | |

9Y1211156ENS0021US0

[2] PREPARATION

(1) Draining Lubricants and Coolant



Draining Engine Oil

⚠ CAUTION

- **Before changing oil, be sure to stop the engine.**
1. Start and warm up the engine for approx. 5 minutes.
 2. Place an oil pan underneath the engine.
 3. To drain the used oil, remove the drain plug (1) at the bottom of the engine and drain the oil completely.
 4. Screw in the drain plug (1).
 5. Fill new oil up to upper line on the dipstick (2).

■ IMPORTANT

- **When using an oil of different manufacture or viscosity from the previous one, remove all of the old oil.**
- **Never mix two different types of oil.**
- **Use the proper SAE Engine Oil according to ambient temperatures.**





Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.

Engine oil capacity	3.1 L 3.3 U.S.qts 2.8 Imp.qts
---------------------	-------------------------------------

- (1) Drain Plug
(2) Dipstick
(3) Oil Inlet Plug

(A) Oil level is acceptable within this range.

9Y1211156ENS0022US0



Draining Transmission Fluid

CAUTION

- Stop the engine before checking and changing the transmission fluid.

1. Place the oil pan under the tractor.
2. Remove the drain plugs (1), (3), (5) at the mid-PTO shaft and at the bottom of the rear axle cases (4), (6).
3. Drain the transmission fluid.
4. After draining the transmission fluid, reinstall the drain plugs (1), (3), (5).

IMPORTANT

- Use only KUBOTA UDT oil. Use of other oils may damage the transmission or hydraulic system. Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.
- Never work the tractor immediately after changing the transmission oil. Keep the engine at medium speed for a few minutes to prevent damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	15 L 4.0 U.S.gals 3.3 Imp.gals
-----------------------------	--------------------------------------

- | | |
|-------------------|---------------------------|
| (1) Drain Plug | (4) Rear Axle Case (L.H.) |
| (2) Mid-PTO Shaft | (5) Drain Plug |
| (3) Drain Plug | (6) Rear Axle Case (R.H.) |

9Y1211156ENS0023US0

Draining Coolant

CAUTION

- Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.

1. Stop the engine and let cool down.
2. Disconnect the radiator hose (1) at the engine side.
3. Remove the radiator cap to completely drain the coolant.
4. After all coolant is drained, connect the radiator hose (1).

(When reassembling)

Coolant	Capacity	3.8 L 4.0 U.S.qts 3.3 Imp.qts
---------	----------	-------------------------------------

- (1) Radiator Hose

9Y1211156ENS0024US0

(2) Separating Engine from Clutch Housing



Bonnet, Side Cover and Battery Cord

1. Open the bonnet (1).
2. Disconnect the battery negative cord.
3. Disconnect the head light connectors and remove the bonnet (1) side covers (2).


■ NOTE

- **When disconnecting the battery cords, disconnect the grounding cord first. When connecting, positive cord first.**

(1) Bonnet
(2) Side Cover

(3) Battery

9Y1211156ENS0025US0





Hydraulic Hoses from Power Steering Cylinder

1. Disconnect the hydraulic hoses (1), (3) from the power steering cylinder (2).

(1) Hydraulic Hose (R.H.)
(2) Power Steering Cylinder

(3) Hydraulic Hose (L.H.)

9Y1211156ENS0026US0




Fuel

1. Disconnect the fuel hose (1) from the fuel filter (2).
2. Drain the fuel to the fuel tank completely.

(1) Fuel Hose (from Fuel Tank) (2) Fuel Filter

9Y1211156ENS0027US0





Wiring Harness, Hour Meter Cable and Clamp (Left Side)

1. Disconnect the wiring harness (1) from battery, dynamo, engine and starter.
2. Remove the clamp (2).
3. Loosen the dynamo mounting bolts and remove the hour meter cable (3).

(1) Wiring Harness
(2) Clamp

(3) Hour Meter Cable

9Y1211156ENS0028US0



Accelerator Rod, Power Steering Hose, Fuel Hoses, Connectors and Others (Right Side)

1. Remove the spring plates (1), oil cooler mounting bolts (2) and oil cooler (3).
2. Remove the clamp (4) and the accelerator rod (5).
3. Disconnect the power steering hose (7), hydraulic delivery pipe (6) and hydraulic inlet hose (9).
4. Disconnect the fuel hoses (8).
5. Disconnect the connectors (11) and glow plug harness (10).
6. Remove the shuttle plate (12).
7. Disconnect the clamp (13).

Tightening torque	Power steering hose 2	24 to 28 N·m 2.5 to 2.8 kgf·m 18 to 20 lbf·ft
-------------------	-----------------------	---

- | | |
|-----------------------------|--------------------------|
| (1) Spring Plate | (8) Fuel Hose |
| (2) Bolt | (9) Hydraulic Inlet Hose |
| (3) Oil Cooler | (10) Glow Plug Harness |
| (4) Clamp | (11) Connector |
| (5) Accelerator Rod | (12) Shuttle Plate |
| (6) Hydraulic Delivery Pipe | (13) Clamp |
| (7) Power Steering Hose | |

9Y1211156ENS0029US0

Separating Clutch Housing

1. Support the transmission with a disassembling stand.
2. Hook the engine with a hoist.
3. Remove the docking bolts and nuts between the engine and the front case.

(When reassembling)

- Align the spline between the front wheel drive shaft and the coupling securely.
- Tighten the docking bolts between the engine and the front case securely.
- Apply liquid gasket (Three Bond 1206D or equivalent) to the joint face of the engine and the front case.

9Y1211156ENS0030US0

(3) Separating Engine from Front Axle Frame



Separating Engine from Front Axle Frame

■ **NOTE**

- **When you replace the engine with new one, please record the serial number of new engine and the parts number which is incorporate with its new engine.**




1. Remove the engine and front axle frame mounting screw and separate the engine from the front axle frame.

Tightening torque	Engine mounting screw	59 to 69 N·m 6.1 to 7.0 kgf·m 44 to 50 lbf·ft
-------------------	-----------------------	---

9Y1211156ENS0031US0

[3] DISASSEMBLING AND ASSEMBLING

(1) External Components



Fan, Water Hose, Fan Belt, Dynamo, Muffler, Air Cleaner, Air Cleaner Bracket, Inlet Hose and etc.

1. Remove the external components as shown in the picture.

(When reassembling)

- Check to see that there are no crack on the fan belt surface.

■ **IMPORTANT**

- **When installing the fan belt (5), be sure to adjust the fan belt tension.**

Fan belt deflection (A)	Factory specification	7.0 to 9.0 mm 0.28 to 0.35 in.
-------------------------	-----------------------	-----------------------------------


■ **NOTE**

- **When remove the compressor, condenser and receiver, be careful not to damage the hose bind.**

- | | |
|-----------------|-------------------------|
| (1) Inlet Hose | (7) Muffler |
| (2) Air Cleaner | (8) Dynamo |
| (3) Inlet Hose | (9) Air Cleaner Bracket |
| (4) Fan | (10) Steel Plate |
| (5) Fan Belt | |
| (6) Water Hose | |
- (A) Deflection**

9Y1211156ENS0032US0

(2) Cylinder Head and Valve and Oil Pan



Cylinder Head Cover

1. Disconnect the breather hose (1).
2. Remove the head cover nut (2).
3. Remove the cylinder head cover (3).


(When reassembling)

- Check to see if the cylinder head cover gasket is not damaged.

Tightening torque	Cylinder head cover nut	7 to 8 N·m 0.7 to 0.9 kgf·m 5 to 6 lbf·ft
-------------------	-------------------------	---

- | | |
|--------------------|-------------------------|
| (1) Breather Hose | (3) Cylinder Head Cover |
| (2) Head Cover Nut | |

9Y1211156ENS0033US0



Injection Pipes

1. Loosen the screws on the pipe clamp (1).
2. Remove the injection pipes (2).


(When reassembling)

- Sent compressed air into the pipes to blow out dust. Then, reassemble the pipes in the reverse order.

Tightening torque	Injection pipe retaining nut	25 to 34 N·m 2.5 to 3.5 kgf·m 18 to 25 lbf·ft
-------------------	------------------------------	---

- (1) Pipe Clamp (2) Injection Pipe

9Y1211156ENS0034US0



Nozzle Heat Seal Service Removal Procedure

■ **IMPORTANT**


- Use a plus (phillips head) screw driver that has a Dia. which is bigger than the heat seal hole (Approx. 6 mm (1/4 in.)).

1. Drive screw driver lightly into the heat seal hole.
2. Turn screw driver three or four times each way.
3. While turning the screw driver, slowly pull the heat seal out together with the injection nozzle gasket.

If the heat seal drops, repeat the above procedure. Heat seal and injection nozzle gasket must be changed when the injection nozzle is removed for cleaning or for service.

- (1) Plus Screw Driver (2) Injection Nozzle
(3) Injection Nozzle Packin (4) Heat Seal

9Y1211156ENS0035US0



Rocker Arm and Push Rod

1. Remove the rocker arm bracket nut.
2. Remove the rocker arm assembly (1).
3. Remove the push rods (2).

(When reassembling)

- When putting the push rods (2) onto the tappets (3), check to see if their ends are properly engaged with the dimples.


■ **IMPORTANT**





- After installing the rocker arm, be sure to adjust the valve clearance.

Tightening torque	Rocker arm bracket nut	22 to 26 N·m 2.2 to 2.7 kgf·m 16 to 19 lbf·ft
-------------------	------------------------	---

- (1) Rocker Arm Assembly (2) Push Rod (3) Tappet

9Y1211156ENS0036US0





Cylinder Head

1. Loosen the hose clamps (1), and remove the water return hose (2).
2. Remove the cylinder head screw in the order of (n or r) to (a).
3. Lift up the cylinder head to remove.
4. Remove the cylinder head gasket.

(When reassembling)

- Replace the cylinder head gasket with new one.
- When mounting the gasket, set it to the pin pipe holes. Be careful not to mount it reversely.
- The cylinder head should be free of scratches and dust.
- Install the cylinder head, using care not to damage the gasket.
- After applying engine oil to the thread of screws, tighten them in several steps and specified sequence (a) to (n or r).

NOTE

- Do not use O-ring on the pin pipe.
- It is not necessary to retighten the cylinder head screw and to readjust valve clearance after engine warmed up.

Tightening torque	Cylinder head screw	64 to 68 N·m 6.5 to 7.0 kgf·m 47 to 50 lbf·ft
-------------------	---------------------	---

- (1) Pipe Clamp
- (2) Water Return Pipe
- (3) Pin Pipe

(n or r) to (a):To Loosen
(a) to (n or r):To Tighten

9Y1211156ENS0037US0

Tappets

1. Remove the tappets (1) from the crankcase.

(When reassembling)


- Visually check the contact between tappets and cams for proper rotation. If problem is found, replace tappets.
- Before installing the tappets, apply engine oil thinly around them.

IMPORTANT

- Do not change the combination of tappet and tappet guide.

- (1) Tappet

9Y1211156ENS0038US0



Valves

1. Remove the valve caps (2).
2. Remove the valve spring collet (3), pushing the valve spring retainer (4) by valve spring replacer (1).
3. Remove the valve spring retainer (4), valve spring (5) and valve stem seal (6).
4. Remove the valve (7).

(When reassembling)


- Wash the valve stem seal and valve guide hole, and apply engine oil sufficiently.
- After installing the valve spring collets, lightly tap the stem to assure proper fit with a plastic hammer.

■ IMPORTANT

- **Do not change the combination of valve and valve guide.**

- | | |
|---------------------------|---------------------|
| (1) Valve Spring Replacer | (5) Valve Spring |
| (2) Valve Cap | (6) Valve Stem Seal |
| (3) Valve Spring Collet | (7) Valve |
| (4) Valve Spring Retainer | |

9Y1211156ENS0039US0



Thermostat Assembly

1. Remove the thermostat cover mounting screws (1), and remove the thermostat cover (2).
2. Remove the thermostat assembly (4).


(When reassembling)

- Apply a liquid gasket (Three Bond 1215 or equivalent) only at the thermostat cover side of the gasket (3).

- | | |
|-------------------------------------|-----------------------------|
| (1) Thermostat Cover Mounting Screw | (3) Thermostat Cover Gasket |
| (2) Thermostat Cover | (4) Thermostat Assembly |

9Y1211156ENS0040US0

(3) Gear Case



Fan Drive Pulley

1. Secure the flywheel to keep it from turning.
2. Remove the fan drive pulley screw.
3. Draw out the fan drive pulley with a puller.


(When reassembling)

- Install the pulley to the crankshaft, aligning the mark (1) on them.
- Apply engine oil to the fan drive pulley retaining screws. And tighten them.

Tightening torque	Fan drive pulley screw	236 to 245 N·m 24.0 to 25.0 kgf·m 174 to 180 lbf·ft
-------------------	------------------------	---

- (1) Alignment Mark

9Y1211156ENS0041US0



Gear Case

1. Remove the gear case (1).


(When reassembling)

- Grease thinly to the oil seal, and install it, ensuring the lip does not come off.

(1) Gear Case

- a: Bolt Length = 45 mm (1.8 in.)
- b: Bolt Length = 50 mm (2.0 in.)
- c: Bolt Length = 55 mm (2.2 in.)
- d: Bolt Length = 65 mm (2.6 in.)
- e: Bolt Length = 68 mm (2.7 in.)
- f: Bolt Length = 85 mm (3.3 in.)
- g: Nut

9Y1211156ENS0042US0



Engine Stop Solenoid and Speed Control Plate

1. Remove the engine stop solenoid.
2. Disconnect the governor spring (2) from the speed control plate (1).
3. Remove the speed control plate.


(When reassembling)



- Apply a liquid gasket (Three Bond 1215 or equivalent) to both sides of the solenoid cover gasket and control plate gasket.
- Be careful not to drop the governor springs into the crankcase.

(1) Speed Control Plate

(2) Governor Spring

9Y1211156ENS0043US0





Injection Pump

1. Disconnect the starter spring (4) on the thrust lever side (5).
2. Align the control rack pin (2) with the notch (1) on the crankcase, and remove the injection pump (3).
3. Remove the injection pump shims.
4. In principle, the injection pump should not be disassembled.

(When reassembling)





- When installing the injection pump, insert the control rack pin (2) firmly into the groove (6) of the thrust lever of fork lever.

■ NOTE

- **The sealant is applied to both sides of the soft metal gasket shim. The liquid gasket is not required for assembling.**
- **Addition or reduction of shim (0.05 mm, 0.002 in.) delays or advances the injection timing by approx. 0.0087 rad (0.5 °).**
- **In disassembling and replacing, be sure to use the same number or new gasket shims with the same thickness.**

- | | |
|----------------------|------------------|
| (1) Notch | (4) Start Spring |
| (2) Control Rack Pin | (5) Thrust Lever |
| (3) Injection Pump | (6) Groove |

9Y1211156ENS0044US0



Cam Gear, Idle Gear 1 and Governor Gear

1. Remove the idle gear 1 (4).
2. Remove the fuel camshaft stopper (6).
3. Draw out the fuel cam gear (1) with fuel camshaft (7).
4. Remove the camshaft stopper bolt.
5. Remove the cam gear (5) with camshaft.
6. Remove the external snap ring (8) from the governor shaft (9).
7. Remove the governor gear (2) with governor shaft (9).

NOTE

• Three-lever type fork lever

To remove the governor shaft (9), follow the procedures in 5, 6 above and never remove fork lever and the max torque limiter.

(When reassembling)



- Apply engine oil thinly to the fuel camshaft (7) before installation.
- Make sure to assemble the external snap ring (8) of the governor shaft (9).
- Check the governor shaft (9) for smooth rotation.

IMPORTANT

- When replacing the ball bearing of governor shaft, securely fit the ball bearing (10) to the crankcase, apply an adhesive (Three Bond 1324B or equivalent) to the set screw (11), and tighten the screw until its tapered part contacts the circumferential end of the ball bearing.
- When installing the idle gear, be sure to align the alignment marks (12) on each gear.

- | | |
|---------------------------|------------------------|
| (1) Fuel Cam Gear | (7) Fuel Camshaft |
| (2) Governor Gear | (8) External Snap Ring |
| (3) Crank Gear | (9) Governor Shaft |
| (4) Idle Gear 1 | (10) Ball Bearing |
| (5) Cam Gear | (11) Set Screw |
| (6) Fuel Camshaft Stopper | (12) Alignment Mark |

9Y1211156ENS0045US0



Oil Pan and Oil Strainer

1. Remove the oil pan mounting screws (5).
2. Remove the oil pan (4).
3. Remove the oil strainer (3).

(When reassembling)

- After cleaning the oil strainer, check to see that the filter mesh is clean, and install it.
- Visually check the O-ring (1), apply engine oil, and install it.
- Securely fit the O-ring to the oil strain.
- To avoid uneven tightening, tighten oil pan mounting screws in diagonal order from the center.



■ IMPORTANT

- **Scrape off the old adhesive completely. Wipe the sealing surface clean using waste cloth soaked with gasoline. Now apply new adhesive 3 to 5 mm (0.12 to 0.20 in.) thick all over the contact surface. Apply the adhesive also on the center of the flange as well as on the inner wall of each screw hole.**
- **Cut the nozzle of the "liquid gasket" container at its second notch. Apply "liquid gasket" about 5 mm (0.2 in.) thick. Within 20 minutes after the application of fluid sealant, reassemble the components. Wait then for about 30 minutes, and pour oil in the crankcase.**

- | | |
|------------------|-----------------------------|
| (1) O-ring | (4) Oil Pan |
| (2) Screw | (5) Oil Pan Mounting Screws |
| (3) Oil Strainer | |

9Y1211156ENS0046US0

(4) Piston and Connecting Rod



Connecting Rod

1. Remove the connecting rod cap.




(When reassembling)

- Align the marks (a) with each other. (Face the marks toward the injection pump.)
- Apply engine oil to the connecting rod screws (1) and lightly screw it in by hand, then tighten it to the specified torque. If the connecting rod screw won't be screwed in smoothly, clean the threads. If the connecting rod screw (1) is still hard to screw in, replace it.

Tightening torque	Connecting rod screw	42 to 46 N·m 4.2 to 4.7 kgf·m 31 to 33 lbf·ft
-------------------	----------------------	---

- | | |
|--------------------------|----------|
| (1) Connecting Rod Screw | (a) Mark |
|--------------------------|----------|

9Y1211156ENS0047US0



Piston

1. Turn the flywheel and bring the piston to top dead center.
2. Draw out the piston upward by lightly tapping it from the bottom of the crankcase with the grip of a hammer.
3. Draw out the other piston in the same method as above.

(When reassembling)

- Before inserting the piston into the cylinder, apply enough engine oil to the piston.
- When inserting the piston into the cylinder, face the mark on the connecting rod to the injection pump.

■ IMPORTANT

- Do not change the combination of cylinder and piston. Make sure of the position of each piston by marking. For example, mark "1" on the No.1 piston.
- When installing the piston into the cylinder, place the gaps of all the piston rings as shown in the figure.
- Carefully insert the piston using a piston ring compressor (1). Otherwise, their chrome-plated section may be scratched, causing trouble inside the cylinder.

(1) Piston Ring Compressor

(a) 0.79 rad (45 °)

(b) 0.79 rad (45 °)

(c) 1.6 rad (90 °)





(A) Top Ring Gap

(B) Second Ring Gap

(C) Oil Ring Gap

(D) Piston Pin Hole

9Y1211156ENS0048US0



Piston Ring and Connecting Rod

1. Remove the piston rings using a piston ring tool.
2. Remove the piston pin (7), and separate the connecting rod (6) from the piston (5).

(When reassembling)

- Install the rings so that the manufacturer's mark (12) near the gap faces the top of the piston.
- When installing the oil ring onto the piston, place the expander joint (10) on the opposite side of the oil ring gap (11).
- Apply engine oil to the piston pin.
- When installing the connecting rod to the piston, immerse the piston in 80 °C (176 °F) oil for 10 to 15 minutes and insert the piston pin to the piston.
- When installing the connecting rod to the piston, align the mark (8) on the connecting rod to the fan-shaped concave (9).






NOTE

- **Mark the same number on the connecting rod and the piston so as not to change the combination.**

- | | |
|--------------------------|--------------------------|
| (1) Top Ring | (7) Piston Pin |
| (2) Second Ring | (8) Mark |
| (3) Oil Ring | (9) Fan-Shaped Concave |
| (4) Piston Pin Snap Ring | (10) Expander Joint |
| (5) Piston | (11) Oil Ring Gap |
| (6) Connecting Rod | (12) Manufacturer's Mark |

9Y1211156ENS0049US0

(5) Crankshaft



Flywheel

1. Secure the flywheel to keep it from turning, using a flywheel stopper.
2. Remove all flywheel screws (1) and then remove the flywheel (2).

(When reassembling)

- Align the "1TC" mark (a) on the the outer surface of the flywheel horizontally with the alignment mark (b) on the rear end plate. Now fit the flywheel in position.
- Apply engine oil to the threads and the undercut surface of the flywheel screw and fit the screw.

Tightening torque	Flywheel screw	53.9 to 58.8 N·m 5.5 to 6.0 kgf·m 39.8 to 43.4 lbf·ft
-------------------	----------------	---

- (1) Flywheel Screw
(2) Flywheel

- (a) 1TC Mark
(b) Alignment Mark

9Y1211156ENS0050US0

Bearing Case Cover

1. Remove the bearing case cover mounting screws.
2. Remove the bearing case cover (6).

■ IMPORTANT

- The length of inside screws (1) and outside screws (2) are difference. Do not take a mistake using inside screws and outside screws.

(When reassembling)

- Fit the bearing case gasket (3) and the bearing case cover gasket (4) with correct directions.
- Install the bearing case cover (6) to position the casting mark "UP" (a) on it upward.
- Apply engine oil to the oil seal (5) lip and be careful that it is not rolled when installing.
- Tighten the bearing case cover mounting screws with even force on the diagonal line.


Tightening torque	Bearing case cover screw	10.8 to 12.2 N·m 1.10 to 1.25 kgf·m 7.96 to 9.04 lbf·ft
-------------------	--------------------------	---

- (1) Bearing Case Cover Mounting Screw (Inside)
(2) Bearing Case Cover Mounting Screw (Outside)
(3) Bearing Case Gasket
(4) Bearing Case Cover Gasket

- (5) Oil Seal
(6) Bearing Case Cover

- (a) Top Mark "UP"
(b) Upside

9Y1211156ENS0051US0



Crankshaft Assembly

1. Remove the main bearing case screw 2 (1).
2. Pull out the crankshaft assembly.

■ **IMPORTANT**

- **Be careful to protect crankshaft bearing 1 from scratches, caused by the crank gear, etc.. (Wrap the gear in vinyl tape, etc.).**


(When reassembling)

- Clean the oil passage of the crankshaft with compressed air.
- Apply oil to the main bearing case screw 2 (1).
- Install the crankshaft assembly, aligning the screw hole of main bearing case with the screw hole of crankcase.
- Clean the oil passage of the crankshaft with compressed air.

Tightening torque	Main bearing case screw 2	49 to 53 N·m 5.0 to 5.5 kgf·m 37 to 39 lbf·ft
-------------------	---------------------------	---

(1) Main Bearing Case Screw 2

9Y1211156ENS0052US0




Main Bearing Case Assembly

1. Remove the two main bearing case screws 1 (3) of each main bearing cases.
2. Remove the main bearing case from crankshaft.

(When reassembling)

- Clean the oil passage in the main bearing cases.
- Apply clean engine oil on the bearings.
- Install the main bearing case assemblies in original positions. Since diameters of main bearing cases vary, install them in order to marking **(b) (A, B, C)** from the gear case side.
- Match the alignment numbers **(a)** on the main bearing case assembly 1.
- When installing the main bearing case 1 and 2, face the mark **"FLYWHEEL"** to the flywheel.
- Install the thrust bearing (2) with its oil groove facing outward.
- Make sure that the main bearing case moves smoothly after tightening the main bearing case screw 1 to the specified torque.



Tightening torque	Main bearing case screw 1	30 to 34 N·m 3.0 to 3.5 kgf·m 22 to 25 lbf·ft
-------------------	---------------------------	---



- (1) Main Bearing Case Assembly 1
 (2) Thrust Bearing
 (3) Main Bearing Case Screw 1

- (a) Alignment Number**
(b) Marking (A, B, C)

9Y1211156ENS0053US0

[4] SERVICING

(1) Cylinder Head and Valves



Top Clearance

1. Remove the cylinder head. (Do not try to remove the cylinder head gasket.)
2. Move the piston up and stick a strip of fuse [1.5 mm dia. (0.059 in. dia.), 5.0 to 7.0 mm long (0.20 to 0.27 in. long)] on the piston head at three positions with grease so as to avoid the intake valve and the exhaust valve and the combustion chamber ports.
3. Lower the piston, and install the cylinder head and tighten the cylinder head screws to the specified torque.
4. Turn the flywheel until the piston exceeds top dead center.
5. Remove the cylinder head, and measure the thickness of the squeezed fuses.
6. If the measurement is not within the factory specifications, check the oil clearance between the crankpin and the crankpin bearing and between the piston pin and the small end bushing.

NOTE

- After checking the top clearance, be sure to assemble the cylinder head with a new cylinder head gasket.



Top clearance	Factory specification	0.55 to 0.75 mm 0.022 to 0.029 in.
---------------	-----------------------	---------------------------------------

Tightening torque	Cylinder head screws	64 to 68 N·m 6.5 to 7.0 kgf·m 47 to 50 lbf·ft
-------------------	----------------------	---

(1) Fuse

(2) Fuse

9Y1211156ENS0054US0



Cylinder Head Surface Flatness


1. Clean the cylinder head surface.
2. Place a straightedge on the cylinder head's four sides and two diagonal as shown in the figure.
3. Measure the clearance with a thickness gauge.
4. If the measurement exceeds the allowable limit, correct it with a surface grinder.

IMPORTANT

- Do not place the straightedge on the combustion chamber.
- Be sure to check the valve recessing after correcting.

Cylinder head surface flatness	Allowable limit	0.05 mm 0.002 in.
--------------------------------	-----------------	----------------------

9Y1211156ENS0055US0




Cylinder Head Flaw

1. Prepare an air spray red check.
2. Clean the surface of the cylinder head with detergent (2).
3. Spray the cylinder head surface with the red permeative liquid (1). Leave it five to ten minutes after spraying.
4. Wash away the red permeative liquid on the cylinder head surface with the detergent (2).
5. Spray the cylinder head surface with white developer (3).
6. If flawed, it can be identified as red marks.

- (1) Red Permeative Liquid (3) White Developer
 (2) Detergent

9Y1211156ENS0056US0




Valve Recessing

1. Clean the cylinder head surface, the valve face and the valve seat.
2. Insert the valve into the valve guide.
3. Measure the valve recessing with a depth gauge.
4. If the measurement exceeds the allowable limit, replace the valve.
5. If it still exceeds the allowable limit after replacing the valve, replace the cylinder head.

Valve recessing	Factory specification	0.050 (protrusion) to 0.25 (recessing) mm 0.0020 (protrusion) to 0.0098 (recessing) in.
	Allowable limit	0.40 (recessing) mm 0.016 (recessing) in.

- (1) Cylinder Head Surface (A) Recessing
 (B) Protrusion

9Y1211156ENS0057US0





Clearance between Valve Stem and Valve Guide


1. Remove carbon from the valve guide section.
2. Measure the valve stem O.D. with an outside micrometer.
3. Measure the valve guide I.D. with a small hole gauge, and calculate the clearance.
4. If the clearance exceeds the allowable limit, replace the valves. If it still exceeds the allowable limit, replace the valve guide.

Clearance between valve stem and valve guide	Factory specification	0.035 to 0.065 mm 0.0014 to 0.0025 in.
	Allowable limit	0.10 mm 0.0039 in.

Valve stem O.D.	Factory specification	6.960 to 6.975 mm 0.2741 to 0.2746 in.
Valve guide I.D.	Factory specification	7.010 to 7.025 mm 0.2760 to 0.2765 in.

9Y1211156ENS0058US0





Replacing Valve Guide

(When removing)

1. Press out the used valve guide using a valve guide replacing tool. (See page "SPECIAL TOOLS".)

(When installing)

1. Clean a new valve guide and valve guide bore, and apply engine oil to them.
2. Press in a new valve guide using a valve guide replacing tool.
3. Ream precisely the I.D. of the valve guide to the specified dimension.

Valve guide I.D. (Intake and exhaust)	Factory specification	7.010 to 7.025 mm 0.2760 to 0.2765 in.
--	-----------------------	---


■ IMPORTANT

- Do not hit the valve guide with a hammer during replacement.

(A) When Removing

(B) When Installing


9Y1211156ENS0059US0



Valve Seating

1. Coat the valve face lightly with prussian blue and put the valve on its seat to check the contact.
2. If the valve does not seat all the way around the valve seat or the valve contact is less than 70 %, correct the valve seating as follows.
3. If the valve contact does not comply with the reference value, replace the valve or correct the contact of valve seating.




Valve seat width	Factory specification	2.12 mm 0.0835 in.
------------------	-----------------------	-----------------------



- (1) Correct
(2) Incorrect

(3) Incorrect

9Y1211156ENS0060US0



Correcting Valve and Valve Seat

■ **NOTE**

- Before correcting the valve and the seat, check the valve stem and the I.D. of valve guide section, and repair them if necessary.
- After correcting the valve seat, be sure to check the valve recessing.

1) Correcting Valve

1. Correct the valve with a valve refacer.

Valve face angle	Factory specification	IN.	1.0 rad 60 °
		EX.	0.79 rad 45 °

2) Correcting Valve Seat

1. Slightly correct the seat surface with a 0.79 rad (45 °) / 1.0 rad (60 °) valve seat cutter.
2. Fitting the valve, check the contact position of the valve face and seat surface with prussian blue. (Visual check) [If the valve has been used for a long period, the seat tends to come in contact with the upper side of the valve face.]
3. Grind the upper surface of the seat with a 0.52 rad (30 °) valve seat cutter until the valve seat touches to the center of the valve face (so that (a) equals (b) as shown in the figure).
4. Grind the seat with a 0.26 rad (15 °) valve seat cutter again, and visually recheck the contact between the valve and the seat.
5. Repeat steps 3 and 4 until the correct contact is achieved.
6. Continue lapping until the seated rate becomes more than 70 % of the total contact area.

Valve seat angle	Factory specification	IN.	1.0 rad 60 °
		EX.	0.79 rad 45 °

(1) Valve Seat Width

(a) Identical Dimensions

(A) Check Contact

(b) Valve Seat Width

(B) Correct Seat Width


(c) 0.26 rad (15 °) or 0.52 rad (30 °)

(C) Correct Seat Surface

(d) 0.79 rad (45 °) or 1.0 rad (60 °)

(D) Check Contact

9Y1211156ENS0061US0




Valve Lapping

1. Apply compound evenly to the valve lapping surface.
2. Insert the valve into the valve guide. Lap the valve onto its seat with a valve flapper or screwdriver.
3. After lapping the valve, wash the compound away and apply oil, then repeat valve lapping with oil.
4. Apply prussian blue to the contact surface to check the seated rate. If it is less than 70 %, repeat valve lapping again.

■ **IMPORTANT**

- When valve lapping is performed, be sure to check the valve recessing and adjust the valve clearance after assembling the valve.

9Y1211156ENS0062US0



Free Length and Tilt of Valve Spring

1. Measure the free length **(B)** of valve spring with vernier calipers. If the measurement is less than the allowable limit, replace it.
2. Put the valve spring on a surface plate, place a square on the side of the valve spring.
3. Check to see if the entire side is in contact with the square. Rotate the valve spring and measure the maximum tilt **(A)**. If the measurement exceeds the allowable limit, replace it.
4. Check the entire surface of the valve spring for scratches. If there is any problem, replace it.


Tilt (A)	Allowable limit	1.0 mm 0.039 in.
-----------------	-----------------	---------------------

Free length (B)	Factory specification	37.0 to 37.5 mm 1.46 to 1.47 in.
	Allowable limit	36.5 mm 1.44 in.

(A) Tilt

(B) Free Length

9Y1211156ENS0063US0



Valve Spring Setting Load

1. Place the valve spring on a tester and compress it to the same length it is actually compressed in the engine.
2. Read the compression load on the gauge.
3. If the measurement is less than the allowable limit, replace it.

Setting load / Setting length	Factory specification	117.4 N / 31.0 mm 11.97 kgf / 31.0 mm 26.39 lbf / 1.22 in.
	Allowable limit	100.0 N / 31.0 mm 10.20 kgf / 31.0 mm 22.48 lbf / 1.22 in.

9Y1211156ENS0064US0



Oil Clearance between Rocker Arm and Rocker Arm Shaft


1. Measure the rocker arm shaft O.D. with an outside micrometer.
2. Measure the rocker arm I.D. with an inside micrometer, and then calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the rocker arm and measure the oil clearance again. If it still exceeds the allowable limit, replace also the rocker arm shaft.

Oil clearance between rocker arm and rocker arm shaft	Factory specification	0.016 to 0.045 mm 0.00063 to 0.0017 in.
	Allowable limit	0.10 mm 0.0039 in.

Rocker arm shaft O.D.	Factory specification	11.973 to 11.984 mm 0.47138 to 0.47181 in.
-----------------------	-----------------------	---

Rocker arm I.D.	Factory specification	12.000 to 12.018 mm 0.47244 to 0.47314 in.
-----------------	-----------------------	---

9Y1211156ENS0065US0



Push Rod Alignment

1. Place the push rod on V blocks.
2. Measure the push rod alignment.
3. If the measurement exceeds the allowable limit, replace the push rod.

Push rod alignment	Allowable limit	0.25 mm 0.0098 in.
--------------------	-----------------	-----------------------


9Y1211156ENS0066US0



Oil Clearance between Tappet and Tappet Guide Bore

1. Measure the tappet O.D. with an outside micrometer.
2. Measure the I.D. of the tappet guide bore with a cylinder gauge, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit or the tappet is damaged, replace the tappet.


Oil Clearance between tappet and tappet guide bore	Factory specification	0.020 to 0.062 mm 0.00079 to 0.0024 in.
	Allowable limit	0.07 mm 0.003 in.



Tappet O.D.	Factory specification	19.959 to 19.980 mm 0.78579 to 0.78661 in.
Tappet guide bore I.D.	Factory specification	20.000 to 20.021 mm 0.78740 to 0.78822 in.

9Y1211156ENS0067US0

(2) Idle Gear and Camshaft



Timing Gear Backlash

1. Set a dial indicator (lever type) with its tip on the gear tooth.
2. Move the gear to measure the backlash, holding its mating gear.
3. If the backlash exceeds the allowable limit, check the oil clearance of the shafts and the gear.
4. If the oil clearance is proper, replace the gear.


Backlash between idle gear 1 and crank gear	Factory specification	0.0320 to 0.115 mm 0.00126 to 0.00452 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between idle gear 1 and cam gear	Factory specification	0.0360 to 0.114 mm 0.00142 to 0.00448 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between idle gear 1 and injection pump gear	Factory specification	0.0340 to 0.116 mm 0.00134 to 0.00456 in.
	Allowable limit	0.15 mm 0.0059 in.

Idle gear 1 and idle gear 2	Factory specification	0.0330 to 0.117 mm 0.00130 to 0.00460 in.
	Allowable limit	0.15 mm 0.0059 in.

9Y1211156ENS0068US0




Idle Gear 1 and 2 Side Clearance

1. Set a dial indicator with its tip on the idle gear.
2. Measure the side clearance by moving the idle gear to the front and rear.
3. If the measurement exceeds the allowable limit, replace the idle gear collar.

Idle gear 1 and 2 side clearance	Factory specification	0.20 to 0.51 mm 0.0079 to 0.020 in.
	Allowable limit	0.8 mm 0.031 in.

9Y1211156ENS0069US0




Camshaft Side Clearance

1. Set a dial indicator with its tip on the camshaft.
2. Measure the side clearance by moving the cam gear to the front to rear.
3. If the measurement exceeds the allowable limit, replace the camshaft stopper.

Camshaft side clearance	Factory specification	0.070 to 0.22 mm 0.0028 to 0.0086 in.
	Allowable limit	0.30 mm 0.012 in.

9Y1211156ENS0070US0




Camshaft Alignment

1. Support the camshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the camshaft alignment.
4. If the measurement exceeds the allowable limit, replace the camshaft.

Camshaft alignment	Allowable limit	0.01 mm 0.0004 in.
--------------------	-----------------	-----------------------

9Y1211156ENS0071US0




Cam Height

1. Measure the height of the cam at its highest point with an outside micrometer.
2. If the measurement is less than the allowable limit, replace the camshaft.

Cam height of intake	Factory specification	28.80 mm 1.134 in.
	Allowable limit	28.75 mm 1.132 in.

Cam height of exhaust	Factory specification	29.00 mm 1.142 in.
	Allowable limit	28.95 mm 1.140 in.


9Y1211156ENS0072US0



Oil Clearance of Camshaft Journal


1. Measure the camshaft journal O.D. with an outside micrometer.
2. Measure the cylinder block bore I.D. for camshaft with a cylinder gauge, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the camshaft.

Oil clearance of camshaft journal	Factory specification	0.050 to 0.091 mm 0.0020 to 0.0035 in.
	Allowable limit	0.15 mm 0.0059 in.



Camshaft journal O.D.	Factory specification	35.934 to 35.950 mm 1.4147 to 1.4153 in.
Camshaft bearing I.D. (Cylinder block bore I.D.)	Factory specification	36.000 to 36.025 mm 1.4173 to 1.4183 in.

9Y1211156ENS0073US0



Replacing Idle Gear Bushing

(When removing)

1. Press out the used idle gear bushing using an idle gear bushing replacing tool. (See page "SPECIAL TOOLS".)

(When installing)


1. Clean a new idle gear bushing and idle gear bore, and apply engine oil to them.
2. Press in a new bushing using an idle gear bushing replacing tool, until it is flush with the end of the idle gear.

(A) When Removing

(B) When Installing

9Y1211156ENS0074US0

(3) Piston and Connecting Rod




Piston Pin Bore I.D.

1. Measure the piston pin bore I.D. in both the horizontal and vertical directions with a cylinder gauge.
2. If the measurement exceeds the allowable limit, replace the piston.

Piston pin bore I.D.	Factory specification	22.000 to 22.013 mm 0.86615 to 0.86665 in.
	Allowable limit	22.03 mm 0.8673 in.

9Y1211156ENS0075US0




Oil Clearance between Piston Pin and Small End Bushing

1. Measure the piston pin O.D. where it contacts the bushing with an outside micrometer.
2. Measure the small end bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing. If it still exceeds the allowable limit, replace the piston pin.

Oil clearance between piston pin and small end bushing	Factory specification	0.014 to 0.038 mm 0.00055 to 0.0014 in.
	Allowable limit	0.15 mm 0.0059 in.

Piston pin O.D.	Factory specification	22.002 to 22.011 mm 0.86622 to 0.86657 in.
Small end bushing I.D.	Factory specification	22.025 to 22.040 mm 0.86713 to 0.86771 in.

9Y1211156ENS0076US0



Replacing Small End Bushing

(When removing)


1. Press out the used bushing using a small end bushing replacing tool. (See page "SPECIAL TOOLS".)

(When installing)

1. Clean a new small end bushing and bore, and apply engine oil to them.
2. Using a small end bushing replacing tool, press in a new bushing (service parts) taking care to see that the connecting rod oil hole matches the bushing hole.

Oil clearance between piston pin and small end bushing (Spare parts)	Factory specification	0.014 to 0.038 mm 0.00056 to 0.0014 in.
	Allowable limit	0.15 mm 0.0059 in.


Small end bushing I.D. (Spare parts)	Factory specification	22.025 to 22.040 mm 0.86713 to 0.86771 in.
--------------------------------------	-----------------------	---



- (1) Seam
- (2) Oil Hole

- (A) When Removing**
- (B) When Installing**
- (a) 0.785 rad (45 °)**

9Y1211156ENS0077US0




Piston Ring Gap

1. Insert the piston ring into the lower part of the cylinder (the least worn out part) with a piston.
2. Measure the ring gap with a thickness gauge.
3. If the measurement exceeds the allowable limit, replace the piston ring.

Piston ring gap [D1005]	Top ring	Factory specification	0.30 to 0.45 mm 0.012 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.
	Second ring	Factory specification	0.30 to 0.45 mm 0.012 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.
	Oil ring	Factory specification	0.25 to 0.45 mm 0.0099 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.

Piston ring gap [D1105]	Top ring	Factory specification	0.15 to 0.25 mm 0.0059 to 0.0098 in.
		Allowable limit	1.20 mm 0.0472 in.
	Second ring	Factory specification	0.40 to 0.55 mm 0.016 to 0.021 in.
		Allowable limit	1.20 mm 0.0472 in.
	Oil ring	Factory specification	0.25 to 0.45 mm 0.0091 to 0.017 in.
		Allowable limit	1.25 mm 0.0492 in.

9Y1211156ENS0078US0




Clearance between Piston ring and Piston Ring Groove

1. Clean the rings and the ring grooves, and install each ring in its groove.
2. Measure the clearance between the ring and the groove with a feeler gauge or depth gauge.
3. If the clearance exceeds the allowable limit, replace the piston ring.
4. If the clearance still exceeds the allowable limit with new ring, replace the piston.

Clearance between piston ring and piston ring groove	Second ring	Factory specification	0.0950 to 0.122 mm 0.00374 to 0.00480 in.
		Allowable limit	0.2 mm 0.008 in.
	Oil ring	Factory specification	0.020 to 0.060 mm 0.00079 to 0.0023 in.
		Allowable limit	0.15 mm 0.0059 in.

9Y1211156ENS0079US0




Connecting Rod Alignment

1. Remove the crankpin bearing, and install the connecting rod cap.
2. Install the piston pin in the connecting rod.
3. Install the connecting rod on the connecting rod alignment tool.
4. Put a gauge over the piston pin, and move it against the face plate.
5. If the gauge does not fit squarely against the face plate, measure the space between the pin of the gauge and the face plate.
6. If the measurement exceeds the allowable limit, replace the connecting rod.

Space between gauge pin face plate	Allowable limit	0.05 mm 0.002 in.
------------------------------------	-----------------	----------------------

9Y1211156ENS0080US0


(4) Crankshaft



Crankshaft Side Clearance

1. Set a dial indicator with its tip on the end of the crankshaft.
2. Measure the side clearance by moving the crankshaft to the front and rear.
3. If the measurement exceeds the allowable limit, replace the thrust bearings.
4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an oversize one referring to the table and figure.

Crankshaft side clearance	Factory specification	0.15 to 0.31 mm 0.0059 to 0.012 in.
	Allowable limit	0.50 mm 0.020 in.




(Reference)

- Oversize dimensions of crankshaft journal

Oversize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	51.50 to 51.70 mm 2.028 to 2.035 in.	51.60 to 51.80 mm 2.032 to 2.039 in.
Dimension B	28.20 to 28.25 mm 1.111 to 1.112 in.	28.40 to 28.45 mm 1.119 to 1.120 in.
Dimension C	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 3.7 mm radius 0.091 to 0.10 in. radius

The crankshaft journal must be fine-finished to higher than Rmax = 0.8S.

9Y1211156ENS0081US0





Crankshaft Alignment

1. Support the crankshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the crankshaft alignment.
4. If the measurement exceeds the allowable limit, replace the crankshaft.

Crankshaft alignment	Allowable limit	0.02 mm 0.0008 in.
----------------------	-----------------	-----------------------

9Y1211156ENS0082US0



Oil Clearance between Crankpin and Crankpin Bearing

1. Clean the crankpin and crankpin bearing.
2. Put a strip of plastigauge on the center of the crankpin.
3. Install the connecting rod cap and tighten the connecting rod screws to the specified torque, and remove the cap again.
4. Measure the amount of the flattening with the scale, and get the oil clearance.
5. If the oil clearance exceeds the allowable limit, replace the crankpin bearing.
6. If the same size bearing is useless because of the crankpin wear, replace it with an undersize one referring to the table and figure.

■ **NOTE**

- **Never insert the plastigauge into the crankpin oil hole.**
- **Be sure not to move the crankshaft while the connecting rod screws are tightened.**

Oil clearance between crankpin and crankpin bearing	Factory specification	0.029 to 0.091 mm 0.0011 to 0.0036 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankpin O.D.	Factory specification	39.959 to 39.975 mm 1.5732 to 1.5738 in.
Crankpin bearing I.D.	Factory specification	40.040 to 40.050 mm 1.5750 to 1.5767 in.





(Reference)

- Undersize dimensions of crankpin

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.8 to 3.2 mm radius 0.11 to 0.12 in. radius	2.8 to 3.2 mm radius 0.11 to 0.12 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	39.759 to 39.775 mm dia. 1.5654 to 1.5659 in. dia.	39.559 to 39.575 mm dia. 1.5575 to 1.5580 in. dia.

The crankpin must be fine-finished to higher than Rmax = 0.8S.
 *Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

9Y1211156ENS0083US0



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 1

1. Measure the O.D. of the crankshaft front journal with an outside micrometer.
2. Measure the I.D. of the crankshaft bearing 1 with an inside micrometer, and calculate the oil clearance.
3. If the clearance exceeds the allowable limit, replace the crankshaft bearing 1.
4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and figure.

Oil clearance between crankshaft journal and crankshaft bearing 1	Factory specification	0.0340 to 0.114 mm 0.00134 to 0.00448 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankshaft journal O.D.	Factory specification	47.934 to 47.950 mm 1.8872 to 1.8877 in.
-------------------------	-----------------------	---

Crankshaft bearing 1 I.D.	Factory specification	47.984 to 48.048 mm 1.8892 to 1.8916 in.
---------------------------	-----------------------	---

(Reference)

- Undersize dimensions of crankshaft journal

Undersize	0.20 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief	1.0 to 1.5 mm relief 0.040 to 0.059 in. relief
Dimension C	47.734 to 47.750 mm dia. 1.8793 to 1.8799 in. dia.	47.534 to 47.550 mm dia. 1.8715 to 1.8720 in. dia.

The crankshaft journal must be fine-finished to higher than Rmax = 0.8S.

*Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

9Y1211156ENS0084US0

Replacing Crankshaft Bearing 1

(When removing)

1. Press out the used crankshaft bearing 1 using a crankshaft bearing 1 replacing tool. (See page "SPECIAL TOOLS".)

(When installing)

1. Clean a new crankshaft bearing 1 and crankshaft journal bore, and apply engine oil to them.
2. Using a crankshaft bearing 1 replacing tool, press in a new bearing 1 (2) so that its seam (1) directs toward the exhaust manifold side. (See figure.)

Dimension (A)	Factory specification	0 to 0.3 mm 0 to 0.01 in.
---------------	-----------------------	------------------------------



(1) Seam

(2) Crankshaft Bearing 1

(3) Cylinder Block

(A) Dimension

9Y1211156ENS0085US0



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 2 (Crankshaft Bearing 3)

1. Put a strip of plastigauge on the center of the journal.
2. Install the bearing case and tighten the bearing case screws 1 to the specified torque, and remove the bearing case again.
3. Measure the amount of the flattening with the scale and get the oil clearance.
4. If the clearance exceeds the allowable limit, replace the crankshaft bearing 2 (1) and crankshaft bearing (3).
5. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and figure.

NOTE

- Be sure not to move the crankshaft while the bearing case screws are tightened.

Oil clearance between crankshaft journal and crankshaft bearing 2	Factory specification	0.034 to 0.095 mm 0.0014 to 0.0037 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankshaft journal O.D. (Intermediate)	Factory specification	47.934 to 47.950 mm 1.8872 to 1.8877 in.
Crankshaft bearing 2 I.D.	Factory specification	47.984 to 48.029 mm 1.8892 to 1.8909 in.

Oil clearance between crankshaft journal and crankshaft bearing 3	Factory specification	0.0340 to 0.103 mm 0.00134 to 0.00405 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankshaft journal O.D. (Flywheel side)	Factory specification	51.921 to 51.940 mm 2.0442 to 2.0448 in.
Crankshaft bearing 3 I.D.	Factory specification	51.974 to 52.024 mm 2.0463 to 2.0481 in.

(Reference)




- Undersize dimensions of crankshaft journal

Undersize	0.020 mm 0.0079 in.	0.40 mm 0.016 in.
Dimension A	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius	2.3 to 2.7 mm radius 0.091 to 0.10 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.040 to 0.0591 in. relief	1.0 to 1.5 mm relief 0.040 to 0.0591 in. relief
Dimension C	47.734 to 47.750 mm dia. 1.8793 to 1.8799 in. dia.	47.534 to 47.550 mm dia. 1.8715 to 1.8720 in. dia.
Dimension D	51.721 to 51.740 mm dia. 2.0363 to 2.0370 in. dia.	51.521 to 51.540 mm dia. 2.0284 to 2.0291 in. dia.

The crankshaft journal must be fine-finished to higher than Rmax = 0.8S
 *Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

9Y1211156ENS0086US0

(5) Cylinder



Cylinder Wear

1. Measure the I.D. of the cylinder at the six positions (see figure) with a cylinder gauge to find the maximum and minimum I.D.'s.
2. Get the difference (Maximum wear) between the maximum and the minimum I.D.'s.
3. If the wear exceeds the allowable limit, bore and hone to the oversize dimension. (Refer to "Correcting Cylinder".)
4. Visually check the cylinder wall for scratches. If deep scratches are found, the cylinder should be bored. (Refer to "Correcting Cylinder".)

Cylinder I.D.	Factory specification	D1005	76.000 to 76.019 mm 2.9922 to 2.9929 in.
		D1105	78.000 to 78.019 mm 3.0709 to 3.0716 in.
	Allowable limit	D1005	76.15 mm 2.998 in.
		D1105	78.15 mm 3.077 in.

(A) Top
(B) Middle
(C) Bottom (Skirt)

(a) Right-angled to Piston Pin
(b) Piston Pin Direction

9Y1211156ENS0087US0

Correcting Cylinder

1. When the cylinder is worn beyond the allowable limit, bore and hone it to the specified dimension.

Oversized cylinder liner I.D.	Factory specification	D1005	76.500 to 76.519 mm 3.0119 to 3.0125 in.
		D1105	78.500 to 78.519 mm 3.0906 to 3.0912 in.
	Allowable limit	D1005	76.65 mm 3.018 in.
		D1105	78.65 mm 3.096 in.
Finishing	Finishing Hone to 1.2 to 2.0 mm μR max. (48 to 78 in. μR max.)		

2. Replace the piston and piston rings with oversize ones.
Oversize: 0.5 mm (0.02 in.)


NOTE

- When the oversize cylinder is worn beyond the allowable limit, replace the cylinder block with a new one.

(1) Cylinder I.D. (Before Correction) (2) Cylinder I.D. (Oversize)

9Y1211156ENS0088US0

(6) Oil Pump




Rotor Lobe Clearance

1. Measure the clearance between lobes of the inner rotor and the outer rotor with a feeler gauge.
2. If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Rotor lobe clearance	Factory specification	0.060 to 0.18 mm 0.0024 to 0.0071 in.
----------------------	-----------------------	--

9Y1211156ENS0089US0




Clearance between Outer Rotor and Pump Body

1. Measure the clearance between the outer rotor and the pump body with a feeler gauge.
2. If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Clearance between outer rotor and pump body	Factory specification	0.100 to 0.180 mm 0.00394 to 0.00708 in.
---	-----------------------	---

9Y1211156ENS0090US0



Clearance between Rotor and Cover

1. Put a strip of plastigauge onto the rotor face with grease.
2. Install the cover and tighten the screws.
3. Remove the cover carefully, and measure the amount of the flattening with the scale and get the clearance.
4. If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Clearance between rotor and cover	Factory specification	0.025 to 0.075 mm 0.00099 to 0.0029 in.
-----------------------------------	-----------------------	--

9Y1211156ENS0091US0


2 TRANSMISSION

MECHANISM

CONTENTS

1. STRUCTURE.....	2-M1
2. FRONT CASE.....	2-M2
3. HYDROSTATIC TRANSMISSION.....	2-M3
[1] STRUCTURE	2-M3
[2] PUMP AND MOTOR	2-M5
[3] OIL FLOW AND VALVES.....	2-M6
[4] CONTROL LINKAGE	2-M13
4. SPEED SET DEVICE	2-M14
[1] SPEED SET LINKAGE.....	2-M14
(1) Speed Set.....	2-M14
(2) Speed Set Release.....	2-M15
5. RANGE GEAR SHIFT SECTION	2-M16
6. FRONT WHEEL DRIVE SECTION.....	2-M17
7. PTO SYSTEM.....	2-M18
[1] STRUCTURE	2-M18
[2] REAR PTO SECTION	2-M19
[3] REAR PTO / MID-PTO SECTION	2-M20
[4] MID-PTO SECTION	2-M21
[5] INDEPENDENT PTO	2-M22
(1) Hydraulic Circuit	2-M22
(2) Independent PTO Control Valve.....	2-M22
(3) Independent PTO Clutch.....	2-M23
(4) Independent PTO Lever "Engaged"	2-M24
(5) Independent PTO Lever "Disengaged"	2-M25
8. DIFFERENTIAL GEAR SYSTEM	2-M26
[1] DIFFERENTIAL FUNCTION	2-M26
[2] DIFFERENTIAL LOCK	2-M27

1. STRUCTURE




9Y1211156TRM001A

- (1) Front Case Section
- (2) Rear PTO and Mid PTO Shift Section
- (3) Front Wheel Drive Section
- (4) Hydrostatic Transmission Section
- (5) Range Gear Shift Section
- (6) Differential Gear Section

9Y1211156TRM0001US0

2. FRONT CASE



In this tractor, clutch disc is not installed.

The input flange (3) is installed on the clutch shaft (4).


Power from the engine is transmitted through the input flange (3) to the clutch shaft (4) and HST pump shaft.

- | | |
|--------------------|-----------------------|
| (1) Flywheel | (9) Front Drive Shaft |
| (2) Clutch Housing | (10) O-ring |
| (3) Input Flange | (11) Circlip |
| (4) Clutch Shaft | (12) Ball Bearing |
| (5) Ball Bearing | (13) O-ring |
| (6) Circlip | (14) Universal Joint |
| (7) Oil Seal | (15) Rear Drive Shaft |
| (8) Circlip | |

9Y1211156TRM0002US0

3. HYDROSTATIC TRANSMISSION


[1] STRUCTURE




Hydrostatic transmission consists of variable displacement piston pump, fixed displacement piston motor and valve system.

- | | |
|--|--|
| (1) Input Shaft (Pump Shaft) | (6) Check Port |
| (2) Housing | (7) Check Port |
| (3) Check and High Pressure Relief Valve (Reverse) | (8) Check and High Pressure Relief Valve (Forward) |
| (4) Center Section | (9) Output Shaft (Motor Shaft) |
| (5) Trunnion Shaft | |


9Y1211156TRM0003US0






- | | |
|----------------------------|---|
| (1) Cylinder Block (Motor) | (9) Piston |
| (2) Piston | (10) Cylinder Block (Pump) |
| (3) Thrust Collar | (11) Charge Relief Valve |
| (4) Motor Shaft | (12) Needle Bearing |
| (5) Thrust Ball Bearing | (13) Valve Plate |
| (6) Thrust Collar | (14) Cradle Bearing |
| (7) Pump Shaft | (15) Check and High Pressure Relief Valve |
| (8) Swashplate | |

9Y1211156TRM0004US0



[2] PUMP AND MOTOR



- (1) Piston
- (2) Cylinder

(3) Oil

- (A) Pump
- (B) Motor

(a) Swashplate


Pump and motor cylinder, each containing pistons, are connected by lines. Cylinders and lines are filled with oil. Piston ride against swashplates located in pump and motor.

In the pump, as the cylinder rotates, pistons move across the sloping face of swashplate and slide in or out of their cylinder bores. The oil forced out by the pump pistons, causes the motor pistons to slide out of their cylinder bores.

In the motor, sliding out of the cylinder and moving across the sloping face of swashplate, the pistons rotate the cylinder.

9Y1211156TRM0005US0

[3] OIL FLOW AND VALVES



9Y1211156TRM006A

- | | | | |
|------------------------------------|--|--|---|
| (1) Oil Filter Cartridge (for HST) | (7) Check and High Pressure Relief Valve (for Forward) | (11) Independent PTO Control Valve | (15) Oil Tank |
| (2) Swashplate | (8) Check and High Pressure Relief Valve (for Reverse) | (12) Oil Cooler | (16) Hydraulic Pump (for 3-points Hitch) |
| (3) Cylinder Block (for Pump) | (9) Neutral Valve (for Forward) | (13) Power Steering | (17) Hydraulic Control Valve (for 3-points Hitch) |
| (4) Charge Relief Valve | (10) Neutral Valve (for Reverse) | (14) Hydraulic Pump (for Power Steering, Independent PTO, HST) | (18) Oil Filter Cartridge |
| (5) Piston | | | |
| (6) Cylinder Block (for Motor) | | | |

(To be continued)

(Continued)


The pump and the motor are joined in a closed hydraulic circuit. Most of oil circulates with in the main oil circuit. A little oil lubricates and oozes out from the clearance between the moving parts in the case. Then oil in the main oil circuit of the HST needs to be supplied a want.

So all of oil fed from hydraulic pump flow to hydraulic transmission for charging and cooling.

The charge oil aids smooth operation of pistons for pump and motor. The charge oil passed to charge relief valve port. The rest of oil passed through the charge relief valve into the HST housing. And overflow oil from HST housing return to the transmission case.

9Y1211156TRM0006US0

Neutral



9Y1211156TRM006B

- | | | | |
|--|--|--|-----------------------------|
| (1) Oil Filter Cartridge (for HST) | (8) Check and High Pressure Relief Valve (for Reverse) | (14) Hydraulic Pump (for Power Steering, Independent PTO, HST) | A: Pump A Port |
| (2) Swashplate | (9) Neutral Valve (for Forward) | (15) Oil Tank | B: Pump B Port |
| (3) Cylinder Block (for Pump) | (10) Neutral Valve (for Reverse) | (16) Hydraulic Pump (for 3-points Hitch) | C: Motor C Port |
| (4) Charge Relief Valve | (11) Independent PTO Control Valve | (17) Hydraulic Control Valve (for 3-points Hitch) | D: Motor D Port |
| (5) Piston | (12) Oil Cooler | (18) Oil Filter Cartridge | a: High Pressure Oil |
| (6) Cylinder Block (for Motor) | (13) Power Steering | | b: Low Pressure Oil |
| (7) Check and High Pressure Relief Valve (for Forward) | | | c: Free Oil |
| | | | d: Suction Oil |

(To be continued)


(Continued)

When the speed control pedal is in "**NEUTRAL**", the variable swashplate is right-angles to the pump pistons. And the pump pistons only rotate with cylinder block (pump) without reciprocating.

Since the oil is not being pumped to the motor, the cylinder block (motor) is stationary. And the output shaft does not rotate.

9Y1211156TRM0007US0

Forward



9Y1211156TRM006C

- | | | | |
|--|--|--|-----------------------------|
| (1) Oil Filter Cartridge (for HST) | (8) Check and High Pressure Relief Valve (for Reverse) | (14) Hydraulic Pump (for Power Steering, Independent PTO, HST) | A: Pump A Port |
| (2) Swashplate | (9) Neutral Valve (for Forward) | (15) Oil Tank | B: Pump B Port |
| (3) Cylinder Block (for Pump) | (10) Neutral Valve (for Reverse) | (16) Hydraulic Pump (for 3-points Hitch) | C: Motor C Port |
| (4) Charge Relief Valve | (11) Independent PTO Control Valve | (17) Hydraulic Control Valve (for 3-points Hitch) | D: Motor D Port |
| (5) Piston | (12) Oil Cooler | (18) Oil Filter Cartridge | a: High Pressure Oil |
| (6) Cylinder Block (for Motor) | (13) Power Steering | | b: Low Pressure Oil |
| (7) Check and High Pressure Relief Valve (for Forward) | | | c: Free Oil |
| | | | d: Suction Oil |

(To be continued)

(Continued)

When the speed control pedal is stepped on and set to "**FORWARD**", the variable swashplate is tilted as shown in figure above.


As the pump cylinder block rotates with the input shaft, oil is forced out of pump port **A** at high pressure. As pressure oil from the pump cylinder block enters to motor port **C**, the pistons, which align with port **C**, are pushed against the swashplate and slide down the inclined surface.

Then the output shaft rotates with the motor cylinder block. This drives the machine forward and the angle of pump swashplate determines the output speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port **D** at low pressure and returns to the pump port **B**.

9Y1211156TRM0008US0

Reverse



9Y1211156TRM006D

- | | | | |
|--|--|--|-----------------------------|
| (1) Oil Filter Cartridge (for HST) | (8) Check and High Pressure Relief Valve (for Reverse) | (14) Hydraulic Pump (for Power Steering, Independent PTO, HST) | A: Pump A Port |
| (2) Swashplate | (9) Neutral Valve (for Forward) | (15) Oil Tank | B: Pump B Port |
| (3) Cylinder Block (for Pump) | (10) Neutral Valve (for Reverse) | (16) Hydraulic Pump (for 3-points Hitch) | C: Motor C Port |
| (4) Charge Relief Valve | (11) Independent PTO Control Valve | (17) Hydraulic Control Valve (for 3-points Hitch) | D: Motor D Port |
| (5) Piston | (12) Oil Cooler | (18) Oil Filter Cartridge | a: High Pressure Oil |
| (6) Cylinder Block (for Motor) | (13) Power Steering | | b: Low Pressure Oil |
| (7) Check and High Pressure Relief Valve (for Forward) | | | c: Free Oil |
| | | | d: Suction Oil |

(To be continued)

(Continued)


When the speed control pedal is stepped on and set to **"REVERSE"**, the variable swashplate is tilted as shown in figure above.

As the pump cylinder block rotates with the input shaft, oil is forced out of pump port **B** at high pressure. As pressure oil from the pump cylinder block enters to motor port **D**, the pistons, which align with port **D**, are pushed against the swashplate and slide down the inclined surface.

Then the output shaft rotates with the motor cylinder block. This drives the machine forward and the angle of pump swashplate determines the output speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port **C** at low pressure and returns to the pump port **A**.

9Y1211156TRM0009US0

[4] CONTROL LINKAGE

9Y1211156TRM007A

The HST pedal (5) and trunnion shaft (4) of swashplate are linked with the HST plate (7) and the neutral holder (3). As the front footrest of the pedal is depressed, the swashplate rotates and forward traveling speed increases. Depressing the rear footrest increases reverse traveling speed.

The roller (2) on the neutral holder arm (1) is held with spring seats and the detent of the neutral holder (3) so that the neutral holder (3) returns to neutral. When the pedal is released, the swashplate is returned to neutral with the neutral holder (3). The damper (8) connected to the HST plate (7) restricts the movement of the linkage to prevent abrupt operation or reversing.


- | | |
|--------------------|---------------|
| (1) Neutral Arm | (5) HST Pedal |
| (2) Roller | (6) Spring |
| (3) Neutral Holder | (7) HST Plate |
| (4) Trunnion Shaft | (8) Damper |

9Y1211156TRM0010US0

4. SPEED SET DEVICE

[1] SPEED SET LINKAGE

(1) Speed Set



9Y1211156TRM008A

- | | | | |
|---------------|----------------------|-----------------|-----------|
| (1) HST pedal | (3) Speed Set Lever | (5) Brake Pedal | (6) Tooth |
| (2) Lever | (4) Speed Set Holder | | |

The speed set device mainly consists of HST pedal holding section and HST pedal releasing section.

When the HST pedal (1) is set to the desired position, the lever (2) turns counter clockwise.


The speed set lever (3) moves to the **"ON"** position.

The speed set holder (4) turns counter clockwise.

On the other hand, since the lever (2) engages with the tooth (6) of the speed set holder (4), the HST pedal (1) is held at the desired set position until the brake pedals (5) are depressed by an operator.

9Y1211156TRM0011US0

(2) Speed Set Release



9Y1211156TRM008B

(1) HST pedal
(2) Lever

(3) Speed Set Lever
(4) Speed Set Holder

(5) Brake Pedal

(6) Brake Link

The speed set release is done by depressing the brake pedals (5).


When an operator depresses the brake pedal (5), the brake link (6) is pushed by the brake pedals (5).

When brake link (6) is pressed, the speed set holder (4) is released.

If you step on the HST pedal on the forward acceleration side, the speed set device will disengage.

9Y1211156TRM0012US0

5. RANGE GEAR SHIFT SECTION



Range gear shift lever (1) is located at left side fender.

Range gear shift lever (1) can select three speed range, low speed, mid speed and high speed.

Range gear shift lever (1) and 14T-21T-29T gear (6) are linked with range shift arm (3) and range shift fork (2) etc..

Three range gear shifts are selected by shifting the 14T-21T-29T gear (6) on 6T bevel pinion shaft to 23T-16T-14T sub shaft (7).

■ **Low Speed Position**


14T of 23T-16T-14T Sub Shaft (7) → 29T of 14T-21T-29T Gear (6) → 6T Bevel Pinion Shaft (4)

■ **Middle Speed Position**

16T of 23T-16T-14T Sub Shaft (7) → 21T of 14T-21T-29T Gear (6) → 6T Bevel Pinion Shaft (4)


■ **High Speed Position**

23T of 23T-16T-14T Sub Shaft (7) → 14T of 14T-21T-29T Gear (6) → 6T Bevel Pinion Shaft (4)





- | | |
|--------------------------------------|-----------------------|
| (1) Range Gear Shift Lever | L: "LOW" Range |
| (2) Range Shift Fork | M: "MID" Range |
| (3) Range Shift Arm | N: "NEUTRAL" Position |
| (4) 6T Bevel Pinion Shaft | H: "HIGH" Range |
| (5) 13T Gear (for Front Wheel Drive) | |
| (6) 14T-21T-29T Gear | |
| (7) 23T-16T-14T Sub Shaft | |

9Y1211156TRM0013US0



6. FRONT WHEEL DRIVE SECTION



Front wheel drive lever (1) is located at the right side fender.

Front wheel drive lever (1) and shifter are linked.

20T shifter gear (3) is located on the front wheel drive shifter (2).

2-wheel drive or 4-wheel drive is selected by changing the position of 20T shifter gear (3) reverse or forward.

When the front wheel drive lever (1) is set to "**4 Wheel Drive**" position, 20T shifter gear (3) slides forward, meshes the 13T gear (4) on the 6T bevel pinion shaft (5).


In this state, power from the 6T bevel pinion shaft (5) is transmitted through 20T shifter gear (3) to the front wheel drive shaft (2) and the front wheels.

- | | |
|-----------------------------|------------------------------------|
| (1) Front Wheel Drive Lever | A: "4 Wheel Drive" Position |
| (2) Front Wheel Drive Shaft | B: "2 Wheel Drive" Position |
| (3) 20T Shifter Gear | F: Power to Front Wheels |
| (4) 13T Gear | R: Power to Rear Wheels |
| (5) 6T Bevel Pinion Shaft | |

9Y1211156TRM0014US0

7. PTO SYSTEM

[1] STRUCTURE



9Y1210972TRM003B

The PTO shift lever (1) is located at left side fender. The PTO shift lever (1) and the PTO shift arm (2) are linked with the control rod (3).

The PTO shift arm (2) shifts the PTO shifter (6).

PTO gear section consists of three sections.


The first section is independent PTO section

(5).

The third section is mid-PTO selection section (10).

In this section, when the PTO shift lever is set to **"Mid-PTO"** shifter slides to the front side and shifter meshes to the housing.


The rear PTO shift does not rotate at this **"Mid-PTO"** position.



9Y1211156TRM012A

- (1) PTO Shift Lever
 - (2) PTO Shift Arm
 - (3) Control Rod
 - (4) Independent PTO Clutch
 - (5) PTO Position Selection Section
 - (6) PTO shifter
 - (7) 25T Mid Gear
 - (8) PTO Clutch Shaft
 - (9) 8T Rear PTO Shaft
 - (10) Mid PTO Selection Section
- R: "Rear PTO" Position**
R/M: "Rear PTO / Mid PTO" Position
M: "Mid PTO" Position

9Y1211156TRM0015US0



9Y1211156TRM013A

[2] REAR PTO SECTION



When the PTO shift lever (1) is set to **"Rear PTO"** (R) position, the PTO shift lever (1) pushes the control rod (3).



The control rod (3) pushes the PTO shift arm (2). In this state, the PTO shift arm (2) shifts the PTO shifter (5) forward. The inner spline of the PTO shifter (5) meshes the independent PTO shaft spline.

Power is transmitted from the independent PTO clutch to the rear PTO shaft as follows.

Independent PTO Clutch → PTO Shifter (5) → Independent PTO Shaft (4) → Rear PTO Shaft

- | | |
|---------------------------|---|
| (1) PTO Shift Lever | R: "Rear PTO" Position |
| (2) PTO Shift Arm | R/M: "Rear PTO / Mid PTO" Position |
| (3) Control Rod | M: "Mid PTO" Position |
| (4) Independent PTO Shaft | |
| (5) PTO Shifter | |
| (6) 25T Mid Gear | |
| (7) 20T Mid Gear Spline | |

9Y1211156TRM0016US0



[3] REAR PTO / MID-PTO SECTION



9Y1210972TRM003D

When the PTO shift lever (1) is set to **"Rear PTO / Mid PTO" (R/M)** position, the PTO shift lever (1) pulls the control rod.

The control rod (3) pulls the PTO shift arm (2).

In this state, the PTO shifter (5) keeps its position between the independent PTO shaft spline and the 20T mid gear spline (7).

In this position, the inner spline of the PTO shifter (5) meshes both independent PTO shaft spline and the 20T mid gear spline (7).


Power is transmitted from the independent PTO clutch to both the rear PTO shaft and the mid PTO shaft as follows.

■ **Rear PTO Section**

Independent PTO Clutch → PTO Shifter (5) → Independent PTO Shaft (4) → Rear PTO Shaft

■ **Mid PTO Section**

Independent PTO Clutch → PTO Shifter (5) → 25T Mid Gear → 26T Gear on Front Wheel Drive Shaft → 17T-26T Mid Gear → 30T Gear → 18T Mid PTO Shaft




9Y1211156TRM012C

- (1) PTO Shift Lever
- (2) PTO Shift Arm
- (3) Control Rod
- (4) Independent PTO Shaft
- (5) PTO Shifter
- (6) 25T Mid Gear
- (7) 20T Mid Gear Spline


- B:** To Rear PTO Shaft
- C:** To Mid PTO Shaft
- R:** "Rear PTO" Position
- R/M:** "Rear PTO / Mid PTO" Position
- M:** Mid PTO Position

9Y1211156TRM0017US0



9Y1211156TRM014B

[4] MID-PTO SECTION






When the PTO shift lever (1) is set to "Mid PTO" (M) position, the PTO shift lever pulls the control rod (3). The control rod (3) pulls the PTO shift arm (2).

In this state, the PTO shift arm (2) shifts the PTO shifter (5) reverse. The inner spline of the PTO shifter (5) meshes the 20T Mid PTO gear spline (7).

Power is transmitted from the independent PTO clutch to the Mid PTO shaft as follows.

Independent PTO Clutch → PTO Shifter (5) → 25T Mid Gear (6) → 26T Gear (8) → 17T-26T Mid Gear (10) → 30T Gear (11) → Mid PTO Shaft (12)




- (1) PTO Shift Lever
- (2) PTO Shift Arm
- (3) Control Rod
- (4) Independent PTO Shaft
- (5) PTO shifter
- (6) 25T Mid Gear
- (7) 20T Mid Gear Spline
- (8) 26T Gear
- (9) Front Wheel Drive Shaft
- (10) 17T-26T Mid Gear
- (11) 30T Gear
- (12) 17T Mid PTO Shaft

R: "Rear PTO" Position
R/M: "Rear PTO / Mid PTO" Position
M: Mid PTO Position

9Y1211156TRM0018US0

[5] INDEPENDENT PTO


(1) Hydraulic Circuit



- (1) PTO Clutch
- (2) Independent PTO Lever
- (3) Independent PTO Control Valve
- (4) Relief Valve
- (5) Oil Cooler
- (6) Oil Filter Cartridge (for HST)
- (7) HST
- (8) Power Steering
- (9) Hydraulic Pump (for HST, Power Steering and Independent PTO)
- (10) Oil Filter Cartridge
- (11) Hydraulic Pump (3-Points Hitch)
- (12) 3-Points Hitch

9Y1211156TRM0019US0

(2) Independent PTO Control Valve



Independent PTO control valve (2) is located at transmission case (1).

The independent PTO control valve (2) consists of PTO arm (3), poppet (5), ball (7) and etc..

The PTO arm (3) is connected to control rod (4) and the independent PTO lever.

The PTO arm (3) is moved to "OFF" or "ON" position by the independent PTO lever.

Oil passage in the PTO arm (3) is turned by the independent PTO lever.

When the PTO arm (3) is moved to "OFF" position, oil in the independent PTO control valve does not flow to the oil passage.


When the PTO arm (3) is moved to "ON" position, oil in the independent PTO control valve flow to the oil passage.

Poppet (5) and spring (6) operate as a relief valve.



- (1) Transmission Case
- (2) Independent PTO Control Valve
- (3) PTO Arm
- (4) Control Rod
- (5) Poppet
- (6) Spring
- (7) Ball
- (8) Spring

A: PTO arm "OFF" position
B: PTO arm "ON" position

9Y1211156TRM0020US0



(3) Independent PTO Clutch



Independent PTO clutch (2) is located behind the HST pump shaft (1) in the transmission case.

Independent PTO clutch (2) is operated with pressured hydraulic oil forced from the independent PTO control valve (3).

When independent PTO lever is shifted to **"ENGAGED"** position, hydraulic oil is forced through the transmission case inner passage (**A**) and PTO clutch shaft (6) to PTO clutch. In this state, power from HST pump shaft is transmitted through independent PTO clutch (2) to independent PTO clutch shaft (6).

When independent PTO lever is shifted to **"DISENGAGED"** position, hydraulic oil is not forced to the PTO clutch. In this state, power from HST pump shaft (1) is not transmitted to independent PTO clutch shaft (6).

- | | |
|-----------------------------------|------------------------------|
| (1) HST Pump Shaft | (7) Seal |
| (2) Independent PTO Clutch | (8) Bearing |
| (3) Independent PTO Control Valve | (9) Shifter |
| (4) HST Motor Shaft | (10) Clutch Discs and Plates |
| (5) Case | (11) Brake Plate 4 |
| (6) PTO Clutch Shaft | (12) Brake Disc |
| | (13) Brake Plate 2 |

9Y1211156TRM0021US0

(4) Independent PTO Lever "Engaged"




When the independent PTO lever (1) is shifted to the **"ENGAGED"** position, the PTO arm (3) is turned to **"ON"** position.

Hydraulic oil from **P** port flows through oil passage (7) of the PTO arm (3), oil passage **S1** in the transmission case (6) and oil passage **S2** in the PTO clutch shaft (5) to the PTO clutch (4).


Since the piston of the PTO clutch (4) is pushed by pressurized oil, clutch discs and clutch plates are pushed, and the PTO clutch (4) is engaged.

- | | |
|-----------------------------------|---|
| (1) Independent PTO Lever | A: "DISENGAGED" Position |
| (2) Independent PTO Control Valve | B: "ENGAGED" Position |
| (3) PTO Arm | P: Pump Port |
| (4) PTO Clutch | H: HST Port |
| (5) PTO Clutch Shaft | T: Tank Port |
| (6) Transmission Case | S1: Oil Passage (in the Transmission Case) |
| (7) Oil Passage (in the PTO Arm) | S2: Oil Passage (in the PTO Clutch Shaft) |

9Y1211156TRM0022US0



(5) Independent PTO Lever "Disengaged"



When the independent PTO lever (1) is shifted to the "DISENGAGED" position, the PTO arm (3) is turned to "OFF" position.

Hydraulic oil is stopped at the PTO arm (3). This oil flows to the HST port.


Oil in the PTO clutch (4) and the PTO clutch shaft (5) drains through oil passage S2, S1 and T port to the transmission case.

- | | |
|-----------------------------------|---|
| (1) Independent PTO Lever | A: "DISENGAGED" Position |
| (2) Independent PTO Control Valve | B: "ENGAGED" Position |
| (3) PTO Arm | P: Pump Port |
| (4) PTO Clutch | H: HST Port |
| (5) PTO Clutch Shaft | T: Tank Port |
| (6) Transmission Case | S1: Oil Passage (in the Transmission Case) |
| | S2: Oil Passage (in the PTO Clutch Shaft) |

9Y1211156TRM0023US0

8. DIFFERENTIAL GEAR SYSTEM

[1] DIFFERENTIAL FUNCTION



- | | | | |
|-------------------------|----------------------------|-------------------------------|----------------------------|
| (1) Spiral Bevel Pinion | (3) Differential Side Gear | (5) Differential Pinion Shaft | (7) Differential Side Gear |
| (2) Differential Pinion | (4) Spiral Bevel Gear | (6) Differential Pinion | (8) Differential Case |

■ During Straight Running

Rotation of the spiral bevel pinion (1) is transmitted to the spiral bevel gear (4) and differential case (8). When road resistance to the right and left wheels are equal, differential pinions (2), (6) and differential side gears (3), (7) are all rotate as a unit. Both rear axles received equal input, and both wheels turn at the same speed, allowing the tractor to straight ahead. At this time, differential pinions (2), (6) does not rotate around the differential pinion shaft (5).

■ During Turning


When the tractor turns, the road resistance to the inside tire increases (as if braking is applied to that side only).

In other words, if one of tires slows down, revolution difference is generated in the differential side gears (3), (7). When rotation of one differential side gear becomes lower than the other, differential pinions (2), (6) begin rotating around differential pinion shaft (5). The other differential side gear is increased in speed by the speed increment of differential pinion shaft (5). This means that rotation of one rear axle is slowed down and that of the other rear axle is increased. Thus, the tractor turns smoothly without power loss.

The combined number of revolutions of the right and left differential side gears is always twice that of the spiral bevel gear (4). When spiral bevel gear revolution is 100 min^{-1} (rpm), and if one of the differential side gears stops moving, the revolution of the other differential side gear becomes 200 min^{-1} (rpm) and if one rotates at 50 min^{-1} (rpm), the other rotates at 150 min^{-1} (rpm).

9Y1211156TRM0024US0

[2] DIFFERENTIAL LOCK



- | | | | |
|-----------------------------|-------------------------------------|-------------------------------|------------------------------------|
| (1) Differential Pinion | (4) Differential Gear Shaft (Right) | (6) Differential Case | (8) Spiral Bevel Pinion |
| (2) Shift Fork | (5) Differential Lock Clutch | (7) Differential Pinion Shaft | (9) Differential Gear Shaft (Left) |
| (3) Differential Lock Lever | | | |

When resistance to the right and the left tires are greatly different due to ground conditions or type of work, the tire with less resistance slips and prevents the tractor from moving ahead. To compensate for this drawback, the differential lock restricts the differential action and causes both rear axles to rotate as a unit.

When the differential lock pedal is stepped on, it causes the differential lock lever (3) to rotate. The differential lock lever (3) will move the shift fork (2) and the differential lock clutch (5) toward the spiral bevel pinion (8). The differential lock clutch (5) engages with the teeth of the differential case (6) to make the differential case (6) and the differential lock clutch (5) to rotate together as a unit.

Therefore, the differential pinions (1) are unable to rotate around the differential pinion shaft (7) and differential revolutions are transmitted to the right and the left differential gear shaft (4), (9).

9Y1211156TRM0025US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	2-S1
2. SERVICING SPECIFICATIONS	2-S5
3. TIGHTENING TORQUES	2-S7
4. CHECKING, DISASSEMBLING AND SERVICING	2-S8
[1] CHECKING AND ADJUSTING.....	2-S8
(1) HST	2-S8
(2) Independent PTO Control Valve.....	2-S13
[2] PREPARATION	2-S14
(1) Dismounting the Step and Floor Seat.....	2-S14
[3] DISASSEMBLING AND ASSEMBLING	2-S20
(1) Separating Engine and Clutch Housing.....	2-S20
(2) Front Case	2-S20
(3) Hydraulic Transmission (HST).....	2-S21
(4) PTO Clutch Case.....	2-S25
(5) Bevel Pinion Shaft	2-S25
(6) Sub Gear Shaft.....	2-S26
(7) Front Wheel Drive Shaft	2-S27
(8) Independent PTO Clutch Shifter.....	2-S29
(9) Independent PTO Clutch	2-S30
(10)Mid-PTO Section	2-S34
(11)Differential Gear Section	2-S36
[4] SERVICING	2-S38
(1) HST	2-S38
(2) Independent PTO Clutch	2-S40
(3) Transmission Case.....	2-S41
(4) Differential Gear	2-S42

1. TROUBLESHOOTING

HYDROSTATIC TRANSMISSION

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page	
System Will Not Operate in Either Direction	1. Oil level is low	Check oil level or fill oil to proper level	G-28	
	2. Speed control pedal linkage damaged	Repair linkage	2-M13	
	3. Charge pressure is too low	Solution order		G-26, G-29
		1. Replace oil filter cartridge		
		2. Check charge pressure		2-S8
		3. Inspect or flush charge relief valve		2-S24
4. Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve		2-S23	
5. Component parts damaged	Replace hydrostatic transmission assembly		2-S20	
Vibration and Noise	1. Oil level is too low	Check oil level or fill oil to proper level	G-28	
	2. Speed control pedal linkage damaged	Repair linkage	2-M13	
	3. Charge pressure is too low	Solution order		G-26, G-29
		1. Replace oil filter cartridge		
		2. Check charge pressure		2-S8
		3. Inspect or flush charge relief valve		2-S24
4. Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve		2-S23	
5. Component part is damaged	Replace hydrostatic transmission assembly		2-S20	
Loss of Power	1. Oil level is low	Check oil level or fill oil to proper level	G-28	
	2. Speed control pedal linkage damaged	Repair linkage	2-M13	
	3. Charge pressure is too low	Solution order		G-26, G-29
		1. Replace oil filter cartridge		
		2. Check charge pressure		2-S8
		3. Inspect or flush charge relief valve		2-S24
4. Check and high pressure relief valve does not move smoothly	Inspect or replace check and high pressure relief valve		2-S23	
5. Component parts damaged	Replace hydrostatic transmission assembly		2-S20	
Transmission Oil Over Heats	1. Low transmission oil level	Fill transmission oil level up to proper level	G-28	
	2. Radiator net clogged	Clean radiator net	G-17	
	3. Improper charge pressure	Solution order		2-S9
		1. Check high relief pressure		
		2. Replace transmission oil filter cartridge		G-29
3. Replace check and high pressure relief valve			2-S23	
	4. Inspect and replace charge relief valve		2-S24	

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Machine Will Not Stop in Neutral Position	1. Speed control linkage is out of adjustment or sticking	Solution order 1. Repair or replace linkage	2-M13
		2. Adjust neutral adjuster	2-S12
System Operates in One Direction Only	1. Speed control linkage damaged	Repair or replace linkage	2-M13
	2. Check and high pressure relief valve damaged	Replace check and high pressure relief valve	2-S23

FRONT CASE

Symptom	Probable Cause	Solution	Reference Page
Noise From Front Case	1. Clutch shaft spline worn	Replace clutch shaft	2-S21
	2. Bearing Worn	Inspect or replace bearing	2-S21

TRANSMISSION CASE SECTION

Symptom	Probable Cause	Solution	Reference Page	
Noise From Front Transmission	1. Transmission oil insufficient	Check transmission oil	G-8	
	2. Gear worn or broken	Replace transmission gear	2-S20	
	3. Improper backlash between spiral bevel pinon and bevel gear	Inspect or adjust backlash	2-S44	
	4. Improper backlash between differential pinion and differential side gear	Inspect or adjust backlash	2-S43	
	5. Bearings worn	Inspect or replace bearing	2-S41	
	6. PTO clutch damaged	Solution order 1. Check PTO control valve setting pressure		2-S13
		2. Inspect clutch disc or plate		2-S31
3. Replace PTO clutch or other parts			2-S30	

INDEPENDENT PTO

Symptom	Probable Cause	Solution	Reference Page
PTO Clutch Slip	1. Operating pressure is low	Solution order 1. Check PTO control valve setting pressure	2-S13
		2. Inspect clutch disc or plate	2-S31
		3. Replace PTO clutch or other parts	2-S30
	2. Independent PTO control valve malfunctioning	Solution order 1. Check PTO control valve setting pressure	2-S13
		2. Inspect or replace poppet or PTO control valve	2-S13
	3. Clutch disc or drive plate excessively worn	Solution order 1. Check PTO control valve setting pressure	2-S13
		2. Inspect or replace clutch disc or plate	2-S31
	4. Deformation of piston or return plate	Solution order 1. Inspect return plate or piston	2-S41
2. Replace return plate or piston		2-S31	
PTO Shaft Does Not Rotate	1. PTO clutch malfunctioning	Solution order 1. Check PTO control valve setting pressure	2-S13
		2. Replace PTO clutch or other parts	2-S30
PTO Clutch Operating Pressure is Low	1. Transmission oil improper or insufficient	Check transmission oil	G-8
	2. Relief valve malfunctioning	Solution order 1. Check PTO control valve setting pressure	2-S13
		2. Replace poppet	2-S13
PTO Clutch Drags	1. Brake plate excessively worn	Replace brake plate	2-S31
	2. Return spring weaken or broken	Inspect or replace return spring	2-S41

DIFFERENTIAL CASE SECTION

Symptom	Probable Cause	Solution	Reference Page
Excessive or Unusual Noise at All Time	1. Insufficient or improper type of transmission fluid used	Check transmission oil	G-8
	2. Improper backlash between spiral bevel pinion and bevel gear	Inspect or adjust backlash	2-S44
	3. Improper backlash between differential pinion and differential side gear	Inspect or adjust backlash	2-S43
	4. Bearing worn	Inspect or replace bearing	2-S41
Noise while Turning	1. Differential pinions or differential side gears worn or damaged	Inspect or replace differential pinion or differential side gear	2-S38
	2. Differential lock binding (does not disengage)	Repair or replace differential lock shifter	3-S4
	3. Bearing worn	Inspect or replace bearing	2-S21
Differential Lock Can Not Be Set	1. Differential lock shift fork damaged	Replace differential shift fork	3-S4
	2. Differential lock shifter mounting pin damaged	Replace differential lock shifter	3-S4
Differential Lock Pedal Does Not Return	1. Differential lock fork shaft rusted	Repair or replace differential lock fork shaft	3-S4
	2. Differential lock pedal return spring weakened or damaged	Replace return spring	2-S41

9Y1211156TRS0001US0

2. SERVICING SPECIFICATIONS

HYDROSTATIC TRANSMISSION (HST)

Item		Factory Specification	Allowable Limit
Charge Relief Valve	Setting Pressure	0.4 to 0.6 MPa 4 to 6 kgf/cm ² 60 to 80 psi	–
Check and High Pressure Relief Valve	Setting Pressure [Relief Valve]	23 to 25 MPa 240 to 250 kgf/cm ² 3400 to 3600 psi	–
Relief Valve	Readjusting Pressure	23 to 25 MPa 240 to 250 kgf/cm ² 3400 to 3600 psi	–
Piston to Cylinder Block Bore (HST)	Clearance	0.02 to 0.03 mm 0.0008 to 0.001 in.	0.04 mm 0.0016 in.

INDEPENDENT PTO CLUTCH

Item		Factory Specification	Allowable Limit
Clutch Disc	Thickness	1.70 to 1.90 mm 0.067 to 0.075 in.	1.55 mm 0.061 in.
Clutch Plate	Thickness	1.15 to 1.25 mm 0.045 to 0.049 in.	1.10 mm 0.043 in.
Pressure Plate	Thickness	1.95 to 2.05 mm 0.0768 to 0.0807 in.	1.8 mm 0.071 in.
Piston Return Spring	Free Length	44.0 mm 1.73 in.	–
	Load / Length	638.7 N / 26 mm 65.13 kgf / 26 mm 143.6 lbf / 1.02 in.	539.4 N / 26 mm 55 kgf / 26 mm 121.3 lbf / 1.02 in.

TRANSMISSION CASE AND DIFFERENTIAL GEAR

Item		Factory Specification	Allowable Limit
Shift Fork to Shifter Groove	Clearance	0.10 to 0.35 mm 0.004 to 0.014 in.	0.5 mm 0.020 in.
Differential case to Differential Side Gear	Clearance	0.025 to 0.066 mm 0.0010 to 0.0026 in.	0.30 mm 0.0118 in.
• Differential Case (Spiral Bevel Gear)	I.D.	32.000 to 32.025 mm 1.2598 to 1.2608 in.	–
• Differential Side Gear Boss	O.D.	31.959 to 31.975 mm 1.2582 to 1.2589 in.	–
Differential Pinion to Differential Pinion Shaft	Clearance	0.048 to 0.084 mm 0.0019 to 0.0033 in.	0.30 mm 0.0118 in.
• Differential Pinion	I.D.	16.032 to 16.050 mm 0.63119 to 0.63188 in.	–
• Differential Pinion Shaft	O.D.	15.966 to 15.984 mm 0.62859 to 0.62929 in.	–
Differential Pinion to Differential Side Gear	Backlash	0.1 to 0.3 mm 0.004 to 0.012 in.	0.4 mm 0.016 in.
Spiral Bevel Pinion Shaft	Movements at Shaft Directions	Approximately 0 mm 0 in.	–
Spiral Bevel Pinion to Spiral Bevel Gear	Backlash	0.10 to 0.30 mm 0.0039 to 0.012 in.	–

9Y1211156TRS0002US0

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)



Item	N·m	kgf·m	lbf·ft
Checking port plug	29 to 44	3.0 to 4.5	21.7 to 32.5
Hex. socket head screw	24.5 to 29.5	2.5 to 3.0	18.1 to 21.7
Steering wheel mounting nut	20 to 40	2.1 to 4.0	15 to 29
3-point hitch shaft setting screw	15 to 20	1.6 to 2.0	11 to 14
3-point hitch shaft setting screw lock nut	43 to 47	4.4 to 4.7	32 to 34
ROPS mounting bolt (M12)	83.4 to 93.2	8.5 to 9.5	61 to 69
ROPS mounting bolt (SEMS bolt)	47.1 to 56.9	4.8 to 5.8	34.7 to 42
Front loader valve pipe joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe joint bolt	48 to 70	4.9 to 7.1	36 to 51
Frame support plate mounting bolt (M12)	64 to 74	6.6 to 7.5	48 to 54
Sub frame mounting bolt (M12)	80 to 90	8.2 to 9.1	59 to 66
Sub frame mounting bolt (M14)	126 to 150	12.9 to 15.2	93.0 to 110
Sub frame mounting bolt (M10)	40 to 45	4.1 to 4.7	30 to 34
Front case mounting nut for aluminum material (M8)	17.7 to 20.5	1.8 to 2.1	13.1 to 15.1
Front case mounting bolt for aluminum material (M10)	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
HST assembly mounting bolt (M10, aluminum)	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
Center section mounting hex. bolt (M10, aluminum)	49 to 59	5.0 to 6.0	37 to 43
Check and high pressure relief valve plug	59 to 78	6.1 to 7.9	44 to 57
Transmission case mounting bolt (M10) and nut	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
Hydraulic cylinder mounting bolt (M10) and nut	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
Rear axle case (LH and RH) mounting bolt for aluminum material (M10)	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
Rear PTO cover mounting bolt for aluminum material (M10)	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
Differential bearing holder mounting bolt for aluminum material (M8)	17.7 to 20.5	1.8 to 2.1	13.1 to 15.1
Spiral bevel gear UBS screw	37.5 to 42.5	3.83 to 4.33	27.7 to 31.3
Screw (M3)	1.5	0.15	1.1
Valve plug	59 to 78	6.1 to 7.9	44 to 57

9Y1211156TRS0003US0

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING

(1) HST



Charge Relief Pressure

⚠ CAUTION

- When checking, park the tractor on flat ground and fully engage the parking brake.

1. Remove the cover (1).
2. Remove the plug from P1 port (reverse) (2) or P2 port (forward) (3).

■ NOTE

- If the plug is tight to remove, warm up the plug by a hair drier etc..

3. Install the adaptor (4) to P1 port (2) or P2 port (3).
4. Install the cable (7) and low pressure gauge to the adaptor (4).

Engine speed	Rated speed
Range gear shift position	Neutral
HST pedal	Neutral

5. Start the engine and warm the oil before testing.
6. Change the range gear shift lever (5) to "NEUTRAL" position.
7. Operate the engine at the rated speed.
8. Release the foot from the HST pedal (6).
9. Read the low pressure gauge to measure the charge relief pressure.
10. If the measurement is not same as factory specification, check the charge relief valve and the related hydraulic components.

Charge pressure	Factory specification	0.4 to 0.6 MPa 4 to 6 kgf/cm ² 60 to 80 psi
-----------------	-----------------------	--

■ NOTE

- Low pressure gauge is 2.9 MPa (30 kgf/cm², 427 psi) full scale.

(When reassembling)


- Apply liquid lock (Three Bond 1324B or its equivalent) to the plug.

Tightening torque	Checking port plug	29 to 44 N-m 3.0 to 4.5 kgf-m 21.7 to 32.5 lbf-ft
-------------------	--------------------	---

- (1) Cover
- (2) P1 port (reverse)
- (3) P2 port (forward)
- (4) Adaptor
- (5) Range Gear Shift Lever
- (6) HST Pedal
- (7) Cable

- L: Low speed position
M: Medium speed position
N: Neutral position
H: High speed position

9Y1211156TRS0004US0



High Pressure Relief Valve (Reverse)

⚠ CAUTION

- When checking, park the tractor on flat ground and fully engage the parking brake.

1. Remove the cover (1).
2. Remove the plug from P1 port (reverse) (2).

■ NOTE

- If the plug is tight to remove, warm up the plug by a hair drier etc..

3. Install the adaptor (4) to P1 port (2).
4. Install the cable (7) and high pressure gauge.

Engine speed	Rated speed
Range gear shift position	High
HST pedal	Reverse
Brake pedal	Depressed

5. Start the engine and warm the oil before testing. Check to see that parking brake is applied.
6. Place the range gear shift lever (5) to "HIGH" position.
7. Operate the engine at the rated speed.
8. Depress the rear side pedal of the HST pedal (6).
9. Read the high pressure gauge to measure the high pressure relief valve pressure.
10. If the measurement is not the same as factory specification, check the check and high pressure relief valve assembly.

Check and high relief pressure (Oil temperature at 50 °C (122 °F))	Factory specification	23 to 25 MPa 240 to 250 kgf/cm ² 3400 to 3600 psi
--	-----------------------	--

■ IMPORTANT

- Measure quickly so that the relief valve may not be in operation more than 10 seconds.

■ NOTE

- High pressure gauge is 40 MPa (400 kgf/cm², 5800 psi) full scale.
- Engine speed: Rated speed
- Oil temperature: 50 °C (122 °F)

(When reassembling)



- Apply liquid lock (Three Bond 1324B or its equivalent) to the plug.

Tightening torque	Checking port plug	29 to 44 N·m 3.0 to 4.5 kgf·m 21.7 to 32.5 lbf·ft
-------------------	--------------------	---

- (1) Cover
- (2) P1 port (reverse)
- (3) P2 port (forward)
- (4) Adaptor
- (5) Range Gear Shift Lever
- (6) HST Pedal
- (7) Cable

- L:** Low speed position
M: Medium speed position
N: Neutral position
H: High speed position

9Y1211156TRS0005US0



High Pressure Relief Valve (Forward)

CAUTION

- When checking, park the tractor on flat ground and fully engage the parking brake.

1. Remove the cover (1).
2. Remove the plug from P2 port (forward) (3).

NOTE

- If the plug is tight to remove, warm up the plug by a hair drier etc..

3. Install the adaptor (4) to P2 port (3).
4. Install the cable (7) and high pressure gauge.

Engine speed	Rated speed
Range gear shift position	High
HST pedal	Forward
Brake pedal	Depressed

5. Start the engine and warm the oil before testing. Check to see that parking brake is applied.
6. Place the range gear shift lever (5) to "HIGH" position.
7. Operate the engine at the rated speed.
8. Depress the front side pedal of the HST pedal (6).
9. Read the high pressure gauge to measure the high pressure relief valve pressure.
10. If the measurement is not same as factory specification, check the check and high pressure relief valve assembly.

Check and high relief pressure (Oil temperature at 50 °C (122 °F))	Factory specification	23 to 25 MPa 240 to 250 kgf/cm ² 3400 to 3600 psi
--	-----------------------	--

IMPORTANT

- Measure quickly so that the relief valve may not be in operation more than 10 seconds.

NOTE

- High pressure gauge is 40 MPa (400 kgf/cm², 5800 psi) full scale.
- Engine speed: Rated speed
- Oil temperature: 50 °C (122 °F)



(When reassembling)

- Apply liquid lock (Three Bond 1324B or its equivalent) to the plug.

Tightening torque	Checking port plug	29 to 44 N·m 3.0 to 4.5 kgf·m 21.7 to 32.5 lbf·ft
-------------------	--------------------	---

- | | |
|----------------------------|---------------------------------|
| (1) Cover | L: Low speed position |
| (2) P1 port (reverse) | M: Medium speed position |
| (3) P2 port (forward) | N: Neutral position |
| (4) Adaptor | H: High speed position |
| (5) Range Gear Shift Lever | |
| (6) HST Pedal | |
| (7) Cable | |

9Y1211156TRS0006US0



Readjustment of Relief Valve (When the HST does not work due to its loose hexagon socket head screw)

■ **IMPORTANT**

- The KUBOTA does not recommend the readjustment of relief valve. And KUBOTA will recommend to replace with genuine parts.
- As the HST may be damaged if the pressure is set to higher by mistake, be careful when adjusting it.

■ **NOTE**

- The relief pressure is set in between 23 to 25 MPa (240 to 250 kgf/cm², 3400 to 3600 psi) when shipped from the factory.

1. Measure the pre-adjustment distance "A".
2. Compress the spring of the relief valve with a relief valve assembling tool (3).
3. Then, find the distance "A" by turning the poppet (4) with a screwdriver.

Reference: The distance "A" changes by about 0.5 mm (0.0197 in.) per one turn of the poppet (4).

4. Repeat the same operation a few times to find the distance "A" as it is difficult to acquire at the first time.
5. After finding the distance "A", hold the setscrew (6) to a vice and fasten the hexagon socket head screw (2) with specified torque.

On this occasion, use a copper plate, etc. for the vice jaws not to damage the setscrew (6).

6. Install the relief valve in the HST.
7. Check the relief pressure as indicated in page 7-S9. The distance "A" is for refresh only. Make sure to check the relief pressure after readjustment.
8. If the relief pressure does not fall within the readjustment pressure range, repeat the processes of the above item 1 onward.



Tightening torque	Hex. socket head screw	24.5 to 29.5 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 lbf·ft
-------------------	------------------------	---

Relief valve readjusting pressure	Factory specification	23 to 25 MPa 240 to 250 kgf/cm ² 3400 to 3600 psi
-----------------------------------	-----------------------	--

Distance "A"	Reference value	38.5 to 38.6 mm 1.516 to 1.519 in.
--------------	-----------------	---------------------------------------

- (1) Relief Valve Assembly
- (2) Hexagon Socket Head Screw
- (3) Relief Valve Assembling Tool
- (4) Poppet
- (5) Valve Seat
- (6) Setscrew

9Y1211156TRS0007US0



Adjusting Neutral

1. Disengage the front wheel drive lever. (Drive only rear wheels.)
2. Lift the rear of the tractor so that the rear wheels are off the ground and operate the engine at low idling and drive only rear wheels.
3. Slightly loosen the neutral adjuster setting screw (2).
4. Rotate the neutral adjuster (1) clockwise so the rear wheels turn reverse.
5. Then rotate it counterclockwise until wheels stop completely.
6. Put a mark on the center frame aligning the groove (3) on neutral adjuster.
7. Rotate the neutral adjuster (1) counterclockwise so the rear wheels turn forward.
8. Then rotate it clockwise until wheels stop completely.
9. Put a mark on the center frame aligning the groove (3) on neutral adjuster.
10. Hold the neutral adjuster so its groove is at the middle of the marks and tighten the setting screw (2).



NOTE

- When the wheels tend to turn forward, rotate neutral adjuster clockwise.
- When the wheels tend to turn reverse, rotate neutral adjuster counterclockwise.

(1) Neutral Adjuster	1: Neutral Adjustment Stage 1
(2) Neutral Adjuster Setting Screw	2: Neutral Adjustment Stage 2
(3) Groove	3: Neutral Adjustment Stage 3
(4) Neutral Spring	4: Neutral Adjustment Stage 4

9Y1211156TRS0008US0

(2) Independent PTO Control Valve



Independent PTO Control Valve Setting Pressure

1. Remove the plug (2) with a hexagon wrench.
2. Install the adapter (3) to the independent PTO control valve (1).
3. Connect the cable and the pressure gauge to the adapter (3).
4. Start the engine and set at the maximum speed. (Pressure at **"ENGAGED"** position)
5. Move the independent PTO lever (9) to **"ENGAGED"** position **A**.
6. Measure the pressure. (Pressure at **"DISENGAGED"** position)
7. Move the independent PTO lever (9) to position **B**.
8. Measure the pressure.
9. If the pressure is not the factory specifications, adjust setting pressure with (the adjusting) shims.

Independent PTO valve setting pressure	Independent PTO lever "ENGAGED" position	1.1 to 1.5 MPa 11.2 to 15.3 kgf/cm ² 160 to 218 psi
	Independent PTO lever "DISENGAGED" position	0 MPa 0 kgf/cm ² 0 psi

Condition

- Engine speed: 2900 min⁻¹ (rpm)
- Oil temperature: 50 °C (122 °F)

- | | |
|-----------------------------------|---------------------------|
| (1) Independent PTO Control Valve | (7) Plug |
| (2) Plug | (8) PTO Arm |
| (3) Adapter | (9) Independent PTO Lever |
| (4) Poppet | |
| (5) Spring | |
| (6) O-ring | |
- A: ENGAGED Position**
B: DISENGAGED Position

9Y1211156TRS0009US0

[2] PREPARATION

(1) Dismounting the Step and Floor Seat



Battery Cable

1. Open the bonnet.
2. Disconnect the battery negative cable (1).

■ NOTE

- **When disconnecting the battery cables, disconnect the grounding cable first. When connecting, the positive cable first.**

(1) Battery Negative Cable

9Y1211156TRS0010US0



Draining Coolant

⚠ CAUTION

- **Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.**




1. Stop the engine and let cool down.
2. Disconnect the radiator hose (1) at the engine side.
3. Remove the radiator cap to completely drain the coolant.
4. After all coolant is drained, connect the radiator hose (1).

(When reassembling)

Coolant	Capacity	3.8 L 4.0 U.S.qts 3.3 Imp.qts

(1) Radiator Hose

9Y1211156ENS0024US0



Draining Transmission Fluid

CAUTION

- Stop the engine before checking and changing the transmission fluid.
1. Place the oil pan under the tractor.
 2. Remove the drain plugs (1), (3), (5) at the mid-PTO shaft and at the bottom of the rear axle cases (4), (6).
 3. Drain the transmission fluid.
 4. After draining the transmission fluid, reinstall the drain plugs (1), (3), (5).

IMPORTANT

- Use only KUBOTA UDT oil. Use of other oils may damage the transmission or hydraulic system. Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.
- Never work the tractor immediately after changing the transmission oil. Keep the engine at medium speed for a few minutes to prevent damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	15 L 4.0 U.S.gals 3.3 Imp.gals
-----------------------------	--------------------------------------

- | | |
|-------------------|---------------------------|
| (1) Drain Plug | (4) Rear Axle Case (L.H.) |
| (2) Mid-PTO Shaft | (5) Drain Plug |
| (3) Drain Plug | (6) Rear Axle Case (R.H.) |

9Y1211156ENS0023US0

Bonnet and Side Cover

1. Open the bonnet (1).
2. Disconnect the connector for head light and remove the clamp (2).
3. Remove the snap pin and bonnet (1).
4. Remove the side covers (3).

- | | |
|------------|----------------|
| (1) Bonnet | (3) Side Cover |
| (2) Clamp | |

9Y1211156TRS0011US0

Steering Wheel

1. Remove the steering wheel cap.
2. Remove the steering wheel mounting nut and remove the steering wheel (1) with a steering wheel puller (2).

(When reassembling)

Tightening torque	Steering wheel mounting nut	20 to 40 N·m 2.1 to 4.0 kgf·m 15 to 29 lbf·ft
-------------------	-----------------------------	---

- | | |
|--------------------|---------------------------|
| (1) Steering Wheel | (2) Steering Wheel Puller |
|--------------------|---------------------------|

9Y1211156TRS0012US0



Panel Lower Cover

1. Remove the panel lower cover mounting bolts and disconnect the key switch connector.
2. Remove the panel lower cover (1).

(1) Panel Lower Cover

9Y1211156TRS0013US0



HST Pedal, Floor Mat and Front Cover

1. Remove the HST pedal mounting bolts (2).
2. Remove the HST pedal (1).
3. Remove the lower adjusting knob (3).
4. Remove the front cover (4), (5).
5. Remove the floor mat (6).

(1) HST Pedal

(4) Front Cover


(2) Bolt

(5) Front Cover

(3) Lower Adjusting Knob

(6) Floor Mat

9Y1211156TRS0014US0



3-Point Linkage

1. Remove the top link (1), lift rods (2), lower links (3) and stabilizers (4).
2. Remove the collars (5), stabilizer bracket (6) and 3-point hitch shaft (7).

(When reassembling)

Tightening torque	3-point hitch shaft setting screw	15 to 20 N·m 1.6 to 2.0 kgf·m 11 to 14 lbf·ft
	3-point hitch shaft setting screw lock nut	43 to 47 N·m 4.4 to 4.7 kgf·m 32 to 34 lbf·ft

(1) Top Link

(5) Collar

(2) Lift Rod


(6) Stabilizer Bracket




(3) Lower Link

(7) 3-Point Hitch Shaft

(4) Stabilizer

9Y1211156TRS0015US0





ROPS

1. Disconnect the tail light connectors (1) and turn signal light connectors.
2. Remove the tail lights (2).
3. Remove the spring pins (3).
4. Remove the bolt (4).
5. Remove the upper frame (5) from lower frames (6).
6. Remove the ROPS mounting bolts (7), (8) and the lower frames (6).

(When reassembling)

- Split the split pin (3) securely as shown in the photo.

NOTE

- **Do not firmly tighten all screws until most components are attached.**

Tightening torque	ROPS mounting bolt (M12)	83.4 to 93.2 N·m 8.5 to 9.5 kgf·m 61 to 69 lbf·ft
	ROPS mounting bolt (SEMS Bolt)	47.1 to 56.9 N·m 4.8 to 5.8 kgf·m 34.7 to 42 lbf·ft

- | | |
|--------------------------|-----------------|
| (1) Tail Light Connector | (5) Upper Frame |
| (2) Tail Light | (6) Lower Frame |
| (3) Spring Pin | (7) Bolt |
| (4) Bolt | (8) SEMS Bolt |

9Y1211156TRS0016US0






Seat and Fenders

1. Remove the seat (1) and the lever grips (2).
2. Disconnect the electrical socket connector (5).
3. Remove the fender LH (3).
4. Remove the fender RH (4).
5. Remove the both side steps and seat under cover (8).
6. Disconnect the seat switch connector (7).
7. Remove the seat support (6).

- | | |
|----------------|---------------------------------|
| (1) Seat | (5) Electrical Socket Connector |
| (2) Lever Grip | (6) Seat Support |
| (3) Fender LH | (7) Seat Switch Connector |
| (4) Fender RH | (8) Seat Under Cover |

9Y1211156TRS0017US0





Hydraulic Pipes and Others

1. Remove the clamps (1).
2. Disconnect the suction pipe (2) and delivery pipe (3).
3. Disconnect the loader valve pipes (4).
4. Disconnect the independent PTO pipe (5).
5. Remove the right side brake rod (6) and sub frame (7).
6. Remove the left side brake rod (6) and sub frame (7).
7. Disconnect the HST pedal switch connector (8).
8. Remove the frame support plate (9) and spring (10).
9. Remove the HST damper (11) and plate (12).

Tightening torque	Front loader valve pipe joint	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	Frame support plate mounting bolt (M12)	64 to 74 N·m 6.6 to 7.5 kgf·m 48 to 54 lbf·ft
	Sub frame mounting bolt (M12)	80 to 90 N·m 8.2 to 9.1 kgf·m 59 to 66 lbf·ft
	Sub frame mounting bolt (M14)	126 to 150 N·m 12.9 to 15.2 kgf·m 93.0 to 110 lbf·ft
	Sub frame mounting bolt (M10)	40 to 45 N·m 4.1 to 4.7 kgf·m 30 to 34 lbf·ft

- | | |
|-----------------------------------|--------------------------------|
| (1) Clamp | (7) Sub Frame |
| (2) Suction Pipe | (8) HST Pedal Switch Connector |
| (3) Delivery Pipe | (9) Plate |
| (4) Front Loader Valve Pipe Joint | (10) Spring |
| (5) Independent PTO Pipe | (11) HST Damper |
| (6) Brake Rod | (12) HST Plate |

9Y1211156TRS0018US0

[3] DISASSEMBLING AND ASSEMBLING

(1) Separating Engine and Clutch Housing


- See page 1-S23.

9Y1211156TRS0019US0

(2) Front Case



3TBAAAG3P058A



3TBAAAG3P059A

Clutch Housing

1. Support the engine securely.
2. Remove the front case mounting bolts (1).
3. Remove the front case (3) from the engine.

(When reassembling)


- Apply liquid gasket (Three Bond 1206D or equivalent) to the joint face of the engine and the front case.

Tightening torque	Front case mounting nut for aluminum material (M8)	17.7 to 20.5 N·m 1.8 to 2.1 kgf·m 13.1 to 15.1 lbf·ft
	Front case mounting bolt for aluminum material (M10)	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft


- (1) Bolt
- (2) Engine Rear-End Plate
- (3) Front Case
- (4) Groove (for liquid gasket)

(A) Front Case Corner


9Y1211156TRS0020US0



3TBAAAG3P060A



3TBAAAG3P061A



Clutch Shaft and Ball Bearing

1. Remove the oil seal (6).
2. Remove the circlip (4), (5).
3. Remove the clutch shaft (2) from the front case (1).

- | | |
|------------------|----------------------|
| (1) Front Case | (4) External Circlip |
| (2) Clutch Shaft | (5) Internal Circlip |
| (3) Ball Bearing | (6) Oil Seal |

9Y1211156TRS0021US0

(3) Hydraulic Transmission (HST)




HST Assembly

1. Remove the HST mounting bolts (2).
2. Separate the HST assembly (1) from the transmission.

(When reassembling)


- Install the O-ring (3) to the transmission case.
- Apply liquid gasket (Three Bond 1206D or equivalent) to the groove (4) of the transmission case.

Tightening torque	HST assembly mounting bolt (M10, aluminum)	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft
-------------------	--	---



- | | |
|--------------------------------|--------------------------------|
| (1) HST Assembly | (3) O-ring |
| (2) HST Assembly Mounting Bolt | (4) Groove (for Liquid Gasket) |

9Y1211156TRS0022US0






Plate Push Rod, Neutral Arm and Neutral Holder

1. Remove the plate push rod (1).
2. Remove the spring (4).
3. Remove the neutral arm mounting bolt.
4. Loosen the bolt of the neutral holder (3).
5. Remove the neutral holder (3).

- (1) Plate Push Rod
- (2) Neutral Arm
- (3) Neutral Holder
- (4) Spring

9Y1211156TRS0023US0



Center Section 1

1. Remove the center section mounting hex. bolts (2).
2. Separate the HST housing (3) from the center section (1).



(When reassembling)

- Use a new gasket.
- Install the poppet to the center section (1). Do not drop the spring (5).
- Check the knock pin.
- Hold the gasket with the hex. bolts (2) not to drop the gasket (4).

Tightening torque	Center section mounting hex. bolt (M10, aluminum)	49 to 59 N·m 5.0 to 6.0 kgf·m 37 to 43 lbf·ft
-------------------	---	---

- (1) Center Section
- (2) Hex. Bolt
- (3) HST Housing
- (4) Gasket
- (5) Spring
- (6) Poppet

9Y1211156TRS0024US0



Oil Seals and Needle Bearings


1. Remove the needle bearing (2).
2. Remove the oil seals (1).


(When reassembling)

- After checking or changing the oil seals, apply the bearing with hydrostatic transmission oil and the oil seal with grease.

- (1) Oil Seal
- (2) Needle Bearing

9Y1211156TRS0025US0





Check and High Pressure Relief Valve


1. Remove the valve plug (1) with a hex. wrench.
2. Remove the spring (3) and the valve (4).

(When reassembling)

Tightening torque	Check and high pressure relief valve plug	59 to 78 N·m 6.1 to 7.9 kgf·m 44 to 57 lbf·ft
-------------------	---	---

- | | |
|----------------|------------|
| (1) Valve Plug | (3) Spring |
| (2) O-ring | (4) Valve |

9Y1211156TRS0026US0



HST Housing Case Cylinder Blocks


1. Remove the cylinder blocks (1), (4) from the pump shaft (2) and the motor shaft (3).

(When reassembling)

- Install the poppet (6) to the center section, not to drop it.
- Install the spring (5) to the HST housing side.

- | | |
|---------------------------|----------------------------|
| (1) Cylinder Block (Pump) | (4) Cylinder Block (Motor) |
| (2) Pump Shaft | (5) Spring |
| (3) Motor Shaft | (6) Poppet |

9Y1211156TRS0027US0



Piston and Spring


1. Remove the pistons (1) with the spring (2).

(When reassembling)

- Install the piston to its original position of the cylinder block.

- | | |
|------------|------------|
| (1) Piston | (2) Spring |
|------------|------------|

9Y1211156TRS0028US0



Motor Shaft and Pump Shaft


1. Remove the circlip (2) and oil seal (3) from the HST housing.
2. Remove the circlip (4) from the pump shaft (1).
3. Remove the pump shaft (1).
4. Remove the motor shaft (5).

(When reassembling)

- Replace the used oil seal with a new one.

- | | |
|----------------|-----------------|
| (1) Pump Shaft | (4) Circlip |
| (2) Circlip | (5) Motor Shaft |
| (3) Oil Seal | |

9Y1211156TRS0029US0




Trunnion Shaft

1. Remove the circlip (1) and oil seal (3) from the HST housing.
2. Remove the circlip (4) from the trunnion shaft (2).
3. Remove the swash plate (5).
4. Strike out the trunnion shaft (2) slightly with a plastic hammer and remove the trunnion shaft (2).

- | | |
|--------------------|-----------------|
| (1) Circlip | (4) Circlip |
| (2) Trunnion Shaft | (5) Swash Plate |
| (3) Oil Seal | |

9Y1211156TRS0030US0






Charge Relief Valve

1. Remove the spring (1) and poppet (2).
- (When reassembling)**
- Check the spring for breakage and wear.


- | | |
|------------|--------------------|
| (1) Spring | (3) Center Section |
| (2) Poppet | |

9Y1211156TRS0031US0

(4) PTO Clutch Case



(5) Bevel Pinion Shaft



Separating Transmission Case and PTO Clutch Case

1. Remove the transmission case mounting bolts.
2. Separate the transmission case (1) from the differential case (2).
3. Remove the PTO brake plate 4 mounting bolt (4).

(When reassembling)

- Install the PTO brake plate 4 (5) to the transmission case groove (7) securely as shown in the picture.
- Place the PTO brake plate 2 (6) between "A" and "B".

Tightening torque	Transmission case mounting bolt (M10) and nut	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft
	Hydraulic cylinder mounting bolt (M10) and nut	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft

- | | |
|-------------------------------------|------------------------------|
| (1) Transmission Case | (6) PTO Brake Plate 2 |
| (2) Differential Case | (7) Transmission Case Groove |
| (3) PTO Clutch Case | |
| (4) PTO Brake Plate 4 Mounting Bolt | A: Position |
| (5) PTO Brake Plate 4 | B: Position |

9Y1211156TRS0032US0

Bevel Pinion Shaft

1. Remove the bevel pinion shaft assembly (1) and range gear shaft assembly (4) from the transmission case.
2. Remove the spacer (2).

(When reassembling)

- Install the spacer (2) to the transmission case.
- Install the bevel pinion shaft assembly (1) and range gear shaft assembly (4).

- | | |
|---------------------------------|-------------------------------|
| (1) Bevel Pinion Shaft Assembly | (3) 14T-21T-29T Gear |
| (2) Spacer | (4) Range Gear Shaft Assembly |

9Y1211156TRS0033US0

(6) Sub Gear Shaft



Sub Gear Shaft Assembly

1. Remove the circlip (1) from the sub gear shaft (2).
2. Remove the sub gear shaft assembly (3) from the transmission case.





(1) Circlip

(3) Sub Gear Shaft Assembly

(2) Sub Gear Shaft

9Y1211156TRS0034US0

(7) Front Wheel Drive Shaft




4WD Shaft

1. Remove the circlip from the 4WD shaft (1).
2. Remove the 4WD gear (8) from the 4WD shaft (1).
3. Remove the 4WD shaft (1) with the 26T gear (3).
4. Remove the 26T gear (3) and the ball bearing (7).

- | | |
|--------------------|--------------------|
| (1) 4WD Shaft | (5) Collar |
| (2) Collar | (6) Circlip |
| (3) 26T Gear | (7) Ball Bearing |
| (4) Needle Bearing | (8) 4WD Gear (20T) |

9Y1211156TRS0035US0



4WD Shift Lever


1. Remove the bolt (4) and the washer with rubber (3).

(When reassembling)


- Install the 4WD gear (5) to the 4WD shaft.
- Install the 4WD shaft arm (6) to the 4WD gear (5).
- Install the O-rings to the 4WD shift arm (6).

- | | |
|------------------------|--------------------|
| (1) Ball | (5) 4WD Gear (19T) |
| (2) Spring | (6) 4WD Shift Arm |
| (3) Washer with Rubber | (7) O-ring |
| (4) Bolt | |

9Y1211156TRS0036US0



(8) Independent PTO Clutch Shifter






Installing PTO Shifter

1. Install the spring (3) and the ball (2) to the transmission.
2. Push the ball (2) by finger from the inside of the transmission case.
3. Push the PTO shift arm ball guide (1) into the transmission case as shown in the picture.
4. Push the PTO shift arm ball guide (1) with the PTO shift arm (4).
5. Install the PTO cotter (5) to the PTO shift arm (4).
6. Align the PTO cotter to the groove of the PTO shifter (6).


- (1) PTO Shift Arm Ball Guide
- (2) Ball
- (3) Spring

- (4) PTO Shift Arm
- (5) PTO Cotter
- (6) PTO Shifter

9Y1211156TRS0037US0



(9) Independent PTO Clutch



PTO Clutch Case

1. Remove the external circlip (11) from the spline boss (12).
2. Remove the internal circlip (13) from the PTO clutch case (2).
3. Remove the clutch discs (9) and the clutch plates (10) from the PTO clutch case (2).
4. Remove the ball bearing (1) from the PTO clutch case (2) with a puller.

■ **NOTE**

- **When removing the circlip, use an adequate size circlip pliers.**

- | | |
|----------------------|-----------------------|
| (1) Ball Bearing | (8) 25T Mid PTO-gear |
| (2) PTO Clutch Case | (9) Clutch Disc |
| (3) Brake Plate 4 | (10) Clutch Plate |
| (4) Brake Plate 2 | (11) External Circlip |
| (5) PTO Clutch Shaft | (12) Spline Boss |
| (6) Thrust Bearing | (13) Internal Circlip |
| (7) PTO Shifter | |

9Y1211156TRS0038US0






PTO Clutch Spring

1. Set the PTO clutch spring compressor (1) to the PTO clutch case (2).
2. Tighten the nut and remove the external circlip (3).
3. Remove the spring collar (4) and the PTO clutch spring (5).

- | | |
|----------------------------------|-----------------------|
| (1) PTO Clutch Spring Compressor | (4) Spring Collar |
| (2) PTO Clutch Case | (5) PTO Clutch Spring |
| (3) External Circlip | |

9Y1211156TRS0039US0




PTO Clutch Discs and Brake

1. After removing the inner circlip (6) from the PTO clutch case (10), remove the pressure plate (5).
2. Remove the clutch discs (3) and clutch plates (2).
3. Remove the external circlip (16) from the spline boss (4).
4. Remove the brake plate (15), the brake discs (14) and the brake plate (13).
5. After removing the external circlip (8) and the spring (18).


(When reassembling)

- Install the parts to the original positions.



- | | |
|----------------------|-----------------------|
| (1) Clutch Piston | (10) PTO Clutch Case |
| (2) Clutch Plate | (11) Circlip |
| (3) Clutch Disc | (12) Ball Bearing |
| (4) Spline Boss | (13) Brake Plate |
| (5) Pressure Plate | (14) PTO Brake Disc |
| (6) Internal Circlip | (15) Brake Plate |
| (7) Spring Collar | (16) External Circlip |
| (8) External Circlip | (17) Bearing Collar |
| (9) Ball Bearing | (18) Spring |

9Y1211156TRS0040US0



Spline Boss Circlip

1. Push the circlip with a small screw driver through the small hole of the spline boss (1).
2. Lift the circlip (2) with a screw driver not to damage it.





(When reassembling)

- Install the circlip (2) holding it by hands.

- (1) Spline Boss
(2) Circlip

- (3) Ball Bearing

9Y1211156TRS0041US0



PTO Shaft



1. Remove the thrust bearing (6) and the PTO shifter (4) not to damage the seal rings (5) located at the PTO shaft front side.
2. Remove the seal rings (5) located at the PTO shaft rear side.
3. Remove the ball bearing (2) with a puller.

(When reassembling)

- Check all seal rings (5).
- If the seal ring (5) is damaged, replace it.
- Check the direction of the thrust bearing (6) and install the thrust bearing (6) as shown in the picture.

- | | |
|----------------------|--------------------|
| (1) PTO Clutch Shaft | (5) Seal Ring |
| (2) Ball Bearing | (6) Thrust Bearing |
| (3) 26T Mid-gear | (7) Needle Bearing |
| (4) PTO Shifter | (8) Collar |

9Y1211156TRS0042US0

(10) Mid-PTO Section**Mid-Gear and Idle Shaft**

1. Remove the idle shaft (2) from the transmission case using a screw driver.
2. Remove the mid-gear (1) from the transmission case.
3. Remove the ball bearings (4), (5) and the internal circlip (6) from the mid-gear (1).




(When reassembling)

- Install the internal circlip (6) to the inner groove of the mid-gear (1) securely.

- (1) 30T Mid-Gear
 (2) Idle Shaft
 (3) Spring Pin

- (4) Ball Bearing
 (5) Ball Bearing
 (6) Internal Circlip

9Y1211156TRS0043US0



Mid-PTO Case and Mid-Gear Shaft

1. Remove the mid-PTO case mounting bolts.
2. Remove the mid-PTO case from the transmission case.
3. Remove the mid-PTO oil seal (4) from the mid-PTO case (2) using a screw driver not to damage it.
4. Remove the internal circlip (5).
5. Remove the mid-gear shaft (3) with the ball bearings (6), (7).
6. Remove the bearing (6), (7) from the mid-gear shaft (3).

(When reassembling)

- If the mid-PTO oil seal (4) is damaged, worn or scratched, replace it.
- Apply grease to the lip and the outer of the mid-PTO oil seal (4).
- After installing the mid-gear (1), apply liquid gasket (Three Bond 1206D or equivalent) to the joint surface of transmission case and the mid-PTO case (2).

- | | |
|--------------------------|------------------|
| (1) 30T Mid-Gear | (6) Ball Bearing |
| (2) Mid-PTO Case | (7) Ball Bearing |
| (3) Mid-Gear Shaft (18T) | |
| (4) Mid-PTO Oil Seal | |
| (5) Internal Circlip | |


A: Joint Surface, Apply liquid gasket

9Y1211156TRS0044US0


(11) Differential Gear Section



3TBAAAG3P158A




3TBAAAG3P159A



3TBAAAG3P160A



3TBAAAG3P161A



3TBAAAG3P162A

Rear Axle Case and Rear PTO Cover

1. Remove the rear axle mounting bolts.
2. Remove the left rear axle case (4) and the right rear axle case (2) from the differential case (3).
3. Remove the rear PTO cover mounting bolts and the rear PTO cover (5).

(When reassembling)

- Apply liquid gasket (Three Bond 1206D or equivalent) to the joint surface of the rear axles cases and the rear PTO cover.

Tightening torque	Rear axle case (LH and RH) mounting bolt for aluminum material (M10)	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft
	Rear PTO cover mounting bolt for aluminum material (M10)	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft

- | | |
|----------------------------------|-------------------------|
| (1) Rear Axle Case Mounting Bolt | (4) Left Rear Axle Case |
| (2) Right Rear Axle Case | (5) Rear PTO Cover |
| (3) Differential Case | (6) PTO Drive Shaft |

9Y1211156TRS0045US0

Differential Bearing Holder (RH)

1. Remove the differential holder mounting bolts (1).
2. Remove the differential holder (2) and shims (3), (4).


(When reassembling)

- 0.2 mm (0.008 in.) shim
- 0.5 mm (0.020 in.) shim

Tightening torque	Differential bearing holder mounting bolt for aluminum material (M8)	17.7 to 20.5 N·m 1.8 to 2.1 kgf·m 13.1 to 15.1 lbf·ft
-------------------	--	---

- | | |
|---|----------|
| (1) Differential Bearing Holder Mounting Bolt | (3) Shim |
| (2) Differential Bearing Holder | (4) Shim |

9Y1211156TRS0046US0




Differential Gear Assembly

1. Remove the internal circlip (1) from the differential case.
2. Remove the shims (2), (3).
3. Remove the differential gear assembly (4) from the differential case.

(When reassembling)


- 0.5 mm (0.020 in.) shim.
- 0.6 mm (0.024 in.) shim.
- 0.7 mm (0.028 in.) shim.
- 0.8 mm (0.031 in.) shim.



- (1) Internal Circlip
(2) Shim

- (3) Shim
(4) Differential Gear Assembly


9Y1211156TRS0047US0



Bearings

1. Remove the right and left bearings from the differential case.

9Y1211156TRS0048US0



Spiral Bevel Gear

1. Remove the spiral bevel gear UBS screws (1).
2. Remove the spiral bevel gear (2) from differential case (3).

(When reassembling)


- Apply liquid lock (Three Bond 1324B or its equivalent) to the spiral bevel gear UBS screws.

Tightening torque	Spiral bevel gear UBS screw	37.5 to 42.5 N·m 3.83 to 4.33 kgf·m 27.7 to 31.3 lbf·ft
-------------------	-----------------------------	---

- (1) Spiral Bevel Gear UBS Screw
(2) Spiral Bevel Gear

- (3) Differential Case

9Y1211156TRS0049US0



Differential Side Gear and Differential Pinion

1. Put parting marks on the differential pinion (1) and the differential side gear (2).
2. Tap out the dowel pin (3).
3. Remove the differential pinion shaft.
4. Remove the differential pinion (4), differential side gear (2) and shim (5).


(When reassembling)

- Install the differential pinion and differential side gear, aligning the parting marks.

- | | |
|----------------------------|-------------------------|
| (1) Differential Pinion | (4) Differential Pinion |
| (2) Differential Side Gear | (5) Shim |
| (3) Dowel Pin | |

9Y1211156TRS0050US0

[4] SERVICING
(1) HST




Pump Shaft

1. Pull out the pump shaft from the HST housing case.
2. Check the oil seal surface (1), the bearing surface (2) and the bearing.
3. If the shaft is rough or grooved, replace it.
4. If the bearing is worn, replace it.

- | | |
|----------------------|---------------------|
| (1) Oil Seal Surface | (2) Bearing Surface |
|----------------------|---------------------|

9Y1211156TRS0051US0



Motor Shaft

1. Pull out the motor shaft from the HST housing case.
2. Check the oil seal surface (1), the bearing surface (2) and the bearing.
3. If the shaft is rough or grooved, replace it.
4. If the bearing is worn, replace it.

- | | |
|----------------------|---------------------|
| (1) Oil Seal Surface | (2) Bearing Surface |
|----------------------|---------------------|

9Y1211156TRS0052US0




Cylinder Block Face

1. Check the polished face (1) of cylinder block for scoring.
2. If scored, replace cylinder block assembly.

- | |
|-------------------|
| (1) Polished Face |
|-------------------|

9Y1211156TRS0053US0



Valve Swash Plate Bearing Face

1. Check the swash plate bearing (1) for scratches and excessive wear.
2. If worn or scored, replace it.

(When reassembling)

- Apply liquid lock (Three Bond 1360F or its equivalent) to the screw.

Tightening torque	Screw (M3)	1.5 N·m 0.15 kgf·m 1.1 lbf·ft
-------------------	------------	-------------------------------------

- (1) Swash Plate Bearing (2) Screw

9Y1211156TRS0054US0




Thrust Collars, Thrust Ball Bearing and Swash Plate Surface

1. Check the thrust collar (1) for scratches and excessive wear.
2. If worn or scored, replace it.
3. Check the thrust ball bearing surface (2) for scratches and excessive wear.
4. If worn or scored, replace it.
5. Check the swash plate (3) for scratches and excessive wear.
6. If worn or scored, replace it.

- (1) Thrust Collar (3) Swash Plate
(2) Thrust Ball Bearing

9Y1211156TRS0055US0




Thrust collars and Thrust Ball Bearing (Motor Side)

1. Check the thrust collars (1) for scratches and excessive wear.
2. If worn or scored, replace it.
3. Check the thrust ball bearing (2) for scratches and excessive wear.
4. If worn or scored, replace it.

- (1) Thrust Collar (2) Thrust Ball Bearing

9Y1211156TRS0056US0



Center Section Oil Seals and Bearings


1. Check the oil seals (1) for damage.
2. Check the needle bearings (2) for wear.
3. If the needle bearings (2) and oil seals (1) are worn, replace all seals and needle bearings.

■ NOTE

- After checking, coat the bearing with hydrostatic transmission oil and the oil seal lip with grease.

- (1) Oil Seal (2) Needle Bearing

9Y1211156TRS0057US0




Check and High Pressure Relief Valve

1. Check the valve plug (4) and valve (1) for scratches and damage.
2. Check the valve seat in the port block for damage.
3. Check the spring (2) for breakage and wear.
4. If anything unusual, replace the check and high pressure relief valve assembly.

Tightening torque	Valve plug	59 to 78 N·m 6.1 to 7.9 kgf·m 44 to 57 lbf·ft
-------------------	------------	---

- (1) Valve
- (2) Spring
- (3) O-ring
- (4) Valve Plug

9Y1211156TRS0058US0




Charge Relief Valve

1. Check the spring (2) for breakage and wear.
2. If it is unusual, replace it.

- (1) HST Housing
- (2) Spring
- (3) Poppet
- (4) Center Section

9Y1211156TRS0059US0



Cylinder Block Bore and Pistons

1. Check the pistons for their free movement in the cylinder block bores.
2. If the piston or the cylinder block bore is scored, replace cylinder block assembly.

■ IMPORTANT

- Do not interchange pistons between pump and motor cylinder block. Pistons and cylinder blocks are matched.

Clearance between piston and bore	Factory specification	0.02 to 0.03 mm 0.0008 to 0.001 in.
	Allowable limit	0.04 mm 0.0016 in.

- (1) Retainer Plate

9Y1211156TRS0060US0


(2) Independent PTO Clutch



Checking Bearing

1. Hold the inner race, and push and pull the outer race in all directions to check for wear and roughness.
2. Apply transmission fluid to the bearing, and hold the inner race. Then, turn the outer race to check rotation.
3. If there is any problem, replace it.

9Y1211156TRS0061US0




Clutch Disc Wear

1. Measure the clutch disc thickness with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Clutch disc wear	Factory specification	1.70 to 1.90 mm 0.067 to 0.075 in.
	Allowable limit	1.55 mm 0.061 in.

9Y1211156TRS0062US0




Steel Plate and Pressure Plate Wear

1. Measure the steel plate thickness with vernier calipers.
2. Measure the pressure plate thickness with vernier calipers.
3. If the thickness is less than the allowable limit, replace.

Steel plate wear	Factory specification	1.15 to 1.25 mm 0.045 to 0.049 in.
	Allowable limit	1.10 mm 0.043 in.

Pressure plate wear	Factory specification	1.95 to 2.05 mm 0.0768 to 0.0807 in.
	Allowable limit	1.8 mm 0.071 in.

9Y1211156TRS0063US0



Piston Return Spring Free Length and Tension

1. Measure the free length of the piston return spring with vernier calipers.
2. Place the piston return spring on a spring compression tester and compress to the specified length, and read the gauge.
3. If the measurement is less than the allowable limit, replace.

Piston / return spring free length	Factory specification	44.0 mm 1.73 in.
------------------------------------	-----------------------	---------------------

Piston return spring tension	Factory specification	638.7 N / 26 mm 65.13 kgf / 26 mm 143.6 lbf / 1.02 in.
	Allowable limit	539.4 N / 26 mm 55 kgf / 26 mm 121.3 lbf / 1.02 in.

9Y1211156TRS0064US0


(3) Transmission Case



Checking Bearing

1. Hold the inner race, and push and pull the outer race in all directions to check for wear and roughness.
2. Apply transmission fluid to the bearing, and hold the inner race. Then, turn the outer race to check rotation.
3. If there is any problem, replace it.

9Y1211156TRS0065US0




Clearance between Shift Fork and Shift Gear Groove

1. Insert the fork into the shift gear groove and measure the clearance with a feeler gauge.
2. If the clearance exceeds the allowable limit, replace it.

Clearance between shift fork and shift gear groove	Factory specification	0.10 to 0.35 mm 0.004 to 0.014 in.
	Allowable limit	0.5 mm 0.020 in.

9Y1211156TRS0066US0

(4) Differential Gear




Clearance between Differential Case (Spiral Bevel Gear) and Differential Side Gear

1. Measure the differential side gear boss O.D. with an outside micrometer.
2. Measure the differential case I.D. and the spiral bevel gear I.D. with an inside micrometer, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace damage parts.

Clearance between differential case (spiral bevel gear) and differential side gear	Factory specification	0.025 to 0.066 mm 0.0010 to 0.0026 in.
	Allowable limit	0.30 mm 0.0118 in.

Differential case I.D.	Factory specification	32.000 to 32.025 mm 1.2598 to 1.2608 in.
Spiral bevel gear I.D.	Factory specification	32.000 to 32.025 mm 1.2598 to 1.2608 in.
Differential side gear O.D.	Factory specification	31.959 to 31.975 mm 1.2582 to 1.2589 in.

9Y1211156TRS0067US0




Clearance between Differential Pinion Shaft and Differential Pinion

1. Measure the differential pinion shaft O.D. with an outside micrometer.
2. Measure the differential pinion I.D. with an inside micrometer, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace damage parts.

Clearance between differential pinion shaft and differential pinion	Factory specification	0.048 to 0.084 mm 0.0019 to 0.0033 in.
	Allowable limit	0.30 mm 0.0118 in.

Differential pinion I.D.	Factory specification	16.032 to 16.050 mm 0.63119 to 0.63188 in.
Differential pinion shaft O.D.	Factory specification	15.966 to 15.984 mm 0.62859 to 0.62929 in.

9Y1211156TRS0068US0



Backlash between Differential Pinion and Differential Side Gear

1. Secure the differential case with a vise.
2. Set the dial indicator (lever type) with its finger on the tooth of the differential side gear.
3. Press differential pinion and side gear against the differential case.
4. Hold the differential pinion and move the differential side gear to measure the backlash.
5. If the backlash exceeds the allowable limit, adjust with differential side gear shims.


Backlash between differential pinion and differential side gear	Factory specification	0.1 to 0.3 mm 0.004 to 0.0012 in.
	Allowable limit	0.4 mm 0.016 in.

■ **NOTE**

- **Thickness of shims:**
0.80 mm (0.0315 in.)
1.00 mm (0.0394 in.)
1.20 mm (0.0472 in.)

9Y1211156TRS0069US0

Backlash between Spiral Bevel Pinion and Spiral Bevel Gear



- (1) Shim
- (2) Spacer
- (3) Spiral Bevel Pinion
- (4) Bearing Holder
- (5) Shim
- (6) Spiral Bevel Gear
- (7) Shim

3TBAAAG3P178A

1. Set the dial indicator (lever type) with its finger on the end of spiral bevel pinion (3).
2. Move the spiral bevel pinion back and forth to each end and measure the side clearance.
3. If the side clearance exceeds the factory specifications, adjust with the shims (1) at front end of spiral bevel pinion.
4. Set the dial indicator (lever type) with its finger on the tooth surface of bevel gear.
5. Measure the backlash by fixing the spiral bevel pinion (3) and moving bevel gear (6) by hand.
6. If the backlash exceeds the factory specifications, adjust with the shims (1), (7) at bearing holder (4) and differential case.
7. Adjust the backlash properly by repeating the above procedure.

(When adjusting)

Movement of spiral bevel pinion shaft at shaft directions	Factory specification	Approx 0 mm 0 in.
Backlash between spiral bevel pinion and spiral bevel gear	Factory specification	0.10 to 0.30 mm 0.0039 to 0.0012 in.

(Reference)

- Thickness of shims (1):
0.2 mm (0.008 in.)
1.4 mm (0.056 in.)
1.8 mm (0.070 in.)
- Thickness of shims (5):
0.2 mm (0.008 in.)
0.5 mm (0.01 in.)
- Thickness of shims (7):
0.5 mm (0.01 in.)
0.6 mm (0.024 in.)
0.7 mm (0.027 in.)
0.8 mm (0.03 in.)

9Y1211156TRS0070US0


3 REAR AXLE

MECHANISM

CONTENTS

1. STRUCTURE.....	3-M1
-------------------	------

1. STRUCTURE



- | | | | |
|-----------------------------|--------------------|-----------------------|-----------------------|
| (1) Differential Gear Shaft | (3) Rear Axle Case | (5) Spur Gear | (7) Differential Gear |
| (2) Ball Bearing | (4) Rear Axle | (6) Spiral Bevel Gear | |

The rear axles are the semi floating type with ball bearing (2) between the rear axle (4) and the rear axle case (3), which supports the rear wheel load as well as transmitting power to the rear wheels.

The differential gears (7) automatically control the revolution of right and left wheels when the rear wheels encounter unequal resistance during turning.

9Y1211156RAM0001US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	3-S1
2. TIGHTENING TORQUES	3-S2
3. DIASSEMBLING AND SERVICING	3-S3
[1] DIASSEMBLING AND ASSEMBLING.....	3-S3
(1) Separating Rear Axle Case	3-S3
(2) Disassembling Rear Axle Case	3-S4
[2] SERVICING	3-S5

1. TROUBLESHOOTING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Excessive or Unusual Noise at All Time	1. Improper backlash between differential gear shaft and final reduction gear	Inspect or adjust backlash	2-S42
	2. Bearing worn	Inspect or replace bearing	3-S5
	3. Insufficient or improper type of transmission fluid used	Check transmission oil	G-8
Noise while Turning	1. Brake shaft and gear and internal gear worn or damaged	Replace brake shaft or gear	3-S5

9Y1211156RAS0001US0

2. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)





Item	N·m	kgf·m	lbf·ft
Rear wheel mounting nut and screw	145 to 150	14.8 to 15.2	107 to 110
Front loader valve pipe joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 1 joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 2 joint bolt (Front loader valve side)	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 2 joint bolt (Hydraulic cylinder case side)	50 to 60	5.1 to 6.1	37 to 44
Rear axle case mounting screw	40 to 44	4.0 to 4.5	29 to 32

9Y1211156RAS0002US0

3. DIASSEMBLING AND SERVICING

[1] DIASSEMBLING AND ASSEMBLING

(1) Separating Rear Axle Case



Draining Transmission Fluid

⚠ CAUTION

- Stop the engine before checking and changing the transmission fluid.
1. Place the oil pan under the tractor.
 2. Remove the drain plugs (1), (3), (5) at the mid-PTO shaft and at the bottom of the rear axle cases (4), (6).
 3. Drain the transmission fluid.
 4. After draining the transmission fluid, reinstall the drain plugs (1), (3), (5).

■ IMPORTANT

- Use only KUBOTA UDT oil. Use of other oils may damage the transmission or hydraulic system. Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.
- Never work the tractor immediately after changing the transmission oil. Keep the engine at medium speed for a few minutes to prevent damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	15 L 4.0 U.S.gals 3.3 Imp.gals
-----------------------------	--------------------------------------

- | | |
|-------------------|---------------------------|
| (1) Drain Plug | (4) Rear Axle Case (L.H.) |
| (2) Mid-PTO Shaft | (5) Drain Plug |
| (3) Drain Plug | (6) Rear Axle Case (R.H.) |

9Y1211156ENS0023US0

Battery Cable

1. Open the bonnet and remove the side cover.
2. Disconnect the battery negative cable (1).

■ NOTE

- When disconnecting the battery cables, disconnect the grounding cable first. When connecting, the positive cable first.

- (1) Battery Negative Cable

9Y1211156RAS0003US0


Rear Wheel

1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel (1).

Tightening torque	Rear wheel mounting nut and screw	145 to 150 N·m 14.8 to 15.2 kgf·m 107 to 110 lbf·ft
-------------------	-----------------------------------	---

- (1) Rear Wheel

9Y1211156RAS0004US0



Rear Axle Case

1. Remove the brake rod (7) and right side fender (2).
2. Remove the 3-point hitch delivery pipe 2 (5) and return hose (6).
3. Remove the pipe clamps and 3-point hitch delivery pipe 1 (3).
4. Remove the front loader valve pipes (8).
5. Remove the loader valve assembly (9).
6. Remove the rear axle case (1).

(When reassembling)


- Do not damage the O-rings of front loader valve pipes and delivery pipes.
- Apply liquid gasket (Three Bond 1206D or equivalent) to joint face of the rear axle case and differential gear case after eliminating the water and oil.

Tightening torque	Front loader valve pipe joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 1 joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 2 joint bolt (Front loader valve side)	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 2 joint bolt (Hydraulic cylinder case side)	50 to 60 N·m 5.1 to 6.1 kgf·m 37 to 44 lbf·ft
	Rear axle case mounting screw	40 to 44 N·m 4.0 to 4.5 kgf·m 29 to 32 lbf·ft

- | | |
|-----------------------------------|-----------------------------|
| (1) Rear Axle Case | (6) Return Hose |
| (2) Fender | (7) Brake Rod |
| (3) 3-Point Hitch Delivery Pipe 1 | (8) Front Loader Valve Pipe |
| (4) Differential Lock Rod | (9) Loader Valve Assembly |
| (5) 3-Point Hitch Delivery Pipe 2 | |

9Y1211156RAS0005US0

(2) Disassembling Rear Axle Case




Differential Lock Shift Fork, Differential Lock Clutch (Right Side Only)

1. Remove the spring (1).
2. Draw out the differential lock shift fork (2) and differential lock clutch (3).

- | | |
|----------------------------------|------------------------------|
| (1) Spring | (3) Differential Lock Clutch |
| (2) Differential Lock Shift Fork | |

9Y1211156RAS0006US0



Rear Axle Shaft


1. Remove the fork rod (1).
2. Remove the ball bearing (4) with a puller.
3. Remove the gear (3).
4. Remove the brake shaft assembly (2).
5. Tap out the rear axle shaft (5) with a rubber hammer to the outside.

(When reassembling)

- Tap in the bearing to the rear axle case.

- | | |
|--------------------------|---------------------|
| (1) Fork Rod | (5) Rear Axle Shaft |
| (2) Brake Shaft Assembly | (6) Oil Seal |
| (3) 57T Gear | (7) Ball Bearing |
| (4) Ball Bearing | |

9Y1211156RAS0007US0



[2] SERVICING



Checking Ball Bearing

1. Hold the inner race, and push and pull the outer race in all directions to check for wear and roughness.
2. Apply transmission fluid to the bearing, and hold the inner race. Then, turn the outer race to check rotation.
3. If there is any problem, replace it.

9Y1211156RAS0008US0


4 BRAKES

MECHANISM

CONTENTS

1. LINKAGE	4-M1
2. OPERATION.....	4-M2

1. LINKAGE



(1) Parking Brake Lever
(2) Brake Pedal

(3) Turnbuckle

(4) Brake Rod


(5) Brake Cam Lever

Independent mechanical wet disc brakes are used for the right and left traveling brakes. They are operated by the brake pedals through the mechanical linkages and provide stable braking and require little adjustment.

The parking brake is a mechanical type which is designed to actuate the traveling brakes through the linkages. Pulling the parking brake lever (1) results in the same state as the obtained when the brake pedals are depressed.

9Y1211156BRM0001US0

2. OPERATION



- | | | | |
|--------------------|--------------------|--|---------------------|
| (1) Cam Plate | (4) Rear Axle Case | (6) Brake Shaft
(Differential Gear Shaft) | (7) Brake Cam |
| (2) Friction Plate | (5) Steel Ball | | (8) Brake Cam Lever |
| (3) Brake Disc | | | |

The brake body is incorporated in the rear axle case (4) filled with transmission oil and is designed to brake when the brake disc (3) splined with the differential gear shaft (6) is pressed against the cam plate (1) by means of the cam mechanism incorporating steel balls (5).

For greater braking force, two brake discs are provided at the right and left sides respectively, and the friction plate (2) fixed to the rear axle case is arranged between the brake discs.

■ During Braking

When the brake pedal is pressed, the linkage causes the brake cam lever (8) and brake cam (7) to turn into the direction of arrow shown in the above figure.

Therefore, the cam plate (1) also moves the direction of arrow. At this time, since the cam plate (1) rides on the steel balls (5) set in the grooves of the rear axle case to press the brake disc (3), the differential gear shaft (6) is braked by the frictional force generated by the cam plate (1) and brake disc (3).

9Y1211156BRM0002US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	4-S1
2. SERVICING SPECIFICATIONS	4-S2
3. TIGHTENING TORQUES	4-S3
4. CHECKING, DISASSEMBLING AND SERVICING	4-S4
[1] CHECKING AND ADJUSTING.....	4-S4
[2] DISASSEMBLING AND ASSEMBLING	4-S4
(1) Separating Rear Axle Case	4-S5
(2) Disassembling Rear Axle Case	4-S6
[3] SERVICING	4-S7

1. TROUBLESHOOTING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Uneven Braking Force	1. Brake pedal free travel unevenly adjusted	Check or adjust brake pedal free travel	4-S4
	2. Brake disc worn	Replace brake disc	4-S7
	3. Cam plate warped	Replace cam plate	4-S7
Brake Drags	1. Brake pedal free travel too small	Check or adjust brake pedal free travel	4-S4
	2. Ball holes of cam plate for uneven wear	Inspect or replace brake cam plate	4-S7
	3. Brake cam rusted	Repair or replace brake cam	4-S7
Poor Braking Force	1. Brake pedal free travel excessive	Check or adjust brake pedal free travel	4-S4
	2. Transmission fluid improper	Check transmission oil	G-8
	3. Brake cam or lever damaged	Repair or replace brake cam or lever	4-S7
	4. Cam plate warped	Inspect or replace cam plate	4-S7
	5. Brake disc worn	Replace brake disc	4-S7

9Y1211156BRS0001US0

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Brake Pedal	Free Travel	30 to 40 mm 1.18 to 1.57 in.	–
	Difference of Stroke (RH and LH)	–	0 to 5 mm 0 to 0.1 in.
Cam Plate and Bearing Holder	Flatness	–	0.30 mm 0.012 in.
Cam Plate and Ball	Height	22.89 to 22.99 mm 0.9012 to 0.9051 in.	22.40 mm 0.8819 in.
Brake Disc	Thickness	3.30 to 3.50 mm 0.130 to 0.137 in.	3.0 mm 0.12 in.
Friction Plate	Thickness	1.92 to 2.08 mm 0.0756 to 0.0818 in.	1.52 mm 0.0598 in.

9Y1211156BRS0002US0

3. TIGHTENING TORQUES



Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)

Item	N·m	kgf·m	lbf·ft
Rear wheel mounting nut and screw	145 to 150	14.8 to 15.2	107 to 110
Front loader valve pipe joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 1 joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 2 joint bolt (Front loader valve side)	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 2 joint bolt (Hydraulic cylinder case side)	50 to 60	5.1 to 6.1	37 to 44
Rear axle case mounting screw	40 to 44	4.0 to 4.5	29 to 32

9Y1211156BRS0003US0

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



Adjusting Brake Pedal Free Travel and Difference of Stroke

⚠ CAUTION

- Stop the engine and chock the wheels before checking brake pedal.
- The difference between the right and left pedal plays must be less than 5 mm (0.1 in.).

1. Release the parking brake.
2. Slightly depress the brake pedals and measure free travel at top of pedal stroke.
3. If the measurement is not within the factory specifications, loosen the lock nut and turn the turnbuckles to adjust the brake rod length.
4. Retighten the lock nut securely.
Keep the free travel in the right and left brake pedals equal.

Brake pedal free travel	Factory specification	30 to 40 mm 1.18 to 1.57 in.
Brake pedal difference of stroke (RH and LH)	Allowable limit	0 to 5 mm 0 to 0.1 in.

■ NOTE



- After checking brake pedal free play, be sure to engage the parking brake lever fully and check to see that the brake pedals are securely locked.

- (1) Brake Pedal
- (2) Turnbuckle
- (3) Lock Nut

A: Brake Pedal Free Travel

9Y1211156BRS0004US0

[2] DISASSEMBLING AND ASSEMBLING



Separating Brake Pedal

1. Remove the left side step (1).
2. Remove the return springs (2).
3. Remove the pin (3) and disconnect brake rod (4) from brake pedal (8).
4. Remove the external circlip (5) and pin (6) from the brake pedal shaft (7).
5. Top out the brake pedal shaft (7) from the brake pedals (8).




(When reassembling)

- Apply grease to the brake pedal shaft.
- Be sure to adjust the brake pedal free travel.

- (1) Step
- (2) Return Spring
- (3) Pin
- (4) Brake Rod
- (5) External Circlip
- (6) Pin
- (7) Brake Pedal Shaft
- (8) Brake Pedal

9Y1211156BRS0005US0

(1) Separating Rear Axle Case



Draining Transmission Fluid

⚠ CAUTION

- Stop the engine before checking and changing the transmission fluid.

1. Place the oil pan under the tractor.
2. Remove the drain plugs (1), (3), (5) at the mid-PTO shaft and at the bottom of the rear axle cases (4), (6).
3. Drain the transmission fluid.
4. After draining the transmission fluid, reinstall the drain plugs (1), (3), (5).

■ IMPORTANT

- Use only KUBOTA UDT oil. Use of other oils may damage the transmission or hydraulic system. Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.
- Never work the tractor immediately after changing the transmission oil. Keep the engine at medium speed for a few minutes to prevent damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	15 L 4.0 U.S.gals 3.3 Imp.gals
-----------------------------	--------------------------------------

- | | |
|-------------------|---------------------------|
| (1) Drain Plug | (4) Rear Axle Case (L.H.) |
| (2) Mid-PTO Shaft | (5) Drain Plug |
| (3) Drain Plug | (6) Rear Axle Case (R.H.) |

9Y1211156ENS0023US0


Rear Wheel

1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel (1).

Tightening torque	Rear wheel mounting nut and screw	145 to 150 N·m 14.8 to 15.2 kgf·m 107 to 110 lbf·ft
-------------------	-----------------------------------	---

- (1) Rear Wheel

9Y1211156BRS0006US0



Rear Axle Case

1. Remove the brake rod (7) and right side fender (2).
2. Remove the 3-point hitch delivery pipe 2 (5) and return hose (6).
3. Remove the pipe clamps and 3-point hitch delivery pipe 1 (3).
4. Remove the front loader valve pipes (8).
5. Remove the loader valve assembly (9).
6. Remove the rear axle case (1).

(When reassembling)


- Do not damage the O-rings of front loader valve pipes and delivery pipes.
- Apply liquid gasket (Three Bond 1206D or equivalent) to joint face of the rear axle case and differential gear case after eliminating the water and oil.

Tightening torque	Front loader valve pipe joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 1 joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 2 joint bolt (Front loader valve side)	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 2 joint bolt (Hydraulic cylinder case side)	50 to 60 N·m 5.1 to 6.1 kgf·m 37 to 44 lbf·ft
	Rear axle case mounting screw	40 to 44 N·m 4.0 to 4.5 kgf·m 29 to 32 lbf·ft

- | | |
|-----------------------------------|-----------------------------|
| (1) Rear Axle Case | (6) Return Hose |
| (2) Fender | (7) Brake Rod |
| (3) 3-Point Hitch Delivery Pipe 1 | (8) Front Loader Valve Pipe |
| (4) Differential Lock Rod | (9) Loader Valve Assembly |
| (5) 3-Point Hitch Delivery Pipe 2 | |

9Y1211156RAS0005US0

(2) Disassembling Rear Axle Case






Differential Lock Shift Fork, Differential Lock Clutch (Right Side Only), 57T Gear and Rear Axle

1. Remove the spring (1).
2. Draw out the differential lock shift fork (2) and differential lock clutch (3).
3. Remove the external snap ring (6) and remove the bearing (5).
4. Draw out the 57T gear (4) from the rear axle (7).
5. Tap out the rear axle (7) to the outside of the rear axle case.

- | | |
|----------------------------------|------------------------|
| (1) Spring | (5) Bearing |
| (2) Differential Lock Shift Fork | (6) External Snap Ring |
| (3) Differential Lock Clutch | (7) Rear Axle |
| (4) 57T Gear | |

9Y1211156BRS0007US0



Brake Assembly

1. Remove the internal snap ring (1).
2. Remove the brake shaft (2) with brake discs.

(When reassembling)

- When installing the internal snap ring (1) to rear axle case (3) as shown in the figure.
- When installing the bearing holder (4) to the rear axle case (3), do not forget to install the straight pin (5).

- | | |
|------------------------|--------------------|
| (1) Internal Snap Ring | (4) Bearing Holder |
| (2) Brake Shaft | (5) Straight Pin |
| (3) Rear Axle Case | |

9Y1211156BRS0008US0

Brake Discs and Friction Plate

1. Remove the external snap ring (1), and remove the brake discs and friction plate.
2. Remove the cam plate and balls.
3. Remove the external snap ring and pull out the brake cam lever.


(When reassembling)

- Install the brake discs with their holes (2) deviation at less than 1/3 of the total hole area.

- | | |
|------------------------|----------|
| (1) External Snap Ring | (2) Hole |
|------------------------|----------|

9Y1211156BRS0009US0


[3] SERVICING



Brake Cam Lever Movement

1. Move the brake cam lever by hand to check the movement.
2. If the movement is heavy, refine the brake cam with emery paper.

9Y1211156BRS0010US0




Cam Plate Flatness and Bearing Holder Wear

1. Place a straightedge of 150 mm (5.91 in.) or more in length on the contacting surface of the cam plate and the bearing holder.
2. Inspect the friction surface of the cam plate and the bearing holder with the straightedge, and determine if a 0.30 mm (0.012 in.) feeler gauge will fit on the part of wear.
3. If it will fit, resurface.

Flatness of cam plate and bearing holder	Allowable limit	0.30 mm 0.012 in.
--	-----------------	----------------------

9Y1211156BRS0011US0




Height of Cam Plate and Ball

1. Measure the dimensions of the cam plate with the ball installed.
2. If the measurement is less than the allowable limit, replace the cam plate and balls.
3. Inspect the ball holes of cam plate for uneven wear.
4. If the uneven wear is found, replace it.

Height of cam plate and ball	Factory specification	22.89 to 22.99 mm 0.9012 to 0.9051 in.
	Allowable limit	22.40 mm 0.8819 in.

9Y1211156BRS0012US0



Brake Disc and Friction Plate Wear

1. Measure the brake disc thickness and the friction plate thickness with an outside micrometer.
2. If the thickness is less than the allowable limit, replace it.

Brake disc thickness	Factory specification	3.30 to 3.50 mm 0.130 to 0.137 in.
	Allowable limit	3.0 mm 0.12 in.

Friction plate thickness	Factory specification	1.92 to 2.08 mm 0.0756 to 0.0818 in.
	Allowable limit	1.52 mm 0.0598 in.

9Y1211156BRS0013US0

5 FRONT AXLE


MECHANISM

CONTENTS

1. STRUCTURE.....	5-M1
[1] 4 WHEEL DRIVE MODEL	5-M1

1. STRUCTURE

[1] 4 WHEEL DRIVE MODEL



3TBAAAG6P001A

- | | | | |
|---------------------|-------------------------------------|------------------------------------|--------------------------------|
| (1) Axle | (6) Bevel Gear | (11) Spiral Bevel Gear | (16) Spiral Bevel Pinion Shaft |
| (2) Axle Flange | (7) Differential Yoke Shaft, L.H. | (12) Differential Yoke Shaft, R.H. | (17) Bevel Gear Shaft |
| (3) Bevel Gear | (8) Front Axle Case | (13) Front Axle Bracket, Rear | (18) Front Gear Case |
| (4) Bevel Gear | (9) Differential Side Gear (14T) | (14) Coupling | (19) Collar |
| (5) Bevel Gear Case | (10) Differential Pinion Gear (10T) | (15) Propeller Shaft | |

The front axle of the 4WD is constructed as shown above. Power is transmitted from the transmission through the propeller shaft (15) to the spiral bevel pinion shaft (16), then to the spiral bevel gear (11) and to the differential side gear (9).

The power through the differential side gear (9) is transmitted to the differential yoke shaft (7), (12), and to the bevel gear shaft (17) through the bevel gears (4), (6) in the bevel gear case (5).

The revolution is greatly reduced by the bevel gears (3), then the power is transmitted to the axle (1).

The differential system allows each wheel to rotate at a different speed to make turning easier.

9Y1211156FAM0001US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	5-S1
2. SERVICING SPECIFICATIONS	5-S2
3. TIGHTENING TORQUES	5-S3
4. CHECKING, DISASSEMBLING AND SERVICING	5-S4
[1] CHECKING AND ADJUSTING.....	5-S4
[2] DISASSEMBLING AND ASSEMBLING	5-S5
(1) Separating Front Axle Assembly	5-S5
(2) Disassembling Front Axle Assembly	5-S6
[3] SERVICING	5-S12

1. TROUBLESHOOTING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Front Wheels Wander to Right or Left	1. Tire pressure uneven	Adjust tire pressure	G-45
	2. Improper toe-in adjustment (improper alignment)	Adjust toe-in	5-S4
	3. Clearance between front axle case boss and front axle bracket bushing (front, rear) excessive	Replace bracket bush	5-S15
	4. Front axle rocking force too small	Adjust front axle rocking force	5-S4
	5. Tie-rod end loose	Tighten tie-rod slotted nut	5-S6
Front Wheels Can Not Be Driven	1. Front wheel driving gears in front axle gear case broken	Replace drive gear (front axle gear case side)	5-S7
	2. Front wheel drive gears in transmission broken	Replace drive gear (transmission side)	2-S27
	3. Front differential gear broken	Replace front differential gear	5-S11
Noise	1. Gear backlash excessive	Inspect or adjust backlash	5-S13
	2. Oil insufficient	Check front axle case oil	5-S5
	3. Bearings damaged or broken	Replace bearing	5-S11
	4. Gears damaged or broken	Replace gear	5-S6
	5. Spiral bevel pinion shaft turning torque improper	Inspect or repair spiral bevel pinion	5-S11, 5-S12

9Y1211156FAS0001US0

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Front Wheel Alignment	Toe-in	0 to 10 mm 0 to 0.39 in.	–
Front Axle	Rocking Force	50.0 to 100.0 N 5.1 to 10.2 kgf 12.8 to 22.4 lbf	–
Differential Pinion to Differential Case	Clearance	0.032 to 0.068 mm 0.0013 to 0.0026 in.	0.2 mm 0.008 in.
• Differential Case Bore	I.D.	15.000 to 15.018 mm 0.59056 to 0.59125 in.	–
• Differential Pinion	O.D.	14.9509 to 14.968 mm 0.58859 to 0.58829 in.	–
Yoke Shaft to Differential Case	Clearance	0.020 to 0.051 mm 0.00079 to 0.0020 in.	0.2 mm 0.008 in.
• Differential Case Bore	I.D.	20.000 to 20.018 mm 0.78741 to 0.78811 in.	–
• Yoke Shaft	O.D.	19.967 to 19.980 mm 0.78611 to 0.78661 in.	–
Spiral Bevel Pinion Shaft	Turning Torque	0.8 to 1.0 N·m 0.08 to 0.10 kgf·m 0.59 to 0.73 lbf·ft	–
Spiral Bevel Pinion Shaft to Spiral Bevel Gear	Backlash	0.10 to 0.30 mm 0.0040 to 0.011 in.	–
Bevel Gear to 16T Bevel Gear	Backlash	0.10 to 0.30 mm 0.0040 to 0.011 in.	–
Front Axle Case Boss to Bracket Bushing (Front)	Clearance	0.125 to 0.285 mm 0.00493 to 0.0112 in.	0.45 mm 0.018 in.
• Front Axle Case Boss	O.D.	54.94 to 54.97 mm 2.163 to 2.164 in.	–
• Bracket Bushing	I.D.	55.095 to 55.225 mm 2.1691 to 2.1742 in.	–
Front Axle Case Boss to Bracket Bushing (Rear)	Clearance	0.120 to 0.300 mm 0.00473 to 0.0118 in.	0.45 mm 0.018 in.
• Front Axle Case Boss	O.D.	65.005 to 65.035 mm 2.5593 to 2.5604 in.	–
• Bracket Bushing	I.D.	65.155 to 65.305 mm 2.5652 to 2.5710 in.	–

9Y1211156FAS0002US0

3. TIGHTENING TORQUES


Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)

Item	N·m	kgf·m	lbf·ft
Front wheel mounting bolt and nut	77.0 to 90.0	7.9 to 9.2	57.0 to 67.0
Delivery hose retaining nut	24 to 28	2.5 to 2.9	17.7 to 20.7
Front axle holder mounting bolt	200 to 230	20.4 to 23.5	147.5 to 169.6
Tie-rod slotted nut	18 to 35	1.8 to 3.5	14 to 25
Tie-rod joint	74 to 84	7.5 to 8.6	54.4 to 61.9
Bevel gear case mounting screw	77.5 to 90.1	7.9 to 9.2	57.1 to 66.5
Axle flange mounting bolt	48.1 to 55.9	4.9 to 5.7	35.5 to 41.2

9Y1211156FAS0003US0

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



Toe-in

1. Inflate the tires to the specified pressure.
2. Turn the front wheels straight ahead.
3. Measure the toe-in ((B) - (A)).
4. If the measurement is not within the factory specifications, adjust the tie-rod length.

Toe-in (B) - (A)	Factory specification	0 to 10 mm 0 to 0.39 in.
------------------	-----------------------	-----------------------------

- (A) Wheel to Wheel Distance at front (C) Front
(B) Wheel to Wheel Distance at rear

9Y1211156FAS0004US0



Toe-in Adjusting

1. Loosen the lock nut (2).
2. Turn the tie-rod end (1) to adjust the rod length until the proper toe-in measurement is obtained.
3. Retighten the lock nut (2).

- (1) Tie-rod End (2) Lock Nut

9Y1211156FAS0005US0



Front Axle Rocking Force

1. Jack up the front side of tractor.
2. Set a spring balance to the front axle flange.
3. Measure the front axle rocking force.
4. If the measurement is not within the factory specifications, adjust with the adjusting screw (2). After applying liquid gasket (Three Bond 1206D or equivalent) to the thread portion of the adjusting screw (2) to prevent front axle oil from leaking out of the front axle holder (3).
5. Tighten the lock nut (1) firmly.


Front axle rocking force	Factory specification	50.0 to 100.0 N 5.1 to 10.2 kgf 12.8 to 22.4 lbf
--------------------------	-----------------------	--



- (1) Lock Nut
(2) Adjusting Screw
(3) Holder
(4) Thrust Collar
(5) Front Axle Case


A: Thread Portion

9Y1211156FAS0006US0



[2] DISASSEMBLING AND ASSEMBLING

(1) Separating Front Axle Assembly



Draining Front Axle Case Oil

1. Place the oil pans underneath the front axle case.
2. Remove the both right and left hand side drain plugs (2) and filling plug (1) to drain the front axle case oil.
3. After draining, reinstall the drain plugs (2).
4. Fill with new oil up to the upper notch on the dipstick.

NOTE


- After ten minutes, check the oil level again, add oil to prescribed level.
- Use KUBOTA SUPER UDT fluid or SAE 80, 90 gear oil. Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.

Front axle case oil capacity	3.5 L 3.7 U.S.qts 3.1 Imp.qts
------------------------------	-------------------------------------

- (1) Filling Plug with Dipstick
(2) Drain Plug

A: Oil level is acceptable within this range

9Y1211156FAS0007US0



Front Wheels and Steering Cylinder Hoses

1. Disconnect the delivery hoses (1), (3).
2. Lift up the tractor front side.
3. Slide the front cover (4).
4. Remove the front wheels.

NOTE

- After disconnecting the delivery hoses, do not steer the front axle so that the steering oil may come out from the delivery hoses.

IMPORTANT


- Connect the delivery hoses to the original position.

(When reassembling)

- Be sure to assemble the delivery hose R.H. and L.H. as shown in figure.

(Bleeding air in power steering circuit)

- Start the engine.
- Turn the steering wheel slowly in bolt directions all the way alternately several times, and stop the engine.





Tightening torque	Front wheel mounting bolt and nut	78 to 90 N·m 8.0 to 9.1 kgf·m 58 to 66 lbf·ft
	Delivery hose retaining nut	24 to 28 N·m 2.5 to 2.9 kgf·m 17.7 to 20.7 lbf·ft

- (1) Delivery Hose (R.H.)
(2) Steering Cylinder

- (3) Delivery Hose (L.H.)
(4) Front Cover

9Y1211156FAS0008US0





Front Axle Holder and Front Axle

1. Place the disassembling stand under the front axle.
2. Remove the front axle holder mounting bolts (1).
3. Separate the front axle holders (2), (3).
4. Separate the front axle from the front axle frame.

(When reassembling)



- Slide the coupling and the front cover to the front drive shaft.
- Align the front axle holders to the front axle frame, and align the coupling to the bevel pinion shaft spline.

Tightening torque	Front axle holder mounting bolt	200 to 230 N·m 20.4 to 23.5 kgf·m 147.5 to 169.6 lbf·ft

- (1) Front Axle Holder Mounting Bolt (3) Front Axle Holder (Rear)
 (2) Front Axle Holder (Front)

9Y1211156FAS0009US0

(2) Disassembling Front Axle Assembly



Front Axle Brackets and Tie-rod Ends

1. Remove the slotted nut (4) and remove the tie-rod end (3).
2. Remove the front axle brackets (1), (2).


(When reassembling)

- Apply grease to the thrust collar of front axle bracket.
- Apply grease to the O-ring and be careful not to damage it.
- After tightening the slotted nut, install cotter pin as shown in the figure.

Tightening torque	Tie-rod slotted nut	18 to 35 N·m 1.8 to 3.5 kgf·m 14 to 25 lbf·ft
	Tie-rod joint	74 to 84 N·m 7.5 to 8.6 kgf·m 54.4 to 61.9 lbf·ft

- (1) Front Axle Bracket (Front) (4) Slotted Nut
 (2) Front Axle Bracket (Rear) (5) Cotter Pin
 (3) Tie-rod End

9Y1211156FAS0010US0



Bevel Gear Case

1. Remove the bevel gear case mounting screws.
2. Remove the bevel gear case (2) and front gear case (1) as a unit from the front axle case (4).


(When reassembling)

- Apply grease to the O-ring (3) and be careful not to damage it.
- Do not interchange right and left bevel gear case assemblies and right and left gear case assemblies.

Tightening torque	Bevel gear case mounting screw	77.5 to 90.1 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 lbf·ft
-------------------	--------------------------------	---

- (1) Front Gear Case (2) Bevel Gear Case (3) O-ring (4) Front Axle Case

9Y1211156FAS0011US0



Front Gear Case and Axle Flange

1. Remove the axle flange mounting bolts.
2. Remove the axle flange (2).

(When reassembling)

- Apply liquid gasket (Three Bond 1206D or equivalent) to joint face of the axle flange (2) and the front gear case (1) after eliminating the water, oil and stuck liquid gasket.
- Tighten the axle flange bolts and nuts diagonally in several steps.



Tightening torque	Axle flange mounting bolt	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 lbf·ft
-------------------	---------------------------	---

- (1) Front Gear Case (2) Axle Flange

A: Portion to apply liquid gasket

9Y1211156FAS0012US0





Bevel Gear Shaft and Bevel Gear Case Oil Seal


1. Remove the external cir-clip (3).
2. Remove the bevel gear case (6) from the front gear case (7).
3. Remove the oil seal (9).
4. Remove the ball bearing (8).
5. Remove the internal cir-clip (5) and remove the ball bearing (4).
6. Remove the bevel gear shaft (2) with the bearing.

(When reassembling)

- Install the oil seal (9) of the bevel gear case, noting its direction as shown in the figure.

- | | |
|-----------------------|------------------------------|
| (1) Axle Flange | (6) Bevel Gear Case |
| (2) Bevel Gear Shaft | (7) Front Gear Case |
| (3) External Cir-clip | (8) Ball Bearing |
| (4) Ball Bearing | (9) Bevel Gear Case Oil Seal |
| (5) Internal Cir-clip | |

9Y1211156FAS0013US0



Bevel Gear Case Gears

1. Remove the internal snap ring (5).
2. Remove the bevel gears (3), (2) with ball bearings (7), (6) and shims (4).

(When reassembling)

- Install the shim (4) to their original position.



(Reference)

- Thickness of adjusting shims:
 - 1.0 mm (0.039 in.)
 - 0.8 mm (0.031 in.)
 - 1.2 mm (0.047 in.)
 - 1.4 mm (0.055 in.)

- (1) Bevel Gear Case
- (2) Bevel Gear
- (3) Bevel Gear

- (4) Shim
- (5) Internal Cir-clip
- (6) Ball Bearing
- (7) Ball Bearing

9Y1211156FAS0014US0



Axle

1. Remove the bearing (1).
2. Remove the bevel gear (2).
3. Remove the collar (3).
4. Tap out the axle (4).

(When reassembling)






- Install the oil seal (7) of axle flange (6), noting its direction as shown in the figure.
- Install the shims (8) to their original position.

(Reference)

- Thickness of adjusting shims:
 - 0.8 mm (0.03 in.): Parts No. 6C040-5714-0
 - 1.0 mm (0.04 in.): Parts No. 6C040-5713-0
 - 1.2 mm (0.05 in.): Parts No. 6C040-5715-0
 - 1.4 mm (0.06 in.): Parts No. 6C040-5716-0

- | | |
|------------------|------------------|
| (1) Ball Bearing | (5) Ball Bearing |
| (2) Bevel Gear | (6) Axle Flange |
| (3) Collar | (7) Oil Seal |
| (4) Axle | (8) Shim |

9Y1211156FAS0015US0



Spiral Bevel Pinion Shaft and Differential Gear Assembly

1. Remove the oil seal from the front axle case (5).
2. Remove the internal cir-clip (2) and the collar (3).
3. Tap out the spiral bevel pinion shaft (4) to the rear side.
4. Remove the differential gear assembly (6) from the right side of the front axle case.
5. Remove the nut (1) from the spiral bevel pinion shaft (4).
6. Remove the taper roller bearings (8).

(When reassembling)

- Replace the oil seal and the nut (1) with new one.
- Apply grease to the oil seal.
- Tighten up the nut (1) until the turning torque of the spiral bevel pinion shaft reaches the factory specifications. (See page 5-S12.)
- Install the same shims and collars before they are removed.
- Install the taper roller bearing correctly, noting their direction, and apply gear oil to them.
- Stake the lock nut firmly.

- | | |
|-------------------------------|-------------------------------------|
| (1) Nut | (6) Differential Gear Assembly |
| (2) Internal Cir-clip | (7) Differential Yoke Shaft (L.H.) |
| (3) Collar | (8) Taper Roller Bearing |
| (4) Spiral Bevel Pinion Shaft | (9) Collar |
| (5) Front axle Case | (10) Differential Yoke Shaft (R.H.) |

9Y1211156FAS0016US0

Differential Gear

1. Remove the external cir-clip (2) from the differential case (8).
2. Tap out the spring pins (11) from the differential yoke shafts (1), (10).
3. Remove the differential yoke shafts (1), (10) from the differential case (8).
4. Remove the bevel gears (6) and the collars (5) from the differential case (8).
5. Remove the spiral bevel gear (3) and the ball bearings (4) from the differential case (8).

NOTE

- Arrange the parts to know their original position.


(When reassembling)

- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of the differential bevel gears (6) and differential pinion (7).

- | | |
|------------------------------------|-------------------------------------|
| (1) Differential Yoke Shaft (R.H.) | (7) Differential Pinion |
| (2) External Cir-clip | (8) Differential Case |
| (3) Spiral Bevel Gear | (9) Ball Bearing |
| (4) Ball Bearing | (10) Differential Yoke Shaft (L.H.) |
| (5) Collar | (11) Spring Pin |
| (6) Bevel Gear | |

9Y1211156FAS0017US0

[3] SERVICING



Clearance between Differential Case and Differential Pinion

1. Measure the differential pinion boss O.D. with an outside micrometer.
2. Measure the differential case bore I.D. with a cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace damage parts.

Clearance between differential case and differential pinion	Factory specification	0.032 to 0.068 mm 0.0013 to 0.0026 in.
	Allowable limit	0.2 mm 0.008 in.

Differential case bore I.D.	Factory specification	15.000 to 15.018 mm 0.59056 to 0.59125 in.
-----------------------------	-----------------------	---

Differential pinion O.D.	Factory specification	14.9509 to 14.968 mm 0.58859 to 0.58829 in.
--------------------------	-----------------------	--

9Y1211156FAS0018US0



Clearance between Differential Case and Yoke Shaft


1. Measure the yoke shaft O.D. with an outside micrometer.
2. Measure the differential case bore I.D. with a cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace damage parts.

Clearance between differential case and yoke shaft	Factory specification	0.020 to 0.051 mm 0.00079 to 0.0020 in.
	Allowable limit	0.2 mm 0.008 in.

Differential pinion shaft I.D.	Factory specification	20.000 to 20.018 mm 0.78741 to 0.78811 in.
--------------------------------	-----------------------	---

Yoke shaft O.D.	Factory specification	19.967 to 19.980 mm 0.78611 to 0.78661 in.
-----------------	-----------------------	---

9Y1211156FAS0019US0



Turning Torque of Spiral Bevel Pinion Shaft

1. Cramp the spiral bevel pinion shaft assembly to the vise and tighten the staking nut.
2. Measure the turning torque of bevel pinion shaft.
3. If the turning torque is not within the factory specifications, adjust with the lock nut.

Turning torque	Factory specification	0.8 to 1.0 N·m 0.08 to 0.10 kgf·m 0.59 to 0.73 lbf·ft
----------------	-----------------------	---




■ **NOTE**

- After turning force adjustment, be sure to stake the lock nut.

(1) Adaptor

(2) Torque Wrench

9Y1211156FAS0020US0



Backlash between Spiral Bevel Pinion Shaft and Spiral Bevel Gear

1. Place the solder wire (2) on the gear tooth of the spiral bevel gear (1).
2. Install the spiral bevel gear (1) and the differential yoke shaft (3) into the front axle case.
3. Install the spiral bevel pinion shaft (4) to the front axle case. Install the internal cir-clip to the front axle case.
4. Turn the spiral bevel pinion shaft (4) holding the differential yoke shaft (3) by hand lightly.
5. Remove the solder wire (2). And measure the solder wire (2).
6. If the backlash is not within the factory specifications, change the adjusting collars (5), (6). For example change the adjusting collar (6) to 0.1 mm (0.004 in.) smaller size, and change the adjusting collar (5) to 0.1 mm (0.004 in.) larger size.
7. Adjust the backlash properly by repeating the above procedures.


Backlash between spiral bevel pinion shaft and spiral bevel gear	Factory specification	0.10 to 0.30 mm 0.0040 to 0.011 in.
--	-----------------------	--

(Reference)

- Above factory specification should be measured on the tooth of spiral bevel pinion. When measuring the backlash on the spline of its shaft, factory specification will be 0.0571 to 0.1714 mm (0.00225 to 0.00675 in.).
- Thickness of adjusting collars (5), (6):
 - 3.4 mm (0.134 in.)
 - 3.6 mm (0.142 in.)
 - 3.8 mm (0.150 in.)
 - 4.0 mm (0.157 in.)
 - 4.1 mm (0.161 in.)
 - 4.2 mm (0.165 in.)
 - 4.4 mm (0.173 in.)
 - 4.6 mm (0.181 in.)

- | | |
|----------------------------------|-------------------------------|
| (1) Spiral Bevel Gear | (4) Spiral Bevel Pinion Shaft |
| (2) Solder Wire | (5) Adjusting Collar |
| (3) Differential Yoke Shaft (RH) | (6) Adjusting Collar |

9Y1211156FAS0021US0



Backlash between 10T or 11T Bevel Gear and 16T Bevel Gear

1. Stick a strip of fuse to three spots on the 16T bevel gear (1) with grease.
2. Fix the front axle case, bevel gear case and front gear case.
3. Turn the axle.
4. Remove the bevel gear case from front axle case and measure the thickness of the fuses with an outside micrometer.
5. If the backlash is not within the factory specifications, adjust with shim (3).

Backlash between bevel gear and bevel gear (16T)	Factory specification	0.10 to 0.30 mm 0.0040 to 0.011 in.
--	-----------------------	--


(Reference)

- Thickness of adjusting shims (3):
 - 0.8 mm (0.031 in.)
 - 1.0 mm (0.039 in.)
 - 1.2 mm (0.047 in.)
 - 1.4 mm (0.055 in.)
- Tooth contact: More than 35 %

(1) Bevel Gear
(2) Bevel Gear

(3) Shim

9Y1211156FAS0022US0



Clearance between Front Axle Case Bosses and Bracket Bushing

1. Measure the front axle case bosses O.D. with an outside micrometer.
2. Measure the bracket Bushing I.D. with a cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the bracket bushing.
4. If the clearance still exceeds the allowable limit, replace the front axle case.

Clearance between front axle case boss (front) and bracket bushing (front)	Factory specification	0.125 to 0.285 mm 0.00493 to 0.0112 in.
	Allowable limit	0.45 mm 0.018 in.

Front axle case boss (front) O.D.	Factory specification	54.94 to 54.97 mm 2.163 to 2.164 in.
Bracket bushing (front) I.D.	Factory specification	55.095 to 55.225 mm 2.1691 to 2.1742 in.

Clearance between front axle case boss (rear) and bracket bushing (rear)	Factory specification	0.120 to 0.300 mm 0.00473 to 0.0118 in.
	Allowable limit	0.45 mm 0.018 in.

Front axle case boss (rear) O.D.	Factory specification	65.005 to 65.035 mm 2.5593 to 2.5604 in.
Bracket bushing (rear) I.D.	Factory specification	65.155 to 65.305 mm 2.5652 to 2.5710 in.

Press-fitting Bushing

- When replacing the bushings (1), press-fit it until bushing contact to inside of the front axle bracket holder.
- Apply grease to the O-rings (2) and be careful not to damage it.

NOTE

- **After replacing the bushing, be sure to adjust the front axle rocking force. (See page 5-S4.)**

(1) Bushing

(2) O-ring

9Y1211156FAS0023US0


6 STEERING

MECHANISM

CONTENTS

1. HYDRAULIC CIRCUIT	6-M1
2. STEERING CONTROLLER.....	6-M2
3. STEERING CYLINDER	6-M3
4. HYDRAULIC PUMP.....	6-M4

1. HYDRAULIC CIRCUIT



The model is provided with a full hydrostatic power steering.


In the hydrostatic power steering, the steering control is connected to the steering cylinder with only the hydraulic piping. Accordingly, it does not have mechanical transmitting parts such as steering gear, pitman arm, drag link, etc.. Therefore, it is simple in construction. This steering system consists of oil filter cartridge (5), hydraulic pump (4), steering controller (2), steering cylinder (1), etc..

By operating the power steering body, the required amount of oil is fed to the steering cylinder (1).


- | | |
|--|-----------------------------------|
| (1) Power Steering Cylinder | A: Independent PTO Control |
| (2) Power Steering Controller | Valve |
| (3) Oil Cooler | B: HST |
| (4) Hydraulic Pump (for Power Steering, Independent PTO and HST) | C: To 3-Points Hitch |
| (5) Oil Filter Cartridge | |
| (6) Hydraulic Pump (for 3-Points Hitch) | |

9Y1211156STM0001US0


2. STEERING CONTROLLER




3TBAAAG7P002A



3TBAAAG7P009A



3TAAAAB7P004B



3TAAAAB7P005B

The steering controller consists of a control valve (4) and a metering device (3).

■ Control Valve

The control valve is a rotating spool type. When the steering wheel is not turned, the position of the spool (7) and sleeve (9) is kept neutral by the centering spring (8). This causes the forming of a "Neutral" oil circuit. When the steering wheel is turned either clockwise or counterclockwise, the position of the spool and sleeve changes in relation to the centering spring. This allows the forming of a "Right Turning" or "Left Turning" oil circuit. At the same time, the gear pump (Metering device) rotates with the spool and sends the oil to the cylinder corresponding to the rotation of the steering wheel.

■ Metering Device

An oil, sent from the hydraulic pump to the steering cylinder, passes through the metering device (3). Namely, when the rotor is driven, two chambers suck in oil due to volumetric change in the pump chambers formed between the rotor (12) and the stator (13), while oil is discharged from other two chambers. On the other hand, rotation of the steering wheel is directly transmitted to the rotor through the spool (7), drive shaft (10), etc. Accordingly, the metering device serves to supply the steering cylinder with oil, amount of which corresponds to the rotation of the steering wheel. The wheels are thus turned by the angle corresponding to the rotation of the steering wheel. When the engine stops or the hydraulic pump malfunctions, the metering device functions as a manual trochoid pump, which makes manual steering possible.

■ Relief Valve

The relief valve (1) is located in the steering controller. It controls the maximum pressure of the power steering system.


Its setting pressure is as follows

- 11.5 to 12.5 MPa
- 118 to 127 kgf/cm²
- 1670 to 1810 psi

- | | |
|-------------------------|--|
| (1) Relief Valve | (12) Rotor |
| (2) Steering Controller | (13) Stator |
| (3) Metering Device | |
| (4) Control Valve | A: Control Valve |
| (5) Steering Cylinder | B: Metering Device |
| (6) Check Valve | P: P Port (from Hydraulic Pump) |
| (7) Spool | T: T Port (to Independent PTO Clutch Valve and HST Circuit) |
| (8) Centering Spring | |
| (9) Sleeve | |
| (10) Drive Shaft | |
| (11) Distributor Plate | |

9Y1211156STM0002US0

3. STEERING CYLINDER



- | | | | |
|---------------|---------------|-------------------|------------|
| (1) Rod | (3) Rod Cover | (5) Piston Seal | (7) O-ring |
| (2) Dust Seal | (4) U gasket | (6) Cylinder Tube | |

The steering cylinder is single piston both rod double-acting type. This steering cylinder is installed parallel to the front axle and connected to tie-rods.

The tie-rods connected to both knuckle arm guarantees equal steering movement to both front wheels.

The steering cylinder provide force in both directions. Depending upon direction the steering wheel is turned pressure oil enters at one end of the cylinder to extend, or the other end to retract it, thereby turning front wheel of the tractor.

9Y1211156STM0003US0

4. HYDRAULIC PUMP

- See page 7-M2.

9Y1211156STM0004US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	6-S1
2. SERVICING SPECIFICATIONS	6-S3
3. TIGHTENING TORQUES.....	6-S4
4. CHECKING, DISASSEMBLING AND SERVICING.....	6-S5
[1] CHECKING.....	6-S5
(1) Relief Valve	6-S5
(2) Hydraulic Pump for Power Steering	6-S5
[2] DISASSEMBLING	6-S6
(1) Separating Power Steering Controller.....	6-S6
(2) Power Steering Controller	6-S6
(3) Power Steering Cylinder.....	6-S7
[3] SERVICING.....	6-S9
(1) Power Steering Cylinder.....	6-S9

1. TROUBLESHOOTING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Cannot Be Steered	1. Steering controller malfunctioning	Replace steering controller	6-S6
Hard Steering	1. Tire air pressure of the tires is incorrect	Check air pressure	G-45
	2. Oil leak from pipe joint	Check hose joint	6-S6
	3. Hydraulic pump malfunctioning	Solution order 1. Check hydraulic flow test	7-S6
		2. Replace hydraulic pump	7-S9
	4. Improper relief valve pressure	Solution order 1. Check system pressure	6-S5
		2. Replace steering controller	6-S6
5. Steering controller malfunctioning	Solution order 1. Check system pressure	6-S5	
	2. Replace steering controller	6-S6	
Steering Force Fluctuates	1. Air sucked in pump due to lack of oil	Check transmission oil	G-8
	2. Air sucked in pump from suction circuit	Bleed air	6-S6
	3. Steering controller malfunctioning	Solution order 1. Check system pressure	6-S5
2. Replace steering controller		6-S6	
Steering Wheel Turns Spontaneously When Released	1. Steering controller malfunctioning	Solution order 1. Check system pressure	6-S5
		2. Replace steering controller	6-S6
Low Operating Pressure	1. Oil leak from pipe	Check or replace pipe	6-S6
	2. Pipe or hose broken	Replace pipe or hose	6-S6
	3. Hydraulic pump malfunctioning	Solution order 1. Check hydraulic flow test	7-S6
		2. Replace hydraulic pump	7-S9
	4. Improper relief valve adjustment	Solution order 1. Check system pressure	6-S5
		2. Replace steering controller	6-S6
5. Relief Valve malfunctioning	Solution order 1. Check system pressure	6-S5	
	2. Replace steering controller	6-S6	

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Front Wheels Wander to Right and Left	1. Tire air pressure of the tires is incorrect	Check air pressure	G-45
	2. Improper toe-in adjustment	Adjust toe-in	5-S4
	3. Insufficient bleeding	Bleed air	6-S6
	4. Air sucked in pump due to lack of oil	Check transmission oil	G-8
	5. Air sucked in pump from suction circuit	Bleed air	6-S6
	6. Steering controller malfunctioning	Solution order 1. Check system pressure	6-S5
		2. Replace steering controller	6-S6
Wheels Are Turned to a Direction Opposite to Steering Direction	1. Cylinder piping connected in reverse	Repair steering cylinder hose	6-S6
Steering Wheel Turns Idle in Manual Steering	1. Insufficient bleeding	Bleed air	6-S6
	2. Air sucked in due to lack of oil	Check transmission oil	G-8
Noise	1. Air sucked in pump due to lack of oil	Check transmission oil	G-8
	2. Air sucked in pump from suction circuit	Bleed air	6-S6
	3. Hose deformed	Replace hose	6-S6
Oil Temperature Increases Rapidly	1. Steering controller (relief valve) malfunctioning	Solution order 1. Check system pressure	6-S5
		2. Replace steering controller	6-S6

9Y1211156STS0001US0

2. SERVICING SPECIFICATIONS

POWER STEERING BODY

Item		Factory Specification	Allowable Limit
Relief Valve	Setting Pressure	11.5 to 12.5 MPa 118 to 127 kgf/cm ² 1670 to 1810 psi	–

POWER STEERING CYLINDER

Item		Factory Specification	Allowable Limit
Steering Cylinder	I.D.	40.000 to 40.062 mm 1.57480 to 1.57724 in.	40.100 mm 1.57874 in.
Piston Rod to Guide	Clearance	0.020 to 0.070 mm 0.00079 to 0.00276 in.	0.200 mm 0.00787 in.

9Y1211156STS0002US0

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)


Item	N·m	kgf·m	lbf·ft
Power steering hose for power steering cylinder	24 to 28	2.5 to 2.9	18 to 20
Power steering controller for pipes and hoses	24 to 28	2.5 to 2.9	18 to 20
Universal joint mounting bolt	24 to 28	2.5 to 2.9	18 to 20
Tie-rod slotted nut	18 to 35	1.9 to 3.5	14 to 25
Tie-rod joint	74 to 84	7.5 to 8.5	55 to 61

9Y1211156STS0003US0

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING

(1) Relief Valve



Relief Valve Operating Pressure

1. Disconnect the power steering hose L.H. (or R.H.) from steering the power steering cylinder, and set a pressure gauge and cable.

(Reference)

- Hose and adaptor size: 9/16-18UNF, 37 ° flare.
2. Start the engine and set at maximum speed.
 3. Fully turn the steering wheel to the left (or right) to check the feeling which the steering wheel lightly locks. Read the relief valve operating pressure when the steering wheel to the above-mentioned lock position by operation force at approximately 9.8 N (1 kgf, 2.2 lbf) of outer.

■ NOTE

- After set a pressure gauge, be sure to bleed air.
- Note that the pressure value changes by the pump action of the power steering controller when the steering operation is continued after the steering wheel is lightly locked and accurate relief valve pressure cannot be measured.

(Bleeding air in power steering circuit)

- Start the engine.
- Turn the steering wheel slowly in both directions all the way alternately several times, and stop the engine.

Relief valve operating pressure	Factory specification	11.5 to 12.5 MPa 118 to 127 kgf/cm ² 1670 to 1810 psi
Tightening torque	Power steering hose for power steering cylinder	24 to 28 N·m 2.5 to 2.9 kgf·m 18 to 20 lbf·ft

(1) Power Steering Hose (R.H.)

(3) Power Steering Hose (L.H.)

(2) Power Steering Cylinder

9Y1211156STS0004US0

(2) Hydraulic Pump for Power Steering

- See page 7-S6.

9Y1211156STS0005US0


[2] DISASSEMBLING

(1) Separating Power Steering Controller

Steering Wheel, Meter Panel Bonnet and Fuel Tank

- See page 1-S23.

9Y1211156STS0006US0



Steering Post Assembly

1. Remove the steering post mounting bolts.
2. Disconnect the power steering hoses (3) from the power steering controller (2).
3. Remove the steering post assembly (4) from the main frame.

(When reassembling)


- Connect the power steering hoses (3) to the power steering controller (2) securely.

Tightening torque	Power steering controller for pipes and hoses	24 to 28 N·m 2.5 to 2.9 kgf·m 18 to 20 lbf·ft
-------------------	---	---

- | | |
|-------------------------------|----------------------------|
| (1) Bolt | (3) Power Steering Hose |
| (2) Power Steering Controller | (4) Steering Post Assembly |

9Y1211156STS0007US0

(2) Power Steering Controller



Power Steering Controller

1. Remove the bolt from the universal joint (3).
2. Remove the power steering controller (1) from the steering post.



(When reassembling)

- If oil leaking from the power steering controller (1) is found, replace the power steering controller (1). O-ring in the power steering controller (1) is not supplied as a spare part.
- Align the power steering controller shaft (4) to the universal joint (3) securely.

Tightening torque	Universal joint mounting bolt	24 to 28 N·m 2.5 to 2.8 kgf·m 18 to 20 lbf·ft
-------------------	-------------------------------	---

- | | |
|-------------------------------------|---------------------------------|
| (1) Power Steering Controller | (6) Adaptor (to Right Cylinder) |
| (2) Steering Shaft | (7) Adaptor (to Left Cylinder) |
| (3) Universal Joint | (8) Adaptor (to Hydraulic Pump) |
| (4) Power Steering Controller Shaft | (9) Adaptor (to Oil Cooler) |
| (5) Relief Valve | |

9Y1211156STS0008US0





(3) Power Steering Cylinder

Front Wheels

- See page 5-S5.

9Y1211156STS0009US0



Tie-rod Joint

1. Remove the slotted nut (4) and remove the tie-rod end (3).
2. Remove the front axle brackets (1), (2).

(When reassembling)

- Apply grease to the thrust collar of front axle bracket.
- Apply grease to the O-ring and be careful not to damage it.
- After tightening the slotted nut, install cotter pin as shown in the figure.





(Bleeding air in power steering circuit)

- Start the engine.
- Turn the steering wheel slowly in both directions all the way alternately several times, and stop the engine.

Tightening torque	Tie-rod slotted nut	18 to 35 N·m 1.9 to 3.5 kgf·m 14 to 25 lbf·ft
	Tie-rod joint	74 to 84 N·m 7.6 to 8.5 kgf·m 55 to 61 lbf·ft

- | | |
|--------------------------------|-----------------|
| (1) Front Axle Bracket (Front) | (4) Slotted Nut |
| (2) Front Axle Bracket (Rear) | (5) Cotter Pin |
| (3) Tie-rod End | |

9Y1211156STS0010US0



Power Steering Cylinder

CAUTION

- Since power steering cylinder is full of high-pressured steering oil, high-pressured oil is injected out from hose adopters by pushing piston rods.
- This injected oil can penetrate the skin or eyes causing serious injury.
- Use appropriate protective wear to prevent serious injury.
- Use waste to cover the adopters.
- Before disassembling drain steering oil from power steering cylinder.

1. Remove the tie-rod end (4) from the rod (1) using spanners (2), (3).
2. Remove the adaptors (8), (9).
3. Remove the rod cover (7).
4. Tap out the rod (1) to the right front wheel side.

(When reassembling)

- Apply the liquid lock (Three Bond 1375N or equivalent) to the tie-rod ends (4), (5).


Tightening torque	Tie-rod joint	74 to 84 N·m 7.5 to 8.6 kgf·m 55 to 61 lbf·ft
-------------------	---------------	---

- | | |
|------------------------|---|
| (1) Rod | (10) O-ring |
| (2) Thin Spanner | (11) Gasket |
| (3) Standard Spanner | (12) Dust Seal |
| (4) Tie-rod End (L.H.) | (13) U Gasket |
| (5) Tie-rod End (R.H.) | |
| (6) Internal Cir-clip | A: Position for thin thickness spanner |
| (7) Rod Cover | B: Position for standard thickness spanner |
| (8) Adaptor (R.H.) | |
| (9) Adaptor (L.H.) | |

9Y1211156STS0011US0

[3] SERVICING

(1) Power Steering Cylinder




Steering Cylinder I.D.

1. Measure the steering cylinder I.D. with a cylinder gauge.
2. If the cylinder I.D. exceed the allowable limit, replace the cylinder barrel.

Steering cylinder I.D.	Factory specification	40.000 to 40.062 mm 1.57480 to 1.57724 in.
	Allowable limit	40.100 mm 1.57874 in.

9Y1211156STS0012US0



Clearance between Rod and Guide

1. Measure the rod guide I.D. with a cylinder gauge.
2. Measure the rod O.D. with an outside micrometer, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace as a unit.

Clearance between rod and guide	Factory specification	0.020 to 0.070 mm 0.00079 to 0.00276 in.
	Allowable limit	0.200 mm 0.00787 in.

9Y1211156STS0013US0


7 HYDRAULIC SYSTEM

MECHANISM

CONTENTS

1. HYDRAULIC CIRCUIT	7-M1
2. HYDRAULIC PUMP.....	7-M2
3. HYDRAULIC CIRCUIT	7-M3
[1] HYDRAULIC CIRCUIT	7-M3
[2] RELIEF VALVE	7-M4
[3] POSITION CONTROL VALVE	7-M5
(1) Structure	7-M5
(2) Operation.....	7-M6
[4] FEEDBACK LINKAGE FOR POSITION CONTROL	7-M8
4. FRONT LOADER CONTROL VALVE	7-M9
[1] STRUCTURE	7-M9
[2] OPERATION	7-M10
5. REMOTE CONTROL VALVE (IF EQUIPPED).....	7-M17
6. HYDRAULIC OUTLET	7-M18

1. HYDRAULIC CIRCUIT



9Y1211156HYM001A



- | | | | |
|--|---|--|-------------------------------------|
| (1) Oil Filter | (7) Regulating Valve (For Independent PTO Clutch) | (12) Oil Filter | (18) Boom Cylinder |
| (2) Hydraulic Pump (For 3-point Hitch) | (8) Control Valve for Independent PTO | (13) HST | (19) Bucket Cylinder |
| (3) Hydraulic Pump (For Power Steering) | (9) Independent PTO Clutch | (14) Check and High Pressure Relief Valve | (20) Rear Hydraulic Outlet |
| (4) Power Steering | (10) Control Valve for Backhoe BH70 | (15) Charge Relief Valve | (21) Position Control Valve |
| (5) Relief Valve (Power Steering Controller) | (11) Relief Valve for Oil Filter | (16) Front Loader Control Valve | (22) Lowering Speed Adjusting Valve |
| (6) Oil Cooler | | (17) Relief Valve (For 3-point Hitch System and Front Loader System) | (23) Hydraulic Cylinder |
| | | | (24) Aux Hydraulic Valve Kit System |

Operating Pressure

(2)	Hydraulic Pump (For 3-point Hitch) Above 21.0 L/min. (5.55 U.S. gals/min., 4.62 Imp. gals/min.)	(14)	Check and High Pressure Relief Valve (For HST) 23 to 25 MPa (240 to 250 kgf/cm ² , 3400 to 3600 psi)
(3)	Hydraulic Pump (For Power Steering) Above 15.8 L/min. (4.17 U.S. gals/min., 3.48 Imp. gals/min.)	(15)	Charge Relief Valve (For HST) 0.4 to 0.6 MPa (4.1 to 6.1 kgf/cm ² , 60 to 80 psi)
(5)	Relief Valve (For Power Steering Controller) 11.5 to 12.5 MPa (118 to 127 kgf/cm ² , 1670 to 1810 psi)	(17)	Relief Valve (3-point Hitch System and Front Loader System) 13.0 to 13.8 MPa (133 to 140 kgf/cm ² , 1890 to 2000 psi)
(7)	Regulating Valve (For Independent PTO) 1.1 to 1.5 MPa (11.2 to 15.3 kgf/cm ² , 160 to 210 psi)		

9Y1211156HYM0001US0

2. HYDRAULIC PUMP



The hydraulic pump consists of the casing (1), side plate (4), and two spur gears (drive gear (3) and driven gear (2)) that are in mesh.

Hydraulic pump is driven by the fuel camshaft.

Maximum displacement is as follows.

Hydraulic Pump (for 3-points Hitch)

Displacement	Engine speed	Condition
21.0 L/min. 5.55 U.S.gals/min. 4.62 Imp.gals/min.	At 2800 min ⁻¹ (rpm)	at no load

Hydraulic Pump (for Power Steering)


Displacement	Engine speed	Condition
15.8 L/min. 4.17 U.S.gals/min. 3.48 Imp.gals/min.	At 2800 min ⁻¹ (rpm)	at no load

- (1) Casing
- (2) Driven Gear
- (3) Drive Gear
- (4) Side Plate
- (5) Hydraulic Pump (for 3-Points Hitch)
- (6) Hydraulic Pump (for Power Steering)

9Y1211156HYM0002US0

3. HYDRAULIC CIRCUIT

[1] HYDRAULIC CIRCUIT



Two hydraulic pumps (4), (6) are installed in this series of machines.



Hydraulic oil is forced from hydraulic pump (6) to the loader control valve (7), relief valve (8), hydraulic outlet (9) and position control valve (10).

Three point hydraulic oil pressure is controlled by the relief valve (8).

- | | |
|--|-------------------------------------|
| (1) Power Steering Controller | (7) Front Loader Control Valve |
| (2) Independent PTO | (8) Relief Valve |
| (3) HST | (9) Hydraulic Outlet |
| (4) Hydraulic Pump (for Power Steering, Independent PTO and HST) | (10) Position Control Valve |
| (5) Oil Filter Cartridge | (11) Lowering Speed Adjusting Valve |
| (6) Hydraulic Pump (for 3-Points Hitch) | (12) Hydraulic Cylinder |

9Y1211156HYM0003US0

[2] RELIEF VALVE



The hydraulic raising and lowering circuit is fitted with a relief valve to control the maximum pressure.

This is a guide piston relief valve with damper, a direct acting relief valve suitable for relatively high pressure and capacity, and constructed so as to prevent chattering and other unstableness associated with direct acting relief valves. As shown in the diagram, poppet (5) has a guide, and there is a valve chamber called a damping chamber (6) in the base of this guide piston. The valve inlet is connected to this chamber through the clearance between the guide surface and the seat so that the chamber provides a damping effect, controlling valve vibration.

When the pressure in the circuit rises, the pressure in the damping chamber also rises, and when it exceeds the relief pressure setting the spring is compressed, making a clearance between the poppet and the seat. The hydraulic oil can escape to the transmission case through this clearance, controlling the pressure rise.

(Reference)

- Relief valve setting pressure
13.0 to 13.8 MPa
133 to 140 kgf/cm²
1890 to 2000 psi

Condition

- Engine speed
Approx. 2800 min⁻¹ (rpm)
- Oil temperature
50 °C (122 °F)


- (1) Relief Valve
- (2) Shim
- (3) Plug
- (4) Seat
- (5) Poppet
- (6) Damping Chamber

- (a) Normal State
- (b) Active State
- T: T Port
(To Transmission Case)
- P: P Port (From Pump)

9Y1211156HYM0004US0

[3] POSITION CONTROL VALVE

(1) Structure




This position control valve (2) is located under the hydraulic cylinder block (1).

This control valve is mechanically connected to the position control lever with linkage.


This control valve is also mechanically connected to the lift arm with a feed back rod.

This control valve controls the oil flow forced from hydraulic pump and the oil returned back from the hydraulic cylinder.


- (1) Hydraulic Cylinder Block
 - (2) Position Control Valve
 - (3) Link
 - (4) Lever
 - (5) Spool
 - (6) Poppet
 - (7) Poppet
 - (8) Poppet
 - (9) Poppet
 - (10) Set Screw
- P: Pump Port**
C: Cylinder Port



9Y1211156HYM0005US0



(2) Operation



Neutral

Oil forced into the control valve through **P** port pushes and opens the unload valve (3), and then returns to the transmission case through **T1** port.


Oil behind the unload valve (3) returns to the transmission case through the groove of the spool (2).

Since the check valve (9) and the poppet 2 (5) are closed, oil in the hydraulic cylinder does not flow to the transmission case. Thus, the implement remains at its fixed position.

- (1) Valve Body
- (2) Spool
- (3) Unload Valve
- (4) Unload Poppet
- (5) Poppet 2
- (6) Sleeve
- (7) Adjusting Bolt
- (8) Connecting Plate
- (9) Check Valve

- P: Pump Port**
- C: Cylinder Port**
- T1: Tank Port**

9Y1211156HYM0006US0



Lift

When the position control lever is set to "**LIFT**" position, the spool (2) is pushed into the valve body (1).

The oil forced into the control valve body (1) through **P** port flows to two oil circuits.


The first circuit is oil flowing to the back of the unload valve (3) to close it.

The second oil circuit is oil flowing to the check valve (9) and the hydraulic cylinder through **C** port to lift the implement.

- (1) Valve Body
- (2) Spool
- (3) Unload Valve
- (4) Unload Poppet
- (5) Poppet 2
- (6) Sleeve
- (7) Adjusting Bolt
- (8) Connecting Plate
- (9) Check Valve

- P: Pump Port**
- C: Cylinder Port**
- T1: Tank Port**

9Y1211156HYM0007US0



Shockless mechanism operating (Lift to Neutral)

When the implement begins to lift up, the feedback rod connected to the lift arm pushes back the spool (2) to near **"NEUTRAL"** position.

When the implement lifts up near the **"NEUTRAL"** position, quantity of oil passing through the orifice (10) is reduced.

It causes oil pressure difference between portion **B** and unload poppet (4).

Since oil pressure at unload poppet (4) is higher than oil pressure at portion **D**, oil forced from **P** port pushes and opens unload poppet (4), and oil drains through **T2** port to transmission case.

Quantity of oil flowing through portion **B** is less.

Quantity of oil flowing to unload poppet (4) is greater.


It causes oil pressure increase at portion **D** of the unload poppet (4).

While the implement is coming to **"NEUTRAL"** position, quantity of oil flowing to spool (2) is reduced at portion **B**. And then, oil drains through unload poppet (4) to transmission case.

It causes implement's smooth stopping at **"NEUTRAL"** position without shock.

- | | |
|----------------------|-------------------------|
| (1) Valve Body | P: Pump Port |
| (2) Spool | B: Portion B |
| (3) Unload Valve | C: Cylinder Port |
| (4) Unload Poppet | D: Portion D |
| (5) Poppet 2 | T1: Tank Port |
| (6) Sleeve | |
| (7) Adjusting Bolt | |
| (8) Connecting Plate | |
| (9) Check Valve | |
| (10) Orifice | |

9Y1211156HYM0008US0



Down

When the position control lever is set to **"DOWN"** position, the spool (2) is pulled out from the control valve body (1).

At the same time, the adjust bolt (7) connected to the connecting plate (8) pushes the poppet 2 (5) into the control valve body (1). And then the poppet 2 (5) is opened.


Oil in the hydraulic cylinder is forced out from C port through and goes valve body (1) to transmission case by the weight of the implement, causing the implement to lower.

Oil forced into the control valve through **P** port pushes and opens the unload valve (3) and returns to the transmission case through **T1** port.


- | | |
|----------------------|-------------------------|
| (1) Valve Body | P: Pump Port |
| (2) Spool | C: Cylinder Port |
| (3) Unload Valve | T1: Tank Port |
| (4) Unload Poppet | T3: Tank Port |
| (5) Poppet 2 | T4: Tank Port |
| (6) Sleeve | |
| (7) Adjusting Bolt | |
| (8) Connecting Plate | |
| (9) Check Valve | |

9Y1211156HYM0009US0


[4] FEEDBACK LINKAGE FOR POSITION CONTROL



9Y1210822HYM006A



3TBAAAG8P020A



3TBAAAG8P021A

When the position control lever is moved to rearward to lift the implement, the spool of the position control valve is pushed in to form a lifting circuit by the motions of the control lever arm, the control lever shaft (3), the connecting arm (7) and the lever (8). After the lift arm (1) moves upward, the spool is pulled out and returns to form a neutral circuit by the motions of the feedback rod (2), the feedback arm (4), the feedback arm shaft (5), the connecting arm (7) and the lever (8).



As a result, the implement height can be easily determined in proportion to the set position of the position control lever.

- | | |
|-------------------------|------------------------|
| (1) Lift Arm | (5) Feedback Arm Shaft |
| (2) Feedback Rod | (6) Control Lever Arm |
| (3) Control Lever Shaft | (7) Connecting Arm |
| (4) Feedback Arm | (8) Lever |

9Y1211156HYM0010US0

4. FRONT LOADER CONTROL VALVE

[1] STRUCTURE



The control valve assembly consists of one casting block and four major section as shown above.

1) Inlet and Outlet Section

This section has **P** and **T** ports.

The **P** port is connected to the **OUTLET** port of hydraulic block by the hydraulic hose.

The **T** port is connected to the **TANK** port of hydraulic block by the hydraulic hose.

2) Boom Control Section

The boom control valve is consists of 4-position, 6-connection, detent, spring center type, consisting of a mono block valve housing, spool, load check valve, etc. This valve has **A1** and **B1** ports and controls oil flow to the boom cylinder.

3) Bucket Control Section

The bucket control valve is consists of 4-position, 6-connection, no detent, spring center type, consisting of a mono block valve housing, spool, load check valve, etc. This valve has **A2** and **B2** ports and controls oil flow to the bucket cylinder.

4) Power Beyond


This section has **PB** port which is connected to the **INLET** port of hydraulic block by the hydraulic hose, and feeds oil to the 3-point hitch hydraulic control valve.

- | | |
|---------------------------|--------------------|
| (1) Pump Port | P: P Port |
| (2) Tank Port | T: T Port |
| (3) Boom Control Spool | A1: A1 Port |
| (4) Bucket Control Spool | A2: A2 Port |
| (5) Power Beyond Port | B1: B1 Port |
| (6) Loader Valve Assembly | B2: B2 Port |
| | PB: PB Port |

9Y1211156HYM0011US0

[2] OPERATION

Neutral



3UFAAAELP007A

- (1) Boom Control Section
- (2) Bucket Control Section
- (3) Spool
- (4) Spool


- (5) PB Passage 1
- (6) PB Passage 2
- (7) Load Check Valve
- (8) Relief Valve

- T: T Port
- P: P Port
- A1: A1 Port
- A2: A2 Port

- B1: B1 Port
- B2: B2 Port
- PB: PB Port
- a: Low Pressure

9Y1211156HYM0012US0

Up




3UF AAAELP008A

- | | | | |
|----------------------------|-----------------------|------------------|---------------------------------------|
| (1) Boom Control Section | (5) Neutral Passage 1 | P: P Port | A1: A1 Port |
| (2) Bucket Control Section | (6) Load Check Valve | T: T Port | (From Boom Cylinder) |
| (3) Spool | (7) Passage 1 | | B1: B1 Port (To Boom Cylinder) |
| (4) PB Passage 1 | (8) Boom Cylinder | | PB: PB Port |
| | | | a: Low Pressure |
| | | | b: High Pressure |
1. When the hydraulic control lever is set to the **"UP"** position, the spool (3) of the boom control section (1) moves to the left, which forms oil passages between passage 1 (7) and **B1** port, and between **A1** port and **PB** passage 1 (4).
 2. As the oil passage from the neutral passage 1 (5) to the **PB** passage 1 (4) is closed by the spool (3), the pressure-fed oil from the **P** port opens the load check valve (6) and flows through the notched section of the spool (3) and **B1** port to extend the boom cylinder (8).
 3. Return oil from the boom cylinder (8) flows from the **A1** port through the passage in the spool (3) and **PB** passage 1 (4) to the bucket control section (2).

9Y1211156HYM0013US0

Down




3UFAAAELP009A

- | | | | |
|----------------------------|-----------------------|------------------|---|
| (1) Boom Control Section | (5) Neutral Passage 1 | P: P Port | A1: A1 Port (To Boom Cylinder) |
| (2) Bucket Control Section | (6) Load Check Valve | T: T Port | B1: B1 Port (From Boom Cylinder) |
| (3) Spool | (7) Passage 1 | | PB: PB Port |
| (4) PB Passage 1 | (8) Boom Cylinder | | a: Low Pressure |
| | | | b: High Pressure |

1. When the hydraulic control lever is set to the **"DOWN"** position, the spool (3) moves to the right, which forms oil passages between passage 1 (7) and **A1** port, and between **B1** port and **PB** passage 1 (4).
2. As the oil passage from the neutral passage 1 (5) to the **PB** passage 1 (4) is closed by the spool (3), the pressure-fed oil from the **P** port opens the load check valve (6) and flows through the notched section of the spool (3) and **A1** port to retract the boom cylinder (8).
3. Return oil from the boom cylinder (8) flows from the **B1** port through the passage in the spool (3) and **PB** passage 1 (4) to the bucket control section (2).

9Y1211156HYM0014US0

Floating

- (1) Boom Control Section
- (2) Bucket Control Section
- (3) Spool
- (4) **PB** Passage 1

- (5) Detent Mechanism
- (6) Neutral Passage 1
- (7) Boom Cylinder


P: P Port
T: T Port

A1: A1 Port
B1: B1 Port
PB: PB Port
a: Low Pressure

1. When the hydraulic control lever is set to the "FLOAT" position, the spool (3) moves further to the right from the "DOWN" position and is retained by the detent mechanism (5).
2. This forms oil passages among the **A1** port, **B1** port and **T** port. As a result, oil in the boom cylinder (7) flows freely from the **A1** port and **B1** port through the **T** port to the transmission case.
3. Oil entering the **P** port flows to the bucket control section (2) through the neutral passage 1 (6) and **PB** passage 1 (4).

9Y1211156HYM0015US0

Roll-back




- | | | | |
|----------------------------|----------------------|------------------------|-------------------------|
| (1) Boom Control Section | (6) PB Passage 2 | P: P Port | B2: B2 Port |
| (2) Bucket Control Section | (7) Load Check Valve | T: T Port | (To Bucket Cylinder) |
| (3) PB Passage 1 | (8) Passage 2 | PB: PB Port | a: Low Pressure |
| (4) Spool | (9) Bucket Cylinder | A2: A2 Port | b: High Pressure |
| (5) Neutral Passage 2 | | (From Bucket Cylinder) | |

- When the hydraulic control lever is set to the "ROLL-BACK" position, the spool (4) of the bucket control section (2) moves to the left, which forms oil passages between passage 2 (8) and B2 port, and between A2 port and T port.
- The pressure-fed oil from the P port flows to the neutral passage 2 (5) through the boom control section (1) and PB passage 1 (3). As the oil passage from the neutral passage 2 (5) to the PB passage 2 (6) is closed by the spool (4), this oil opens the load check valve (7), and flows through the notched section of the spool (4) and B2 port to retract the bucket cylinder (9).
- Return oil from the bucket cylinder (9) flows to the transmission case through the A2 port and T port.

9Y1211156HYM0016US0

Dump 1



3UF AAAELP012A

- | | | | |
|----------------------------|----------------------|--------------------|-------------------------|
| (1) Boom Control Section | (6) PB Passage 2 | P: P Port | A2: A2 Port |
| (2) Bucket Control Section | (7) Load Check Valve | T: T Port | (To Bucket Cylinder) |
| (3) PB Passage 1 | (8) Passage 2 | PB: PB Port | B2: B2 Port |
| (4) Spool | (9) Bucket Cylinder | | (From Bucket Cylinder) |
| (5) Neutral Passage 2 | | | b: High Pressure |


- When the hydraulic control lever is set to the "DUMP 1" position, the spool (4), which forms oil passages among passage 2 (8), A2 port and B2 port.
- The pressure-fed oil from the P port flows through the boom control valve, opens the load check valve, and flows to the bucket cylinder to extend the cylinder through the notched section of the spool and A2 port.
- Return oil from the bucket cylinder (9) flows from the B2 port to the passage 2 (8), and flows to the A2 port together with the pressure-fed oil from the P port. As a result, the dump speed is increased.

(Reference)

- The oil pressure of the A2 port and B2 port is identical, but the bucket cylinder extend by the difference of received pressure area (cylinder rod part).

9Y1211156HYM0017US0

Dump 2




3UF AAAELP013A

- | | | | |
|----------------------------|----------------------|--------------------|-------------------------|
| (1) Boom Control Section | (6) PB Passage 2 | P: P Port | A2: A2 Port |
| (2) Bucket Control Section | (7) Load Check Valve | T: T Port | (To Bucket Cylinder) |
| (3) PB Passage 1 | (8) Passage 2 | PB: PB Port | B2: B2 Port |
| (4) Spool | (9) Bucket Cylinder | | (From Bucket Cylinder) |
| (5) Neutral Passage 2 | | | a: Low Pressure |
| | | | b: High Pressure |

- When the hydraulic control lever is set to the "DUMP 2" position, the spool (4) of the bucket control section (2) moves to the right of the bucket control section (2) moves further to the right from the "DUMP 1" position, which forms oil passages between passage 2 (8) and A2 port, and between B2 port and T port.
- The pressure-fed oil from the P port flows to the neutral passage 2 (5) through the boom control section (1) and PB passage 1 (3). As the oil passage from the neutral passage 2 (5) to the PB passage 2 (6) is closed by the spool (4), this oil opens the load check valve (7) and flows through the notched section of the spool (4) and B2 port to extend the bucket cylinder (9).
- Return oil from the bucket cylinder (9) flows to the transmission case through the B2 port and T port.

9Y1211156HYM0018US0

5. REMOTE CONTROL VALVE (IF EQUIPPED)



Neutral


Pressure-fed oil from the hydraulic pump is delivered into the **P** port, and flows to the rear hydraulic outlet through **BY** port.

At this time, oil from **A** port to the **T** port is blocked by the mechanical check valve (Poppet (1)). Therefore the position of implement is kept at the set position.

- (1) Poppet
- (2) Piston
- (3) Spool

P: Pump Port
T: Tank Port
BY: BY Port (To Position Control Valve)
A: A Port
B: B Port

9Y1211156HYM0019US0



Lift


When the remote control valve operating lever is set to **LIFT** position, the spool (3) moves to the right and the passage from **P** port to the **BY** port is blocked by the spool (3).

Then the pressure-fed oil open the poppet (1) and flow through the **A** port to the hydraulic cylinder to lift the implement.

- (1) Poppet
- (2) Piston
- (3) Spool

P: Pump Port
T: Tank Port
(To Transmission Case)
BY: BY Port
A: A Port
B: B Port

9Y1211156HYM0020US0



Down

When the remote control valve operating lever is set to **DOWN** position, the spool (3) moves to the left and the passage from **P** port to the **BY** port is blocked by the spool (3). At the same time, the piston (2) and poppet (1) moves upward, and open the passage from **A** port to **T** port.


Then the pressure-fed oil flow through the **B** port to the hydraulic cylinder to lower the implement. Return oil from hydraulic cylinder flows from **A** port to the transmission case.

- (1) Poppet
- (2) Piston
- (3) Spool

P: Pump Port
T: Tank Port
(To Transmission Case)
BY: BY Port
A: A Port
B: B Port

9Y1211156HYM0021US0

6. HYDRAULIC OUTLET



The hydraulic block type outlet is located at the right hand side of the engine.


This hydraulic block type outlet is provided to take power out from the tractor to operate the hydraulic cylinders on the implement.

(1) Hydraulic Block Cover

A: From Hydraulic Pump

B: To Control Valve

9Y1211156HYM0022US0



SERVICING

CONTENTS

1. TROUBLESHOOTING.....	7-S1
2. SERVICING SPECIFICATIONS	7-S2
3. TIGHTENING TORQUES	7-S3
4. CHECKING, DISASSEMBLING AND SERVICING	7-S4
[1] CHECKING AND ADJUSTING.....	7-S4
(1) Hydraulic Pump (For 3-Point Hitch Hydraulic System).....	7-S4
(2) Hydraulic Pump (For Power Steering, PTO Clutch and HST).....	7-S6
(3) 3-Points Hitch Relief Valve	7-S8
(4) Lift Arm	7-S8
[2] DISASSEMBLING AND ASSEMBLING	7-S9
(1) Hydraulic Pump	7-S9
(2) 3-Point Hitch.....	7-S10
(3) Separating Hydraulic Cylinder From Tractor Body	7-S10
(4) 3-Points Hitch: Hydraulic Cylinder	7-S12
(5) Front Loader Control Valve Assembly (If Equipped)	7-S15
(6) Remote Control Valve (If Equipped).....	7-S18
[3] SERVICING	7-S18

1. TROUBLESHOOTING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Implement Does Not Rise (No Noise)	1. Transmission fluid improper	Check transmission oil	G-8
	2. Hydraulic pump malfunctioning	Solution order 1. Check hydraulic flow test	7-S4
		2. Replace hydraulic pump	7-S9
	3. Relief valve malfunctioning	Solution order 1. Check relief valve	7-S8
		2. Check or adjust relief valve	7-S8
		3. Replace relief valve	7-S8
	4. Piston O-ring or cylinder damaged	Replace O-ring or cylinder	7-S17
	5. Control valve malfunctioning	Replace control valve	7-S13
6. Control valve improperly adjusted	Check or adjust control valve	7-S12	
7. Control valve improperly assembled	Repair control valve	7-S15	
Implement Does Not Rise (Noise)	1. Transmission fluid improper	Check transmission oil	G-8
	2. Oil filter cartridge clogged	Replace oil filter cartridge	G-26, G-29
	3. Suction pipe loosen or broken	Check or repair suction pipe	7-S9
	4. Suction pipe connecting hose loosen or broken	Check or repair suction hose	7-S9
	5. Relief valve setting pressure too low	Solution order 1. Check relief valve	7-S8
		2. Check or adjust relief valve	7-S8
		3. Replace relief valve	7-S8
6. Hydraulic pump broken	Solution order 1. Check hydraulic flow test	7-S4	
	2. Replace hydraulic pump	7-S9	
Implement Does Not Reach Maximum Height	1. Feedback rod improperly adjusted	Solution order 1. Check lift arm free play	7-S8
		2. Adjust feedback rod	7-S8
Implement Does Not Lower	1. Control valve malfunctioning	Replace control valve	7-S13
Implement Drops by Its Weight	1. Piston O-ring worn or damaged	Replace O-ring or cylinder	7-S17
	2. Control valve malfunctioning	Replace control valve	7-S13

9Y1211156HYS0001US0

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Hydraulic Pump (For 3-Point Hitch) Condition <ul style="list-style-type: none"> Engine rated speed: 2800 min⁻¹ (rpm) Rated pressure 13.0 to 13.8 MPa 130 to 140 kgf/cm² 1890 to 2000 psi Oil temperature: 50 °C (122 °F) 	Delivery (At No Pressure)	Above 20.1 L/min. 5.55 U.S.gals/min. 4.62 Imp.gals/min.	–
	Delivery (At Rated Pressure)	Above 19.7 L/min. 5.20 U.S.gals/min. 4.33 Imp.gals/min.	Above 16.5 L/min. 4.36 U.S.gals/min. 3.63 Imp.gals/min.
Hydraulic Pump (For Power Steering, PTO Clutch and HST) Condition <ul style="list-style-type: none"> Engine rated speed: 2800 min⁻¹ (rpm) Rated pressure 11.5 to 12.5 MPa 118 to 127 kgf/cm² 1670 to 1810 psi Oil temperature: 50 °C (122 °F) 	Delivery (At No Pressure)	Above 15.8 L/min. 4.17 U.S.gals/min. 3.48 Imp.gals/min.	–
	Delivery (At Rated Pressure)	Above 15.4 L/min. 4.07 U.S.gals/min. 3.39 Imp.gals/min.	Above 12.9 L/min. 3.41 U.S.gals/min. 2.84 Imp.gals/min.
Relief Valve Condition <ul style="list-style-type: none"> Engine rated speed: 2800 min⁻¹ (rpm) Oil temperature: 50 °C (122 °F) 	Setting Pressure	13.0 to 13.8 MPa 133 to 140 kgf/cm ² 1890 to 2000 psi	–
Lift Arm	Free Play	5 to 15 mm 0.20 to 0.59 in.	–
Tip of Gear Tooth to Casing	Clearance	–	0.15 mm 0.0059 in.
Bushings to Shaft <ul style="list-style-type: none"> Shaft Bushing 	Clearance	0.020 to 0.091 mm 0.0008 to 0.0036 in.	0.12 mm 0.0047 in.
	O.D.	14.970 to 14.980 mm 0.5894 to 0.5898 in.	–
	I.D.	15.000 to 15.061 mm 0.5906 to 0.5930 in.	–
Side Plate	Thickness	2.48 to 2.50 mm 0.0976 to 0.0984 in.	2.40 mm 0.0945 in.
Hydraulic Cylinder	I.D.	75.05 to 75.10 mm 2.955 to 2.956 in.	75.15 mm 2.959 in.
Hydraulic Arm Shaft to Bushing <ul style="list-style-type: none"> Hydraulic Arm Shaft (Right) Hydraulic Arm Shaft (Left) Bushing (Right) Bushing (Left) 	Clearance	0.020 to 0.110 mm 0.0008 to 0.0043 in.	0.30 mm 0.0118 in.
	O.D.	37.925 to 37.950 mm 1.4931 to 1.4941 in.	–
	O.D.	34.925 to 34.950 mm 1.3750 to 1.3759 in.	–
	I.D.	37.970 to 38.035 mm 1.4949 to 1.4974 in.	–
	I.D.	34.970 to 35.035 mm 1.3768 to 1.3793 in.	–

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)

Item	N·m	kgf·m	lbf·ft
Hydraulic pump cover mounting screw	35 to 39	3.5 to 4.0	26 to 28
Set bolt of the lower link pin	15 to 20	1.6 to 2.0	11 to 14
Lock nut of the lower link pin	43 to 47	4.4 to 4.7	32 to 34
Rear wheel mounting nut and screw	145 to 150	14.8 to 15.2	107 to 110
Front loader valve pipe joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 1 joint bolt	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 2 joint bolt (Front loader valve side)	48 to 70	4.9 to 7.1	36 to 51
3-point hitch delivery pipe 2 joint bolt (Hydraulic cylinder case side)	50 to 60	5.1 to 6.1	37 to 44
Plug 1 (Remote control valve)	29.4 to 49.0	3.0 to 5.0	21.7 to 36.2
Bracket mounting screw (Remote control valve)	4.9 to 7.8	0.5 to 0.8	3.6 to 5.8
Plug 2 (Remote control valve)	39.3 to 58.8	4.0 to 6.0	28.9 to 43.4

9Y1211156HYS0003US0

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING

(1) Hydraulic Pump (For 3-Point Hitch Hydraulic System)



Test Preparation (For 3-Point Hitch)

■ IMPORTANT

- When using a flowmeter other than KUBOTA specified flowmeter (Code No. 07916-52792), be sure to use the instructions with that flowmeter.
- In this hook-up, there is no relief valve. Therefore while testing, do not close the flowmeter loading valve completely.

1. Install the flowmeter adaptor to the loader pipe.
2. Connect the hydraulic test hose (Code No. 07916-52651) to the flowmeter (Code No. 07916-52791) inlet port.
3. Connect the another hydraulic test hose to flowmeter outlet port and transmission oil filling port, firmly.
4. Open the flowmeter loading valve completely. (Turn counterclockwise)
5. Start the engine and set the engine speed at 2800 min^{-1} (rpm).
6. Slowly close the loading valve to generate the pressure approximately 10.8 MPa (110 kgf/cm^2 , 1570 psi).
7. Hold this condition until the oil temperature reaches approximately $50 \text{ }^\circ\text{C}$ ($122 \text{ }^\circ\text{F}$).

- (1) Delivery Pipe (to 3-Point Hitch) (3) Hydraulic Pump
(2) Delivery Hose (to Power Steering)

9Y1211156HYS0004US0



Hydraulic Pump Test (For 3-Point Hitch)

■ NOTE

- Before pump testing, do the "Test Preparation".
1. Open the flowmeter loading valve completely (Turn counterclockwise).
 2. Start the engine and set at approx. 2800 min⁻¹ (rpm).
 3. Read and note the pump delivery at no pressure.
 4. Slowly close the loading valve to increase the pressure to the rated pressure as shown in the table below.
 5. Read and note the pump delivery at rated pressure.
 6. Open the loading valve and stop the engine.
 7. If the pump delivery does not reach the allowable limit, check the pump suction line, oil filter or hydraulic pump.

(Reference)


Hydraulic pump delivery at no pressure	Factory specification	Above 20.1 L/min. 5.55 U.S.gals/min. 4.62 Imp.gals/min.
Hydraulic pump delivery at rated pressure	Factory specification	Above 19.7 L/min. 5.20 U.S.gals/min. 4.33 Imp.gals/min.
	Allowable limit	Above 16.5 L/min. 4.36 U.S.gals/min. 3.63 Imp.gals/min.

Condition

- Engine rated speed
2800 min⁻¹ (rpm)
- Rated pressure
13.0 to 13.8 MPa
130 to 140 kgf/cm²
1890 to 2000 psi
- Oil temperature
50 °C (122 °F)

9Y1211156HYS0005US0

(2) Hydraulic Pump (For Power Steering, PTO Clutch and HST)



Test Preparation (For Power Steering, PTO Clutch and HST)

■ IMPORTANT

- When using a flowmeter other than KUBOTA specified flowmeter (Code No. 07916-52792), be sure to use the instructions with that flowmeter.
- In this hook-up, there is no relief valve. Therefore while testing, do not close the flowmeter loading valve completely.

1. Disconnect the delivery hose (2).
2. Install the flowmeter adaptor to the hydraulic pump body.
3. Connect the hydraulic test hose (Code No. 07916-52651) to the flowmeter (Code No. 07916-52791) inlet port.
4. Connect the another hydraulic test hose to flowmeter outlet port and transmission oil filling port, firmly.
5. Open the flowmeter loading valve completely. (Turn counterclockwise)
6. Start the engine and set the engine speed at 2800 min⁻¹ (rpm).
7. Slowly close the loading valve to generate the pressure approximately 9.5 MPa (97 kgf/cm², 1400 psi).
8. Hold this condition until the oil temperature reaches approximately 50 °C (122 °F).

- (1) Delivery Pipe (to 3-Point Hitch) (3) Hydraulic Pump
 (2) Delivery Hose (to Power Steering)

9Y1211156HYS0006US0



Hydraulic Pump Test (For Power Steering, PTO Clutch and HST)

NOTE

- **Before pump testing, do the "Test Preparation".**
- 1. Open the flowmeter loading valve completely (Turn counterclockwise).
- 2. Start the engine and set at approx. 2800 min⁻¹ (rpm).
- 3. Read and note the pump delivery at no pressure.
- 4. Slowly close the loading valve to increase the pressure to the rated pressure as shown in the table below.
- 5. Read and note the pump delivery at rated pressure.
- 6. Open the loading valve and stop the engine.
- 7. If the pump delivery does not reach the allowable limit, check the pump suction line, oil filter or hydraulic pump.

(Reference)


Hydraulic pump delivery at no pressure	Factory specification	Above 15.8 L/min. 4.17 U.S.gals/min. 3.48 Imp.gals/min.
Hydraulic pump delivery at rated pressure	Factory specification	Above 15.4 L/min. 4.07 U.S.gals/min. 3.39 Imp.gals/min.
	Allowable limit	Above 12.9 L/min. 3.41 U.S.gals/min. 2.84 Imp.gals/min.

Condition

- Engine rated speed
2800 min⁻¹ (rpm)
- Rated pressure
11.5 to 12.5 MPa
118 to 127 kgf/cm²
1670 to 1810 psi
- Oil temperature
50 °C (122 °F)

9Y1211156HYS0007US0

(3) 3-Points Hitch Relief Valve



3-Points Hitch Relief Valve Setting Pressure

1. Install the adaptor. Then connect the cable and the pressure gauge to the adaptor (Size 1/4).
2. Start the engine and set the engine speed at 2800 min⁻¹ (rpm).
3. Set the front loader valve lever to the down ward position and read the pressure gauge when the relief valve is actuated.
4. If the pressure is not factory specifications, adjust the relief valve setting pressure with the adjusting shims (4).

Relief valve setting pressure	Factory specification	13.0 to 13.8 MPa 133 to 140 kgf/cm ² 1890 to 2000 psi
-------------------------------	-----------------------	--

Condition

- Engine rated speed
2800 min⁻¹ (rpm)
- Oil temperature
50 °C (122 °F)

(Reference)

- Thickness of shims (4)
0.10 mm (0.0039 in.)
0.20 mm (0.0079 in.)
0.40 mm (0.016 in.)
0.60 mm (0.024 in.)

- | | |
|---------------------------|----------------|
| (1) Loader Valve Assembly | (5) Spring |
| (2) Plug | (6) Poppet |
| (3) Plain Washer | (7) Valve Seat |
| (4) Shim | |

9Y1211156HYS0008US0

(4) Lift Arm



Lift Arm Free Play

1. Set the position control lever (1) to the lowest position.
2. Start the engine, and set at the idling speed.
3. Move the position control lever (1) to the uppermost position.
4. Move the lift arm (2) to the upper end by hand and measure the free play.
5. If the measurement is not within the factory specifications, adjust the free play by changing the position control feedback rod setting length.


Lift arm free play	Factory specification	5 to 15 mm 0.20 to 0.59 in.
--------------------	-----------------------	--------------------------------

- | | |
|----------------------------|------------------------------|
| (1) Position Control Lever | L: Lowest Position |
| (2) Lift Arm | H: Uppermost Position |

9Y1211156HYS0009US0

[2] DISASSEMBLING AND ASSEMBLING

(1) Hydraulic Pump



Removing Hydraulic Pump


1. Open the bonnet then remove the side cover (R.H.) and disconnect the battery grounding cord.
2. Disconnect the connector of the engine stop solenoid and accelerator rod.
3. Disconnect the power steering delivery hose (3).
4. Remove the engine stop solenoid.
5. Disconnect the suction hose (4).
6. Disconnect 3-points hitch delivery pipe (2) and the hydraulic pump (1).

(When reassembling)

- Apply liquid gasket (Three Bond 1206D or equivalent) to engine stop solenoid.

- | | |
|---------------------------------|----------------------------------|
| (1) Hydraulic Pump | (3) Power Steering Delivery Hose |
| (2) 3-Point Hitch Delivery Pipe | (4) Suction Hose |

9Y1211156HYS0010US0



Hydraulic Pump Cover, Side Plate and Gear

1. Secure the hydraulic pump with a vise, and remove the hydraulic pump cover (6) with casing (5).
2. Remove the side plate (4).
3. Remove the drive gear (3) and driven gear (2) from the casing (1).


(When reassembling)

- Be careful not to damage the O-ring.
- Align the holes of the cover and casing (1).
- Install the side plate (4), noting its location and direction.
- Install the gears (2), (3), noting its direction.

Tightening torque	Hydraulic pump cover mounting screw	35 to 39 N·m 3.5 to 4.0 kgf·m 26 to 28 lbf·ft
-------------------	-------------------------------------	---

- | | |
|-----------------|--------------------------|
| (1) Casing | (4) Side Plate |
| (2) Driven Gear | (5) Casing |
| (3) Drive Gear | (6) Hydraulic Pump Cover |

9Y1211156HYS0011US0



Oil Seal

1. Remove the internal snap ring (2), and remove the oil seal (1).



(When reassembling)

- If the oil seal is damaged, worn or scratched, replace it.

- | | |
|--------------|------------------------|
| (1) Oil Seal | (2) Internal Snap Ring |
|--------------|------------------------|

9Y1211156HYS0012US0

(2) 3-Point Hitch



3-Point Hitch

1. Remove the top link (1).
2. Remove the lift rods (2).
3. Remove the stabilizer (4).
4. Remove the lower links (3).
5. Loosen the lock nut (6) and remove the set screw (5).
6. Remove the lower link pin (7).

(When reassembling)

■ IMPORTANT




- Be sure to align the set screw (5) and lower link pin hole (8), when installing the lower link pin (7).

Tightening torque	Set bolt of the lower link pin	15 to 20 N·m 1.6 to 2.0 kgf·m 11 to 14 lbf·ft
	Lock nut of the lower link pin	43 to 47 N·m 4.4 to 4.7 kgf·m 32 to 34 lbf·ft

- | | |
|----------------|-------------------------|
| (1) Top Link | (5) Set Screw |
| (2) Lift Rod | (6) Lock Nut |
| (3) Lower link | (7) Lower Link Pin |
| (4) Stabilizer | (8) Lower Link Pin Hole |

9Y1211156HYS0013US0

(3) Separating Hydraulic Cylinder From Tractor Body



Draining Transmission Fluid

⚠ CAUTION

- Stop the engine before checking and changing the transmission fluid.

1. Place the oil pan under the tractor.
2. Remove the drain plugs (1), (3), (5) at the mid-PTO shaft and at the bottom of the rear axle cases (4), (6).
3. Drain the transmission fluid.
4. After draining the transmission fluid, reinstall the drain plugs (1), (3), (5).

■ IMPORTANT

- Use only KUBOTA UDT oil. Use of other oils may damage the transmission or hydraulic system. Refer to "4. LUBRICANTS, FUEL AND COOLANT" on page G-8.
- Never work the tractor immediately after changing the transmission oil. Keep the engine at medium speed for a few minutes to prevent damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	15 L 4.0 U.S.gals 3.3 Imp.gals
-----------------------------	--------------------------------------

- | | |
|-------------------|---------------------------|
| (1) Drain Plug | (4) Rear Axle Case (L.H.) |
| (2) Mid-PTO Shaft | (5) Drain Plug |
| (3) Drain Plug | (6) Rear Axle Case (R.H.) |

9Y1211156ENS0023US0



Battery Negative Cable

1. Disconnect the battery negative cable (2).

(1) Battery

(2) Battery Negative Cable

9Y1211156HYS0014US0



Seat

1. Remove the seat (1) and lever grips (2).
2. Remove the both side lever guides (3).
3. Remove the seat under cover (4).
4. Disconnect the seat switch connector (5).
5. Remove the seat support (6).

(1) Seat

(4) Seat Under Cover


(2) Lever Grip

(5) Seat Switch Connector

(3) Lever Guide

(6) Seat Support

9Y1211156HYS0015US0





Separating Hydraulic Cylinder from Tractor Body

1. Disconnect lever linkage from hydraulic cylinder.
2. Disconnect the hydraulic delivery pipe from hydraulic cylinder.
3. Disconnect the wiring harness from switches and pull the wiring harness to the front side.
4. Remove the hydraulic cylinder.

9Y1211156HYS0016US0

(4) 3-Points Hitch: Hydraulic Cylinder



Checking the Length of the Adjusting Bolt

■ NOTE

- Before disassembling the control valve, check the length of the adjusting bolt.

1. Push the spool (1) into the control valve (2).
2. Check the length "L" of the adjusting bolt (3) as shown in the picture.




(Reference)

- Length L
Approx. 10.70 mm (0.421 in.)

- (1) Spool
- (2) Control Valve
- (3) Adjusting Bolt
- (4) Connecting Plate
- (5) Nut

L: Length of the adjusting bolt

9Y1211156HYS0017US0



Control Valve






■ **NOTE**

- When the control valve is installed in the hydraulic cylinder, the hexagon wrench is not aligned straight to the hexagon bolt without pushing the spool as shown in the picture.

1. Push the spool (1) into the control valve (3).
2. Remove the hexagon bolts (2) with a hexagon wrench (4).

- | | |
|-------------------|--------------------|
| (1) Spool | (4) Hexagon Wrench |
| (2) Hexagon Bolt | (5) Adjusting Bolt |
| (3) Control Valve | |

9Y1211156HYS0018US0



Lift Arm, Hydraulic Arm Shaft and Hydraulic Arm

1. Remove the external snap ring, and remove the lift arm L.H. (2).
2. Draw out the hydraulic arm shaft (3) and lift arm R.H. (4) as a unit.

(When reassembling)

- Align the alignment marks (5) of the hydraulic arm and hydraulic arm shaft.
- Align the alignment marks (6) of the lift arm L.H. and hydraulic arm shaft.
- Apply grease to the right and left bushings and O-rings.
- Be careful not to damage the O-rings.

- | | |
|-------------------------|---------------------|
| (1) Lift Arm R.H. | (4) Hydraulic Arm |
| (2) Hydraulic Arm Shaft | (5) Alignment Marks |
| (3) Lift Arm L.H. | (6) Alignment Marks |

9Y1211156HYS0019US0

Hydraulic Piston

1. Inject the compressed air into the hydraulic cylinder, and remove the hydraulic piston (1).

(When reassembling)

- Be careful not to damage the O-ring (3) and backup ring (2).
- Apply transmission fluid to the O-ring.
- Replace the O-ring if it is damaged, worn or scratched, which may cause oil leakage.

- | | |
|----------------------|------------|
| (1) Hydraulic Piston | (3) O-ring |
| (2) Backup Ring | |

9Y1211156HYS0020US0


Hydraulic Adjust Shaft

1. Remove the internal cir-clip (1) and the hydraulic adjusting shaft (2).
2. Draw out the ball (5), the spring (6) and the collar (7).


(When reassembling)

- Be careful not to damage the O-rings.
- | | |
|----------------------------|------------|
| (1) Internal Cir-clip | (5) Ball |
| (2) Hydraulic Adjust Shaft | (6) Spring |
| (3) Stopper | (7) Collar |
| (4) O-ring | |

9Y1211156HYS0021US0



3TBAAAG8P076A



3TBAAAG8P077A



3TBAAAG8P070B

Disassembling Position Control Valve

1. After removing the control valve, disassemble the component parts as shown in the picture.

(When reassembling)

- Readjust the length "L" of the adjusting bolt.

(Reference)

- Length "L": approximately 10.70 mm (0.4213 in.)

- | | |
|------------------------|-------------------------|
| (1) External Cir-clip | (15) Unload Poppet |
| (2) Lever | (16) Control Valve Body |
| (3) Spring | (17) Nut |
| (4) Spool | (18) Poppet |
| (5) Spring Holder | (19) Spring |
| (6) Poppet | (20) Plug |
| (7) O-ring | (21) Spring |
| (8) Control Valve Body | (22) Spring Holder |
| (9) Plug | (23) External Cir-clip |
| (10) Spring | (24) Adjusting Bolt |
| (11) Unload Plug | (25) Connecting Plate |
| (12) Plug | |
| (13) Poppet | |
| (14) Spring | |

L: Length of adjusting bolt

9Y1211156HYS0022US0

(5) Front Loader Control Valve Assembly (If Equipped)



9Y1211156BRS003A


Rear Wheel

1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel (1).

Tightening torque	Rear wheel mounting nut and screw	145 to 150 N·m 14.8 to 15.2 kgf·m 107 to 110 lbf·ft
-------------------	-----------------------------------	---

- (1) Rear Wheel

9Y1211156BRS0006US0



Front Loader Valve Assembly

1. Remove the brake rod (1).
2. Disconnect the 3-point hitch delivery pipe 1 (2), 3-point hitch delivery pipe 2 (4) and return hose (6).
3. Remove the front loader valve pipes (5).
4. Remove the loader valve assembly (3).

(When reassembling)

- Do not damage the O-rings of front loader valve pipes and delivery pipes.
- Apply liquid gasket (Three Bond 1206D or equivalent) to joint face of the rear axle case and differential gear case after eliminating the water and oil.


Tightening torque	Front loader valve pipe joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 1 joint bolt	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 2 joint bolt (Front loader valve side)	48 to 70 N·m 4.9 to 7.1 kgf·m 36 to 51 lbf·ft
	3-point hitch delivery pipe 2 joint bolt (Hydraulic cylinder case side)	50 to 60 N·m 5.1 to 6.1 kgf·m 37 to 44 lbf·ft

- | | |
|-----------------------------------|-----------------------------------|
| (1) Brake Rod | (4) 3-Point Hitch Delivery Pipe 2 |
| (2) 3-Point Hitch Delivery Pipe 1 | (5) Front Loader Valve Pipe |
| (3) Loader Valve Assembly | (6) Return Hose |

9Y1211156HYS0023US0

Disassembling Front Loader Control Valve and Relief Valve**NOTE**

- Refer to the page 7-S8 for the relief valve.

**Boom Control Section and Bucket Control Section**


1. Remove the plug (8), the spring (10) and load check valve (11).
2. Remove the plug (24) from valve body (14).
3. Remove the internal circlip (30), the stopper (27), detent spring (25), detent ring (26), and ball (28).
4. Draw out the spool (15), (16) with other component parts from valve body (14).

Relief Valve

1. Remove the plug (1), the spring (5) and poppet (6), (7).

9Y1211156HYS0024US0

(6) Remote Control Valve (If Equipped)



Poppet and Piston (Mechanical Check Valve)

1. Remove the plug 1 (4) and draw out the spring (7), ball guide (3), balls (1), (6), poppet (2) and piston (5).


(When reassembling)

- Be careful not to damage the O-ring.

Tightening torque	Plug 1	29.4 to 49.0 N·m 3.0 to 5.0 kgf·m 21.7 to 36.2 lbf·ft

- | | |
|----------------|------------|
| (1) Ball | (5) Piston |
| (2) Poppet | (6) Ball |
| (3) Ball Guide | (7) Spring |
| (4) Plug 1 | |

9Y1211156HYS0025US0



Spool

1. Remove the screws (6), and remove the bracket (7).
2. Remove the plug 2 (9), and draw out the spool (8).

(When reassembling)


- Be careful not to damage the O-rings and backup rings.

Tightening torque	Bracket mounting screw	4.9 to 7.8 N·m 0.5 to 0.8 kgf·m 3.6 to 5.8 lbf·ft
	Plug 2	39.3 to 58.8 N·m 4.0 to 6.0 kgf·m 28.9 to 43.4 lbf·ft

- | | |
|-----------------|-------------|
| (1) Collar | (6) Screw |
| (2) Backup Ring | (7) Bracket |
| (3) O-ring | (8) Spool |
| (4) O-ring | (9) Plug 2 |
| (5) Backup Ring | |

9Y1211156HYS0026US0

[3] SERVICING




Clearance between Tip of Gear Tooth and Casing

1. Measure the clearance between gear and casing at several points with feeler gauge.
2. If the clearance exceeds the allowable limit, replace the assembly.

Clearance between tip of gear tooth and casing	Allowable limit	0.15 mm 0.0059 in.
--	-----------------	-----------------------

9Y1211156HYS0027US0




Clearance between Bushing and Shaft

1. Measure the shaft O.D. with an outside micrometer.
2. Measure the bushing I.D. with a cylinder gauge.
3. If the clearance exceeds the allowable limit, replace it.

Clearance between bushing and shaft	Factory specification	0.020 to 0.091 mm 0.0008 to 0.0036 in.
	Allowable limit	0.12 mm 0.0047 in.

Shaft O.D.	Factory specification	14.970 to 14.980 mm 0.5894 to 0.5898 in.
Bushing I.D.	Factory specification	15.000 to 15.061 mm 0.5906 to 0.5930 in.

9Y1211156HYS0028US0




Side Plate Thickness

1. Measure the side plate thickness with an outside micrometer.
2. If the thickness is less than the allowable limit, replace it.

Side plate thickness	Factory specification	2.48 to 2.50 mm 0.0976 to 0.0984 in.
	Allowable limit	2.40 mm 0.0945 in.

9Y1211156HYS0029US0




Hydraulic Cylinder Bore

1. Check the cylinder internal surface for scoring or damage.
2. Measure the cylinder I.D. with a cylinder gauge.
3. If the measurement exceeds the allowable limit, replace the hydraulic cylinder block.

Cylinder I.D.	Factory specification	75.05 to 75.10 mm 2.955 to 2.956 in.
	Allowable limit	75.15 mm 2.959 in.

9Y1211156HYS0030US0



Clearance between Hydraulic Arm Shaft and Bushing

1. Measure the hydraulic arm shaft O.D. with an outside micrometer.
2. Measure the bushing I.D. with a cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the bushing.

Clearance between hydraulic arm shaft and bushing	Factory specification	0.020 to 0.110 mm 0.0008 to 0.0043 in.
	Allowable limit	0.30 mm 0.0118 in.

Hydraulic arm shaft O.D.	Factory specification	Right	37.925 to 37.950 mm 1.4931 to 1.4941 in.
		Left	34.925 to 34.950 mm 1.3750 to 1.3759 in.

Bushing I.D. (after press filed)	Factory specification	Right	37.970 to 38.035 mm 1.4949 to 1.4974 in.
		Left	34.970 to 35.035 mm 1.3768 to 1.3793 in.

9Y1211156HYS0031US0


8 ELECTRICAL SYSTEM

MECHANISM

CONTENTS

1. WIRING DIAGRAM.....	8-M1
2. ENGINE STARTING SYSTEM AND STOPPING SYSTEM	8-M2
[1] OPC SYSTEM CIRCUIT	8-M2
[2] CONTROLLER	8-M3
[3] SAFETY SWITCH	8-M6
(1) PTO Select Lever Switch.....	8-M6
(2) PTO Clutch Lever Switch	8-M6
(3) HST Pedal Switch (HST Model)	8-M7
(4) Seat Switch.....	8-M7
[4] STARTER.....	8-M8
[5] ENGINE STOP SOLENOID	8-M8
[6] GLOW PLUG	8-M9
3. CHARGING SYSTEM.....	8-M10
4. LIGHTING SYSTEM	8-M11
[1] HEAD LIGHT	8-M11
[2] TURN SIGNAL LIGHT	8-M11
[3] HAZARD LIGHT	8-M12
5. INSTRUMENT PANEL	8-M13
[1] EASY CHECKER™	8-M13
[2] SWITCHES AND SENSORS	8-M13

1. WIRING DIAGRAM



2. ENGINE STARTING SYSTEM AND STOPPING SYSTEM

This series tractors equipped operator presence control (OPC) system. This system will automatically stop the engine when operator stands up from the seat while shifting the PTO gear shift lever, depressing the HST pedal.


This system is controlled by five switches, (PTO clutch lever switch, PTO select lever switch, seat switch, seat tilt switch, HST safety switch) and controller.

Engine starting is operated with starter after current flowing from controller to stator motor.

Engine stopping is operated with engine stop solenoid after current flowing from controller through engine stop solenoid relay to engine stop solenoid.

9Y1211156ELM0002US0

[1] OPC SYSTEM CIRCUIT




- (1) Battery
- (2) Fuse
- (3) Fuse
- (4) Slow Blow Fuse (50 A)
- (5) Key Switch
- (6) Controller

- (7) Relay (Engine Stop Solenoid)
- (8) Engine Stop Solenoid
- (9) Starter Motor
- (10) AC Terminal Lead
- (11) PTO Clutch Lever Switch
- (12) PTO Select Lever Switch
- (13) Seat Tilt Switch
- (14) HST Pedal Switch
- (15) Seat Switch
- (16) Regulator
- (17) Frame Earth

a to l: Controller Terminal
AC: AC Terminal
G: G Terminal
ST: ST Terminal

9Y1211156ELM0003US0

[2] CONTROLLER



Operator Presence Control (OPC) System

This series tractor tractors are equipped with an "Operator Presence Control (OPC)" system to control engine starting and engine automatically stopping.



This OPC system mainly consists of controller and engine starting / stopping control switches such as PTO clutch lever switch, PTO select lever switch, seat tilt switch, seat switch, HST pedal switch.

Main parts regarding OPC system are laid out as shown in the electrical circuit.

- | | |
|-----------------------------------|---------------------------|
| (1) Key Switch | (11) Engine Stop Solenoid |
| (2) PTO Clutch Lever Switch | (12) Battery |
| (3) PTO Select Lever Switch | (13) OPC Controller |
| (4) Seat Tilt Switch | |
| (5) Seat Switch | |
| (6) HST Pedal Switch | |
| (7) Regulator | |
| (8) Frame Earth | |
| (9) Starter Motor | |
| (10) Relay (Engine Stop Solenoid) | |

a to l: Controller Terminal
ST: Key Switch ST Terminal
G: Key Switch G Terminal
AC: Key Switch AC Terminal
B: Starter Motor B Terminal
S: Starter Motor S Terminal

9Y1211156ELM0004US0



Controller

Controller is located inside the panel board.

Current from the key switch, safety switches and regulator flows to controller.

Controller receives current as data, processes the data, and sends out current computing results to starter motor, relay (engine stop solenoid), and engine stop solenoid.

OPC controller (13) controls engine starting and engine stopping.

Current flows from battery to controller.

Current from switches such as PTO clutch lever switch (2), PTO select lever switch (3), seat tilt switch (4), seat switch (5), HST pedal switch (6), flows to the controller.

Current from regulator (7) flows to the controller.

When starting the engine, the controller (13) supplies current to starter motor **S** terminal and relay (engine stop solenoid) (10).

Controller (13) receives data, processes the data, and sends out the computing results.


Controller (13) receives data from safety switches, processes the data inside the controller itself, and sends out the computing results to starter motor (9) for engine starting, and relay (engine stop solenoid) (10) for engine stopping.

- (1) Key Switch
- (2) PTO Clutch Lever Switch
- (3) PTO Select Lever Switch
- (4) Seat Tilt Switch
- (5) Seat Switch
- (6) HST Pedal Switch
- (7) Regulator
- (8) Frame Earth
- (9) Starter Motor
- (10) Relay (Engine Stop Solenoid)

- (11) Engine Stop Solenoid
- (12) Battery
- (13) OPC Controller

- a to l: Controller Terminal**
- ST: Key Switch ST Terminal**
- G: Key Switch G Terminal**
- AC: Key Switch AC Terminal**
- B: Starter Motor B Terminal**
- S: Starter Motor S Terminal**
- : Current Flow**

9Y1211156ELM0005US0




Engine Starting

When the following conditions become complete, output voltage (12 V) reaches coil terminal of the starter motor from controller k terminal, the engine can be started.

PTO Clutch Lever Switch (Disengaged: ON, Engaged: OFF)	ON
HST Pedal Switch (Neutral: ON, Forward and Reverse: OFF)	ON

- (1) Key Switch
 - (2) **ST** Terminal Lead
 - (3) **AC** Terminal Lead
 - (4) PTO Clutch Lever Switch
 - (5) PTO Select Lever Switch
 - (6) Seat Tilt Switch
 - (7) Seat Switch
 - (8) Regulator
 - (9) HST Pedal Switch
 - (10) Frame Earth
 - (11) Controller
 - (12) Starter Motor
 - (13) Relay (Engine Stop Solenoid)
 - (14) Engine Stop Solenoid
- ST, G, AC: Key Switch Terminals**
a to l: Controller Terminals
B: Starter Motor B Terminal
S: Starter Motor S Terminal
 →: **Current Flow**

9Y1211156ELM0006US0



One Second Delay Engine Stop

When one condition of the three patterns becomes complete, output voltage (12 V) to the relay (engine stop solenoid) from controller j terminal will stop in one second delay.

Pattern 1

Seat Switch (Occupied: ON, Vacant: OFF)	OFF
HST Pedal Switch (Neutral: ON, Forward and Reverse: OFF)	OFF

Pattern 2


Seat Switch (Occupied: ON, Vacant: OFF)	OFF
PTO Clutch Lever Switch (Disengaged: ON, Engaged: OFF)	OFF
Seat Tilt Switch (Tilted : ON, Normal : OFF)	OFF
PTO Select Lever Switch (Rear PTO: ON, Rear/Mid or Mid PTO: OFF)	ON

Pattern 3

Seat Switch (Occupied: ON, Vacant: OFF)	OFF
PTO Clutch Lever Switch (Disengaged: ON, Engaged: OFF)	OFF
PTO Select Lever Switch (Rear PTO: ON, Rear/Mid or Mid PTO: OFF)	OFF



- (1) Key Switch
 - (2) **ST** Terminal Lead
 - (3) **AC** Terminal Lead
 - (4) PTO Clutch Lever Switch
 - (5) PTO Select Lever Switch
 - (6) Seat Tilt Switch
 - (7) Seat Switch
 - (8) Regulator
 - (9) HST Pedal Switch
 - (10) Frame Earth
 - (11) Controller
 - (12) Starter Motor
 - (13) Relay (Engine Stop Solenoid)
 - (14) Engine Stop Solenoid
- [A] Pattern 2 and 3**
[B] Pattern 1
ST, G, AC: Key Switch Terminals
B: Starter Motor B Terminal
S: Starter Motor S Terminal
a to l: Controller Terminals
 →: **Current Flow**

9Y1211156ELM0007US0



[3] SAFETY SWITCH

(1) PTO Select Lever Switch



PTO Select Lever Switch

This switch locates at transmission case.

This switch is a push type.

This switch detects the position of the PTO select lever.


When the PTO select lever is at **"REAR PTO"** position, this switch is turned to **"ON"**.

When the PTO select lever is at **"Rear/Mid, Mid PTO"** position, this switch is turned to **"OFF"**.

- | | |
|-----------------------------|---------------------------------------|
| (1) PTO Select Lever Switch | A: Rear PTO Position |
| (2) PTO Select Lever | B: Rear PTO / Mid PTO Position |
| | C: Mid PTO Position |

9Y1211156ELM0008US0

(2) PTO Clutch Lever Switch



PTO Clutch Lever Switch

This switch is a push type.

This switch detects the PTO clutch engagement.


When the PTO clutch lever is set to **"DISENGAGED"** position, this switch is turned to **"ON"**.

When the PTO clutch lever is set to **"ENGAGED"** position, this switch is turned to **"OFF"**.

- | | |
|-----------------------------|---------------------------------|
| (1) PTO Clutch Lever Switch | A: "DISENGAGED" Position |
| (2) PTO Clutch Lever | B: "ENGAGED" Position |

9Y1211156ELM0009US0

(3) HST Pedal Switch (HST Model)



HST Pedal Switch

This switch located at the neutral switch stay.

This switch is a push type.

This switch detects the position of the HST pedal.

When HST pedal is at "**NEUTRAL**" position, this switch is turned to "**ON**".


When HST pedal is at "**FORWARD**" or "**REVERSE**" position, this switch is turned to "**OFF**".

- (1) HST Pedal Switch
(2) Neutral Holder

F: FORWARD
N: NEUTRAL
R: REVERSE

9Y1211156ELM0010US0

(4) Seat Switch



Seat Switch and Seat Tilt Switch


These switches are located under the seat. When sitting on the seat, the seat switch (2) is pushed in and electrical circuit is closed. When the seat is vacant, this switch is not pushed and electric circuit is opened. Other seat tilt switch (1) is to detect tilting the seat. When tilting the seat forward as shown in the figure, the seat tilt switch (1) is pushed in and electrical circuit is closed.

- (1) Seat Tilt Switch

- (2) Seat Switch

9Y1211156ELM0011US0

[4] STARTER




- (1) Housing
- (2) Magnetic Switch
- (3) Overrunning Clutch
- (4) Drive Lever
- (5) Internal Gear
- (6) Gear Shaft
- (7) Planetary Gear
- (8) Armature Shaft
- (9) Yoke
- (10) Brush Holder
- (11) Rear End Frame

The starter is a reduction type.

The reduction system is used planetary gears, and the speed of gear shaft (6) is reduced to approximately one fifth of the armature shaft (8).

9Y1211156ELM0012US0

[5] ENGINE STOP SOLENOID




Flowing of the battery current into the engine stop solenoid, the plunger (2) move to left side so that the movement of control rack (4) becomes free. When the battery current stops, the plunger (2) is returned to the original position by the spring to keep the control rack (4) in "No fuel injection" position.


- (1) Engine Stop Solenoid
- (2) Plunger
- (3) Injection Pump
- (4) Control Rack

9Y1211156ELM0013US0

[6] GLOW PLUG



3TAAAAB9P005A



3TAAAAB9P006A

This plug is a two-material type QGS (Quick Glow System) for quick temperature rise, and has self-controlling function as well as excellent durability.

The heater (4) connected in series to the heater (3), which also functions as the resistor, is incorporated in the sheath tube (1) of the super glow plug.

The resistance of this heater (3) cum resistor is small when the temperature is low, while the resistance becomes large when the temperature rises.

Therefore, because sufficient current is flown to the heater (4) during the initial period of energization, the temperature rises quickly and the resistance grows with the rise in the temperature of the resistor, the flowing current is reduced to prevent the heater (4) from being heated.


The ignition point is in the area of 2 to 3 mm (0.079 to 0.118 in.) from the tip of the plug in order to reduce its projection into the combustion chamber.

- | | |
|---|--------------------------------|
| (1) Sheath Tube | (a) Glow Plug Temperature (°C) |
| (2) Insulation Powder | (b) Current (A) |
| (3) Heater also functioning as a Resistor | (c) Time (Sec.) |
| (4) Heater | |
| (5) Super Glow Plug | |
| (6) Conventional Quick-heating type Glow Plug | |
| (7) Glow Plug Current | |

9Y1211156ELM0014US0

3. CHARGING SYSTEM

Charging System Circuit



- (1) Battery
- (2) Slow Blow Fuse
- (3) Dynamo
- (4) Regulator
- (5) Fuse
- (6) Key Switch
- (7) Instrument Panel
- (8) OPC Controller

The charging system supplies electric power for various electrical devices and also charges the battery while the engine operates.


9Y1211156ELM0015US0

4. LIGHTING SYSTEM

The lighting system consists of combination switch (light switch and hazard switch), head lights, tail lights, hazard lights, etc..

9Y1211156ELM0016US0


[1] HEAD LIGHT



The light switch, which forms a combination switch with the turn signal light switch, has two position **OFF** and **ON**. Current passes through the light circuit as shown in the figure above.

9Y1211156ELM0017US0


[2] TURN SIGNAL LIGHT



The turn signal light switch which forms a combination switch with the light switch, has three position; **OFF**, **1.**, **2.**. When using turn signal light switch, only one side light blinks and other one stays on. The operation of the turn signal light switch is given to priority when the hazard switch and the turn signal light switch are turned on at the same time.

9Y1211156ELM0018US0

[3] HAZARD LIGHT




Hazard switch has two positions; **ON** and **OFF**. Blinking the hazard lights as shown in the figure above. The hazard light is operative when the key switch is in either the **ON** or **OFF** positions.

9Y1211156ELM0019US0

5. INSTRUMENT PANEL

[1] EASY CHECKER™



If the warning lamps of the Easy Checker™ come on during operation, immediately stop the engine, and find the cause as shown below.

Never operate the machine while Easy Checker™ lamp is on.

■ **Electrical Charge Warning Indicator**

If the dynamo is not charging the battery, the warning lamp in the Easy Checker™ will come on.

If this should happen during operation, check the electrical charging system.

■ **Glow Plug Indicator**

When the key switch is in the "PREHEAT" position, the glow plug indicator illuminates.


■ **Engine Oil Pressure Warning Indicator**

If the oil pressure in the engine goes below 49 kPa (0.5 kgf/cm², 7 psi), the warning lamp in the Easy Checker™ will come on.

- (1) Engine Oil Pressure Warning Indicator
- (2) Electrical Charge Warning Indicator
- (3) Glow Plug Indicator
- (4) Coolant Temperature Gauge
- (5) Fuel Gauge

9Y1211156ELM0020US0

[2] SWITCHES AND SENSORS




Oil Pressure Switch

While oil pressure is high and the force applied to the diaphragm (2) is larger than the spring tension, the terminal contact (1) is open separated from the body contact (3). If the pressure drops below approx. 49 kPa (0.5 kgf/cm², 7.1 psi), the contact closes.

- (1) Terminal Contact
- (2) Diaphragm
- (3) Body Contact

9Y1211156ELM0021US0



Fuel Sensor


The remaining fuel quantity is detected by the fuel level sensor installed in the fuel tank and indicated on the fuel gauge. For detection, a float and a resistor are used.

As the float (1) lowers, the resistance of the variable resistor (2) varies. The relation between the amount of fuel and the resistance is as follows.

F	1/2	E
1 to 5 Ω	32.5 Ω (Reference)	103 to 117 Ω

- (1) Float
- (2) Variable Resistor

9Y1211156ELM0022US0



Coolant Temperature Sensor

The coolant temperature sensor is installed to the cylinder head of engine, and its tip is in touch with the coolant. It contains a thermistor (4) whose electrical resistance decreases as the temperature increases.

Current varies with changes in the coolant temperature, and the increases or decreases in the current move the pointer of gauge.

Characteristics of Thermistor	
Temperature	Resistance
50 °C (122 °F)	148.8 Ω
80 °C (176 °F)	50.3 Ω
120 °C (248 °F)	16.0 Ω
170 °C (338 °F)	5.6 Ω

(1) Terminal
(2) Insulator

(3) Body
(4) Thermistor

9Y1211156ELM0023US0

SERVICING

CONTENTS

1. TROUBLESHOOTING.....	8-S1
2. SERVICING SPECIFICATIONS	8-S8
3. TIGHTENING TORQUES	8-S9
4. CHECKING AND ADJUSTING.....	8-S10
[1] BATTERY	8-S10
[2] FUSE	8-S11
[3] RELAYS	8-S12
(1) Relays.....	8-S12
[4] STARTING SYSTEM.....	8-S13
(1) Key Switch.....	8-S13
(2) Safety Switches.....	8-S14
(3) OPC Controller	8-S15
(4) Engine Stop Solenoid.....	8-S15
(5) Starter.....	8-S15
(6) Glow Plug	8-S16
[5] CHARGING SYSTEM	8-S17
(1) AC Dynamo	8-S17
(2) Regulator	8-S17
[6] LIGHTING SYSTEM.....	8-S18
(1) Combination Switch.....	8-S18
(2) Flasher Unit	8-S20
[7] WARNING LAMP, INDICATOR LAMP AND GAUGE	8-S20
(1) Instrument Panel	8-S20
(2) Engine Oil Pressure Switch.....	8-S21
(3) Coolant Temperature Sensor	8-S21
(4) Fuel Sensor	8-S22
5. DISASSEMBLING AND ASSEMBLING	8-S23
[1] STARTER.....	8-S23
[2] AC DYNAMO.....	8-S24
6. SERVICING	8-S25
[1] STARTER.....	8-S25

1. TROUBLESHOOTING

FUSE AND WIRING

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
All Electrical Equipment Do Not Operate	1. Battery discharged or damaged	Check or recharge battery	8-S10
	2. Battery positive cable disconnected or improperly connected	Repair or replace battery positive cable	8-S10
	3. Battery negative cable disconnected or improperly connected	Repair or replace negative cable	8-S10
	4. Slow blow fuse blown	Repair main harness	8-M1
Fuse Blown Frequently	1. Short-circuited	Repair or replace fuse	G-34

BATTERY

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Battery Discharges Too Quickly	1. Battery damaged	Recharge or replace battery	8-S11
	2. Dynamo damaged	Repair or replace dynamo	8-S17
	3. Wiring harness disconnected or improperly connected	Repair or replace connector and wire harness	8-M1
	4. Cooling fan belt slipping	Adjust fan belt	1-S25

STARTING SYSTEM

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page	
Starter Motor Does Not Operate	1. Battery discharged or damaged	Recharge or replace battery	8-S11	
	2. Slow blow fuse blown	Replace main harness or other	8-M1	
	3. Safety switch improperly adjusted or damaged	Repair or replace safety switch	8-S14	
	4. Wiring harness disconnected or improperly connected	Repair or replace connector and wire harness	8-M1	
	5. Engine stop solenoid relay damaged	Replace engine stop solenoid relay	8-S12	
	6. Starter motor damaged		Solution order 1. Check starter motor	8-S15
			2. Replace starter motor	8-S15
7. Key switch damaged	Check or replace key switch	8-S13		

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Pre-heat indicator Lamp Does Not Light When Key Switch Is in Pre-heat Position	1. Battery discharged or damaged	Recharge or replace battery	8-S11
	2. Slow blow fuse blown	Repair glow harness or other	8-M1
	3. Wiring harness disconnected or improperly connected	Repair or replace connector and wire harness	8-M1
	4. Key switch damaged	Check or replace key switch	8-S13
	5. Glow plug indicator damaged	Replace main panel	8-S20

OPERATOR PRESENCE CONTROL (OPC)

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Engine Does Not Stop	1. Solenoid fuse blown (30 A)	Repair wire harness or other	8-M1
	2. Engine stop solenoid relay damaged	Replace engine stop solenoid relay	8-S12
	3. Engine stop solenoid damaged	Replace engine stop solenoid	8-S15
	4. Operator presence controller damaged	Check or replace operator presence controller	8-M3
	5. PTO select lever switch damaged	Check or replace PTO select lever switch	8-M6
	6. PTO lever switch damaged	Check or replace PTO lever switch	8-M6
	7. HST pedal switch damaged	Check or replace HST pedal switch	8-M7
	8. Seat switch damaged	Check or replace seat switch	8-M7
	9. Relay damaged	Replace relay	8-S12
	10. Wiring harness disconnected or improperly connected (between engine stop solenoid relay and engine stop solenoid, between engine stop solenoid relay between key switch and operator presence controller, between safety switches and operator presence controller and battery positive terminal)	Repair or replace connector and wire harness	8-M1
	11. Wiring harness disconnected or improperly connected (between operator presence controller and engine stop solenoid relay)	Repair or replace connector and wire harness	8-M1

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Starter Motor Does Not Operate	1. Solenoid fuse blown (30 A)	Replace wire harness or other	G-34, 8-M1
	2. Engine stop solenoid damaged	Check engine stop solenoid	8-S15
	3. Engine stop solenoid relay damaged	Check engine stop solenoid relay	8-S12
	4. Seat switch damaged	Replace seat switch	8-M7
	5. PTO select lever switch damaged	Check or replace PTO select lever switch	8-M6
	6. PTO lever switch damaged	Check or replace PTO lever switch	8-M6
	7. HST pedal switch damaged	Check or replace HST pedal switch	8-M7
	8. Operator presence controller damaged	Check or replace operator presence controller	8-M3
	9. Wiring harness disconnected or improperly connected (between engine stop solenoid relay and engine stop solenoid, between engine stop solenoid relay between key switch and operator presence controller, between safety switches and operator presence controller and battery positive terminal)	Repair or replace connector and wire harness	8-M1
	10. Wiring harness disconnected or improperly connected (between operator presence controller and engine stop solenoid relay)	Repair or replace connector and wire harness	8-M1
Engine Stops When HST Pedal or Shuttle Shift Switch is Pushed in Forward or in Reverse	1. OPC switch damaged	1. Check OPC switch	8-S14
		2. Replace seat	7-S11

CHARGING SYSTEM

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Charging Lamp Does Not Light When Key Switch is Turned ON	1. Fuse blown (10 A)	Replace wire harness or other	G-34, 8-M1
	2. Wiring harness disconnected or improperly connected (between key switch AC terminal and panel board, between panel board and dynamo)	Repair or replace connector and other	8-M1
	3. Dynamo damaged	Repair or replace dynamo	8-S17
Charging Lamp Does Not Go Off When Engine Operates	1. Wiring harness disconnected or improperly connected (between key switch terminal and dynamo, between panel board and dynamo)	Repair or replace connector and wire harness	8-M1
	2. Dynamo damaged	Repair or replace dynamo	8-S17

LIGHTING SYSTEM

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Head Light Does Not Light	1. Fuse blown (10 A)	Replace wire harness or other	8-M1
	2. Bulb blown	Replace bulb	G-34
	3. Wiring harness disconnected or improperly connected (between key switch AC terminal and combination switch terminal, between combination switch 1 terminal and headlight)	Repair or replace connector and wire harness	8-M1
	4. Flasher unit damaged	Repair flasher unit	8-S20
	5. Combination switch damaged	Check or replace combination switch	8-S18
Tail Light Does Not Light	1. Fuse blown (10 A)	Repair wire harness or other	8-M1
	2. Bulb blown	Replace bulb	G-34
	3. Wiring harness disconnected or improperly connected (between key switch AC terminal and combination switch terminal, between combination switch T terminal and tail light)	Repair or replace connector and wire harness	8-M1
	4. Flasher unit damaged	Repair flasher unit	8-S20

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Illumination Light Does Not Light	1. Fuse blown (15 A)	Replace fuse	G-34
	2. Bulb blown	Replace bulb	G-34
	3. Wiring harness disconnected or improperly connected (between key switch AC terminal and combination switch terminal, between combination switch T terminal and panel board)	Repair or replace connector and wire harness	8-M1
Hazard Light (Tail Light) Does Not Light	1. Fuse blown (15 A)	Repair wire harness or other	G-34, 8-M1
	2. Bulb blown	Replace bulb	G-34
	3. Wiring harness disconnected or improperly connected	Repair or replace connector and wire harness	8-M1
	4. Flasher unit damaged	Replace flasher unit	8-S20
	5. Hazard switch damaged	Replace combination switch	8-S18
Hazard Indicator Lamp (Turn Signal Lamp) Does Not Light	1. Bulb blown	Replace bulb	G-34
	2. Wiring harness disconnected or improperly connected	Repair or replace connector and wire harness	8-M1
Hazard Light (Tail Light) Does Not Flicker	1. Flasher unit damaged	Replace flasher unit	8-S20
Turn Signal Light Does Not Light	1. Fuse blown (10 A)	Repair wire harness or other	8-M1
	2. Bulb blown	Replace bulb	G-34
	3. Wiring harness disconnected or improperly connected	Repair or replace connector and wire harness	8-M1
	4. Flasher unit damaged	Replace flasher unit	8-S20
	5. Combination switch damaged	Replace combination switch	8-S18
Turn Signal Light Indicator Lamp Does Not Light	1. Bulb blown	Replace bulb	G-34
	2. Wiring harness disconnected or improperly connected (between combination switch R or L terminal and panel board)	Repair or replace connector and wire harness	8-M1
Turn Signal Light Does Not Flicker	1. Flasher unit damaged	Replace flasher unit	8-S20

EASY CHECKER™

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Oil Pressure Lamp Lights Up When Engine Operates	1. Engine oil insufficient	Check engine oil	G-8
	2. Engine oil pressure too low	Solution order	1-S14
		1. Check engine oil pressure	
		2. Check or change engine oil	G-26
		3. Check or replace oil filter	G-25
	4. Check or replace oil pump	7-S9	
3. Oil pressure switch damaged	Check or replace oil pressure switch	8-S21	
4. Short circuit between oil pressure switch lead and chassis	Repair or replace connector and wire harness	8-M1	
5. Circuit in panel board damaged	Replace meter panel	8-S20	
Oil Pressure Lamp Does Not Light When Key Switch Is Turned On and Engine Is Not Operating	1. Bulb blown	Replace bulb	G-34
	2. Oil pressure switch damaged	Check or replace oil pressure switch	8-S21
	3. Wiring harness disconnected or improperly connected (between panel board and oil pressure switch)	Repair or replace connector and wire harness	8-M1
	4. Circuit in panel board damaged	Replace meter panel	8-S20

GAUGES

Symptom	Probable Cause and Checking Procedure	Solution	Reference Page
Fuel Gauge Does Not Function	1. Fuel gauge damaged	Replace fuel gauge	8-S22
	2. Fuel level sensor damaged	Replace fuel level sensor	8-S22
	3. Wiring harness disconnected or improperly connected (between panel board and fuel level sensor)	Repair or replace connector and wire harness	8-M1
	4. Circuit in panel board damaged	Replace meter panel	8-S20
Coolant Temperature Gauge Does Not Function	1. Coolant temperature gauge damaged	Replace coolant temperature gauge	8-S21
	2. Coolant temperature sensor damaged	Replace coolant temperature sensor	8-S21
	3. Wiring harness disconnected or improperly connected (between panel board and coolant temperature sensor)	Repair or replace connector and wire harness	8-M1
	4. Circuit in panel board damaged	Replace meter panel	8-S20

9Y1211156ELS0001US0

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Battery	Voltage	More than 12 V	–
	Potential Difference	Less than 0.1 V	–
Glow Plug	Resistance	Approx. 0.9 Ω	–
Coolant Temperature Sensor	Resistance at 130 °C (266 °F)	Approx. 12.2 Ω	–
	at 105 °C (221 °F)	Approx. 23.6 Ω	–
	at 80 °C (176 °F)	Approx. 51.9 Ω	–
	at 50 °C (122 °F)	Approx. 153.9 Ω	–
Fuel Sensor	Resistance Float at upper-most position	1 to 5 Ω	–
	Float at lower-most position	103 to 117 Ω	–

STARTER

Item		Factory Specification	Allowable Limit
Commutator	O.D.	28.0 mm 1.102 in.	27.0 mm 1.063 in.
	Difference of O.D.'s	Less than 0.02 mm 0.0008 in.	0.05 mm 0.0020 in.
Mica	Undercut	0.60 mm 0.0236 in.	0.20 mm 0.0079 in.
Brush	Length	14 mm 0.551 in.	9.0 mm 0.354 in.
Brush Holder to Holder Support	Resistance	Infinity	–

9Y1211156ELS0002US0

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts: Refer to "5. TIGHTENING TORQUES" on page G-11.)

Item	N·m	kgf·m	lbf·ft
Coolant temperature sensor	11.8 to 17.6	1.20 to 1.80	8.68 to 13.0

9Y1211156ELS0003US0

4. CHECKING AND ADJUSTING

⚠ CAUTION


- To avoid accidental short circuit, be sure to attach the positive cable to the positive terminal before the negative cable is attached to the negative terminal.
- Never remove the battery cap while the engine operates.
- Keep electrolyte away from eyes, hands and clothes. If you are splattered with it, wash it away completely with water immediately.
- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.

■ IMPORTANT

- If the machine is to be operated for a short time without battery (using a slave battery for starting), use additional current (lights) while engine operates and insulate terminal of battery. If this advice is disregarded, damage to dynamo and regulator may result.

9Y1211156ELS0004US0

[1] BATTERY




Battery Voltage

1. Stop the engine and turn the key switch off.
2. Connect the COM (-) lead of the voltmeter to the battery's negative terminal post and the (+) lead to the positive terminal post, and measure the battery voltage.
3. If the battery voltage is less than the factory specification, check the battery specific gravity and recharge the battery.

Battery voltage	Factory specification	More than 12 V
-----------------	-----------------------	----------------

9Y1211156ELS0005US0




Battery Terminal Connection

1. Turn the key switch on, and turn on the head light.
2. Measure the voltage with a voltmeter across the battery's positive terminal post and the cable terminal, and the voltage across the battery's negative terminal post and the chassis.
3. If the measurement exceeds the factory specification, clean the battery terminal posts and cable clamps, and tighten them firmly.

Potential difference	Factory specification	Less than 0.1 V
----------------------	-----------------------	-----------------

9Y1211156ELS0006US0



Battery Condition Indicator

1. Check the battery condition by reading the indicator (2).

State of indicator display	
Green	Specific gravity of electrolyte and quality of electrolyte are both in good condition.
Black	Needs charging battery
White	Needs replacing battery


■ IMPORTANT

- The factory installed battery is of non-refillable type. If the indicator turns white, do not charge the battery but replace it with new one.

(1) Battery

(2) Indicator

9Y1211156ELS0007US0



Recharging

⚠ CAUTION

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.
 - When disconnecting the cable from the battery, start with the negative terminal first. When connecting the cable to the battery, start with the positive terminal first.
 - Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.
1. To slow charge the battery (1), connect the battery positive terminal to the charge positive terminal and the negative to the negative, then recharge in the standard fashion.
 2. A boost charge is only for emergencies. It will partially charge the battery at a high rate and in a short time. When using a boost-charged battery, it is necessary to recharge the battery as early as possible. Failure to do this will shorten the battery's service life.
 3. The battery is charge if the indicator display turns green from black.
 4. When exchanging an old battery for a new one, use battery of equal specification shown in table.

Table

Battery Type	Volt (V)	Capacity at 5 H.R.	Reserve at (min.)	Cold Cranking Amps	Normal Charging Rate (A)
55B24L (S)-MF	12	36	80	430	4.5

(1) Battery

(2) Indicator

9Y1211156ELS0008US0

Directions for Storage

1. When shutting down the tractor for long periods of time, remove the battery from the tractor, store the battery in a well ventilated place where it is not exposed to direct sunlight.
2. Since the battery self-discharges by approx. 0.5 % per day even in storage, it must be once every two months in cold season.
3. When storing the battery mounted on the tractor, disconnect the ground cable from the battery's negative terminal post.

(Reference)

- Self-discharge Rate

Temperature	Self-discharge rate
30 °C (86 °F)	Approx. 1.0 % per day
20 °C (68 °F)	Approx. 0.5 % per day
10 °C (50 °F)	Approx. 0.25 % per day

9Y1211156ELS0009US0

[2] FUSE

1. When inspecting the circuit line, check the related fuses. For the detail of the fuses, refer to the page G-34.
2. If any of the fuse is blown, replace with a new one of the same capacity.



■ IMPORTANT

- If a fuse is blown, check the cause and be sure to replace it with a new one of the same capacity.

9Y1211156ELS0010US0

[3] RELAYS

(1) Relays



Relay

1. Remove the relay.
2. Apply battery voltage across 2 terminal and 4 terminal, and check for continuity across 1 terminal and 3 terminal.
3. If 0 Ω is not indicated, renew the relay.

Resistance	1 terminal – 3 terminal	Battery voltage is applied across 2 terminal and 4 terminal	0 Ω
------------	-------------------------	---	-----

■ Color of wiring (To identify the each relay position)

Item	Terminal No.	Color of Wiring
Relay (Engine Stop Solenoid)	1	R
	2	WL
	3	RL
	4	B
Relay (R2)	1	R
	2	RB
	3	YL
	4	B






- (1) Relay
 (2) Connector (Relay)

- (3) Connector (Wire Harness)

9Y1211156ELS0011US0

[4] STARTING SYSTEM

(1) Key Switch



Connector Voltage

1. Measure the voltage with a voltmeter across the connector **B** terminal (2) and chassis.
2. If the voltage differs from the battery voltage (11 to 14 V), the wiring harness is damaged.

Voltage	Connector B terminal – Chassis	Approx. battery voltage
---------	---------------------------------------	-------------------------

- | | |
|------------------------|------------------------|
| (1) Key Switch | (4) ST Terminal |
| (2) B Terminal | (5) G Terminal |
| (3) AC Terminal | |

9Y1211156ELS0012US0

Key Switch Continuity

1) Key Switch Key at "OFF" Position

1. Set the key switch **OFF** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **AC** terminal, **B** terminal and **ST** terminal, **B** terminal and **G** terminal.
3. If infinity is not indicated, the contacts of the key switch are damaged.

Resistance	B terminal – AC terminal	Infinity
	B terminal – ST terminal	
	B terminal – G terminal	

9Y1211156ELS0013US0

2) Key Switch Key at "ON" Position

1. Set the key switch **ON** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **AC** terminal.
3. If 0 Ω is not indicated, the **B** - **AC** contact of the key switch are damaged.

Resistance	B terminal – AC terminal	0 Ω
------------	--	-----


9Y1211156ELS0014US0

3) Key Switch Key at "PREHEAT" Position

1. Set and hold the key switch key at the **PREHEAT** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **G** terminal, and measure the resistance across the **B** terminal and the **AC** terminal.
3. If 0 Ω is not indicated, these contacts of the key switch are damaged.

Resistance	B terminal – G terminal	0 Ω
	B terminal – AC terminal	

9Y1211156ELS0015US0



4) Key Switch Key at "START" Position

1. Set and hold the key switch key at the **START** position.
2. Measure the resistance with an ohmmeter across the **B** terminal and the **G** terminal, across the **B** terminal and the **ST** terminal, and across the **B** terminal and the **AC** terminal.
3. If 0 Ω is not indicated, these contacts of the key switch are damaged.



Resistance	B terminal – G terminal	0 Ω
	B terminal – ST terminal	
	B terminal – AC terminal	

Key Position	Terminal			
	B	AC	G	ST
OFF	●			
ON	●	●		
PREHEAT	●	●	●	
START	●	●	●	●

9Y1211156ELS006US

9Y1211156ELS0016US0

(2) Safety Switches



Safety Switch Continuity

1. Disconnect the safety switch leads or couplers.
2. Connect the circuit tester to the safety switch leads.
3. Measure the resistance between leads.
4. If the safety switch is damaged, replace it.

Safety switch	Condition	Resistance
HST Pedal Switch	HST pedal in neutral	0 Ω
	HST pedal in forward or reverse	Infinity
PTO Clutch Lever Switch	PTO clutch lever in disengaged position	0 Ω
	PTO clutch lever in engaged position	Infinity
PTO Select Lever Switch	PTO select lever in Rear PTO position	0 Ω
	PTO select lever in Rear PTO / Mid PTO or Mid PTO position	Infinity
Seat Switch	Operator on the seat	0 Ω
	Vacant	Infinity
Seat Tilt Switch	Tilting the seat	0 Ω
	Not tilting the seat	Infinity

- | | |
|-----------------------------|----------------------|
| (1) PTO Clutch Lever Switch | (4) Seat Tilt Switch |
| (2) PTO Select Lever Switch | (5) Seat Switch |
| (3) HST Pedal Switch | |

9Y1211156ELS0017US0

(3) OPC Controller




OPC Controller

1. Check the "Engine Starting Conditions" and "Automatic Engine Stop Conditions". (See page 8-M5.)
2. If the tractor does not operate appropriately, check all parts according to the "1.TROUBLESHOOTING" section.
3. If all parts except the OPC controller (1) is not damaged, replace the OPC controller (1).

(1) OPC Controller

9Y1211156ELS0018US0

(4) Engine Stop Solenoid



Connector Voltage


1. Disconnect the **2P** connector from engine stop solenoid.
2. Turn the key switch key to the "ON" position.
3. Measure the voltage with voltmeter between the terminal 1, terminal 2 of wiring harness side and body.
4. If the voltage differs from the battery voltage, the wiring harness or key switch is damaged.

Voltage	Terminal 1 – Body	Approx. battery voltage
	Terminal 2 – Body	Approx. battery voltage

(1) Terminal 2

(2) Terminal 1

9Y1211156ELS0019US0




Engine Stop Solenoid Test

1. Disconnect the lead from the engine stop solenoid after turning the key switch off.
2. Connect jumper leads from the battery positive terminal to the engine stop solenoid terminal 1 and 2, then from the battery negative terminal to the engine stop solenoid body.
3. If the solenoid plunger is not attracted, the engine stop solenoid is damaged.

(1) Battery

9Y1211156ELS0020US0

(5) Starter



Motor Test



CAUTION


- **Secure the starter to prevent it from jumping up and down while testing the motor.**

1. Disconnect the battery negative cable from the battery.
2. Disconnect the battery positive cable and the leads from the starter **B** terminal.
3. Remove the starter from the engine.
4. Disconnect the connecting lead (2) from the starter **C** terminal (1).
5. Connect a jumper lead from the connecting lead (2) to the battery positive terminal post.
6. Connect a jumper lead momentarily between the starter motor housing and the battery negative terminal post.
7. If the motor does not operate, check the motor.

(1) C Terminal

(2) Connecting Lead

9Y1211156ELS0021US0



Magnetic Switch Test

1. Disconnect the battery negative cable from the battery.
2. Disconnect the battery positive cable and the leads from the starter **B** terminal.
3. Remove the starter from the engine.
4. Disconnect the connecting lead (3) from the starter **C** terminal (2).
5. Connect a jumper lead from the starter **S** terminal (2) to the battery positive terminal post.
6. Connect a jumper lead momentarily between the starter **C** terminal (2) and the battery negative terminal post.
7. If the pinion gear does not pop out, check the magnetic switch.

■ **NOTE**


- **This test should take no longer than 3 to 5 seconds at a time.**

- (1) **S** Terminal
 (2) **C** Terminal

- (3) Connecting Lead

9Y1211156ELS0022US0

(6) Glow Plug



Lead Terminal Voltage


1. Disconnect the wiring lead (1) from the glow plug (2) after turning the key switch **OFF**.
2. Turn the key switch to the **PREHEAT** position, and measure the voltage between the lead terminal and the chassis.
3. Turn the key switch to the **START** position, and measure the voltage with a voltmeter between the lead terminal and the chassis.
4. If the voltage at either position differs from the battery voltage, the wiring harness or key switch is damaged.

Voltage (Lead terminal - Chassis)	Key switch at PREHEAT	Approx. battery voltage
	Key switch at START	

- (1) Wiring Lead

- (2) Glow Plug

9Y1211156ELS0023US0



Glow Plug Continuity


1. Disconnect the leads from the glow plugs.
2. Measure the resistance with an ohmmeter between the glow plug terminal and chassis.
3. If 0 Ω is indicated, the screw at the tip of the glow plug and the housing are short-circuited.
4. If the factory specification is not indicated, the glow plug is damaged.

Glow plug resistance	Factory specification	Approx. 0.9 Ω
----------------------	-----------------------	---------------

9Y1211156ELS0024US0

[5] CHARGING SYSTEM

(1) AC Dynamo




Dynamo No-load Voltage

1. Disconnect the lead wires from the dynamo.
2. Start the engine, and check the generating voltage of the dynamo.

Factory specification	Voltage	14 to 15 V (at engine idling speed)
-----------------------	---------	-------------------------------------

9Y1211156ELS0025US0

(2) Regulator



Continuity across Regulator's Terminals

1. Remove the regulator (1).
2. Check with a tester whether the regulator (1) is in optimum condition or not as table below.
3. If the continuity is not measured as shown in the table below, the contacts of the regulators are damaged.

NOTE

- Use analog tester for measuring the continuity. Do not use insulation resistance tester.
- On the check table below, "ON" means that the pointer of tester is swung and "OFF" means it is not swung. The value kΩ is reference value by measuring 1 kΩ range. And this value is changed by range, measurement tools and so on.
- When measuring, remove wire harness and measure the value of regulator itself.

Tester (-) terminal		Tester (+) terminal					
		Cord colors					
		1	2	3	4	5	6
Cord colors	1	-	OFF	OFF	OFF	OFF	ON (7.1 kΩ)
	2	OFF	-	OFF	OFF	OFF	OFF
	3	OFF	OFF	-	OFF	OFF	ON (7.1 kΩ)
	4	OFF	OFF	OFF	-	OFF	OFF
	5	ON (7.1 kΩ)	ON (7.1 kΩ)	ON (7.1 kΩ)	OFF	-	ON (7.1 kΩ)
	6	OFF	OFF	OFF	OFF	OFF	-

(1) Regulator

- 1 : Sky Blue
- 2 : Black
- 3 : Sky Blue
- 4 : Green
- 5 : Yellow
- 6 : Red

9Y1211156ELS0026US0

[6] LIGHTING SYSTEM

(1) Combination Switch




Combination Switch

1. Remove the steering wheel and panel lower cover.
2. Disconnect the combination switch connector.
3. Remove the combination switch (1) and perform the following checks 1) to 8).

(1) Combination Switch

9Y1211156ELS0027US0




1) Connector Voltage

1. Measure the voltage with a voltmeter across the connector **B2**, **B4**, **TL**, **TR** terminal and chassis when the key switch is **ON** position.
2. If the voltage differs from the battery voltage, the wiring harness and key switch is damaged.

Voltage	Key switch at ON position	B2 terminal – Chassis	Battery voltage
		B4 terminal – Chassis	
		TL terminal – Chassis	
		TR terminal – Chassis	

9Y1211156ELS0028US0




2) Head Light Switch Continuity When Setting Switch at OFF Position

1. Set the light switch to the **OFF** position.
2. Measure the resistance with an ohmmeter across the **B4** terminal to the **T** terminal, the **B4** terminal to the terminal **1**.
3. If infinity is not indicated, the head light switch is damaged.

Resistance (Switch at OFF position)	B4 terminal – T terminal	Infinity
	B4 terminal – 1 terminal	

9Y1211156ELS0029US0




3) Head Light Switch Continuity When Setting Switch at ON Position

1. Set the light switch to the **ON** position.
2. Measure the resistance with an ohmmeter across the **B4** terminal to the **T** terminal and the **B4** terminal to the terminal **1**.
3. If 0 Ω is not indicated, the head light switch is damaged.

Resistance (Switch at ON position)	B4 terminal – T terminal	0 Ω
	B4 terminal – 1 terminal	

9Y1211156ELS0030US0




4) Turn Signal Light Switch Continuity When Setting Switch Knob OFF Position

1. Set the turn signal light switch to the **OFF** position.
2. Measure the resistance with an ohmmeter across the **B3** terminal and **TL** terminal, the **B3** terminal and **TR** terminal.
3. If infinity is not indicated, the combination switch is damaged.

Resistance (Switch knob at OFF position)	B3 terminal – TL terminal	Infinity
	B3 terminal – TR terminal	

9Y1211156ELS0031US0




5) Turn Signal Light Switch Continuity When Setting Switch Knob at L Position

1. Set the turn signal light switch to the **L** position.
2. Measure the resistance with an ohmmeter across the **B3** terminal and **TL** terminal.
3. If 0 Ω is not indicated, the combination switch is damaged.

Resistance (Switch knob at left position)	B3 terminal – TL terminal	0 Ω
	B3 terminal – TR terminal	Infinity

9Y1211156ELS0032US0




6) Turn Signal Light Switch Continuity When Setting Switch Knob at R Position

1. Set the turn signal light switch to the **R** position.
2. Measure the resistance with an ohmmeter across the **B3** terminal and **TR** terminal.
3. If 0 Ω is not indicated, the combination switch is damaged.

Resistance (Switch knob at right position)	B3 terminal – TR terminal	0 Ω
	B3 terminal – TL terminal	Infinity

9Y1211156ELS0033US0




7) Hazard Switch Continuity when Not Pushing Button

1. Set the hazard switch to the **OFF** position.
2. Measure the resistance with an ohmmeter across the **B2** terminal and the **F** terminal.
3. If infinity is not indicated, the combination switch is damaged.

Resistance (Hazard switch at OFF position)	B2 terminal – F terminal	Infinity
--	---	----------

9Y1211156ELS0034US0



8) Hazard Switch at "ON" Position

1. Set the hazard switch to the **ON** position.
2. Measure the resistance with an ohmmeter across the **B2** terminal and the **F** terminal.
3. If 0 Ω is not indicated, the combination switch is damaged.

Resistance (Hazard switch at ON position)	B2 terminal – F terminal	0 Ω
---	---	-----

9Y1211156ELS0035US0

(2) Flasher Unit



Flasher Unit Connector Voltage


1. Remove the instrument panel.
2. Disconnect the connector (1) from the flasher unit (2).
3. Measure the voltage with a voltmeter across the h terminal and chassis.
4. If the voltage differ from the battery voltage, the wiring harness is damaged.

Voltage	h terminal – Chassis	Approx. battery voltage
---------	----------------------	-------------------------

- (1) Connector
- (2) Flasher Unit


- a: Frame Earth
- b: Hazard Input
- c: Vacant
- d: Turn Signal (Left) Input
- f: Turn Signal (Right) Output
- h: Battery
- i: Turn Signal (Left) Output
- j: Turn Signal (Right) Input

9Y1211156ELS0036US0



[7] WARNING LAMP, INDICATOR LAMP AND GAUGE

(1) Instrument Panel



Monitor Lamp (for Charge, Engine Oil Pressure, Pre-heat, Illumination and Hazard)


1. Removing the meter panel from the tractor.
2. Remove the each lamp.
3. Measure the lamp resistance.
4. If it is infinity, replace the lamp with new.

All lamp	Lamp specification	12 V, 1.7 W
----------	--------------------	-------------

- (1) Illumination
- (2) Pre-heat
- (3) Hazard
- (4) Charge
- (5) Engine Oil Pressure
- (6) Position
- (7) Turn (R)
- (8) Turn (L)

9Y1211156ELS0037US0

(2) Engine Oil Pressure Switch



Engine Oil Pressure Switch Continuity


1. Measure the resistance with an ohmmeter across the switch terminal and the chassis.
2. If 0 Ω is not indicated in the normal state, the switch is damaged.
3. If infinity is not indicated at pressure over 49 kPa (0.50 kgf/cm², 7.1 psi), the switch is damaged.

Resistance (Switch terminal – Chassis)	In normal state	0 Ω
	At pressure over approx. 49 kPa (0.50 kgf/cm ² , 7.1 psi)	Infinity

(1) Engine Oil Pressure Switch

9Y1211156ELS0038US0

(3) Coolant Temperature Sensor



Coolant Temperature Sensor

1) Lead Terminal Voltage

1. Disconnect the lead from the coolant temperature sensor after turning the key switch **OFF**.
2. Turn the key switch **ON** and measure the voltage with a voltmeter across the lead terminal and the chassis. If the voltage differs from the battery voltage, the wiring harness fuse or coolant temperature gauge is damaged.

Voltage	Lead terminal – Chassis	Approx. 5 V
---------	-------------------------	-------------

2) Sensor Continuity

1. Measure the resistances with an ohmmeter across the sensor terminal and the chassis.
2. If the reference value is not indicated, the sensor is damaged.



Resistance (Sensor terminal – Chassis)	Reference value	Approx. 12.2 Ω at 130 °C (266 °F) Approx. 23.6 Ω at 105 °C (221 °F) Approx. 51.9 Ω at 80 °C (176 °F) Approx. 153.9 Ω at 50 °C (122 °F)
--	-----------------	---

Tightening torque	Coolant temperature sensor	11.8 to 17.6 N·m 1.20 to 1.80 kgf·m 8.68 to 13.0 lbf·ft
-------------------	----------------------------	---


(1) Coolant Temperature Sensor

(a) From Temperature Gauge

9Y1211156ELS0039US0



(4) Fuel Sensor



Fuel Sensor

1) Sensor Continuity


1. Remove the fuel lever sensor from the fuel tank.
2. Measure the resistance across the sensor terminal and its body.
3. If the reference value are not indicated, the sensor is damaged.

Resistance (Sensor terminal – its body)	Reference value	Float at upper-most position	1 to 5 Ω
		Float at lower-most position	103 to 117 Ω

9Y1211156ELS0040US0

5. DISASSEMBLING AND ASSEMBLING

[1] STARTER



- (1) Screw
- (2) Front Bracket
- (3) Magnetic Switch
- (4) Overrunning Clutch
- (5) Drive Lever
- (6) Internal Gear
- (7) Shaft
- (8) Planetary Gear
- (9) Shaft Assembly
- (10) Ball
- (11) Gasket
- (12) Yoke
- (13) Armature
- (14) Brush Holder
- (15) Rear End Frame
- (16) Screw
- (17) Through Bolt

3TBAAAF9P041B


1. Disconnect the connecting lead from the magnetic switch (3).
2. Remove the screw (1) and remove the magnet switch (3).
3. Remove the screw (16) and through bolt (17), and separate the rear end frame (15).
4. Remove the brush holder (14).
5. Draw out the armature (13) and yoke (12).
6. Remove the gasket (11), gasket (19) and plate (18).
7. Draw out the shaft assembly (9) with the drive lever (5).

■ NOTE

- Do not damage the brush and commutator.
- Do not miss the ball (10).

9Y1211156ELS0041US0

[2] AC DYNAMO




Stator

1. Remove the nut (3) and separate the stator comp. (4).
2. Remove the screws (1) and remove the stator (2).

(1) Screw
(2) Stator

(3) Nut
(4) Stator Comp.

9Y1211156ELS0042US0



Rotor

1. Tap out the shaft (1) from the rotor (3).

(When reassembling)

- Be careful the direction of the collar (4), the flat side should face to the pulley (2) side.






(1) Shaft
(2) Pulley
(3) Rotor

(4) Collar
(5) Bearings
(6) Collar

9Y1211156ELS0043US0

6. SERVICING

[1] STARTER



Commutator and Mica

1. Check the contact face of the commutator for wear, and grind the commutator with emery paper if it is slightly worn.
2. Measure the commutator O.D. with an outside micrometer at several points.
3. If the minimum O.D. is less than the allowable limit, correct the commutator on a lathe to the factory specification.
4. Measure the mica undercut.
5. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

Commutator O.D.	Factory specification	28.0 mm 1.102 in.
	Allowable limit	27.0 mm 1.063 in.

Difference of O.D.'s	Factory specification	Less than 0.02 mm 0.0008 in.
	Allowable limit	0.05 mm 0.0020 in.

Mica undercut	Factory specification	0.60 mm 0.0236 in.
	Allowable limit	0.20 mm 0.0079 in.

- (1) Segment
 - (2) Undercut
 - (3) Mica
- (a) **Correct**
 - (b) **Incorrect**

9Y1211156ELS0044US0

Brush Wear

1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length (A) with vernier calipers.
3. If the length is less than the allowable limit, replace the yoke assembly and brush holder.

Brush length (A)	Factory specification	14.0 mm 0.551 in.
	Allowable limit	9.0 mm 0.354 in.


9Y1211156ELS0045US0

Brush Holder

1. Check the continuity across the brush holder and the holder support with an ohmmeter.
2. If it conducts, replace the brush holder.

Resistance	Brush holder – Holder support	Infinity
------------	-------------------------------	----------


9Y1211156ELS0046US0



Armature Coil

1. Check the continuity between the commutator and armature coil core with an ohmmeter.
2. If it conducts, replace the armature.
3. Check the continuity between the segments of the commutator with an ohmmeter.
4. If it does not conduct, replace the armature.

9Y1211156ELS0047US0



EDITOR:

KUBOTA FARM & INDUSTRIAL MACHINERY SERVICE, LTD.

64, ISHIZU-KITAMACHI, SAKAI-KU, SAKAI-CITY, OSAKA, 590-0823, JAPAN

PHONE : (81)72-241-1129

FAX : (81)72-245-2484

E-mail : ks_g.ksos-pub@kubota.com
